# SERVO DRIVER BLOCKS

sigma\_delta uC **SDELTA GPIO** uc\_gpio.sch sigma\_delta.sch uC AC CLK SYM **TEMP** LEM IN Dbg **VBUS** uC UI **MEAS** Power vbus\_meas.sch connectors uC **IGBT** CONN **ADC** 

**ENDAT STEP** DIR

**QEP** 


Ether **NET** 

CAN


**RS485** 

Ether **CAT** ethercat.sch

Pablo Slavkin dci Sheet: / File: servo.sch Title: servo drive



# USB HOST




 Pablo Slavkin

 dci
 Sheet: /ethernet/


 File: ethernet.sch
 Title: ethernet

 Size: A3
 Date: 2020-01-09
 Rev: 1.0


 KiCad E.D.A. kicad 5.0.2+dfsg1-1
 Id: 2/20




Pablo Slavkin dci Sheet: /uc\_adc/ File: uc\_adc.sch Title: ADC Size: A3 Date: 2020-01-09 KiCad E.D.A. kicad 5.0.2+dfsg1-1





# **DECOUPLING FILTERS**




#### Ferrite Beads Place near U1









## CLK + JTAG + SCI




## **BOOTSRAP R's**



# ADC/DAC DBG OUT




# SPI FLASH



Pablo Slavkin		
dci		
Sheet: /uc_clk_ File: uc_clk_dbg		
Title: clk		
Size: A3	Date: 2020-01-09	Rev: 1.0
KiCad E.D.A. ki	cad 5.0.2+dfsg1-1	ld: 6/20
	7	0

# Main Power


in case the control board have to be supply effectly with societ voltage (220) populate these. It's not a good idea cause I'll the to keep hight voltage outside these controller board, but it's a requeriment, so I let it as an option. But you have the law voltage input 15vc and 15vh connections also commercial and 2 power supply for Cold and first sides because for Colore to and 2 power supply for Cold and first sides because a Colore Colore to the Colo





# **COLD SUPPLY**


It is inteded to use only, I mean ONLY inside the control board, none of these coopers wires has to leave the board. I isolate every single pin from these supply to go outside, take these in account


# HOT SUPPLY The description for the first same and the description of the same and the description of the same and the sam
















Pablo Slavkin dci
Sheet: /ac\_in/
File: ac\_in.sch


Title: AC input Size: A3 Date: 2020-01-09 KiCad E.D.A. kicad 5.0.2+dfsg1-1


## PWM OUT -> ISOLATOR -> BUFFER -> FILTER






# 2 isolated NTC interfase + 1 isolated 1-wire/485





# Differential STEP-DIR input HOT



Pablo Slavkin
dci

Sheet: /step\_dir/
File: step\_dir.sch


Title: ENDAT/BISS Interface


Size: A3 Date: 2020-01-09 Rev: 1.0

KiCad E.D.A. kicad 5.0.2+dfsg1-1 Id: 10/20

# 2x Isolated Idifferential incremental encoder interfase 5v input A-B-I-S

left the Input for two Isolated Incremental encoders. Left the 4 signals Input plus two auxiliary output for eny porpous plus





# Symbols Slots fiducials, and others

#### Case



#### Fiducials TOP

● H1301 ● H1303 ● H1305 ● H1307 fiducials ● H1307

#### Fiducials Bottom

H1302 H1304 H1306 H1308 H1308 H1308 H1308

### mounting holes

### SLOT V LEMs

● H1345 ● H1346 ● H1348 ● H1347 Slot

● H1349 ● H1351 ● H1353 ● H1355 Slot

● H1350 ● H1352 ● H1354 ● H1356 Slot

logo recycler

logo nanocut

logo kicad

OOO pslavkin\_bottom

O O O pslavkin\_top

4444

logo neurona



logo stackup


logo design

SLOT 'I' anyware


H1338 H1340 H1342 H1344 Slot Slot

H1358 H1357 Slot

Pablo Slavkin Sheet: /symbols/ File: symbols.sch Title: gpio Size: A3 Date: 2020-01-09 KiCad E.D.A. kicad 5.0.2+dfsg1-1











these LEN's version doesn't seed a buffer. It's one already included inside LEN LEN's one already included inside LEN LEN's in LEN's and CAS pin to pin compatible, but LXS is a little better, I don't use an opamp become with the external conecition I have x.2x and X an applifer option without any compareds. I've decided to make the loop over the LEN on board and if you warns change it you have to use the soldering from becouse the connetor is 2 terminal, not 6

chanlog1: I've decided to return to a 2x3 terminal block output 'cause it match the size of the LEM










LEM\_A\_W XLEM\_B\_W

The decided to eliminate 1 LER, you could use 3 in line measurement, or 2 in line plus one for all. De reason is size of board and complexity

Pablo Slavkin dci Sheet: /lem/ File: lem.sch Title: LEM currente measurement Size: A3 Date: 2020-01-09 KiCad E.D.A. kicad 5.0.2+dfsg1-1

# VBUS -> R divider -> ISO ADC -> uC

It's intended to measure the Vbus, one per motor, but they cold be joined if both motor share same VBus. The Vbus informatio will be used by the control algorith and to drive the break resistor PWM to



VBUS2\_N\_H

Pablo Slavkin

dci


Sheet: //bus meas/
File: vbus\_meas.sch


Title: Shunt isolated

Size: A3 Date: 2020-01-09 Rev: 1.0

KiCad E.D.A. kicad 5.0.2+dfsg1-1 Id: 16/20

# Common Connections





 Pablo Slavkin

 dci

 Sheet: /connectors/


 File: conn.sch

 Title: Common connections

 Size: A3
 Date: 2020-01-09
 Rev: 1.0

 KiCad E.D.A. kicad 5.0.2+dfsg1-1
 Id: 17/20

# Isolated sigma delta ADC



Pablo Slavkin

dci


Sheet: /sigma\_delta/
File: sigma\_delta.sch

Title: Shunt Sigma Delta isolated

Size: A3 Date: 2020-01-09 Rev: 1.0

KiCad E.D.A. kicad 5.0.2+dfsg1-1 Id: 18/20

### 2X Isolated diferential ENDAT interface



 Pablo Slavkin

 dci
 Sheet: /endat/

 File: endat.sch
 Title: ENDAT/BISS Interface

 Size: A3
 Date: 2020-01-09
 Rev: 1.0

 KiCad E.D.A. kicad 5.0.2+dfsg1-1
 Id: 19/20

## uC GPIO's pins

I've spend hours to choose the GPIO's for each laterface trying to not creat one to the other, just pay attention if you wanna move some I've used global labels connector to go from one page to another isseed the off-page connector because it's more proue to errors. I know that is not too controllor, but I've better and fastly for now

