


Please, configure the winMIPS64 processor architecture with the *Base Configuration* provided in the following:


- Integer ALU: 1 clock cycle Data memory: 1 clock cycle
- Branch delay slot: 1 clock cycle
- Code address bus: 12Data address bus: 12
- Pipelined FP arithmetic unit (latency): 6 stages
- Pipelined FP multiplier unit (latency): 8 stages
- FP divider unit (latency): not pipelined unit, 28 clock cycles
- Forwarding optimization is disabled
- Branch prediction is disabled
- Branch delay slot optimization is disabled.

Use the Configure menu:


- Running the *WinMIPS* simulator, launching the graphical user interface (*folder to simulator*)...\winMIPS64\winmips64.exe
- Disable <u>ALL</u> the optimization (a mark appears when they are enabled)
- Browse the Architecture menu (Ctrl-A)



- Modify the defaults Architectural parameters (where needed)



- Verify in the Pipeline window that the configuration is effective (usually in the left bottom window)



1) Exercise your assembly skills.

Write and run an assembly program called **program_0.s** (to be delivered) for the *MIPS64* architecture.

The program must:

- 1. Given three arrays of 9 8-bit integer numbers (v1,v2,v3), check **for each one of them** if the content corresponds to a **palindrome** sequence of numbers. If yes, use three 8-bit unsigned variables (flags) to store the results. The variables will be equal to 1 is the sequence is palindrome, 0 otherwise.
- 2. Only for the palindrome arrays, compute the sum element by element and place the result in another array v4 (i.e. v4[i] = v2[i] + v3[i] supposing that only v2 and v3 are palindromes)

Example of a vectors sequence containing only 9 numbers:

v1:	. byte	2, 6, -3, 11, 9, 11, -3, 6, 2
<i>v2:</i>	. byte	4, 7, -10,3, 11, 9, 7, 6, 4
v3:	. byte	9, 22, 5, -1, 9, -1, 5, 22, 9

flag1: .space 1 flag2: .space 1 flag3: .space 1 v4: .space 9

2) Use the *WinMIPS* simulator.

Identify and use the main components of the simulator:

- a. Running the *WinMIPS* simulator
 - Launch the graphic interface ...\winMIPS64\winmips64.exe
- b. Load your program in the simulator:
 - Load the program from the **File**□**Open** menu (*CTRL-O*). In the case the of errors, you may use the following command in the command line to compile the program and check the errors:
 - ...\winMIPS64\asm program 0.s
- c. Run your program step by step (F7), identifying the whole processor behavior in the six simulator windows:

Pipeline, Code, Data, Register, Cycles and Statistics

d. Collect the clock cycles to fill the following table (fill all required data in the table before exporting this file to pdf format to be delivered).

Table 1: **Program performance for the specific processor configurations**

Program	Clock cycles	Number of Instructions	Clocks per instruction (CPI)	Instructions per Clock (IPC)
program_0	314	195	1,610	0,621

3) Perform execution and time measurements.

Measure the processor performance by running a benchmark of programs. Change the weights of the programs as indicated in the following to evaluate how these variations may produce different performance results.

Search in the winMIPS64 folder the following benchmark programs:

a. testio.s
b. mult.s
c. series.s
d. program_0.s (your program)

Starting from the basic configuration with no optimizations, compute by simulation the number of cycles required to execute these programs; in this initial scenario, it is assumed that the weight of the programs is the same (25%) for everyone. Assume a processor frequency of 1.75 kHz (*a very old technology node*).

Then, change processor configuration and vary the programs' weights as follows. Compute again the performance for every case and fill the table below (fill all required data in the table before exporting this file to pdf format to be delivered).:

1) Configuration 1

- a. Enable Forwarding
- b. Disable branch target buffer
- c. Disable Delay Slot

Assume that the weight of all programs is the same (25%).

2) Configuration 2

- a. Enable Forwarding
- b. Enable branch target buffer
- c. Disable Delay Slot

Assume that the weight of all programs is the same (25%).

3) Configuration 3

Configuration 1, but assume that the weight of the program your program is 43.33%.

4) Configuration 4

Configuration 1, but assume that the weight of the program series.s is 60%.

Table 2: Processor performance for different weighted programs

Program	No opt	Conf. 1	Conf. 2	Conf. 3	Conf. 4
testio.s	0,107	0,069	0,063	0,052	0,037
mult.s	0,269	0,140	0,132	0,106	0,075
series.s	0,079	0,033	0,033	0,025	0,018
program_0.s	0,045	0,039	0,037	0,067	0,093
TOTAL Time	0,500	0,281	0,265	0,250	0,223
(@ 1.75kHz)					

Nota per i docenti: la riga TOTAL Time contiene la somma delle varie colonne No opt, Conf1,Conf2,Conf3 e Conf4.

Le altre righe invece contengono **Clock Cycles/Freq*Peso** dove **Freq=1750**(1.75kHZ) e **peso** quello indicato sopra nelle configurazioni.

WinMIPS64 - branch if pair of registers are not equal begz - branch if register is equal to zero The following assembler directives are supported - start of data segment bnez - branch if register is not equal to zero .text - start of code segment .code - start of code segment (same as .text) - jump to address - jump to address in register .org <n> - start address - jump and link to address (call subroutine) .space <n> - leave n empty bytes jal .asciiz <s> - enters zero terminated ascii string jalr - jump and link to address in register (call .ascii <s> - enter ascii string subroutine) .align <n> - align to n-byte boundary .word $\langle n1 \rangle, \langle n2 \rangle$.. - enters word(s) of data (64-bits) dsll - shift left logical .byte < n1>, < n2>... - enter bytes dsrl - shift right logical .word32 <n1>,<n2>.. - enters 32 bit number(s) dsra - shift right arithmetic .word16 <n1>,<n2>.. - enters 16 bit number(s) dsllv - shift left logical by variable amount dsrlv - shift right logical by variable amount .double <n1>,<n2>.. - enters floating-point number(s) dsrav - shift right arithmetic by variable amount where <n> denotes a number like 24, <s> denotes a string movz - move if register equals zero like "fred", and movn - move if register not equal to zero <n1>,<n2>.. denotes numbers seperated by commas. - no operation nop - logical and and The following instructions are supported - logical or load byte logical xor lbu - load byte unsigned - set if less than sltu - set if less than unsigned sb - store byte lh - load 16-bit half-word dadd - add integers lhu - load 16-bit half word unsigned daddu - add integers unsigned - store 16-bit half-word dsub - subtract integers sh - load 32-bit word dsubu - subtract integers unsigned 1w lwu - load 32-bit word unsigned sw - store 32-bit word add.d - add floating-point ld - load 64-bit double-word sub.d - subtract floating-point - store 64-bit double-word mul.d - multiply floating-point sd - load 64-bit floating-point div.d - divide floating-point s.d - store 64-bit floating-point mov.d - move floating-point halt - stops the program cvt.d.l - convert 64-bit integer to a double FP format cvt.l.d - convert double FP to a 64-bit integer format daddi - add immediate c.lt.d - set FP flag if less than daddui - add immediate unsigned c.le.d - set FP flag if less than or equal to andi - logical and immediate c.eq.d - set FP flag if equal to ori - logical or immediate bc1f - branch to address if FP flag is FALSE xori - exclusive or immediate bc1t - branch to address if FP flag is TRUE lui - load upper half of register immediate mtc1 - move data from integer register to FP register slti - set if less than or equal immediate mfc1 - move data from FP register to integer register sltiu - set if less than or equal immediate unsigned

beq - branch if pair of registers are equal