## Tampereen Teknillinen Yliopisto (TTY)

## TAMPERE UNIVERSITY OF TECHNOLOGY

Institute of Digital and Computer Systems

## **MILK COPROCESSOR**

External version 1.0

Author: Claudio Brunelli

rev. June 2007

## **Contents**

1	Inte	ernal architecture	1
	1.1	Interface and block schemes	1
	1.2	I/O logic	4
	1.3	Register file	6
	1.4	Control logic	9
	1.5	Interrupt request signal generator	13
	1.6	Register locking	14
	1.7	Main functional units	17
		1.7.1 Integer to single precision conversion	18
		1.7.2 Single precision to integer conversion	19
		1.7.3 Floating-point multiplication	20
		1.7.4 Floating-point division	21
		1.7.5 Floating-point algebric addition	22
		1.7.6 Floating-point square root	23
2	Reg	risters	25
	2.1	Status register	25
	2.2	Control register	27
3	Cho	pices and assumptions	29
	3.1	instructions scheduling	29
	3.2	NaNs handling	29
	3.3	Underflow definition	31
	3.4	Traps	31
	3.5	Rounding modes	32
4	Inst	truction set	33
	4.1	Instructions description	33
	4.2	Instruction encoding	37

ii CONTENTS

## **List of Figures**

1.1	Milk coprocessor	1
1.2	Milk coprocessor internal architecture	3
1.3	Milk coprocessor I/O logic	4
1.4	Milk coprocessor register file	7
1.5	Milk coprocessor control logic	10
1.6	Milk coprocessor interrupt request signal generation logic	13
1.7	Milk coprocessor control logic	15
1.8	Milk coprocessor integer to single FP conversion logic	18
1.9	Milk coprocessor single FP to integer conversion logic	19
1.10	Milk coprocessor floating-point multiplier	20
1.11	Milk coprocessor floating-point divider	21
1.12	Milk coprocessor floating-point addsub functional unit	22
1.13	Milk coprocessor floating-point SQRT functional unit	23
2.1	Milk coprocessor status register	26
2.2	Milk coprocessor control word	27

## **List of Tables**

1.1	milk coprocessor external pins	2
1.2	IO logic external ports	5
1.3	register file external ports	8
1.4	control logic external ports	11
1.5	control logic external ports (continued)	12
1.6	register locking logic: external ports (continued)	16
1.7	Clock cycles per instruction	17

## **Chapter 1**

## Internal architecture

## 1.1 Interface and block schemes




Figure 1.1: Milk coprocessor

Milk (figure 1.1) is a floating-point unit (FPU) which can be used as a coprocessor for a RISC core; in particular it was developed to interface with two cores (even though it could be attached virtually to any core, by modifying its interface or adding a wrapper): the COFFEE RISC core from Tampere University of Technology, and Qrisc core, from the University of Bologna.


Milk is attached to the core via a dedicated, local data bus which is 32-bit wide.

The address bus is split in two parts: one part (made up of signal c\_index) is used to index Milk among the other coprocessors which could possibly be attached to the core, and the other part (made up of signal  $r_index$ ) is used to access one of its internal registers. Signal  $r_index$  is also made so that its 3 least significant bits identify one of the general purpose registers of Milk (as long as the MSB, that is  $r_index(3)$ , is equal to 0); when  $r_index(3)$  is equal to 1 then we are accessing a special purpose register inside Milk. In particular, the configuration 1000 addresses the control register, the configuration 1001 addresses the status register, the configuration 1010 addresses the register whose MSB contains the result of comparisons (for compatibility with Qrisc core).

The interface of Milk comprises then a set of control signals; they are all described in table 1.1. A description of each of the internal blocks which build up Milk coprocessor will be presented in the next pages.

Table 1.1: milk coprocessor external pins

PIN NAME	DIR	WIDTH	DESCRIPTION
clk	in	1	clock signal.
reset	in	1	reset signal.
enable	in	1	enables the internal registers of the coproces-
			sor to sample their inputs.
cop_in	in	32	data bus used by the core to load operands
			and instruction words into Milk.
cop_out	out	32	data bus used by the core to read back results
			and the contents of the status register of Milk.
rd_cop	in	1	read command. When it is set to its "high"
			logical value the core reads the result of an
			arithmetic operation (or the contents of the
			status register) from Milk.
wr_cop	in	1	write command. When it is set to its "high"
			logical value the core writes an operand (or
			an instruction word) inside Milk.
c_index	in	2	coprocessor address. The configuration "01"
			identifies Milk among the other coprocessors
			which can possibly be connected to the core.
r_index	in	4	register address.
cop_exc	out	1	when an exception occurs inside Milk during
			computation, this signal is pulsed. In partic-
			ular, it keeps an high value for one clk cycle.
read_hit	out	1	this signal goes high when the core reads a
			data from milk.
write_hit	out	1	this signal goes high when the core writes a
			data or an instruction into milk.
cop_stall	out	1	this (pulsed) signal is used to send an inter-
			rupt request to the core.



Internal architecture

## 1.2 I/O logic

The I/O logic is in charge of providing an interface between Milk and the core.




Figure 1.3: Milk coprocessor I/O logic

1.2 I/O logic 5

Table 1.2: IO logic external ports

PORT NAME	DIR	WIDTH	DESCRIPTION
enable	in	1	driven by signal cs, which is set active when Milk
			coprocessor is the one currently indexed by the core.
rd	in	1	driven directly by port rd_cop, which is the control
			command used by the core to read data from Milk.
Wr	in	1	driven directly by port wr_cop, which is the control
			command used by the core to send data to Milk.
regtype_sel	in	2	driven by signal regtype_sgl, which specifies
			whether the currently indexed register is a general
			purpose register, or the instruction register, or the
			status register.
gated_write	out	1	drives signal write_hit_s, which is used in com-
			bination with with signal r_index(3) to generate
			signal rcoffee_we, that is the write enable com-
			mand of the registers in the register file. Signal
			rcoffee_we is connected to port rcoffee_we of
			the REGISTER_FILE.
gated_read	out	1	drives signal read_hit_s, which is connected to
			the output port read_hit of Milk.
creg_we	out	1	drives signal cr_we, which is connected to port
			cr_we in the CONTROL LOGIC and is used to let the
			current instruction word reach the instruction regis-
		1	ter.
sreg_we	out	1	drives signal coffee_sreg_write, which
			is connected to port restore in the
			STICKY STATUS LOGIC, and is used to man-
	0114	32	ually reset the flag bits in the status register.
outgoing_data	out	32	Directly connected to port cop_out, that is the external outgoing data bus.
ingoming data	in	32	Directly connected to port cop_in, that is the exter-
incoming_data	ш	32	nal incoming data bus.
data_in	0114	32	drives signal coffee_data_in, which is con-
data_III	out	32	nected to port coffee_in in the REGISTER FILE,
			and brings data from the core to the register file, the
			control register and the status register.
sreg_out	in	32	driven by signal status_reg_out, which comes
breg_out	111	32	from the status register, making available its content
			to the core.
data_out	in	32	driven by signal ext_data_out, which comes
4454_546	***	J.Z	from port coffee_out in the REGISTER FILE. It
			brings to the core the result of computations (stored
			in the indexed register).
			in the macked register).

## 1.3 Register file

The Register file contains 8 registers, each 32-bits wide, and the mux/demux logic to route the desired values to/from the selected registers. They are general purpose registers, used to store the operands and the results of arithmetic computations.




 Table 1.3: register file external ports

PORT NAME	DIR	WIDTH	DESCRIPTION
clk	in	1	clock signal
reset	in	1	reset signal
enable	in	1	driven by an high value.
rd_we(j)	in	1	driven by signal wb_enable, which is used by the
			control logic in order to specify that a functional
			unit is enabled to perform a writeback of its result
			in the register file.
rd(j)	in	3	driven by signal wb_reg, which is used by the con-
			trol logic in order to specify the address of the target
			register in which the result has to be stored.
rcoffee_we	in	1	driven by signal rcoffee_we, which is used in or-
			der to specify that the core is enabled to write a data
			in the register file.
rcoffee_in	in	3	driven by signal r_index[20], which is used in
			order to specify the address of the target register in
			which the data from the core has to be stored.
coffee_in	in	32	driven by signal coffee_data_in, which is the
			data sent by the core.
d(j)_in	in	32	driven by signal (FU name)_out, which is the re-
			sult sent by the selected functional unit.
coffee_out	out	32	drives signal ext_data_out, that is connected to
			port data_out in the IO LOGIC and is then con-
			nected to the external outgoing data bus.
rs1_out	out	32	drives signal op1, which is connected to the port of
			the first operand of each of the functional unit.
rs2_out	out	32	drives signal op2, which is connected to the port of
			the second operand of each functional unit which
			require two operands.

## 1.4 Control logic

The control logic rules the execution inside Milk. Inside the control logic there is the control register, which stores the instruction words sent to Milk by the core (the details of the instruction register can be found in chapter 3, special regsiters, while the encoding of the instructions can be found in chapter 4, instruction set). The control logic enables each functional unit (FU) to make the writeback of results only at the right time. Moreover, it controls the flow of data inside Milk, selecting the correct source/destination registers.




Figure 1.5: Milk coprocessor control logic

Table 1.4: control logic external ports

PORT NAME	DIR	WIDTH	DESCRIPTION
clk	in	1	clock signal.
reset	in	1	reset signal.
enable	in	1	driven by main enable signal sent by the core.
cr_we	in	1	driven by signal cr_we, which is used by the
			IO logic in order to specify that the control
			register has to sample the control word sent
			by the core.
coffee_data	in	32	driven by signal coffee_data_in, which is
			the control word sent by the core.
cvt_s_we	out	1	drives signal cvt_s_we, which enables the
			"integer to single precision float" converter to
			sample the current operands.
trunc_s_we	out	1	drives signal trunc_s_we, which enables
			the "single precision float to integer" con-
			verter to sample the current operands.
mul_s_we	out	1	drives signal mul_s_we, which enables the
			multiplier to sample the current operands.
add_s_we	out	1	drives signal add_s_we, which enables the
			adder to sample the current operands.
sub_s_we	out	1	drives signal sub_s_we, which enables the
			adder to sample the current operands.
div_s_we	out	1	drives signal div_s_we, which enables the
			divider to sample the current operands.
sqrt_s_we	out	1	drives signal sqrt_s_we, which enables the
			square root extractor to sample the current
			operands.
compare_s_we	out	1	drives signal compare_s_we, which en-
			ables the comparator to sample the current
			operands.

 Table 1.5: control logic external ports (continued)

exc_unknown_instruction	out	1	drives signal exception_bus(19). It's set to a logical high value when the core writes an instruction word containing an opcode which is not valid for Milk.
wb_en_(j)	out	1	drives signal wb_en_(j), that is connected to port rd_we(j) in the REGISTER FILE and enables the target register to sample the current result from functional unit (j).
wb_reg_(j)	out	3	drives signal wb_reg_(j), which is connected to port rd_(j) in the REGISTER FILE, and specifies the address of the target register.
rs1	out	3	drives signal rs1, which is connected to port rs1 in the REGISTER FILE, and specifies the address of the first of the current operands.
rs2	out	3	drives signal rs2, which is connected to port rs2 in the REGISTER FILE, and specifies the address of the second of the current operands.
opcd	out	6	drives signal opcode, which is connected to port opcode in the comparator, and specifies the address of the first of the current operands.

## 1.5 Interrupt request signal generator

It is a very simple logic, which ensures that interrupt signals (sent by Milk to the core) last for one clock cycle.




Figure 1.6: Milk coprocessor interrupt request signal generation logic

## 1.6 Register locking

This block generates a stall signal, which freezes the core when necessary, in order to guarantee the logic consistency of the flow of application programs. In particular, the core is stalled whenever it tries to read a result from Milk when it is not ready yet (the result is still being calculated); the core is also stalled when it tries to issue to Milk an instruction which is dependent on the result(s) of one or more previous instructions, which are still running in Milk's pipeline.




 Table 1.6: register locking logic: external ports (continued)

PORT NAME	DIR	WIDTH	DESCRIPTION
clk	in	1	clock signal.
reset	in	1	reset signal.
enable	in	1	driven by main enable signal sent by the core.
cop_we	in	1	driven by signal wr_cop. It's set to a logical
			high value when the core writes a data or an
			instruction.
cop_rd_enable	in	1	driven by signal rd_cop, It's set to a logical
			high value when the core reads a result from
			Milk.
cop_rs1_addr	in	3	driven by signal wb_reg_(j), which
			is connected to port rd_(j) in the
			REGISTER FILE, and specifies the ad-
			dress of the target register.
cop_rs2_addr	in	3	driven by signal rs1, which is connected to
			port rsl in the REGISTER FILE, and spec-
			ifies the address of the first of the current
1 17 (')	•	1	operands.
cop_wb_enable_(j)	in	1	driven by signal rs2, which is connected to
			port rs2 in the REGISTER FILE, and specifies the address of the second of the current
			operands.
cop_wb_addr_(j)	in	3	driven by signal wb_reg_(j), which is con-
Cop_wb_addr_()	ш	3	nected to port wb_reg_(j), which is con-
			logic, and specifies the address of the first of
			the destination register.
lock_micro	out	1	drives port cop_stall.
creg_rd	in	1	address of the register in the register file to
Creg_ru	1111	1	wich the result is stored.
creg_opcode	in	2	it is the most significant part of the opcode.
next_lock_vector_p	out	8	it represents the content of the lock vector in
			the following clock cycle.
	l .		and rome mig clock by clo.

## 1.7 Main functional units

The functional units (FUs) are a set of components, each dedicated to perform the elaboration of a given arithmetic operation (multiplication, division, etc.). Each FU can be freely removed from the architecture just setting to 0 the value of the corresponding VHDL generic, so that the user can save area on chip when he know in advance that he won't need too often a certain operation. In particular, the divider and the square root together take a lot of area (approximately 70in certain cases. The latencies (in terms of clock cycles) of each FU are:

Table 1.7: Clock cycles per instruction

instruction	clk cycles amount
ADD.S	5
SUB.S	5
MUL.S	3
DIV.S	12
SQRT.S	8
ABS.S	1
MOV.S	1
NEG.S	1
NOP.S	1
NEG.S	1
COP.CVT.S	2
COP.CVT.W	2
COP.C.cond	1

Note that by excluding from the implementation the hardware logic which handles the denormal operands, all the latencies are then reduced by one cycle.

## 1.7.1 Integer to single precision conversion




Figure 1.8: Milk coprocessor integer to single FP conversion logic

# 1.7.2 Single precision to integer conversion




Figure 1.9: Milk coprocessor single FP to integer conversion logic

## 1.7.3 Floating-point multiplication




Figure 1.10: Milk coprocessor floating-point multiplier

## 1.7.4 Floating-point division




Figure 1.11: Milk coprocessor floating-point divider

## 1.7.5 Floating-point algebric addition




Figure 1.12: Milk coprocessor floating-point addsub functional unit

## 1.7.6 Floating-point square root




Figure 1.13: Milk coprocessor floating-point SQRT functional unit

## **Chapter 2**

## Registers

Milk has 8 general purpose 32-bit registers for arithmetic operands and results storage. Two special purpose registers are present in the achitecture: status register and control register. they are described in the following two subsections.

## 2.1 Status register

It's a 32-bit register (see figure 2.1). Bits 31..18, bit 7 and bit 0 are not used in the current implementation, and it's assumed they all are zeroes. Bits 17..14 contain the result of the latest comparison instruction: bit 17 is a logical flag that specifies whether the requested comparison (operand a is less than operand b, operand a is equal to operand b, and so forth) returned a TRUE or FALSE result. This result is used by the Qrisc processor. Bits 16..14 instead have respectively the following meaning: equal, less, unordered. They are used by Coffee RISC core to know what kind of relationship holds between the operands of the latest comparison issued. For instance, if bit 16 is set to one while bits 15 and 14 are zero, then it means that operand a is equal to operand b; if operand a is smaller than operand b, then bits 16 and 14 are zero while bit 15 is set to one.

Bits 13..8 are the flag bits related to floating-point exceptions, and they refer to the whole computation since last reset or last writing from user. Bits 6..1 are the same flags, but they refer to the last executed instruction only.

A more accurate description of each flag is listed below:

### • overflow (OFC, OFA)

The result, rounded as if the exponent range were unbounded, would be larger in magnitude than the destination format's largest finite number.

26 Registers



Figure 2.1: Milk coprocessor status register

## • underflow (UFC, UFA)

The rounded result is inexact and would be smaller in magnitude than the smallest normalized number in the destination format. Result is tiny and loss of accuracy occurs (may be either a denormalization loss or an inexact result).

## • inexact result (NXC, NXA)

The rounded result of an operation differs from the infinitely precise unrounded result.

## • invalid (NVC, NVA)

An operand is improper for the operation to be performed.

### • division by zero (DZC, DZA)

Division of a subnormal or normalized number by a null divisor. Note that if also dividend is null (invalid operation), DZC is not set.

### • unsupported instruction (UIC, UIA)

The current opcode is not recognized by Milk since corresponding instruction is not implemented in hardware.

## 2.2 Control register

The content of the control register is shown in figure 2.2: Bits 31..26 contains



Figure 2.2: Milk coprocessor control word

the encoding of the "cop" instruction of Coffee RISC core.

Bits 25..24 are used to index one among the 4 coprocessors that can be attached to Coffee RISC core.

Bits 23..22 are unused.

Bit 21 specifies the floating-point precision. Only single precision is currently supported by Milk coprocessor, and this bit is always 0.

Bits 20..16 are the address of the second operand's source register. When the current instruction supports only on operand this field is ignored. Note that since only 8 registers are present in the architecture, bits 20 and 19 are not used. Bits 15..11 are the address of the first operand's source register. Note that since only 8 registers are present in the architecture, bits 15 and 14 are not used.

Bits 10..6 are the address of the destination's register. Note that since only 8 registers are present in the architecture, bits 10 and 9 are not used.

Bits 5..0 are the opcode of the current instruction performed by Milk.

More details and precise examples can be found further in the text, in instruction set describing section.

28 Registers

# **Chapter 3**

# Choices and assumptions

Many of the choices about results to be delivered and computation in general are directly following what is stated in IEEE 754-1985 standard for binary floating-point arithmetic and in IEEE 1754-1994 standard for a 32-bit microprocessor architecture.

IEEE 754 doesn't require that all aspects of the standard are implemented in hardware. So privileged-mode software shall emulate any functionality not present in the hardware.

## 3.1 instructions scheduling

Instructions can be executed in parallel, and shorter operations can be started while longer ones are still running.

Programmer should take care of data consistency inside registers (for example, he should pay attention not to write data to a register that contains a data that still has to be read).

He also should never write a data to a register where a functional unit is writing back its result at the same time; if so, then Milk will allow the functional unit to write the result, and the data from the core will be discarded.

# 3.2 NaNs handling

NaNs are handled completely by hardware, without trapping to software routines. Anyway it is possible for the user to "remove" the logic which takes care of normalizing denormal operands just setting to zero the value of the corresponding VHDL generic. This way some area on chip can be saved, and all the latencies of the FUs are shortened (1 clock cycle less).

**NaN transformation**: when a SNaN is read by a functional unit, the result is the QNaN obtained by setting the most significant bit of the fractional part (quiet bit) to 1, and the invalid operation flag is set. when converting to a narrower destination format excess low-order bits of the operand fraction are discarded. When converting to a wider format, excess low-order bits of the result fraction are set to zero.

If the instruction is a MOV, or anyway a non arithmetic instruction, then the invalid operation flag is not set, and the number is copied as it is (change of sign could be performed if specified by the instruction).

The result of an elaboration involving NaN operands depends is instruction dependent:

#### • trunc

operand is a NaN, infinity, large argument (  $\geq$  2147483648.0 or  $\leq$  -2147483649.0): invalid exception is raised. If operand is positive result is 2147483647, otherwise result is -2147483648.

#### • arithmetic operations with one operand

- no NaN operands: for all invalid operations, like sqrt(-1), the result will be the QNaN with sign = zero, exponent = all ones, fraction = all ones.
- QNaN operand: no exception, result is the QNaN operand.
- SNaN operand: invalid exception, result is the QNaN obtained by NaN transformation.

#### • arithmetic operations with two operands

- no NaN operands: for all invalid operations, like 0/0, the result will be the QNaN with sign = zero, exponent = all ones, fraction = all ones.
- both QNaN operands: no exception, result is the QNaN operand loaded from source register 2.
- both SNaN operands: invalid exception, result is the QNaN operand obtained from NaN transformation of SNaN in source register 2.
- one SNaN operand: invalid exception, result is the QNaN obtained by NaN transformation.
- one QNaN operand: no exception, result is the QNaN operand.

## 3.3 Underflow definition

Underflow occurs if **both** of the following conditions are verified ("tinyness" and "loss of accuracy"):

- the result has magnitude between zero and the smallest normalized nomber in the destination format (result is tiny)
- the correctly rounded result in the destination format suffers a **loss of accuracy**. This happens for example after rounding of the exact tiny value.

Note that this implies that if the exact unrounded value is equal to the rounded one (no rounding error), then the result is not inexact and not causes underflow even if it's "tiny". The same way, any tiny result that leads to a rounding error arises both inexact and underflow exceptions, even if rounded result is zero or the smallest normalized number.

## 3.4 Traps

Up to now architecture doesn't allow the user to choose whether or not to enable traps for exceptions; they are set to disabled by default. Only "unsupported instruction" exceptions causes a trap to the core using the cop\_exc signal.

# 3.5 Rounding modes

Milk currently supports only the default rounding mode, that is *Round towards nearest even*.

# **Chapter 4**

# **Instruction set**

## 4.1 Instructions description

This chapter describes the machine instructions recognized by Milk coprocessor. The following set of instructions is what the assembler should provide; the syntax is made of an instruction mnemonic followed by destination and source registers.

Abbreviations used:

- dr : destination registers, number in the range 0...31
- sr1, sr2 : source registers, number in the range 0...31 ( in case that the instruction only needs one operand, it's simply named sr)
- opc: opcode of Milk instructions

Note that each of the supported instructions' mnemonics ends with a number (coprocessor index), for example, fadd0, fadd1, fmul1, etc.

This is due to the fact that Coffee RISC core supports up to 4 coprocessors, so any of them could be a floating-point unit (FPU), and the one who should actually perform the operation is that indexed by the number specified by the number at the end of the mnemonic. This way, fadd0 is a floating-point addiction to be executed by coprocessor number 0, fadd1 is a floating-point addiction to be executed by coprocessor number 1, and so on (for this reason, in the following pages are explained the instructions related to coprocessor number 0, because the instructions related to the other ones are exactly the same for meaning and syntax, and differs only for the coprocessor index).

#### fadd0

syntax description fadd0 dr, sr1, sr2

Single-precision floating-point (algebraic) addiction to be executed by coprocessor number 0. The contents of the source registers sr1 and sr2 are added together and the result is placed to the destination register dr. Overflow exception is generated if the result's exponent exceeds 127. Underflow exception is generated if the result's exponent exceeds -150. Together with overflow and underflow, also inexact exception occurs. Invalid operation exception occurs whenever both operands are infinites with opposite signs, or when at least one of the operands is a SNaN.

#### fsub0

syntax description fsub0 dr, sr1, sr2

Single-precision floating-point (algebraic) subtraction to be executed by coprocessor number 0. The contents of the source register sr2 is subtracted by the one in sr1 (meaning that: rd = sr1 - sr2) and the result is placed to the destination register dr. Overflow exception is generated if the result's exponent exceeds 127.Underflow exception is generated if the result's exponent exceeds -150. Together with overflow and underflow, also inexact exception occurs. Invalid operation exception occurs whenever both operands are infinites with opposite signs, or when at least one of the operands is a SNaN.

#### fmul0

syntax description fmul0 dr, sr1, sr2

Single-precision floating-point multiplication to be executed by coprocessor number 0. The contents of the source registers sr1 and sr2 are multiplied and the result is placed to the destination register dr. Overflow exception is generated if one of the operands is infinite and the other is a finite number, or if the result's exponent exceeds 127. Underflow exception is generated if the result's exponent exceeds -150. Together with overflow and underflow, also inexact exception occurs. Invalid operation exception occurs whenever one operand is infinite and the other one is null, or when at least one of the operands is a SNaN.

#### fdiv0

syntax description

fdiv0 dr, sr1, sr2

Single-precision floating-point division to be executed by coprocessor number 0. The contents of the source register sr1 is divided by the one in sr2 and the result is placed to the destination register dr (meaning that: rd = sr1 / sr2). Overflow exception is generated if dividend is infinite and divisor is zero, or if the result's exponent exceeds 127. Underflow exception is generated if the result's exponent exceeds -150. Together with overflow and underflow, also inexact exception occurs. Invalid operation exception occurs whenever both operands are infinite or both are null, or when at least one of the operands is a SNaN. Division by zero exception is raised when a finite non-null number is divided by a null divisor.

#### fsqrt0

syntax description fsgrt0 dr, sr

Single-precision floating-point square-root to be executed by coprocessor number 0. The content of the source register sr is square-rooted and the result is placed to the destination register dr. Invalid operation exception occurs whenever radicand is negative, or when it's a SNaN.

#### fabs0

syntax description

fabs0 dr, sr

Single-precision floating-point absolute value (ABS) to be executed by coprocessor number 0. The absolute value of the content of the source

coprocessor number 0. The absolute value of the content of the source register sr is placed to the destination register dr. Invalid operation

exception occurs whenever operand is a NaN.

#### fmov0

syntax description fmov0 dr, sr

The operand has to be moved to another register by coprocessor number 0. The value of the content of the source register sr is moved to the

destination register dr.

#### fneg0

syntax

fneg0 dr, sr

**description** Single-precision floating-point sign inversion to be executed by copro-

cessor number 0. The value of the content of the source register sr is inverted in sign and placed to the destination register dr. Invalid oper-

ation exception occurs whenever operand is a NaN.

#### fnop0

syntax

fnop0

**description** No operation is executed.

#### fcvt.s0

syntax description fcvt.s0 dr, sr

Integer to single-precision floating-point conversion to be executed by coprocessor number 0. The value of the content of the source register (considered as an integer) sr is converted into signle precision floating-point format and placed to the destination register dr.

#### fcvt.w0

syntax description

fcvt.s0 dr, sr

Single-precision floating-point to integer conversion to be executed by coprocessor number 0. The value of the content of the source register sr (considered as a single precision floating-point number) is converted into integer format and placed to the destination register dr. Invalid operation exception is generated if operand is a NaN, infinity, or a large argument (  $\geq$  2147483648.0 or  $\leq$  -2147483649.0). Denormal numbers are flattened to zero, and inexact result exception is raised.

#### fcCONDITION0

syntax description fcCONDITION0 dr, sr1, sr2

Comparison to be executed by coprocessor number 0. The contents of the source registers sr1 and sr2 are compared according to the condition specified in the name of the instruction and the result is placed to the destination register dr. Invalid operation exception occurs when at least one of the operands is a NaN and MSB in the opcode is set; result is unordered. NaN compares unordered with everything including itself. Sign of zero is ignored, so +0 = -0.

## 4.2 Instruction encoding

Here are listed the instruction words sent from the core to Milk coprocessor. Notes:

- first 6 bits (bits 31..26) of the instruction words correspond to the **cop** instruction of the Coffee RISC core, and are ignored by Milk
- bits 25..24 of the instruction words specify which one among the 4 coprocessors supported by Coffee RISC is the one to be used. They are the same as bits c\_index[1..0]
- bits 23..22 are ignored by Milk
- bit 21 specifies wether the istruction has to be executed in single-precision or in double-precision. At the moment only single precision is implemented in hardware
- bits 20..16, 15..11 and 10..6 specify the addresses (inside Milk coprocessor's register file) of operands and result of the instruction. They all are 5-bit fields so that up to 32 internal registers are supported, but actually only 8 registers are implemented inside Milk, so only the 3 least significant bits are considered.
- bits 5..0 represent the opcode of one instruction supported by Milk
- milk internal opcodes opc = 010000 and opc = 010001 are RESERVED

fadd0 dr, sr1	sr2			
111100   00   $XX$   0 = single precision	sr2	sr1	dr	opc = 000000
				_
fadd1 dr, sr1	sr2			
111100   01   $XX$   0 = single precision	sr2	sr1	dr	opc = 000000
fadd2 dr, sr1,	sr2			
111100   10   $XX$   0 = single precision	sr2	sr1	dr	opc = 000000
				_
fadd3 dr, sr1,	sr2			
111100   11   XX   0 = single precision	sr2	sr1	dr	opc = 000000
fsub0 dr, sr1,	sr2			
$111100 \mid 00 \mid XX \mid 0 = \text{single precision}$	sr2	sr1	dr	opc = 000001
			ı	*
fsub1 dr, sr1,	sr?			
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	sr2	sr1	dr	opc = 000001
	1		l	1
fsub2 dr, sr1,	cr?			
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	sr2	sr1	dr	opc = 000001
8.1				·
fsub3 dr, sr1,	sr2			
111100 $11$ $XX$ $0 = single precision$	sr2	sr1	dr	opc = 000001
			l	
fmul0 dr, sr1	cr?			
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	sr2	sr1	dr	opc = 000010
	-			or conservation
fmul1 dr, sr1	er?			
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	sr2	sr1	dr	opc = 000010
or   /2   o onigic precision		U. 1	1	-P- 000010
f10 J1	C#O			
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	sr2	sr1	dr	opc = 000010
111100   10   701   0 = bittgle precision	012	011	<u> </u>	-pe 000010

fmı	12	dr	cr1	sr2
	11.7	ur.	511	. SIZ

111100   11   XX   0 = single precision   sr2   sr1   dr   opc = 000010	111100	11	XX	0 = single precision	sr2	sr1	dr	opc = 000010
---	--------	----	----	----------------------	-----	-----	----	--------------

### fdiv0 dr, sr1, sr2

111100 00 XX	0 = single precision	sr2	sr1	dr	opc = 000011

## fdiv1 dr, sr1, sr2

444400	0.4	3 (3 (				•	000011
111100	(1)1		0 = single precision	cr')	cr!	dr	-0000 - 000011
111100	O1	$\Lambda\Lambda$	0 - Single precision	514	51.1	uı	
			0 1				1

### fdiv2 dr, sr1, sr2

$111100 \mid 10 \mid XX \mid 0 = \text{single precision}$	sr2 sr	1 dr	opc = 000011
---	--------	------	--------------

## fdiv3 dr, sr1, sr2

	111100	11	XX	0 = single precision	sr2	sr1	dr	opc = 000011
--	--------	----	----	----------------------	-----	-----	----	--------------

## fsqrt0 dr, sr

1	111100	00	XX	0 = single precision	XXXXX	sr	dr	opc = 000100
				0 · I				- I

## fsqrt1 dr, sr

				fsqrt2 dr,	sr			
111100	10	XX	0 = single		XXXXX	sr	dr	opc = 000100
111100	11	VV	0 1	fsqrt3 dr,			1	000100
111100	11	XX	0 = single	precision	XXXXX	sr	dr	opc = 000100
				falson du	<b></b>			
111100	00	XX	0 = single	fabs0 dr,	XXXXX	sr	dr	opc = 000101
			5 5	r				or contain
				fabs1 dr,	sr			
111100	01	XX	0 = single		XXXXX	sr	dr	opc = 000101
				fabs2 dr,				
111100	10	XX	0 = single	precision	XXXXX	sr	dr	opc = 000101
111100	11	XX	0 = single	fabs3 dr,	sr XXXXX	C#	dr	opc = 000101
111100	11	$\Lambda\Lambda$	0 – sirigie	precision	λλλλλ	sr	uı	opc = 000101
				fmov0 dr	cr			
111100	00	XX	0 = single		XXXXX	sr	dr	opc = 000110
			<u> </u>					1
				fmov1 dr	, sr			
111100	01	XX	0 = single		XXXXX	sr	dr	opc = 000110
444400	40	3/3/		fmov2 dr		1		000115
111100	10	XX	0 = single	precision	XXXXX	sr	dr	opc = 000110
111100	11	XX	0 = single	fmov3 dr	XXXXX	sr	dr	opc = 000110
111100	11	$\Lambda\Lambda$	0 – 3111816	Piccision		31	uı	ope – 000110
				fneg0 dr,	sr			
111100	00	XX	0 = single		XXXXX	sr	dr	opc = 000111

fneg1 dr, sr

111100 01 XX 0 = single precisio	n XXXXX	sr	dr	opc = 000111
----------------------------------	---------	----	----	--------------

fneg2 dr, sr

111100	10	XX	0 = single precision	XXXXX	sr	dr	opc = 000111

fneg3 dr, sr

ı	111100	11	XX	0 = single precision	XXXXX	sr	dr	opc = 000111
	111100		,	o single precision	, , , , , , , , , , , , , , , , , , , ,	01		ope coorri

fnop0

111100	00	XX	0 = single precision	XXXXX	XXXXX	XXXXX	opc = 001000

fnop1

111100   01   XX   0 = single precision   $\lambda$	XXXXX XXXXXX XX	XXXX opc = $001000$
---	-----------------	---------------------

fnop2

1	111100	10	XX	0 = single precision	XXXXX	XXXXX	XXXXX	opc = 001000
	111100	10	70.0	o = brigic precision	700000	70000	700000	ope = 001000

fnop3

fcvt.s0 dr, sr								
111100 00	XX	0 = single precision	XXXXX	sr	dr	opc =	100000	
	201	fcvt.s1 dr				T	100000	
111100 01	XX	0 = single precision	XXXXX	sr	dr	opc =	100000	
111100   10	XX	fcvt.s2 dr	xxxxx	C#	dr	010.0	100000	
111100   10	$\Lambda\Lambda$	0 = single precision	λλλλλ	sr	ar	ope =	100000	
		C						
111100   11	XX		xxxxx	sr	dr	onc =	100000	
111100 11	λλ	0 - Single precision	700000	51	aı	орс –	100000	
		fcvt.w0 dı	r cr					
111100 00	XX	0 = single precision	XXXXXX	sr	dr	opc =	100100	
I I		0 1						
		fcvt.w1 dı	r. sr					
111100 01	XX	0 = single precision	XXXXX	sr	dr	opc =	100100	
	•							
		fcvt.w2 dı	r, sr					
111100 10	XX	0 = single precision	XXXXX	sr	dr	opc =	100100	
		fcvt.w3 dı						
111100   11	XX	0 = single precision	XXXXX	sr	dr	opc =	100100	
111100 00	1 3/3/	fc.f0 dr, sr1		4	1 1	1	10000	
111100 00	XX	0 = single precision	sr2 s	r1	dr	opc = 1	10000	
		4 4. 4	_					
111100 01	Lvv	fc.f1 dr, sr1		<sub>0</sub> 1 .	du	ona – 1	10000	
111100 01	XX	0 = single precision	i Srz S.	r1   0	dr	opc = 1	10000	
		6.60.1	0					
111100   10	XX		., <b>sr</b> 2 n sr2 si	r1 (	dr	opc = 1	10000	
111100   10	1,00	5 Shight precision	. 012 0.	'		Spc - 1	10000	

$f_C$	f3	dr	cr1	. sr2
и.	.13	uı.	21.1	- 512

111100   11   XX   $0 = \text{single precision}$   $\text{sr2}$   $\text{sr1}$   $\text{dr}$   $\text{opc} = 110$	111100	11 XX	0 = single precision	sr2 sr1	dr	opc = 110000
---	--------	-------	----------------------	---------	----	--------------

#### fc.un0 dr, sr1, sr2

111100	00	XX	0 = single precision	sr2	sr1	dr	opc = 110001

### fc.un1 dr, sr1, sr2

111100	Ω1	ΥY	0 = single precision	cr2	cr1	dr	opc = 110001
111100	01	70.0	0 - birigic precibion	012	011	a.	ope = 110001

### fc.un2 dr, sr1, sr2

111100	10 X	X = 0 = single precisi	on sr2 sr1	dr	opc = 110001
--------	------	------------------------	------------	----	--------------

## fc.un3 dr, sr1, sr2

111100	11	XX	0 = single precision	sr2	sr1	dr	opc = 110001
--------	----	----	----------------------	-----	-----	----	--------------

### fc.eq0 dr, sr1, sr2

111100	00	XX	0 = single precision	sr2	sr1	dr	opc = 110010

## fc.eq1 dr, sr1, sr2

	111100	01	XX	0 = single	precision	sr2	sr1	dr	opc = 110010	l
--	--------	----	----	------------	-----------	-----	-----	----	--------------	---

fc.eq2 dr, sr1, sr2								
111100   10   XX   $0 = \text{single precision}$	sr2	sr1	dr	opc = $110010$				
fc.eq3 dr, sr1,	sr2							
111100   11   XX   0 = single precision	sr2	sr1	dr	opc = 110010				
				_				
fc.ueq0 dr, sr1	. sr2							
111100  00  XX  0 = single precision	sr2	sr1	dr	opc = 110011				
		<u>I</u>	<u>I</u>	1				
fa yaa1 dr cr1	c*?							
fc.ueq1 dr, sr1 $111100 \ 01 \ XX \ 0 = \text{single precision}$	sr2	sr1	dr	opc = 110011				
111100   01   701   0 = single precision	512	511	ai	ope = 110011				
fc.ueq2 dr, sr1	_	au1	J.,	110011				
111100   10   XX   0 = single precision	sr2	sr1	dr	opc = 110011				
fc.ueq3 dr, sr1		1						
111100   11   $XX$   0 = single precision	sr2	sr1	dr	opc = $110011$				
fc.olt0 dr, sr1,	sr2							
111100   00   XX   $0 = \text{single precision}$	sr2	sr1	dr	opc = $110100$				
fc.olt1 dr, sr1,	sr2							
111100 01 XX 0 = single precision	sr2	sr1	dr	opc = 110100				
·								
fc.olt2 dr, sr1,	sr2							
111100 10 XX $0 = \text{single precision}$	sr2	sr1	dr	opc = 110100				
		1		*				
fc.olt3 dr, sr1,	er?							
111100   11   XX   0 = single precision	sr2	sr1	dr	opc = 110100				
in joingle precision	512	J11	1 41	JFC 110100				
4 10 1	_							
fc.ult0 dr, sr1, $111100 \mid 00 \mid XX \mid 0 = \text{single precision}$		cr1	d.	one = 110101				
111100   00   XX   $0 = \text{single precision}$	sr2	sr1	dr	opc = $110101$				

$f_{\mathcal{C}}$	111	1+1	dr	cr1	sr2
TC.	.uı	ш	CIT.	SEL	SEZ

### fc.ult2 dr, sr1, sr2

111100	10	XX	0 = single precision	sr2	sr1	dr	opc = 110101

### fc.ult3 dr, sr1, sr2

111100	11	XX	0 = single precision	sr2	sr1	dr	opc = 110101
--------	----	----	----------------------	-----	-----	----	--------------

### fc.ole0 dr, sr1, sr2

111100 0	00 XX	0 = single precision	sr2	sr1	dr	opc = 110110
----------	-------	----------------------	-----	-----	----	--------------

## fc.ole1 dr, sr1, sr2

111100	01	XX	0 = single precision	sr2	sr1	dr	opc = 110110

## fc.ole2 dr, sr1, sr2

111100	10	XX	0 = single precision	sr2	sr1	dr	opc = 110110

### fc.ole3 dr, sr1, sr2

$1111100 \mid 11 \mid XX \mid 0 = 8$	single precision   sr2	srl dr	opc = 110110
--------------------------------------	------------------------	--------	--------------

fc.ule0 dr, sr	1, sr2				
111100   00   XX   $0 = \text{single precision}$	sr2	sr1	dr	opc =	= 110111
fc.ule1 dr, sr	_		,	_	440444
$\begin{array}{ c c c c c c c c c c c c c c c c c c c$	sr2	sr1	dr	opc =	= 110111
fc.ule2 dr, sr $111100 \mid 10 \mid XX \mid 0 = $ single precision	1, sr2   sr2	sr1	dr	one -	= 110111
111100 10 AX 0 - Shigle precision	512	51 1	uı	opc -	- 110111
fc.ule3 dr, sr	1 cr2				
111100  11  XX  0 = single precision	sr2	sr1	dr	opc =	= 110111
fc.sf0 dr, sr1	, sr2				
111100   00   XX   $0 = \text{single precision}$		sr1	dr	opc =	= 111000
fc.sf1 dr, sr1					
111100   01   $XX$   0 = single precision	sr2	sr1	dr	opc =	= 111000
fc.sf2 dr, sr1		T 1	1	1	111000
111100   10   XX   $0 = \text{single precision}$	sr2	sr1	dr	opc =	= 111000
((0.1	0				
fc.sf3 dr, sr1 $111100 \mid 11 \mid XX \mid 0 = $ single precision	sr2	sr1	dr	opc =	= 111000
111100   11   700   0   Shighe precision	512	511	a.	ope	111000
fc.ngle0 dr, si	1. sr2				
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	sr2	sr1	dr	opc =	= 111001
	•			-	
fc.ngle1 dr, si	1, sr2				
111100   01   $XX$   0 = single precision	sr2	sr1	dr	opc =	= 111001
fc.ngle2 dr, sr		1 1	1	ı	111001
111100   10   XX   0 = single precision	sr2	sr1	dr	opc =	= 111001

fc.ngle3 dr, sr1, sr2

111100	11	XX	0 = single	precision	sr2	sr1	dr	opc = 111001
			0	F				-r

fc.seq0 dr, sr1, sr2

				<u>, , , , , , , , , , , , , , , , , , , </u>				
111100	00	XX	0 = single pi	recision	sr2	sr1	dr	opc = 111010

fc.seq1 dr, sr1, sr2

111100	01	XX	0 = single precision	sr2	sr1	dr	opc = 111010
111100	O1	$\mathcal{M}$	0 - single precision	312	31 1	uı	opc = 111010

fc.seq2 dr, sr1, sr2

111100	10	XX	0 = single precision	sr2	sr1	dr	opc = 111010

fc.seq3 dr, sr1, sr2

			reiseqs ar, srr	,			
111100	11	XX	0 = single precision	sr2	sr1	dr	opc = 111010

fc.ngl0 dr, sr1, sr2

111100	00	XX	0 = single precision	sr2	sr1	dr	opc = 111011

fc.ngl1 dr, sr1, sr2

111100	01   XX	0 = single precision	sr2	srl	ar	opc = 111011
--------	---------	----------------------	-----	-----	----	--------------

fc.ngl2 dr, sr1, sr2           fc.ngl3 dr, sr1, sr2           fc.ngl3 dr, sr1, sr2           111100 11 XX 0 = single precision sr2 sr1 dr opc = 111011           fc.lt0 dr, sr1, sr2           111100 00 XX 0 = single precision sr2 sr1 dr opc = 111100           fc.lt1 dr, sr1, sr2           111100 01 XX 0 = single precision sr2 sr1 dr opc = 111100
111100         11         XX         0 = single precision         sr2         sr1         dr         opc = 111011           fc.lt0 dr, sr1, sr2           111100         00         XX         0 = single precision         sr2         sr1         dr         opc = 111100           fc.lt1 dr, sr1, sr2
111100         11         XX         0 = single precision         sr2         sr1         dr         opc = 111011           fc.lt0 dr, sr1, sr2           111100         00         XX         0 = single precision         sr2         sr1         dr         opc = 111100           fc.lt1 dr, sr1, sr2
111100         11         XX         0 = single precision         sr2         sr1         dr         opc = 111011           fc.lt0 dr, sr1, sr2           111100         00         XX         0 = single precision         sr2         sr1         dr         opc = 111100           fc.lt1 dr, sr1, sr2
fc.lt0 dr, sr1, sr2  111100   00   XX   0 = single precision   sr2   sr1   dr   opc = 111100    fc.lt1 dr, sr1, sr2
111100   00   XX   0 = single precision   sr2   sr1   dr   opc = 111100   fc.lt1 dr, sr1, sr2
111100   00   XX   0 = single precision   sr2   sr1   dr   opc = 111100   fc.lt1 dr, sr1, sr2
111100   00   XX   0 = single precision   sr2   sr1   dr   opc = 111100   fc.lt1 dr, sr1, sr2
fc.lt1 dr, sr1, sr2
111100   01   XX   0 = single precision   sr2   sr1   dr   opc = 111100
fc.lt2 dr, sr1, sr2           111100         10         XX         0 = single precision         sr2         sr1         dr         opc = 111100
111100 10 700 0 - single precision 312 311 at ope - 111100
fc.lt3 dr, sr1, sr2
111100   11   XX   0 = single precision   sr2   sr1   dr   opc = 111100
fc.nge0 dr, sr1, sr2
111100   00   XX   0 = single precision   sr2   sr1   dr   opc = 111101
fc.nge1 dr, sr1, sr2
111100 01 XX 0 = single precision   sr2   sr1   dr   opc = 111101
fc.nge2 dr, sr1, sr2
111100   10   XX   0 = single precision   sr2   sr1   dr   opc = 111101
fc.nge3 dr, sr1, sr2
111100   11   XX   0 = single precision   sr2   sr1   dr   opc = 111101
fc.le0 dr, sr1, sr2
111100   00   XX   0 = single precision   sr2   sr1   dr   opc = 111110

	1 4	1	4	_
TC.	ıeı	ar.	SrI.	sr2

#### fc.le2 dr, sr1, sr2

111100	10	XX	0 = single precision	sr2	sr1	dr	opc = 1111110

### fc.le3 dr, sr1, sr2

111100	11	XX	0 = single precision	sr2	sr1	dr	opc = 111110
--------	----	----	----------------------	-----	-----	----	--------------

## fc.ngt0 dr, sr1, sr2

111100	00 2	XX	0 = single precision	sr2	sr1	dr	opc = 1111111
--------	------	----	----------------------	-----	-----	----	---------------

## fc.ngt1 dr, sr1, sr2

111100	01	XX	0 = single precision	sr2	sr1	dr	opc = 111111

### fc.ngt2 dr, sr1, sr2

			<u> </u>				
111100	10	XX	0 = single precision	sr2	sr1	dr	opc = 111111

### fc.ngt3 dr, sr1, sr2

111100	11 XX	0 = single precision	sr2	srl	ar	opc = 111111
--------	-------	----------------------	-----	-----	----	--------------