```
Button_Drivers.s
      .include "Equates.s"
 1
 2
 3
      .global InitButton
 4
      .global CheckButton
 5
      .global Init_EXTI0
 6
      .global Reset_EXTI0
 7
 8
      .syntax unified
 9
      .section
                .text.ButtonDriver
10
11 // GPIO initialization for button
12 InitButton:
13
      ldr r0,=RCC //RCC register block
14
      ldr r1,[r0,#AHBENR] //read RCC_AHB1ENR
      orr r1,#GPIOAEN // enable GPIOA clock
15
      str r1,[r0,#AHBENR] // update AHB1ENR
16
17
      ldr r0,=GPIOA //GPIOA register block
18
      ldr r1,[r0,#MODER] //current mode register
19
      bic r1,#0x03 //MODER[1:0] = 00 for PA0 input
20
      str r1,[r0,#MODER] //update mode register
21
      bx lr //return
22
23 // CheckButton - return state of push button
24// r0 = return value of 0 or 1
25 CheckButton:
      ldr r0,=GPIOA //GPIO port A
26
27
      ldrh r0,[r0,#IDR] //set bit
28
      and r0,#0x01 //mask all but bit 0
29
      bx r14 //return
30
31 Init_EXTIO:
32
      //select PA0 as EXTI0
33
      ldr r1,=SYSCFG
34
      ldrh r2,[r1,#EXTICR1] //EXTI priorities for EXTI0
                             //bits 3-0 = 0000 to select PA0 = EXTI0
35
      bic r2,#0x0f
36
      strh r2,[r1,#EXTICR1] //EXTI priorities for EXTI0
37
      //configure EXTIO as rising edge triggered
38
      ldr r1,=EXTI
39
      mov r2,#1
                             //bit #0 for EXTI0
40
      str r2,[r1,#FTSR]
                             //select falling edge trigger
41
      str r2,[r1,#PR]
                             //clear any pending event
42
      str r2,[r1,#IMR]
                             //enable EXTI0
43
      //configure NVIC to enable EXTIO as priority 1
      ldr r1,=NVIC_ISER0
44
45
      mov r2,#0x40
                             //EXTI0 is IRQ 6
46
      str r2,[r1]
                             //Set enable IRQ 6
      ldr r1,=NVIC_IPR1
47
48
      mov r2,#0x00100000
                             //Make EXTIO priority 1
49
                             //Write IPR1 3rd byte
      str r2,[r1]
50
      bx lr
51
52 Reset EXTIO:
      // Reset EXTIO pending bit in EXTI
53
      ldr r0,=EXTI //point to EXTI registers
54
55
      mov r1,#0x01 //bit 0 = EXTI0 pending bit
56
      str r1,[r0,#PR] //reset EXTIO pending bit (write 1 to it)
57
      // Reset EXTIO pending bit in NVIC (in case triggered by bounce)
```

64 65 Saturday, November 18, 2023, 5:22 PM