

Yet Another Clock Featuring the PIC16C924

Author: Rodger Richey

Microchip Technology Inc.

INTRODUCTION

Once again, because of its universal familiarity and range of functionality, the clock is used to convey the use of the PIC16C92X microcontrollers. In this case we have added a twist to the clock with the addition of a thermometer. The LCD panel has a two digit temperature readout.

This application note will discuss the use of the following peripherals used to implement the clock: Timer1, PORTB, CCP, A/D converter, and the LCD Module. All source code and examples are written in C and compiled using Microchip's MPLAB-C compiler.

The features of the PIC16C924 are:

- 4K x 14 EPROM program memory
- 176 x 8 SRAM data memory
- DC 8 MHz operating speed
- Timer0, Timer1, and Timer2
- · One CCP pin
- SSP Module with SPI and I²C capability
- 8-bit. 5 channel A/D converter
- · LCD Module
 - Multiple LCD timing sources
 - LCD can be driven while in SLEEP
 - Static, 1/2, 1/3 and 1/4 multiplex modes
 - Static and 1/3 bias capability
 - Up to 32 segments, up to 4 commons

1 COM x 32 SEGs = 32 pixels


2 COMs x 31 SEGs = 62 pixels

3 COMs x 30 SEGs = 90 pixels

4 COMs x 29 SEGs = 116 pixels

 Available in DIE form, 68-pin PLCC, and 64-pin TQFP packages

FIGURE 1: SIMPLIFIED BLOCK DIAGRAM




LCD panels offer many advantages over LED type displays such as; lower cost, lower power consumption, and better display quality. Figure 2 shows typical examples of an LED and an LCD application. Table 1 further describes each application according to components, cost, power consumption, etc.

TABLE 1: LED vs. LCD

	LED	LCD
Cost (1000 units)	\$7.05	\$5.42
# Components	20	6
Power Consumption	~ 10 mA	~ 50 µA
Hardware	Timer, 12 I/O pins	LCD Module
Signal Generation	Firmware	LCD Module


FIGURE 2: EXAMPLE LED AND LCD APPLICATIONS



TIMER1

Currently, the Timer1 module exists in all the PIC16CXXX devices with 28 or more pins. This module can be used to easily implement a real-time clock. Instead of an external real-time clock device, an inexpensive 32.768 kHz watch crystal and two 33 pF capacitors are used to complete the circuit. Figure 3 shows the block diagram for Timer1.

FIGURE 3: TIMER1 BLOCK DIAGRAM



In this application, Timer1 is clocked by an external crystal connected across RC0 and RC1. The following is some sample code to initialize Timer1.

```
TMR1H = 0x80;
TMR1L = 0x00;
T1CON = 0b00001111;
PIR1.TMR1IF = 0;
PIE1.TMR1IE = 1;
```

The first step in initializing Timer1 is to preset TMR1H:TMR1L to 0x8000. Since Timer1 is a 16-bit timer, the 32.768 kHz crystal will cause Timer1 to overflow every two seconds or 65536 counts. For this reason, Timer1 is initialized to 0x8000 so that every overflow relates to one second. The second step is to configure Timer1. For this mode, the Timer1 oscillator must be enabled via T1CON<T1OSCEN>. This bit enables the internal oscillator, which is functionally equivalent to the LP oscillator of the microcontroller. The clock source for Timer1 is selected to be the external input using the T1CON<TMR1CS> bit. The prescaler is set to 1:1 using the T1CKPS1:T1CKPS0 bits of the T1CON register. Since the timer is to operate during SLEEP, it is not synchronized to the internal Fosc clock. Synchronization is controlled by the T1SYNC bit of the T1CON register. Finally, the clock source is enabled to clock TMR1H:TMR1L using the TMR1ON bit of T1CON.

In this mode of operation, Timer1 can operate during SLEEP while consuming a minimal amount of current ($\approx\!20~\mu A)$. The last two lines of code clear the Timer1 Overflow flag and enable the Timer1 Overflow interrupt. This interrupt will wake up the processor from SLEEP at a predetermined rate for updating the clock, in this case once each second. The following is a sample interrupt service routine for Timer1 Overflow:

```
if(PIR1.TMR1IF)
   Seconds++;
                      //Increment seconds
   if(Seconds > 59)
                      //60 seconds?
     Seconds = 0;
     Minutes++;
   if(Minutes > 59)
                      //60 minutes?
     Minutes = 0;
     Hours++;
   if(Hours > 12)
                      //Do not use 24hr
     Hours = 1;
                      //military time
  TMR1H = 0x80;
                      //Reset_timer1
  PIR1.TMR1IF = 0;
                      //Clear flag
```

First, register PIR1 is checked to verify that the Timer1 Overflow interrupt occurred. Next the variable Seconds is incremented every time a Timer1 overflow occurs. Once Seconds reaches 60, the Minutes variable is incremented and Seconds is cleared thus implementing 60 seconds per minute. If Minutes reaches 60, then the Hours variable is incremented

and Minutes is cleared which implements 60 minutes per hour. For civilian time, if Hours is greater than 12, Hours is reset to 1. Military time uses 24 hours a day, so that when Hours reaches 24 it is reset to 1.

Since it takes a finite amount of time to enter the interrupt service routine and execute it, the program adds 0x80 to TMR1H so that the next Timer1 Overflow interrupt occurs exactly in one second. If the program simply cleared TMR1L and set TMR1H to 0x80, the real-time clock would now be off by the finite amount of time previously described. Finally, the Timer1 Overflow interrupt flag is reset.

PORTB

The wake-up on change feature of PORTB was specifically designed to interface keys or a keypad directly to the microcontroller. Internal weak pull-up resistors are provided to reduce external parts count, while adding only a small amount of current. This feature allows the microcontroller to remain in the low-power SLEEP mode until a key is pressed. The device will wake-up from SLEEP when the key is pressed. The interrupt service routine will process the key input. The following example routine shows how to initialize the PORTB wake-up on change interrupt.

```
OPTION.RBPU = 0;
Temp = PORTB;
INTCON.RBIF = 0;
INTCON.RBIE = 1;
```

Whenever the state of the RB7:RB4 pins change, a mismatch condition occurs inside the microcontroller. The only way to clear the mismatch condition is to read PORTB, which also allows the RBIF interrupt flag to be cleared. In the previous code, the first line enables the internal weak pull-up resistors. The second line of the code resets the mismatch condition. Then the following lines clear the interrupt flag and enable the interrupt. A sample interrupt service routine is given below.

```
if(INTCON.RBIF)
      Temp = PORTB;
      Delay_Ms_4MHz(16); //key debounce
      if(Temp!=0xf0 && Temp==PORTB)
         StartBEEP(); //key press starts
beep
         if(!Temp.SET)
                              //SET key
            Flags.SET = 1;
         if(!Temp.UP)
                              //UP key
            Flags.UP = 1;
         if(!Temp.SOUND)
                             //SOUND key
            if(Flags.SOUND_STATE)
               Flags.SOUND_STATE = 0;
            else
               Flags.SOUND_STATE = 1;
      INTCON.RBIF = 0;
                             //clear flag
```

The first line of the above example is used to verify that a change on PORTB interrupt has occurred. The next line is a 5 ms delay followed by a read of PORTB. This resets the mismatch condition. The following 20 ms delay is used in conjunction with the previous 5 ms delay for switch debouncing. The value of Temp and PORTB are compared and if equal a key press has been detected. The if statement also checks to see if the mismatch condition is from a key press or when the key is released. The key inputs are processed only when a key is pressed. When a key is pressed, it grounds the respective input pin. The nested if statements check each of the individual keys to see which have been pressed. If the SOUND key has been pressed, it merely toggles whether the hourly beep is enabled. Finally, the RBIF interrupt flag is cleared.

This application takes advantage of the wake-up on change and internal pull-up resistors to implement the SET, ▲, and SOUND keys. The SET key puts the clock in program mode and the PROG icon appears on the LCD. Program mode allows the user to set the time, AM or PM, and day of the week (see LCD Module for details on the LCD). Once in program mode, the hours digits flash. Pressing the ▲ key increments Hours from 12 to 11 AM and then from 12 to 11 PM. At any point the SET key can be pressed to advance to the minutes digits. The minutes digits are incremented using the A key. Minutes can be incremented from 0 to 59. Pressing the SET key again flashes the day of the week. Using the ▲ key increments the day of the week from SU to SA. Finally, pressing the SET key takes the user out of program mode. If no key presses are detected for five seconds the program exits program mode.

CCP

The CCP module is used in Pulse Width Modulation (PWM) mode. The PWM signal is used to drive a piezo alarm circuit. The operation of PWM mode will not be discussed since it has been explained in great depth in application notes AN531, AN538, AN539, AN564, and AN594.

An example of configuring the CCP as a PWM output is shown below.

The CCP1CON register is set to 0x0F which puts the CCP into PWM mode. The period or frequency of the PWM output is set using the PR2 register. The following formula is used to calculate the value in PR2.

```
PWM period = [(PR2) + 1] \cdot 4 \cdot Tosc \cdot (TMR2 prescale value)]
```

Another step in configuring the CCP is to set the value of the T2CON register. In the case above, a value of 0x7D configures the Timer2 output postscaler to 1:16, enables Timer2, and sets the Timer2 clock prescaler to 4. Using PR2 = 122, Tosc = 250 ns, and TMR2 prescale = 4, the resultant PWM period is approximately $500\,\mu s$ or 2 kHz. This is the resonant frequency of the piezo alarm. The duty cycle, or more specifically the time the PWM output stays high, of the PWM output is set by the value of CCPR1L and bits CCP1CON<5:4>. The following formula uses the 10-bit value of CCPR1L:CCP1CON<5:4> to calculate the duty cycle.

```
PWM duty cycle = [ (CCPR1L:CCP1CON<5:4>) •
Tosc • (TMR2 prescale value) ]
```

Using 0x014 as the value of CCPR1L:CCP1CON<5:4>, Tosc = 250 ns, and a TMR2 prescale = 4, the PWM duty cycle is calculated to be 20 μs or 4% duty cycle. The TRISC register must also be configured such that the PWM pin is setup as an output.

The Timer2 Overflow interrupt is used to turn off the PWM output. This produces a "beep" when the keys are pressed or an hourly alarm. The Timer2 postscaler waits for 16 PWM periods before the interrupt occurs. The following interrupt service routine is an example of how to generate a "beep".

The first line of code detects if a Timer2 Overflow interrupt has occurred. The variable Count is used to vary the length of the beep. Count is set previous to enabling the PWM. If Count reaches zero the following occurs:

- The PWM is disabled by clearing the CCP1CON register
- Timer2 is disabled by clearing the T2CON register
- The Timer2 Overflow interrupt is disabled by clearing the TMR2IE bit of the register PIE1
- · The duty cycle register is cleared

Before exiting the service routine, the TMR2IF interrupt flag is cleared.

A/D CONVERTER

Since the PIC16C924 has a five channel, 8-bit A/D converter and the LCD has a $^{\circ}$ (degree) symbol and two digits, the application circuit has a thermistor for measuring temperature. Thermistors typically take hundreds of milliseconds to stabilize at a particular temperature and therefore the A/D converter is ideal for temperature measurements. Another feature of the A/D converter is the on-chip RC oscillator that can be used as the conversion clock. This feature allows the A/D to operate in SLEEP. The following code segment is used to initialize the A/D converter.

```
ADCON0 = 0b11000001; //Enable A/D
ADCON1 = 0b00000100; //Configure D/A I/O
PIR1.ADIF = 0; //Clear flag
PIE1.ADIE = 1; //Enable interrupt
```

The first line enables the internal RC for conversion clock, channel 0, and enables the A/D converter. The second line makes PORTA<1:0> analog inputs and PORTA<5,3:2> as digital I/O. The following lines clear the A/D conversion complete interrupt flag and enable the interrupt. The application uses the Timer1 Overflow interrupt to start a conversion every second using the GO bit of the ADCON0 register. The A/D conversion complete interrupt then processes the result of the conversion. The following is an example of the service routine.

```
if(PIR1.ADIF)
{
   TempC = ThermTable[ADRES];
   PIR1.ADIF = 0;
}
```

The first line checks for the ADIF interrupt flag. A lookup table, <code>ThermTable</code>, is used to convert the A/D result into a temperature reading. This table was created using calibration data from the thermistor. Finally, the ADIF interrupt flag is cleared.

The following code was added to the Timer1 interrupt service routine to start the A/D conversion.

```
TRISA.THERM_GND = 0;
DELAY_10_µs_4MHz(4);
ADCON0.GO = 1
NOP();
NOP();
TRISA.THERM_GND = 1;
```

The first line of code grounds the I/O pin connected to resistor R1. The 40 μs delay is provided so the A/D converter can sample the input signal. The A/D converter is then instructed to convert by setting the GO bit. A two cycle delay is added so that the sampling capacitor is disconnected from the input. Finally the I/O pin connected to R1 is made an input. This scheme only powers the thermistor when sampling, to reduce power consumption.

LCD MODULE

The LCD Module has a wealth of features typically found on more expensive dedicated LCD driver devices. The following is a detailed list of features:


- LCD Timing Sources
 - Fosc/256 (internal system clock)
 - Timer1 oscillator
 - Internal RC oscillator
- LCD Voltage Generation
 - Internal charge pump
 - External resistor ladder
- Bias
 - Static
 - 1/3
- Multiplex
 - Static
 - 1/2
 - 1/3
 - 1/4
- Operation during SLEEP
 - Only with internal RC or Timer1 clock sources

- · Capable of up to 4 commons and 32 segments
 - 1 COM x 32 SEGs, total of 32 pixels
 - 2 COMs x 31 SEGs, total of 62 pixels
 - 3 COMs x 30 SEGs, total of 90 pixels
 - 4 COMs x 29 SEGs, total of 116 pixels
- 16 x 8 LCD data registers

The LCD Module is ideal for systems that use one controller board that has several applications with different displays. Microchip's OTP technology means that the controller board can be assembled with blank microcontrollers, and at final test the device can be programmed depending on the display type. This helps to reduce overhead and creates one board to track in inventory.

The particular LCD panel that was selected for this application is shown in Figure 2. It has four common electrodes and 12 segment electrodes. The panel provides 3 1/2 digits, colon, and AM/PM icons for time display. The panel also has day of the week icons (SU,MO,TU,WE,TH,FR,SA). This was the basis of another clock design using the PIC16C924.

FIGURE 4: LCD PINOUT



	COM0, pin 1	COM1, pin 8	COM2, pin 9	COM3, pin 16
SEG0, pin 2	SU	D2.e	D2.f	D1
SEG1, pin 3	МО	D3.e	:	D2.b
SEG2, pin 4	TU	D3.c	D3.b	D4.f
SEG3, pin 5	WE	D4.c	D4.b	AM
SEG4, pin 6	FR	D5.c	D6.f	D5.b
SEG5, pin 7	SA	D6.c	D6.b	٥
SEG6, pin 10	D6.d	D6.e	D6.g	D6.a
SEG7, pin 11	D5.d	D5.e	D5.g	D5.a
SEG8, pin 12	TH	PROG	PM	D5.f
SEG9, pin 13	D4.d	D4.e	D4.g	D4.a
SEG10, pin 14	D3.d	D3.g	D3.f	D3.a
SEG11, pin 15	D2.d	D2.c	D2.g	D2.a

The LCD Module is initialized by the following code:

```
STATUS.RP1 = 1;
                     //Change to Bank 2
LCDPS = 6;
                     //Frame freq to 37Hz
LCDSE = 0xff;
                     //All LCD I/O as LCD
LCDCON = 0b00010111; //1/4 MUX charge pump
LCDD00 = 0;
                    //Clear all LCD
LCDD01 = 0;
                     //data RAM
LCDD02 = 0;
LCDD03 = 0;
LCDD04 = 0;
LCDD05 = 0;
LCDD06 = 0;
LCDD07 = 0;
LCDD08 = 0;
LCDD09 = 0;
LCDD10 = 0;
LCDD11 = 0;
LCDD12 = 0;
LCDD13 = 0;
LCDD14 = 0;
LCDD15 = 0;
LCDCON.LCDEN = 1;
                       //Enable LCD module
                       //Back to Bank 0
STATUS.RP1 = 0;
PIR1.LCDIF = 0;
                       //Clear flag
PIE1.LCDIE = 1;
                       //Enable interrupt
```

Note: At the time when this application note was generated, four banks of data memory were not supported by the MPC or MPLAB-C compilers.

The PIC16C924 starts a new page in Microchip history with four banks of data memory for the PIC16CXXX mid-range products. The first line of code switches to the second set of banks. The second line of code sets a frame frequency of approximately 37 Hz using the Timer1 oscillator. This frequency can be calculated by using the following formula:

```
Clock source / (128 • (LP3:LP0 + 1))
```

Using 32.768 kHz as the clock source and LP3:LP0 = 6 the resultant frame frequency is 36.57 Hz. Setting LCDSE to 0xFF configures ports D,E,F, and G as LCD drivers. Setting LCDCON to 0x17 configures the LCD Module for 1/4 MUX, 1/3 Bias, Timer1 clock source, charge pump enabled, and the LCD module will continue to drive during SLEEP. The LCD data registers LCDD00 - LCDD15 are all cleared, which turns off all pixels on the LCD panel. Any unused bits in the LCD data registers can be used as general purpose RAM. The PIC16C924 Clock can use the upper 4-bits of registers LCDD01, LCDD05, LCDD09, LCDD13 and all of LCDD02, LCDD03, LCDD06, LCDD07, LCDD10, LCDD11, LCDD14, LCDD15. This is a result of not using segments 13 through 28. The LCD Module is then enabled by setting the LCDEN bit in the LCDCON register. Finally the LCD interrupt flag is cleared and the interrupt is enabled.

The following is an example of the LCD interrupt service routine.


```
if(PIR1.LCDIF)
{
    Flags.FRAME = 1;
    PIR1.LCDIF = 0;
}
```

In this application, the LCD interrupt is used to signal the main routine that the LCD data registers can be updated without causing any flicker on the panel. Finally, as in any interrupt service routine, the interrupt flag is cleared.

CONCLUSION

The PIC16C924 is ideally suited towards battery applications such as thermostats or meters. It can extend battery life while maintaining a rich feature set such as A/D converter, SPI/I²C module, and CCP module. All of the peripherals that have been previously described can operate during SLEEP, thus lowering the average current consumption. If the 8-bit A/D converter is not sufficient or not used in your design, Microchip also offers the PIC16C923 which has all the features of the PIC16C924 without the A/D converter. This device can use an external higher resolution A/D converter that can be interfaced to the SSP module, specifically the SPI port.

APPENDIX A: PIC16C924 CLOCK SCHEMATIC



APPENDIX B: PIC16C924 CLOCK FIRMWARE LISTING

```
* Filename: CLK.C
               *************************
                  Author: Rodger Richey
                  Company: Microchip Technology Incorporated
                  Revision: A3
                          12-17-96
                  Date:
                  Compiled using MPLAB-C Version 00.00.14
               Include files:
                  16C924.h Rev 1.00
                  MUSIC.C Rev A2
                  LCD.C
                          Rev Al
                  TIME.C
                           Rev Al
               ******************
                  Peripheral Modules Used:
                           : Used by the music generation program for timing notes
                    Timer0
                             and durations
                    Timer1 : Used as a real time clock using an external 32.768 \mathrm{KHz}
                             crystal and (2) 33pF capacitors
                    Timer2 : Used in conjunction with the PWM
                           : Used in PWM mode, for driving the piezo alarm
                    PORTB : Used to decode key presses
                    A/D
                           : Used to measure temperature via a thermistor on RAO
                            : Used to display time, temperature, day of week
               ***********************
                  External Clock Frequency : 4MHz
Timerl OSC Frequency : 32.768KHz
                  Configuration Bit Settings : XT Oscillator
                                         : Watchdog Timer OFF
                                         : Code Protect OFF
                                         : Power-Up Timer ON
                  Program Memory Usage
                                         : 1095 words
                  Data Memory Usage
                                         : 19 bytes
                  Revision History
                  A1 - First Release
                  A2 - Added code to clear CCPR1L after PWM has finished
                     - Set No sleep flag in StartMusic
                  A3 - Changed __INT interrupt service routine.
                  Added INTCON.TOIE to check for TimerO interrupt
               Note: Make sure that the temporary variables in the 16c924.h file
                       have been changed to locations 0x7a to 0x7f
               ************************
               #include <16c924.h>
               #include <delay14.h>
               // PORTA pin defines
0002
               #define THERM_GND 2
               // PORTB key defines
0004
               #define EXTRA 4
0005
               #define SOUND 5
               #define UP 6
0006
0007
               #define SET 7
               // Variable declarations
                                        // Contains flag bits for various events
0026
               bits Flags;
0027
               bits Temp;
                                        // Temporary storage
0028
               bits Count;
                                       // Number of Timer2 Interrupts to count
0029
               bits Ticks;
                                       // Counts seconds will in program mode
0078
               bits Mode @ 0x78;
                                       // Contains flag bits to turn on LCD pixels
002A
               unsigned char FrameCnt;
                                        // Count LCD frames
```

```
// Bit defines for Flags
                                                                                                                                                                                                                             #define UPDATE 0
  0000
  0001
                                                                                                                                                                                                                             #define FRAME 1
  0003
                                                                                                                                                                                                                           #define PROGRAM 3
  0004
                                                                                                                                                                                                                           #define SOUND_STATE 4
  0005
                                                                                                                                                                                                                           #define SLEEP_STATE 5
                                                                                                                                                                                                                           // Time variables
0070
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   // Holds number of seconds
                                                                                                                                                                                                                         unsigned char Seconds @ 0x70;
  0071
                                                                                                                                                                                                                           unsigned char Minutes @ 0x71;
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         // Holds number of minutes
  0072
                                                                                                                                                                                                                           unsigned char Hours @ 0x72;
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   // Holds number of hours
0073
                                                                                                                                                                                                                       bits LStatus @ 0x73;
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       // bit 7 -> 0=AM, 1=PM
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         // bits 0-3 -> 0000=SUN
  0074
                                                                                                                                                                                                                       bits DayOfWeek @0x74;
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       // 0001=MON
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         // 0010=TUE
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         // 0011=WED
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         // 0100=THU
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         // 0101=FRI
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         // 0110=SAT
                                                                                                                                                                                                                             // Bit defines for LStatus
  0007
                                                                                                                                                                                                                             #define AMPM 7
                                                                                                                                                                                                                             // Temperature Variable
  0075
                                                                                                                                                                                                                           unsigned char TempC @ 0x75;
  0000
                                                                                                                                                                                                                           #define FRAME_COUNT 12
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         // Number of frames in blink in prgm mode
  0004
                                                                                                                                                                                                                           #define BEEP_COUNT 4
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       // PWM duty cycle value for "beep"
                                                                                                                                                                                                                             // Thermistor calibration table, OC to 99C
                                                                                                                                                                                                                           const unsigned int ThermTable[] =
                                                                                                                                                                                                 0 \\ \times 00 \\ , 0 \\ , 0 \\ \times 00 \\
                                                                                                                                                                                                 0 \times 05 , 0 \times 06 , 0 \times 06 , 0 \times 07 , 0 \times 08 , 0 \times 09 , 0 \times 09 , 0 \times 09 , 0 \times 10 , 0 \times 11 , 0 \times 11 , 0 \times 12 , 0 \times 12 , 0 \times 13 , 0 \times 13 , 0 \times 14 , 0
                                                                                                                                                                                                 0 \times 15, 0 \times 15, 0 \times 16, 0 \times 16, 0 \times 17, 0 \times 17, 0 \times 17, 0 \times 18, 0 \times 19, 0 \times 19, 0 \times 20, 0 \times 20, 0 \times 21, 0 \times 21, 0 \times 22, 0 \times 22, 0 \times 21, 0 \times 
                                                                                                                                                                                                 0 \times 23, 0 \times 23, 0 \times 24, 0 \times 24, 0 \times 25, 0 \times 25, 0 \times 25, 0 \times 26, 0 \times 26, 0 \times 27, 0 \times 27, 0 \times 28, 0 \times 28, 0 \times 28, 0 \times 29, 0 \times 
                                                                                                                                                                                                 0 x 43, 0 x 43, 0 x 44, 0 x 44, 0 x 44, 0 x 45, 0 x 45, 0 x 45, 0 x 46, 0 x 46, 0 x 47, 0 x 47, 0 x 48, 0 x 48, 0 x 48, 0 x 49, 0 x 
                                                                                                                                                                                                 0 \\ x49, 0 \\ x50, 0 \\ x50, 0 \\ x50, 0 \\ x51, 0 \\ x51, 0 \\ x51, 0 \\ x51, 0 \\ x52, 0 \\ x52, 0 \\ x52, 0 \\ x53, 0 \\ x53, 0 \\ x54, 0 \\ x54, 0 \\ x55, 0 \\ x55, 0 \\ x56, 0
                                                                                                                                                                                                 0 \times 57, 0 \times 57, 0 \times 58, 0 \times 58, 0 \times 59, 0 \times 59, 0 \times 59, 0 \times 60, 0 \times 60, 0 \times 61, 0 \times 61, 0 \times 62, 0 \times 62, 0 \times 63, 0 \times 63, 0 \times 64, 0 \times 
                                                                                                                                                                                                 0x65, 0x65, 0x66, 0x66, 0x67, 0x67, 0x68, 0x68, 0x69, 0x69, 0x70, 0x71, 0x71, 0x72, 0x73, 0x73, 0x73, 0x70, 0x71, 0x71, 0x72, 0x73, 0x73
                                                                                                                                                                                                 0 \times 74, 0 \times 74, 0 \times 75, 0 \times 76, 0 \times 76, 0 \times 77, 0 \times 78, 0 \times 78, 0 \times 79, 0 \times 79, 0 \times 80, 0 \times 81, 0 \times 81, 0 \times 82, 0 \times 83, 0 \times 84, 0 \times 80, 0 \times 81, 0 \times 
                                                                                                                                                                                                 0x84,0x85,0x86,0x87,0x88,0x89,0x90,0x91,0x92,0x93,0x94,0x95,0x96,0x97,0x98,0x99,
                                                                                                                                                                                                 0 \\ \times 99, 0 \\ 
                                                                                                                                                                                                 };
  0005 0782
                                                                                                                                                                       ADDWF
                                                                                                                                                                                                                                                                  02
0006 3400
                                                                                                                                                                                                                                                              00h
                                                                                                                                                                     RETLW
0007 3400
                                                                                                                                                                     RETLW 00h
0008 3400
                                                                                                                                                                     RETLW 00h
  0009 3400
                                                                                                                                                                     RETLW 00h
000A 3400
                                                                                                                                                                     RETLW 00h
  000B 3400
                                                                                                                                                                   RETLW 00h
  000C 3400
                                                                                                                                                                     RETLW
                                                                                                                                                                                                                                                              00h
  000D 3400
                                                                                                                                                                     RETLW
                                                                                                                                                                                                                                                                  00h
  000E 3400
                                                                                                                                                                                                                                                                  00h
                                                                                                                                                                     RETLW
000F 3400
                                                                                                                                                                     RETLW
                                                                                                                                                                                                                                                                00h
0010 3400
                                                                                                                                                                     RETLW
                                                                                                                                                                                                                                                                00h
0011 3400
                                                                                                                                                                     RETLW
                                                                                                                                                                                                                                                                00h
  0012 3400
                                                                                                                                                                     RETLW
  0013 3400
                                                                                                                                                                       RETLW
                                                                                                                                                                                                                                                                  00h
  0014 3400
                                                                                                                                                                       RETLW 00h
```

0015	3400	RETLW	00h
0016	3400	RETLW	00h
0017	3400	RETLW	00h
0018	3400	RETLW	00h
0019	3400	RETLW	00h
001A	3400	RETLW	00h
001B	3400	RETLW	00h
001C	3400	RETLW	00h
001D 001E	3400 3400	RETLW	00h 00h
001E	3400	RETLW RETLW	00h
0011	3400	RETLW	00h
0021	3400	RETLW	00h
0022	3400	RETLW	00h
0023	3400	RETLW	00h
0024	3400	RETLW	00h
0025	3400	RETLW	00h
0026	3400	RETLW	00h
0027	3400	RETLW	00h
0028	3400	RETLW	00h
0029	3400	RETLW	00h
002A	3400	RETLW	00h
002B	3400	RETLW	00h
002C	3400	RETLW	00h
002D	3400	RETLW	00h
002E 002F	3400 3400	RETLW	00h
002F	3400	RETLW RETLW	00h 00h
0030	3400	RETLW	00h
0032	3401	RETLW	01h
0033	3402	RETLW	02h
0034	3403	RETLW	03h
0035	3404	RETLW	04h
0036	3405	RETLW	05h
0037	3406	RETLW	06h
0038	3406	RETLW	06h
0039	3407	RETLW	07h
003A	3408	RETLW	08h
003B	3409	RETLW	09h
003C	3409	RETLW	09h
003D	3410	RETLW	10h
003E 003F	3411 3411	RETLW RETLW	11h 11h
0031	3412	RETLW	12h
	3412	RETLW	12h
	3413	RETLW	13h
0043	3413	RETLW	13h
	3414	RETLW	14h
0045	3414	RETLW	14h
0046	3415	RETLW	15h
	3415	RETLW	15h
0048	3416	RETLW	16h
0049	3416	RETLW	16h
	3417	RETLW	17h
004B	3417	RETLW	17h
004C	3418	RETLW	18h
	3418	RETLW	18h
	3419	RETLW	19h
004F 0050	3419 3420	RETLW RETLW	19h 20h
0050	3420	RETLW	20h 20h
0051	3421	RETLW	2011 21h
	3421	RETLW	21h
	3422	RETLW	22h
0055	3422	RETLW	22h
	3423	RETLW	23h

0057	3423	RETLW	23h
0058	3424	RETLW	24h
0059	3424	RETLW	24h
005A	3425	RETLW	25h
005B	3425	RETLW	25h
005C	3425	RETLW	25h
005D	3426	RETLW	26h
005E	3426	RETLW	26h
005F	3427	RETLW	27h
0060	3427	RETLW	27h
0061	3428	RETLW	28h
0062	3428	RETLW	28h
0063	3428	RETLW	28h
0064	3429	RETLW	29h
0065	3429	RETLW	29h
0066	3430	RETLW	30h
0067	3430	RETLW	30h
0068	3430	RETLW	30h
0069	3431	RETLW	31h
006A 006B	3431 3432	RETLW	31h
006B	3432	RETLW RETLW	32h 32h
006D	3432	RETLW	32h
006E	3433	RETLW	3211 33h
006E	3433	RETLW	33h
0070	3433	RETLW	33h
0071	3434	RETLW	34h
0072	3434	RETLW	34h
0073	3435	RETLW	35h
0074	3435	RETLW	35h
0075	3435	RETLW	35h
0076	3436	RETLW	36h
0077	3436	RETLW	36h
0078	3437	RETLW	37h
0079	3437	RETLW	37h
007A	3438	RETLW	38h
007в	3438	RETLW	38h
007C	3438	RETLW	38h
007D	3439	RETLW	39h
007E	3439	RETLW	39h
007F	3440	RETLW	40h
0800	3440	RETLW	40h
0081	3440	RETLW	40h
0082	3441	RETLW	41h
0083	3441	RETLW	41h
0084	3442	RETLW	42h
0085	3442	RETLW	42h
0086	3443	RETLW	43h
0087	3443	RETLW	43h
	3443	RETLW	43h
0089 008A	3444 3444	RETLW RETLW	44h 44h
	3444	RETLW	45h
008C	3445	RETLW	45h
008D	3445	RETLW	45h
	3446	RETLW	46h
008F	3446	RETLW	46h
0090	3447	RETLW	47h
	3447	RETLW	47h
0092	3448	RETLW	48h
0093	3448	RETLW	48h
	3448	RETLW	48h
0095	3449	RETLW	49h
0096	3449	RETLW	49h
0097	3450	RETLW	50h
0098	3450	RETLW	50h

0099	3450	RETLW	50h
009A	3451	RETLW	51h
009В	3451	RETLW	51h
009C	3452	RETLW	52h
009D	3452	RETLW	52h
009E	3453	RETLW	53h
009F	3453	RETLW	53h
00A0 00A1	3454 3454	RETLW RETLW	54h 54h
00A1	3455	RETLW	55h
00A2	3455	RETLW	55h
00A4	3456	RETLW	56h
00A5	3456	RETLW	56h
00A6	3457	RETLW	57h
00A7	3457	RETLW	57h
8A00	3458	RETLW	58h
00A9	3458	RETLW	58h
AA00	3459	RETLW	59h
00AB	3459	RETLW	59h
OAC	3460	RETLW	60h
OAD	3460 3461	RETLW	60h
00AE 00AF	3461	RETLW RETLW	61h 61h
00B0	3462	RETLW	62h
00B0	3462	RETLW	62h
00B2	3463	RETLW	63h
00B3	3463	RETLW	63h
00B4	3464	RETLW	64h
00B5	3464	RETLW	64h
00B6	3465	RETLW	65h
00B7	3465	RETLW	65h
00B8	3466	RETLW	66h
00B9	3466	RETLW	66h
00BA	3467	RETLW	67h
00BB	3467	RETLW	67h
00BC 00BD	3468 3468	RETLW RETLW	68h 68h
00BE	3469	RETLW	69h
00BF	3469	RETLW	69h
00C0	3470	RETLW	70h
00C1	3471	RETLW	71h
00C2	3471	RETLW	71h
00C3	3472	RETLW	72h
00C4	3473	RETLW	73h
	3473	RETLW	73h
00C6	3474	RETLW	74h
00C7	3474	RETLW	74h
00C8	3475 3476	RETLW	75h
00C9	3476	RETLW RETLW	76h 76h
00CB		RETLW	77h
00CC	3478	RETLW	78h
00CD	3478	RETLW	78h
00CE	3479	RETLW	79h
00CF	3479	RETLW	79h
00D0	3480	RETLW	80h
00D1	3481	RETLW	81h
00D2	3481	RETLW	81h
00D3	3482	RETLW	82h
00D4	3483	RETLW	83h
00D5	3484	RETLW	84h
00D6 00D7	3484	RETLW	84h
	3485 3486	RETLW RETLW	85h 86h
00D8	3486	RETLW	87h
	3488	RETLW	88h
ODA	5 100	1411111	0.011

```
RETLW 89h
00DB 3489
00DC 3490
           RETLW
                  90h
00DD 3491
           RETLW
                  91h
00DE 3492
           RETLW 92h
00DF 3493
           RETLW 93h
00E0 3494
           RETIW 94h
00E1 3495
           RETLW 95h
00E2 3496
           RETLW 96h
00E3 3497
           RETLW 97h
00E4 3498
           RETLW 98h
00E5 3499
           RETLW 99h
00E6 3499
           RETLW
                  99h
00E7 3499
           RETLW 99h
00E8 3499
           RETLW 99h
00E9 3499
           RETLW 99h
00EA 3499
           RETLW 99h
00EB 3499
           RETLW 99h
00EC 3499
           RETLW 99h
00ED 3499
           RETLW 99h
00EE 3499
           RETLW 99h
00EF 3499
           RETLW
                  99h
00F0 3499
           RETLW
                  99h
00F1 3499
           RETLW 99h
00F2 3499
           RETLW 99h
00F3 3499
           RETLW 99h
00F4 3499
           RETLW 99h
00F5 3499
           RETLW 99h
00F6 3499
           RETLW 99h
00F7 3499
           RETLW 99h
00F8 3499
           RETLW 99h
00F9 3499
           RETLW
                  99h
00FA 3499
           RETLW 99h
00FB 3499
           RETLW 99h
00FC 3499
           RETIW 99h
00FD 3499
           RETLW 99h
00FE 3499
           RETLW 99h
00FF 3499
           RETLW 99h
                /*******************************
                    StartBEEP
                     Function: This routine configures the necessary hardware to emit a
                              beep from the piezo
                 void StartBEEP(void)
                                  Flags.SLEEP_STATE = 1; // Don't let the 924 go to sleep
0100 1283
           BCF
                 03,5
0101 16A6
         BSF
                  26,5
                                  Count = BEEP_COUNT;  // Set Count for length of beep
0102 3004
          MOVLW 04h
0103 00A8
           MOVWF
                  28
0104 300F
           MOVLW
                  0Fh
                                  CCP1CON = 0x0f;
                                                       // Set the CCP module to PWM
0105 0097
           MOVWF 17
0106 307A
           MOVLW 7Ah
                                  PR2 = 122;
                                                       // Set the period to 2048Hz
0107 1683
           BSF
                  03,5
0108 0092
           MOVWF 12
0109 3003
          MOVLW 03h
                                  CCPR1L = 3;
                                                       // Set the duty cycle very low
010A 1283
           BCF
                  03,5
010B 0095
           MOVWF 15
010C 307D
           MOVLW 7Dh
                                  T2CON = 0b01111101;
                                                       // Enable Timer2
010D 0092
           MOVWF 12
010E 108C
                  0C,1
                                  PIR1.TMR2IF = 0;
                                                       // Clear the Timer2 Interrupt flag
           BCF
010F 1683
           BSF
                  03,5
                                  PIE1.TMR2IE = 1;
                                                       // Enable the Timer2 Interrupt
0110 148C
           BSF
                  0C,1
0111 0008
           RETURN
                                  return;
                               // Include source files
```

```
#include "lcd.c"
                                      // Contains programs that control the LCD
                /******************************
                * Filename: LCD.C
                    Author:
                             Rodger Richey
                   Company: Microchip Technology Incorporated
                   Revision: A0
                            6-14-96
                   Compiled using MPLAB-C Version 00.00.14
                *******************
                    This file contains routines to output time, day of week, AM/PM, and
                    temperature. It also contains routines to blink the different groupings
                    of numbers, i.e. hours, seconds, day of the week. Finally, the last
                   routine displays the state of the hourly beep.
                // Bit defines for the Mode variable, tells the UpdateLCD routine which
                // groups of numbers to display
0000
                #define HOURS 0
0001
                #define MINUTES 1
0002
                #define DAYOFWEEK 2
0005
                #define PROG 5
                                      // PROG icon
0006
                #define COLON 6
                                      // colon, :, for the hours/seconds time display
0007
                #define DEGREES 7
                                      // degrees symbol for temperature
                /*************************
                   UpdateLCD
                   Function: This function updates the LCD display based on the Mode
                          variable.
                *************************
                void UpdateLCD(void)
                   // Array of 7-segment numbers
                                                     // gfedcba
                   const unsigned char SevenSegTable[16]={ 0b001111111, // Zero
                                                      0b00000110, // One
                                                      0b01011011, // Two
                                                       0b01001111, // Three
                                                       0b01100110, // Four
                                                       0b01101101, // Five
                                                       0b01111101, // Six
                                                       0b00000111, // Seven
                                                       0b01111111, // Eight
                                                       0b01101111, // Nine
                                                       0b01110111, // Ten
                                                       0b01111100, // Eleven
                                                       0b01011000, // Twelve
                                                       0b01011110, // Thirteen
                                                       0b01111001, // Fourteen
         GOTO 0124h
ADDWF 02
0112 2924
                                                       0b01110001};// Fifteen
0113 0782
         RETLW 3Fh
0114 343F
0115 3406
         RETLW 06h
0116 345B RETLW 5Bh
0117 344F RETLW 4Fh
0118 3466 RETLW 66h
0119 346D RETLW 6Dh
011A 347D
         RETLW 7Dh
011B 3407
           RETLW 07h
011C 347F
           RETLW
                 7Fh
011D 346F
          RETLW 6Fh
011E 3477
         RETLW 77h
011F 347C
         RETLW 7Ch
0120 3458
         RETLW 58h
0121 345E
         RETLW 5Eh
0122 3479
           RETLW 79h
```

```
0123 3471
             RETLW 71h
                                          // Temporary variables in common RAM locations
0076
                                           bits segment @ 0x76;
0077
                                           unsigned char index @ 0x77;
                                          // Change to Bank 2, and clear all LCD data RAM
0124 1703
                    03,6
                                          STATUS.RP1 = 1;
                                          LCDD00 = 0;
0125 1283
             BCF
                    03,5
0126 0190
                    10
             CLRF
0127 0191
             CLRF
                                          LCDD01 = 0;
                    11
0128 0194
                                           LCDD04 = 0;
             CLRF
                    14
0129 0195
             CLRF
                    15
                                          LCDD05 = 0;
                                          LCDD08 = 0;
012A 0198
             CLRF
                    18
012B 0199
                                          LCDD09 = 0;
             CLRF
                    19
012C 019C
             CLRF
                    1C
                                          LCDD12 = 0;
012D 019D
             CLRF
                                          LCDD13 = 0;
                                          // Update day of the week if enabled
             BTFSS
                    78,2
012E 1D78
                                          if(Mode.DAYOFWEEK)
012F 2965
             GOTO
                    0165h
0130
                                               // Update Day of the Week
                    74
0130 08F4
             MOVF
                                               if(DayOfWeek == 0)
                                                                               // Sunday
0131 1D03
             BTFSS 03,2
0132 2936
             GOTO
                    0136h
0133 1283
                    03,5
                                                   LCDD00.0 = 1;
             BCF
0134 1410
                    10,0
             BSF
0135 2965
             GOTO
                    0165h
                                               else if(DayOfWeek == 1)
                                                                              // Monday
0136 3001
             MOVLW 01h
                                                   LCDD00.1 = 1;
0137 1283
                    03,5
             BCF
0138 0274
             SUBWF
                    74,W
0139 1D03
             BTFSS 03,2
013A 293E
             COTO
                    013Eh
013B 1283
             BCF
                    03,5
013C 1490
                    10,1
            BSF
                                               else if(DayOfWeek == 2)
013D 2965
             GOTO
                    0165h
                                                                               // Tuesday
013E 3002
                                                   LCDD00.2 = 1;
             MOVLW 02h
013F 1283
             BCF
                    03.5
0140 0274
                    74,W
             SUBWF
0141 1D03
             BTFSS
                    03,2
0142 2946
             GOTO
                    0146h
0143 1283
             BCF
                    03,5
0144 1510
                    10,2
             BSF
0145 2965
                                               else if(DayOfWeek == 3)
             GOTO
                    0165h
                                                                              // Wednesday
0146 3003
             MOVLW 03h
                                                   LCDD00.3 = 1;
0147 1283
             BCF
                    03,5
0148 0274
                    74,W
             SUBWF
0149 1D03
             BTFSS 03,2
014A 294E
             GOTO
                    014Eh
014B 1283
             BCF
                    03,5
014C 1590
                    10,3
             BSF
014D 2965
             GOTO 0165h
                                               else if(DayOfWeek == 4)
                                                                              // Thursday
014E 3004
             MOVLW 04h
                                                   LCDD01.0 = 1;
014F 1283
             BCF
                    03,5
0150 0274
             SUBWF 74,W
0151 1D03
             BTFSS 03,2
0152 2956
             GOTO
                    0156h
0153 1283
             BCF
                    03,5
0154 1411
             BSF
                    11,0
0155 2965
                                               else if(DayOfWeek == 5)
             GOTO
                    0165h
                                                                              // Friday
0156 3005
             MOVLW 05h
                                                   LCDD00.4 = 1;
0157 1283
             BCF
                    03,5
0158 0274
                    74,W
             SUBWF
0159 1D03
             BTFSS 03,2
015A 295E
             GOTO
                    015Eh
```

```
015B 1283
             BCF
                    03.5
015C 1610
             BSF
                    10,4
015D 2965
             GOTO
                    0165h
                                              else if(DayOfWeek == 6)
                                                                              // Saturday
015E 3006
                                                   LCDD00.5 = 1;
             MOVLW 06h
015F 1283
             BCF
                    03,5
             SUBWF
0160 0274
                    74.W
0161 1D03
             BTFSS 03,2
0162 2965
             GOTO
                    0165h
0163 1283
             BCF
                    03,5
0164 1690
             BSF
                    10,5
                                          }
                                           // Update Time if enabled
0165 1283
             BCF
                    03,5
                                           if(Mode.HOURS)
0166 1C78
             BTFSS 78,0
0167 2988
             GOTO
                    0188h
0168
                                               // Update AM/PM icons
0168 1FF3
            BTFSS 73,7
                                              if(LStatus.AMPM)
0169 296C
             GOTO
                    016Ch
016A 1419
                                                       LCDD09.0 = 1;
             BSF
                    19,0
016B 296D
             GOTO
                    016Dh
                                               else
016C 159C
             BSF
                    1C,3
                                                       LCDD12.3 = 1;
                                               // Digit 1
016D 1A72
             BTFSC 72,4
                                              if(Hours&0x10)
016E 141C
             BSF
                    1C,0
                                                   LCDD12.0 = 1;
                                              // Digit 2
016F 300F
             MOVLW
                    0Fh
                                              index = Hours & 0x0f;
0170 0572
             ANDWF
                    72,W
0171 00F7
             MOVWF
                    77
0172 00FB
             MOVWF
                    7B
                                               segment = SevenSegTable[index];
0173 3001
            MOVLW 01h
0174 008A
           MOVWF 0A
0175 08FB
            MOVF
0176 0877
            MOVF
                    77,W
0177 2113
             CALL
                    0113h
0178 1283
             BCF
                    03,5
0179 00F6
             MOVWF
                    76
017A 1876
             BTFSC
                    76,0
                                               if(segment.0)
                                                                                  // D2.a
017B 159D
             BSF
                    1D,3
                                                   LCDD13.3 = 1;
017C 18F6
             BTFSC 76,1
                                               if(segment.1)
                                                                                  // D2.b
017D 149C
             BSF
                    1C,1
                                                  LCDD12.1 = 1;
017E 1976
             BTFSC 76,2
                                               if(segment.2)
                                                                                  // D2.c
017F 1595
             BSF
                    15,3
                                                   LCDD05.3 = 1;
0180 19F6
             BTFSC 76,3
                                               if(segment.3)
                                                                                  // D2.d
0181 1591
                                                   LCDD01.3 = 1;
             BSF
                    11,3
0182 1A76
             BTFSC
                   76,4
                                              if(segment.4)
                                                                                  // D2.e
0183 1414
             BSF
                    14,0
                                                   LCDD04.0 = 1;
0184 1AF6
             BTFSC
                   76,5
                                               if(segment.5)
                                                                                  // D2.f
0185 1418
                    18,0
                                                   LCDD08.0 = 1;
             BSF
                                                                                  // D2.g
0186 1B76
             BTFSC 76,6
                                               if(segment.6)
0187 1599
             BSF
                    19,3
                                                   LCDD09.3 = 1;
                                          }
                                          // Update Minutes if enabled
0188 1CF8
             BTFSS 78,1
                                          if(Mode.MINUTES)
0189 29C6
             GOTO
                    01C6h
018A
                                               // Digit 3
018A 30F0
             MOVLW
                    F0h
                                              index = Minutes & 0xf0;
018B 0571
             ANDWF
                    71,W
018C 00F7
             MOVWF
                    77
018D 1003
             BCF
                    03,0
                                              index >>= 4;
018E 0CF7
                    77
             RRF
```

```
018F 1003
                    03.0
             BCF
0190 OCF7
             RRF
                    77
0191 1003
                    03,0
             BCF
0192 OCF7
             RRF
                    77
0193 1003
             BCF
                    03,0
0194 OCF7
                    77
             RRF
0195 00FB
             MOVWF
                    7в
                                               segment = SevenSegTable[index];
0196 3001
             MOVLW 01h
0197 008A
             MOVWF
                    0A
0198 08FB
                    7B
             MOVF
0199 0877
             MOVF
                    77,W
019A 2113
                    0113h
             CALL
019B 1283
             BCF
                    03,5
019C 00F6
             MOVWF
                    76
019D 1876
             BTFSC 76,0
                                               if(segment.0)
                                                                                    // D3.a
019E 151D
             BSF
                    1D,2
                                                   LCDD13.2 = 1;
019F 18F6
             BTFSC 76,1
                                               if(segment.1)
                                                                                    // D3.b
01A0 1518
             BSF
                    18,2
                                                   LCDD08.2 = 1;
01A1 1976
             BTFSC 76,2
                                               if(segment.2)
                                                                                    // D3.c
01A2 1514
                                                   LCDD04.2 = 1;
             BSF
                    14.2
01A3 19F6
             BTFSC
                    76,3
                                               if(segment.3)
                                                                                    // D3.d
01A4 1511
             BSF
                    11,2
                                                   LCDD01.2 = 1;
01A5 1A76
             BTFSC 76,4
                                               if(segment.4)
                                                                                    // D3.e
01A6 1494
                    14.1
                                                   LCDD04.1 = 1;
             BSF
01A7 1AF6
             BTFSC 76,5
                                                                                    // D3.f
                                               if(segment.5)
01A8 1519
             BSF
                    19,2
                                                   LCDD09.2 = 1;
01A9 1B76
             BTFSC
                    76,6
                                               if(segment.6)
                                                                                    // D3.g
01AA 1515
                    15,2
                                                   LCDD05.2 = 1;
             BSF
                                               // Digit 4
01AB 300F
             MOVLW
                    0Fh
                                               index = Minutes & 0x0f;
01AC 0571
             ANDWF
                    71,W
01AD 00F7
                    77
             MOVWF
01AE 00FB
             MOVWF
                    7B
                                               segment = SevenSegTable[index];
01AF 3001
             MOVLW 01h
01B0 008A
             MOVWF 0A
01B1 08FB
             MOVF
                    7в
01B2 0877
             MOVF
                    77,W
01B3 118A
             BCF
                    0A.3
01B4 2113
                    0113h
             CALL
01B5 118A
             BCF
                    0A,3
01B6 1283
             BCF
                    03,5
01B7 00F6
                    76
             MOVWF
01B8 1876
                    76,0
                                               if(segment.0)
                                                                                    // D4.a
             BTFSC
                                                   LCDD13.1 = 1;
01B9 149D
             BSF
                    1D,1
01BA 18F6
             BTFSC 76,1
                                               if(segment.1)
                                                                                    // D4.b
01BB 1598
             BSF
                    18,3
                                                   LCDD08.3 = 1;
01BC 1976
             BTFSC
                    76,2
                                               if(segment.2)
                                                                                    // D4.c
01BD 1594
             BSF
                    14,3
                                                   LCDD04.3 = 1;
01BE 19F6
             BTFSC
                    76,3
                                               if(segment.3)
                                                                                    // D4.d
01BF 1491
             BSF
                    11,1
                                                   LCDD01.1 = 1;
01C0 1A76
                                               if(segment.4)
             BTFSC 76.4
                                                                                    // D4.e
01C1 1495
             BSF
                    15,1
                                                   LCDD05.1 = 1;
01C2 1AF6
             BTFSC 76,5
                                               if(segment.5)
                                                                                    // D4.f
01C3 151C
             BSF
                    1C,2
                                                   LCDD12.2 = 1;
01C4 1B76
             BTFSC 76,6
                                               if(segment.6)
                                                                                    // D4.g
01C5 1499
                                                   LCDD09.1 = 1;
             BSF
                    19,1
                                           }
                                          // Update Temperature
                                          // Digit 5
01C6 30F0
             MOVLW
                    F0h
                                           index = TempC&0xf0;
01C7 0575
             ANDWF
                    75,W
01C8 00F7
                    77
             MOVWF
01C9 1003
             BCF
                    03,0
                                           index >>= 4;
01CA 0CF7
             RRF
                    77
```

```
01CB 1003
            BCF
                    03,0
01CC 0CF7
            RRF
                    77
01CD 1003
                    03,0
             BCF
01CE 0CF7
             RRF
                    77
01CF 1003
             BCF
                    03,0
01D0 0CF7
            RRF
                    77
01D1 00FB
            MOVWF 7B
                                          segment = SevenSegTable[index];
01D2 3001
            MOVLW 01h
01D3 008A
            MOVWF 0A
01D4 08FB
            MOVF
                    7B
01D5 0877
            MOVF
                    77,W
01D6 2113
            CALL
                    0113h
01D7 1283
             BCF
                    03,5
            MOVWF 76
01D8 00F6
01D9 1876
            BTFSC 76,0
                                          if(segment.0)
                                                                                  // D5.a
01DA 179C
            BSF
                    1C,7
                                                 LCDD12.7 = 1;
                                                                                  // D5.b
01DB 18F6
            BTFSC 76,1
                                          if(segment.1)
01DC 161C
            BSF
                    1C,4
                                                 LCDD12.4 = 1;
01DD 1976
           BTFSC 76,2
                                          if(segment.2)
                                                                                  // D5.c
01DE 1614
            BSF
                    14,4
                                                 LCDD04.4 = 1;
01DF 19F6
             BTFSC 76,3
                                          if(segment.3)
                                                                                  // D5.d
01E0 1790
             BSF
                    10,7
                                                 LCDD00.7 = 1;
01E1 1A76
             BTFSC 76,4
                                          if(segment.4)
                                                                                  // D5.e
01E2 1794
            BSF
                    14,7
                                                 LCDD04.7 = 1;
01E3 1AF6
             BTFSC 76,5
                                          if(segment.5)
                                                                                  // D5.f
01E4 141D
             BSF
                    1D,0
                                                 LCDD13.0 = 1;
01E5 1B76
             BTFSC 76,6
                                          if(segment.6)
                                                                                  // D5.g
01E6 1798
             BSF
                    18,7
                                                 LCDD08.7 = 1;
                                          // Digit 6
01E7 300F
            MOVLW
                    0Fh
                                          index = TempC&0x0f;
01E8 0575
             ANDWF
                    75,W
01E9 00F7
            MOVWF
                   77
01EA 00FB
            MOVWF 7B
                                          segment = SevenSegTable[index];
01EB 3001
            MOVLW 01h
01EC 008A
           MOVWF 0A
01ED 08FB
           MOVF
                   7в
01EE 0877
            MOVF
                   77,W
01EF 118A
            BCF
                    0A.3
01F0 2113
                    0113h
             CALL
01F1 118A
             BCF
                    0A,3
01F2 1283
             BCF
                    03,5
01F3 00F6
            MOVWF 76
01F4 1876
             BTFSC 76,0
                                          if(segment.0)
                                                                                  // D6.a
01F5 171C
                                                 LCDD12.6 = 1;
            BSF
                    1C,6
01F6 18F6
             BTFSC 76,1
                                          if(segment.1)
                                                                                  // D6.b
01F7 1698
            BSF
                    18,5
                                                 LCDD08.5 = 1;
01F8 1976
            BTFSC 76,2
                                          if(segment.2)
                                                                                  // D6.c
01F9 1694
            BSF
                    14,5
                                                 LCDD04.5 = 1;
01FA 19F6
             BTFSC
                   76,3
                                          if(segment.3)
                                                                                  // D6.d
01FB 1710
             BSF
                    10,6
                                                 LCDD00.6 = 1;
01FC 1A76
            BTFSC 76,4
                                                                                  // D6.e
                                          if(segment.4)
01FD 1714
            BSF
                   14,6
                                                 LCDD04.6 = 1;
01FE 1AF6
            BTFSC 76,5
                                          if(segment.5)
                                                                                  // D6.f
01FF 1618
            BSF
                   18,4
                                                 LCDD08.4 = 1;
0200 1B76
            BTFSC 76,6
                                          if(segment.6)
                                                                                  // D6.g
                                                 LCDD08.6 = 1;
0201 1718
           BSF
                   18,6
                                          // Turn on : if enabled
0202 1B78
             BTFSC 78,6
                                          if(Mode.COLON)
0203 1498
                    18.1
                                                  LCDD08.1 = 1;
             BSF
                                          // Turn on degrees symbol if enabled
0204 1BF8
             BTFSC 78,7
                                          if(Mode.DEGREES)
0205 169C
             BSF
                    1C,5
                                                  LCDD12.5 = 1;
```

```
// Turn on PROG symbol if enabled
0206 1AF8
           BTFSC 78,5
                                     if(Mode.PROG)
0207 1415
           BSF
                 15,0
                                            LCDD05.0 = 1;
                                      // Make copies of the LCD data registers
0208 0810
          MOVF 10.W
                                     LCDD02 = LCDD00;
0209 0092
         MOVWF 12
020A 0811
         MOVF 11,W
                                     LCDD03 = LCDD01;
020B 0093
         MOVWF 13
020C 0814
          MOVF 14,W
                                     LCDD06 = LCDD04;
020D 0096
           MOVWF 16
020E 0815
           MOVF
                 15,W
                                     LCDD07 = LCDD05;
           MOVWF 17
020F 0097
           MOVF
0210 0818
                 18,W
                                     LCDD10 = LCDD08;
0211 009A
           MOVWF 1A
0212 0819
          MOVF 19,W
                                     LCDD11 = LCDD09;
0213 009B
         MOVWF 1B
0214 081C
         MOVF 1C,W
                                     LCDD14 = LCDD12;
0215 009E
         MOVWF 1E
0216 081D
          MOVF 1D,W
                                     LCDD15 = LCDD13;
0217 009F
           MOVWF 1F
0218 1303
           BCF
                 03,6
                                     STATUS.RP1 = 0;
                                                            // Return to Bank 0
0219 0008
           RETURN
                                     return;
                              }
                /****************************
                    BlinkLCD
                    Function: This function is used in program mode to blink hours, minutes
                          or day of the week depending on the current status.
                 **********************
                              void BlinkLCD(bits which)
002B
021A 1283
         BCF
                03.5
021B 00AB
         MOVWF 2B
021C 1C26
                                  if(Flags.UPDATE) // If UPDATE flag is set, blank the
         BTFSS 26,0
021D 2A3C
         GOTO 023Ch
021E
                                                            // corresponding group
                                     Flags.UPDATE = 0;
                                                            // Clear UPDATE flag
021E 1026
          BCF
                 26,0
                                     if(which==0x01)
                                                            // Blank Hours
021F 3001
           MOVLW 01h
0220 022B
           SUBWF
                 2B,W
0221 1D03
           BTFSS 03,2
0222 2A28
           GOTO 0228h
0223
0223 30E6
         MOVLW E6h
                                         Mode = 0b11100110;
0224 1283
         BCF
                  03,5
0225 00F8
         MOVWF 78
0226 2112
         CALL 0112h
                                         UpdateLCD();
                                      }
0227 2A3B
          GOTO
                 023Bh
                                     else if(which == 0x02) // Blank Minutes
0228 3002
           MOVLW 02h
0229 1283
           BCF
                 03,5
022A 022B
           SUBWF 2B,W
022B 1D03
         BTFSS 03,2
022C 2A32
         GOTO 0232h
022D 30E5
         MOVLW E5h
                                         Mode = 0b11100101;
022E 1283
         BCF
                  03,5
022F 00F8
          MOVWF 78
0230 2112
           CALL
                 0112h
                                         UpdateLCD();
0231 2A3B
           GOTO
                 023Bh
                                     else if(which == 0x04) // Blank day of the week
0232 3004
           MOVLW 04h
0233 1283
           BCF
                  03,5
0234 022B
           SUBWF 2B,W
0235 1D03
           BTFSS 03,2
0236 2A3B
           GOTO 023Bh
```

```
0237 30E3
                                       MOVLW E3h
                                                                                                                                               Mode = 0b11100011;
0238 1283
                                        BCF
                                                               03,5
0239 00F8
                                                              78
                                        MOVWF
023A 2112
                                         CALL
                                                              0112h
                                                                                                                                               UpdateLCD();
                                                                                                                                   }
                                                                                                                       }
023B 2A40
                                                                                                                                                                                               // Turn on all groups if UPDATE
                                   GOTO 0240h
                                                                                                                       else
flag is
                                                                                                                       {
                                                                                                                                                                                               // cleared
023C 1426
                                        BSF
                                                              26.0
                                                                                                                                   Flags.UPDATE = 1; // Set the UPDATE flag
023D 30E7
                                       MOVLW E7h
                                                                                                                                   Mode = 0b11100111; // Set bits in Mode to turn all on
023E 00F8
                                        MOVWF
                                                              78
023F 2112
                                         CALL
                                                              0112h
                                                                                                                                   UpdateLCD();
0240 0008
                                   RETURN
                                                                                                                       return;
                                                                                                           }
                                                         /*****************************
                                                           * DisplaySoundState
                                                                       Function: When the SOUND button is pressed the state of the hourly beep
                                                                                             is toggle between on and off. This routine displays to the % \left\{ 1\right\} =\left\{ 1\right\} 
                                                                                                                                      user the state, Snd OF or Snd On.
                                                            ************************
                                                                                                          void DisplaySoundState(void)
002C
                                                                                                                       unsigned char frames; // Frame count variable
0241 300C
                                                                                                                      frames = FRAME_COUNT; // Initialize the frame counter
                                   MOVLW 0Ch
                                  BCF
0242 1283
                                                              03.5
0243 00AC
                                       MOVWF 2C
0244 1283
                                        BCF
                                                              03,5
                                                                                                                      while(!Flags.FRAME);
                                                                                                                                                                                              // Wait for next frame to occur
0245 1CA6
                                       BTFSS 26,1
0246 2A44
                                        COTO
                                                              0244h
0247 1283
                                  BCF
                                                              03,5
                                                                                                                      Flags.FRAME = 0;
                                                                                                                                                                                               // Clear FRAME flag
0248 10A6
                                 BCF
                                                              26,1
                                   BSF
0249 1703
                                                              03,6
                                                                                                                      STATUS.RP1 = 1;
                                                                                                                                                                                               // Change to Bank 2
                                      MOVLW 80h
024A 3080
                                                                                                                      LCDD00 = 0b10000000;
                                                                                                                                                                                               // Write data common to both
024B 0090
                                       MOVWF
                                                              10
024C 300A
                                        MOVLW
                                                              0Ah
                                                                                                                      LCDD01 = 0b00001010;
                                                                                                                                                                                               // Snd On and Snd OF
024D 0091
                                        MOVWF
                                                              11
024E 300E
                                       MOVLW 0Eh
                                                                                                                      LCDD05 = 0b00001110;
024F 0095
                                       MOVWF 15
                                                                                                                      LCDD09 = 0b00001010;
0250 300A
                                       MOVLW 0Ah
0251 0099
                                       MOVWF 19
0252 3009
                                      MOVLW 09h
                                                                                                                      LCDD13 = 0b00001001;
                                  MOVWF 1D
0253 009D
0254 1303
                                        BCF
                                                              03,6
                                                                                                                       STATUS.RP1 = 0;
                                                                                                                                                                                              // Change to Bank 0
0255 1E26
                                        BTFSS 26,4
                                                                                                                       if(Flags.SOUND_STATE) // Sound on
0256 2A5F
                                       GOTO 025Fh
0257
0257 1703
                                   BSF
                                                              03,6
                                                                                                                                   STATUS.RP1 = 1; // Change to Bank 2
0258 30FE
                                 MOVLW FEh
                                                                                                                                   LCDD04 = 0b111111110; // Write data specific to Snd On
0259 0094
                                 MOVWF 14
                                       MOVLW 49h
025A 3049
                                                                                                                                  LCDD08 = 0b01001001;
025B 0098
                                        MOVWF 18
                                                                                                                                  LCDD12 = 0b10010000;
025C 3090
                                        MOVLW 90h
025D 009C
                                        MOVWF 1C
                                                                                                                       }
025E 2A66
                                        GOTO
                                                              0266h
                                                                                                                       else
                                                                                                                                                                                               // Sound off
025F 1703
                                                               03,6
                                                                                                                                   STATUS.RP1 = 1;
                                                                                                                                                                                           // Change to Bank 2
                                        BSF
0260 30DE
                                         MOVLW DEh
                                                                                                                                   LCDD04 = 0b11011110;// Write data specific to Snd OFF
0261 0094
                                        MOVWF 14
```

```
0262 3059
         MOVLW 59h
                                 LCDD08 = 0b01011001;
0263 0098
         MOVWF
               18
0264 30D0
         MOVLW D0h
                                 LCDD12 = 0b11010000;
0265 009C
         MOVWF 1C
0266 1303
        BCF
              03.6
                              STATUS.RP1 = 0;
                                                 // Change to Bank 0
                              while(frames) // Delay a specific number of frames so
                                                  // the user can see the message
0267 1283
         BCF
               03.5
0268 08AC
         MOVF
               2C
         BTFSC 03,2
0269 1903
026A 2A71
          GOTO 0271h
026B
                                 if(Flags.FRAME)
                                                 // Decrement frames until 0
026B 1283
        BCF
              03.5
                                  {
026C 1CA6
        BTFSS 26,1
        GOTO 0270h
026D 2A70
026E 10A6
        BCF
               26,1
                                    Flags.FRAME = 0;
026F 03AC
         DECF
              2.C
                                     frames--;
                                 }
0270 2A67
          GOTO 0267h
0271 0008
          RETURN
                              return;
                           #include "time.c"
                                             // Contains programs for timekeeping
              /******************************
               * Filename: TIME.C
               ******************
                  Author:
                           Rodger Richey
                  Company: Microchip Technology Incorporated
                  Revision: A0
                  Date:
                          6-14-96
                 Compiled using MPLAB-C Version 00.00.14
                  This file contains the routines to increment time and set the time in
                  program mode.
               /*******************************
               * IncMinutes
                  Function: Increments minutes and performs checks. Minutes is in BCD.
               ************************
                           void IncMinutes(void)
0272 1283
                              Seconds = 0;
        BCF
              03,5
                                                   // Clear Seconds
0273 01F0
        CLRF 70
0274 0AF1
        INCF
               71
                              Minutes++;
                                                    // Increment Minutes
        MOVLW 0Fh
0275 300F
                              if( (Minutes&0x0f) > 0x09) // Check for BCD overflow
0276 0571
         ANDWF
               71,W
0277 00FB
         MOVWF
               7в
0278 3009
          MOVLW 09h
0279 027B
         SUBWF 7B,W
027A 1D03
        BTFSS 03,2
027B 1C03
        BTFSS 03,0
027C 2A82
        GOTO 0282h
027D
027D 30F0
                                Minutes &= 0xf0;
        MOVLW F0h
027E 1283
         BCF
               03,5
          ANDWF
027F 05F1
               71
0280 3010
          MOVLW
               10h
                                Minutes += 0x10;
          ADDWF 71
0281 07F1
                              }
0282 0008
        RETURN
                              return;
              /*****************************
```

```
IncHours
                      Function: Increments hours and performs checks. Hours is in BCD.
                   ****************************
                                  void IncHours(void)
                                      if(!Flags.PROGRAM) // If program mode, do not clear Minutes
0283 1283
            BCF
                    03.5
0284 1DA6
            BTFSS 26,3
0285 01F1
             CLRF
                    71
                                         Minutes = 0;
0286 0AF2
             INCF
                    72
                                      Hours++;
                                                                 // Increment Hours
0287 300F
            MOVLW 0Fh
                                      if((Hours&0x0f) > 0x09)
                                                                // Check for BCD overflow
0288 0572
             ANDWF
                    72,W
0289 00FB
            MOVWF
                    7B
028A 3009
             MOVLW
                    09h
028B 027B
             SUBWF
                    7B,W
028C 1D03
            BTFSS 03,2
028D 1C03
            BTFSS 03,0
028E 2A94
            GOTO
                    0294h
028F
028F 30F0
            MOVLW F0h
                                        Hours &= 0xf0;
0290 1283
            BCF
                    03.5
0291 05F2
             ANDWF
                    72
0292 3010
             MOVLW
                   10h
                                        Hours += 0x10;
0293 07F2
            ADDWF 72
0294 3012
            MOVLW 12h
                                      if(Hours == 0x12)
                                                           // If hours = 12 then change AM/PM
            BCF
0295 1283
                    03,5
0296 0272
             SUBWF
                   72,W
             BTFSS 03,2
0297 1D03
0298 2AA8
            GOTO
                    02A8h
0299
                                                            // and day of the week accordingly
0299 1283
             BCF
                    03,5
                                         if(LStatus.AMPM)
029A 1FF3
             BTFSS
                   73,7
029B 2AA7
             GOTO
                    02A7h
029C
029C 13F3
            BCF
                    73,7
                                          LStatus.AMPM = 0; // change to AM
029D 19A6
            BTFSC 26,3
                                           if(!Flags.PROGRAM) // If not prog mode, increment day
029E 2AA6
            GOTO
                    02A6h
029F
                                                          // of the week and check for overflow
                                            DayOfWeek++;
029F 0AF4
            INCF
                    74
02A0 3007
                                           if(DayOfWeek == 0x07)
            MOVLW
                    07h
02A1 0274
             SUBWF
                    74,W
02A2 1D03
             BTFSS
                    03,2
02A3 2AA6
             GOTO
                    02A6h
02A4 1283
             BCF
                                               DayOfWeek = 0;
                    03.5
02A5 01F4
             CLRF
                                           }
02A6 2AA8
             COTO
                    02A8h
                                         else
                                                             // Otherwise change to PM
02A7 17F3
             BSF
                    73,7
                                          LStatus.AMPM = 1;
02A8 1283
             BCF
                    03,5
                                      if(Flags.SOUND_STATE) // Start hourly beep if enabled
02A9 1E26
                   26,4
            BTFSS
02AA 2AAC
             GOTO
                    02ACh
02AB 2100
            CALL
                    0100h
                                         StartBEEP();
02AC 3013
            MOVLW 13h
                                      if(Hours == 0x13)
                                                          // If hours has overflowed, set to 1
02AD 1283
                    03,5
            BCF
02AE 0272
             SUBWF
                    72,W
02AF 1D03
             BTFSS
                    03,2
02B0 2AB4
             GOTO
                    02B4h
02B1 3001
                                        Hours = 0x01;
             MOVLW
                   01h
02B2 1283
             BCF
                    03.5
02B3 00F2
            MOVWF 72
02B4 0008
             RETURN
                                      return;
                                  }
```

```
SetTime
                      Function: This routine sets the time in program mode. Allows hours,
                            minutes and day of the week to be configured.
                                 void SetTime(void)
02B5 300C
            MOVLW 0Ch
                                     FrameCnt = FRAME_COUNT; // Initialize the frame counter
02B6 1283
            BCF
                   03,5
02B7 00AA
            MOVWF
                   2A
                                     while(!Flags.SET)
                                                        // Wait for the SET button to be
02B8 1283
            BCF
                   03,5
                                                        // hit before advancing to minutes
02B9 1BA6
            BTFSC 26,7
02BA 2AD2
                   02D2h
            GOTO
02BB
                                        if(Flags.UP)
                                                        // If UP button pressed, inc Minutes
02BB 1F26
            BTFSS 26,6
                                        {
02BC 2ABF
            GOTO
                   02BFh
                                         Flags.UP = 0;
02BD 1326
            BCF
                   26,6
02BE 2283
            CALL
                   0283h
                                         IncHours();
02BF 1283
            BCF
                   03,5
                                        if(Flags.FRAME) // Toggle display state (blink) every
02C0 1CA6
            BTFSS 26,1
02C1 2ACC
                   02CCh
            GOTO
02C2
                                                        // FRAME_COUNT frames
02C2 10A6
            BCF
                   26,1
                                          Flags.FRAME = 0;
02C3 03AA
            DECF
                                          if(!FrameCnt) // If frame count = zero, toggle state
02C4 08AA
            MOVF
                   2.A
02C5 1D03
            BTFSS 03,2
02C6 2ACC
            GOTO
                   02CCh
02C7
02C7 300C
            MOVLW
                   0Ch
                                           FrameCnt = FRAME_COUNT;
02C8 1283
            BCF
                   03,5
02C9 00AA
            TWVOM
                   2.A
                                          BlinkLCD(0x01);
02CA 3001
            MOVLW 01h
02CB 221A
            CALL
02CC 3005
            MOVIW 05h
                                        if(Ticks == 5)
                                                            // If no button pressed in 5 secs
02CD 1283
            BCF
                   03,5
02CE 0229
            SUBWF
                   29,W
02CF 1903
            BTFSC 03,2
02D0 0008
            RETURN
                                                             // exit program mode
                                         return;
02D1 2AB8
                   02B8h
            GOTO
02D2 1283
            BCF
                   03,5
                                     Flags.SET = 0;
02D3 13A6
            BCF
                   26,7
                                     FrameCnt = FRAME_COUNT; // Initialize the frame counter
02D4 300C
            MOVIW OCh
02D5 00AA
            MOVWF
                   2A
                                     while(!Flags.SET)
                                                         // Wait for the SET button to be hit
02D6 1283
            BCF
                   03,5
                                                      // before advancing to day of the week
02D7 1BA6
            BTFSC 26,7
02D8 2AF7
            GOTO
                   02F7h
02D9
                                        if(Flags.UP) // If the UP button is hit, inc Minutes
02D9 1F26
            BTFSS 26,6
02DA 2AE4
            GOTO
                   02E4h
02DB 1326
            BCF
                                         Flags.UP = 0;
                   26,6
02DC 2272
                   0272h
            CALL
                                         IncMinutes();
02DD 3060
            MOVLW 60h
                                         if(Minutes >= 0x60)
                                                               // Check for upper limit
02DE 1283
                   03,5
            BCF
02DF 0271
            SUBWF
                   71,W
02E0 1C03
            BTFSS 03.0
02E1 2AE4
                   02E4h
            GOTO
02E2 1283
                                           Minutes = 0;
            BCF
                   03,5
02E3 01F1
            CLRF
                   71
                                        }
```

```
02E4 1283
             BCF
                    03.5
                                          if(Flags.FRAME)
                                                             // Toggle the display state (blink)
02E5 1CA6
             BTFSS
                    26,1
02E6 2AF1
                    02F1h
             GOTO
02E7
                                                                  // every FRAME_COUNT frames
02E7 10A6
             BCF
                    26,1
                                            Flags.FRAME = 0;
02E8 03AA
             DECE
                    2.A
                                            FrameCnt --;
02E9 08AA
             MOVF
                    2A
                                            if(!FrameCnt)
                                                             // If FRAME_COUNT=zero, toggle state
02EA 1D03
             BTFSS
                    03,2
02EB 2AF1
             GOTO
                    02F1h
02EC
02EC 300C
             MOVLW
                    0Ch
                                             FrameCnt = FRAME_COUNT;
02ED 1283
             BCF
                    03,5
02EE 00AA
             MOVWF
                    2A
02EF 3002
                                             BlinkLCD(0x02);
             MOVLW
                    02h
02F0 221A
             CALL
                    021Ah
                                            }
02F1 3005
             MOVLW 05h
                                          if(Ticks == 5)
                                                             // If no button pressed in 5 secs
02F2 1283
             BCF
                    03,5
02F3 0229
             SUBWF
                    29,W
02F4 1903
             BTFSC
                    03,2
02F5 0008
             RETURN
                                            return;
                                                                  // exit program mode
02F6 2AD6
             GOTO
                    02D6h
02F7 1283
                                       Flags.SET = 0;
                    03,5
             BCF
02F8 13A6
                    26,7
             BCF
02F9 300C
             MOVLW
                    0Ch
                                       FrameCnt = FRAME_COUNT; // Initialize the frame counter
02FA 00AA
             MOVWF
                                       while(!Flags.SET)
                                                                 // Wait for SET button to be hit
02FB 1283
             BCF
                    03,5
                                                                 // before exiting program mode
                                       {
02FC 1BA6
             BTFSC
                    26,7
02FD 2B1B
             GOTO
                    031Bh
                                                                 // If the UP key is pressed, inc
02FE
                                          if(Flags.UP)
02FE 1F26
             BTFSS 26,6
                                                                 // inc. day of week
02FF 2B08
             GOTO
                    0308h
0300 1326
             BCF
                                            Flags.UP = 0;
                    26,6
0301 0AF4
             INCF
                    74
                                            DayOfWeek++;
0302 3007
             MOVLW 07h
                                            if(DayOfWeek == 0x07) // Check for overflow
0303 0274
             SUBWF
                    74.W
0304 1D03
             BTFSS
                    03,2
0305 2B08
             GOTO
                    0308h
0306 1283
             BCF
                    03,5
                                             DayOfWeek = 0;
0307 01F4
             CLRF
                    74
0308 1283
                    03,5
             BCF
                                          if(Flags.FRAME)
                                                                 // Toggle display state every
0309 1CA6
             BTFSS
                    26,1
030A 2B15
             GOTO
                    0315h
030B
                                                                 // every FRAME_COUNT frames
030B 10A6
             BCF
                    26,1
                                            Flags.FRAME = 0;
030C 03AA
             DECF
                    2A
                                            FrameCnt--;
030D 08AA
             MOVF
                    2A
                                            if(!FrameCnt)
030E 1D03
                    03,2
             BTFSS
030F 2B15
             GOTO
                    0315h
0310
0310 300C
             MOVLW 0Ch
                                             FrameCnt = FRAME_COUNT;
0311 1283
             BCF
                    03,5
0312 00AA
             MOVWF
                    2.A
0313 3004
             MOVLW 04h
                                             BlinkLCD(0x04);
0314 221A
             CALL
                    021Ah
0315 3005
             MOVLW 05h
                                          if(Ticks == 5)
                                                                  // If no button pressed in 5 secs
0316 1283
             BCF
                    03,5
0317 0229
                    29,W
             SUBWF
0318 1903
             BTFSC 03,2
0319 0008
             RETURN
                                            return;
                                                              // exit program mode
```

```
GOTO 02FBh
031A 2AFB
031B 1283
           BCF
                 03,5
                                  Flags.SET = 0;
031C 13A6
           BCF
                 26,7
031D 0008
           RETURN
                                  return;
                /***********************
                    Function: This routine initializes the peripherals and CPU of the
                          PTC16C924
                 *********************
                             void Init924(void)
                             {
031E 1283
           BCF
                03,5
                      STATUS.RP0 = 0;
                                            // Change to Bank 0
031F 1303
           BCF 03,6 STATUS.RP1 = 0;
0320 3053
          MOVLW 53h
                        OPTION = 0b01010011; // Pull-ups on, T0 int clk source,
0321 1683
          BSF
                 03.5
0322 0081
          MOVWF 01
                                            // Prescaler assigned to T0, 1:16
         MOVLW C1h
0323 30C1
                      ADCONO = 0b11000001; // Internal RC clk src, Ch0, A/D on
0324 1283
           BCF
                 03,5
0325 009F
           MOVWF 1F
0326 0185
           CLRF
                 05
                        PORTA = 0;
                                            // Clear ports A,B,C
          CLRF 06
0327 0186
                        PORTB = 0;
0328 0187
          CLRF 07
                        PORTC = 0;
0329 3007
         MOVLW 07h
                        TRISA = 0b00000111; // RAZ:RA1> digi outputs
032A 1683
         BSF
                 03,5
032B 0085
         MOVWF 05
032C 30F0
         MOVLW F0h TRISB = 0xf0;
                                            // Upper 4 pins are inputs for keys
032D 0086
          MOVWF 06
032E 3003
                                            // RC<0:1> used for Timer1
           MOVLW 03h
                       TRISC = 0x03;
032F 0087
           MOVWF 07
                                            // external crystal
           MOVLW 04h
                      ADCON1 = 0b00000100; // RA<0:1,3> are analog
0330 3004
0331 009F
          MOVWF 1F
0332 1283
         BCF 03.5 PIR1.ADIF = 0;
                                           // Clear A/D interrupt flag
0333 130C
         BCF
               0C,6
0334 1683
          BSF 03,5 PIE1.ADIE = 1;
                                            // Enable A/D interrupt
0335 170C
          BSF 0C,6
0336 1283
           BCF
                 03,5
                        Temp = PORTB;
                                           // Clear mismatch condition
0337 0806
           MOVF
                 06,W
                                            // on PORTB
           MOVWF 27
0338 00A7
0339 100B
           BCF
                  0B,0
                       INTCON.RBIF = 0;
                                            // Clear PORTB interrupt flag
033A 158B
                 OB, 3 INTCON.RBIE = 1;
           BSF
                                            // Enable PORTB interrupt
033B 3080
         MOVLW 80h
                      TMR1H = 0x80;
                                            // Initialize Timer1 to 0x8000
033C 008F
         MOVWF OF
033D 018E
                        TMR1L = 0x00;
           CLRF
                 OF:
033E 300F
           MOVLW 0Fh
                        T1CON = 0b00001111;
                                           // Timerl 1:1 prescale, Osc
033F 0090
           MOVWF 10
                                            // enabled, no sync, external
                                            // clock source, Timer1 on
                                            // Clear Timer1 Overflow int flag
0340 100C
                0C.0 PIR1.TMR1IF = 0;
           BCF
0341 1683
           BSF
                03,5 PIE1.TMR1IE = 1;
                                           // Enable T1 Overflow interrupt
0342 140C
                0C,0
         BSF
0343 1703
         BSF
                03,6 STATUS.RP1 = 1;
                                            // Go to Bank 2
         MOVLW 06h
                                            // Set LCD frame freq to 37 Hz,
0344 3006
                        LCDPS = 6;
0345 1283
           BCF
                 03,5
                                            // Timer1 clk source
0346 008E
           MOVWF 0E
0347 30FF
                      LCDSE = 0xff;
                                            // Ports D,E,F,G are all LCD pins
           MOVLW
                 FFh
0348 008D
           MOVWF 0D
           MOVLW 17h LCDCON = 0b00010111; // Drive in SLEEP, charge pump on, Timer1 clk src
0349 3017
034A 008F
           MOVWF OF
                                            // Timer1 clk src 1/4 mux, 1/3 bias
034B 0190
                     LCDD00 = 0;
                                            // Clear all LCD data registers
           CLRF 10
034C 0191
          CLRF 11
                     LCDD01 = 0;
```

```
034D 0192
          CLRF
                                   LCDD02 = 0;
                  12
                                   LCDD03 = 0;
034E 0193
           CLRF
                  13
034F 0194
           CLRF
                                   LCDD04 = 0;
                  14
                 15
0350 0195
                                   LCDD05 = 0;
            CLRF
0351 0196
                 16
                                   LCDD06 = 0;
           CLRF
0352 0197
           CLRF
                 17
                                   LCDD07 = 0;
0353 0198
          CLRF
                 18
                                   LCDD08 = 0;
0354 0199
          CLRF 19
                                   LCDD09 = 0;
                                   LCDD10 = 0;
0355 019A
          CLRF 1A
0356 019B
           CLRF
                 1B
                                   LCDD11 = 0;
                 1C
0357 019C
           CLRF
                                   LCDD12 = 0;
0358 019D
                                   LCDD13 = 0;
           CLRF
                  1D
0359 019E
            CLRF
                  1E
                                   LCDD14 = 0;
035A 019F
            CLRF
                  1F
                                   LCDD15 = 0;
035B 178F
                  OF,7
                                   LCDCON.LCDEN = 1; // Enable the LCD Module
           BSF
035C 1303
           BCF
                  03,6
                                   STATUS.RP1 = 0;
                                                      // Go to Bank 0
035D 138C
          BCF
                  OC,7
                                   PIR1.LCDIF = 0;
                                                     // Clear LCD interrupt flag
035E 1683
          BSF
                  03,5
                                   PIE1.LCDIE = 1;
                                                      // Enable LCD interrupt
035F 178C
         BSF
                  OC,7
0360 1283
           BCF
                  03,5
                                   Seconds = 0;
                                                      // Initialize data variables
0361 01F0
            CLRF
                  70
0362 01F1
            CLRF
                  71
                                   Minutes = 0;
           MOVLW 12h
                                   Hours = 0x12;
0363 3012
                                                      // Set time to 12:00AM Sunday
0364 00F2
           MOVWF 72
                                   LStatus = 0;
0365 01F3
           CLRF
                 73
0366 01F4
          CLRF
                  74
                                   DayOfWeek = 0;
0367 3011
           MOVLW 11h
                                   Flags = 0b00010001;
0368 00A6
          MOVWF 26
0369 01F5
           CLRF
                  75
                                   TempC = 0;
036A 01A9
            CLRF
                   29
                                   Ticks = 0;
036B 3004
            MOVLW 04h
                                   Count = BEEP_COUNT;
036C 00A8
           MOVWF 28
036D 30C7
           MOVLW C7h
                                   Mode = 0b11000111; // Turn on :,degrees,hours,
036E 00F8
          MOVWF 78
                                                      // minutes, day of week
036F 170B
          BSF
                  0B,6
                                   INTCON.PEIE = 1;  // Enable peripheral interrupts
          BSF
0370 178B
                  0B,7
                                   INTCON.GIE = 1;  // Enable global interrupts
0371 0008
           RETURN
                                   return;
                                }
                 /*****************************
                     main
                     Function: Controls the clock. Calls routines to update the LCD panel,
                              play music, program mode, and display state of sound.
                                void main(void)
0372 231E
            CALL
                 031Eh
                                    Init924();
                                                     // Initialize the PIC16C924
                                    while(1)
0373 1283
                                      if(Flags.UPDATE&&Flags.FRAME) // Refresh the LCD
          BCF
                  03,5
0374 1C26
          BTFSS 26,0
                                                                   // data registers
0375 2B7D
          GOTO
                  037Dh
0376 1CA6
          BTFSS 26,1
0377 2B7D
          GOTO 037Dh
0378
                                                      // based on new data
           BCF
0378 1283
                  03,5
                                        Flags.UPDATE = 0;
                                                             // Clear the UPDATE flag
0379 1026
            BCF
                   26,0
037A 10A6
                                        Flags.FRAME = 0;
                                                               // Clear the FRAME flag
            BCF
                  26,1
                                                               // Update LCD data regs
037B 2112
           CALL
                  0112h
                                        UpdateLCD();
037C 2B84
            GOTO
                   0384h
                                      else if(!Flags.UPDATE&&Flags.FRAME) // Clear FRAME
037D 1283
            BCF
                   03,5
                                        Flags.FRAME = 0;
                                                                     // flag if no UPDATE
037E 1826
            BTFSC 26.0
```

```
0384h
037F 2B84
           GOTO
0380 1CA6
          BTFSS 26,1
0381 2B84
           GOTO
                 0384h
0382 1283
           BCF
                  03.5
0383 10A6
           BCF
                 26,1
0384 1283
         BCF 03,5
                                     if(Flags.SET)
                                                         // Enter program mode
0385 1FA6
         BTFSS 26,7
0386 2B9A
          GOTO 039Ah
0387
0387 13A6
          BCF
                 26,7
                                       Flags.SET = 0;
                                                         // Clear the SET, UP flags
                                       Flags.UP = 0;
0388 1326
           BCF
                  26,6
                29
0389 01A9
           CLRF
                                       Ticks = 0;
                                                          // Clear the Ticks
                                       Flags.PROGRAM = 1;  // Change to program mode
038A 15A6
           BSF
                  26,3
                                       while(!Flags.FRAME); // Wait for next frame to occur
038B 1283
           BCF
                 03,5
038C 1CA6
          BTFSS 26,1
038D 2B8B
         GOTO 038Bh
038E 1283
         BCF
                 03,5
                                      Flags.FRAME = 0;
                                                          // Clear FRAME flag
038F 10A6
          BCF
                  26,1
0390 30E7
          MOVLW E7h
                                      Mode = 0b11100111;
                                                         // Enable PROG icon on LCD
0391 00F8
           MOVWF
                 78
0392 2112
           CALL
                 0112h
                                       UpdateLCD();
                                                          // Refresh the LCD
           CALL 02B5h
0393 22B5
                                                         // Call program to set time
                                      SetTime();
0394 1283
         BCF
                03,5
                                       Flags.PROGRAM = 0;
                                                         // Exit program mode
0395 11A6
                  26,3
          BCF
                 70
0396 01F0
           CLRF
                                       Seconds = 0;
                                                         // Clear seconds
                                      Flags.UPDATE = 1;
0397 1426
           BSF
                  26,0
                                                         // Set UPDATE flag
0398 30C7
           MOVLW C7h
                                      Mode = 0b11000111;
                                                         // Reset display mode,
0399 00F8
           MOVWF 78
                                                          // PROG icon off
039A 1EF3
         BTFSS 73,5
                                                         // Enable/disable hourly beep
                                     if(LStatus.SOUND)
039B 2B9E
          GOTO 039Eh
039C
                                       LStatus.SOUND = 0; // Reset SOUND flag
039C 12F3
           BCF
                 73.5
039D 2241
          CALL 0241h
                                       DisplaySoundState(); // Display state of hourly beep
039E 1283
           BCF
                  03,5
                                     if(!Flags.SLEEP_STATE) // If 924 can go to sleep,
039F 1EA6
           BTFSS 26,5
                                                         // go ahead
03A0 0063
                                      SLEEP();
           SLEEP
03A1 2B73
           GOTO 0373h
                                  }
03A2 0008
           RETURN
                /***********************************
                    Function: Interrupt service routine for LCD, PORTB, Timer2, Timer1,
                          Timer0, and A/D
                 0004 2BA3
           GOTO 03A3h
                              void ___INT(void)
03A3
                              {
                                                          // "push" W and STATUS
                              #asm
03A3 00FA
                         movwf temp_WREG
03A4 0E03
                         swapf STATUS,W
03A5 1283
                               STATUS, RP0
                         bcf
03A6 1303
                                STATUS, RP1
                         bcf
03A7 00FE
                         movwf
                               temp_STATUS
03A8 0804
                         movf
                               FSR,W
03A9 00FF
                         movwf temp_FSR
                              #endasm
03AA 1283
                  03,5
           BCF
                                  if(PIR1.LCDIF)
                                                         // Ok to write to LCD data regs
03AB 1F8C
           BTFSS 0C,7
03AC 2BAF
           GOTO 03AFh
```

```
03AD
                                       {
03AD 14A6
             BSF
                    26,1
                                          Flags.FRAME = 1;
                                                              // Set FRAME flag
03AE 138C
                                          PIR1.LCDIF = 0;
                                                              // Clear LCD interrupt flag
             BCF
                    0C,7
                                       if(INTCON.RBIF)
03AF 1C0B
             BTFSS
                    0B.0
                                                               // Key press/release detected
03B0 2BD7
             GOTO
                    03D7h
03B1
03B1 3005
             MOVLW
                    05h
                                          Delay_Ms_4MHz(5);
                                                               // Debounce for 5msec
03B2 2432
             CALL
                    0432h
03B3 1283
             BCF
                    03,5
                                          Temp = PORTB;
                                                               // Read PORTB
03B4 0806
             MOVF
                    06,W
03B5 00A7
             MOVWF
                    27
03B6 3014
             MOVLW 14h
                                          Delay_Ms_4MHz(20); // Debounce for 20msec more
03B7 2432
             CALL
                    0432h
03B8 30F0
             MOVLW F0h
                                          if(Temp!=0xf0 && Temp==PORTB) // If same state as
03B9 1283
             BCF
                    03,5
                                                                         // previous read
03BA 0227
             SUBWF 27,W
03BB 1903
             BTFSC 03,2
03BC 2BD4
             GOTO
                    03D4h
03BD 1283
             BCF
                    03,5
03BE 0827
             MOVF
                    27,W
03BF 0206
             SUBWF
                    06,W
03C0 1D03
             BTFSS
                    03,2
03C1 2BD4
             GOTO
                    03D4h
03C2
                                                               // and interrupt is not for release
03C2 2100
             CALL
                    0100h
                                            StartBEEP();
                                                               // Beep when key is pressed
03C3 1283
             BCF
                    03.5
                                            if(!Temp.SET)
                                                               // Set the SET flag
03C4 1FA7
             BTFSS
                    27,7
03C5 17A6
                    26,7
                                             Flags.SET = 1;
             BSF
03C6 1F27
             BTFSS
                    27,6
                                            if(!Temp.UP)
                                                               // Set the UP flag
03C7 1726
             BSF
                    26,6
                                            Flags.UP = 1;
03C8 118A
                    0A,3
             BCF
                                            if(!Temp.SOUND&&!Flags.PROGRAM)
03C9 1AA7
             BTFSC 27,5
03CA 2BD4
             GOTO
                    03D4h
03CB 19A6
             BTFSC 26,3
03CC 2BD4
             GOTO
                    03D4h
03CD
                                                                   // Toggle the SOUND state
                    03,5
                                               if(Flags.SOUND_STATE)
03CD 1283
             BCF
03CE 1E26
             BTFSS
                    26,4
03CF 2BD2
             GOTO
                    03D2h
03D0 1226
                                                 Flags.SOUND_STATE = 0;
             BCF
                    26,4
03D1 2BD3
                    03D3h
             GOTO
                                             else
03D2 1626
             BSF
                    26,4
                                                 Flags.SOUND_STATE = 1;
03D3 16F3
             BSF
                    73,5
                                             LStatus.SOUND = 1; // Set the SOUND flag
                                            }
03D4 1283
             BCF
                    03,5
                                          Ticks = 0;
                                                                    // Reset Ticks, because key
03D5 01A9
             CLRF
                    29
                                                                    // was pressed
03D6 100B
             BCF
                    0B,0
                                          INTCON.RBIF = 0;
                                                                    // Clear PORTB interrupt flag
                                       }
03D7 1C8C
             BTFSS 0C,1
                                       if(PIR1.TMR2IF&&PIE1.TMR2IE)// T2 Overflow used for beep
03D8 2BEE
             GOTO
                    03EEh
03D9 1683
             BSF
                    03,5
03DA 1C8C
             BTFSS 0C,1
03DB 2BEE
             GOTO
                    03EEh
03DC
03DC 1683
             BSF
                    03,5
                                          if(PIE1.TMR2IE)
                                                                   // If Timer2 int is enabled
03DD 1C8C
             BTFSS
                    0C,1
03DE 2BEC
             GOTO
                    03ECh
03DF
03DF 1283
             BCF
                    03,5
                                            Count--;
                                                                    // Decrement count
03E0 03A8
             DECF
                    28
03E1 08A8
             MOVF
                    2.8
                                            if(!Count)
                                                                  // If count has reached zero
```

```
BTFSS 03,2
03E2 1D03
03E3 2BEC
             GOTO
                    03ECh
03E4
                                                                  // Disable CCP module
03E4 1283
             BCF
                    03,5
                                             CCP1CON = 0;
03E5 0197
             CLRF
                    17
                                                                  // Disable Timer2
03E6 0192
                    12
                                             T2CON = 0;
             CLRF
03E7 0195
             CLRF
                    15
                                             CCPR1L = 0;
                                                                  // Clear the Duty Cycle
03E8 1683
             BSF
                    03,5
                                             PIE1.TMR2IE = 0;
                                                                  // Disable Timer2 Interrupt
03E9 108C
             BCF
                    0C,1
03EA 1283
                    03.5
                                             Flags.SLEEP_STATE = 0; // Enable 924 to SLEEP
             BCF
03EB 12A6
             BCF
                    26,5
03EC 1283
             BCF
                    03,5
                                          PIR1.TMR2IF = 0;
                                                                  // Clear Timer2 interrupt flag
03ED 108C
             BCF
                    0C,1
                                       }
03EE 1283
             BCF
                    03,5
                                       if(PIR1.TMR1IF)
                                                                  // T1 Overflow, once every sec
03EF 1C0C
             BTFSS 0C,0
03F0 2C23
             GOTO
                    0423h
03F1
03F1 19A6
             BTFSC
                    26,3
                                          if(!Flags.PROGRAM)
                                                                  // If not in program mode
03F2 2C16
             GOTO
                    0416h
03F3
03F3 0AF0
             INCF
                    70
                                                                  // Increment seconds
                                            Seconds++;
03F4 300F
             MOVLW
                    0Fh
                                            if( (Seconds&0x0f) > 0x09)
                                                                          // check for seconds
03F5 0570
             ANDWF
                    70,W
                                                                           // overflow within
03F6 00FB
             MOVWF
                    7B
03F7 3009
             MOVLW
                    09h
03F8 027B
             SUBWF
                    7B,W
03F9 1D03
                    03,2
             BTFSS
03FA 1C03
             BTFSS
                    03,0
03FB 2C01
             GOTO
                    0401h
03FC
                                                                  // seconds
03FC 30F0
             MOVLW F0h
                                             Seconds &= 0xf0;
03FD 1283
             BCF
                    03,5
                    70
03FE 05F0
             ANDWF
03FF 3010
             MOVLW
                    10h
                                             Seconds += 0x10;
0400 07F0
             ADDWF
                    70
0401 3060
             MOVLW
                    60h
                                            if(Seconds >= 0x60) // check for seconds overflow
0402 1283
             BCF
                    03,5
0403 0270
                    70,W
             SUBWF
0404 1C03
             BTFSS
                    03,0
0405 2C07
             GOTO
                    0407h
0406 2272
             CALL
                    0272h
                                             IncMinutes();
                                                                  // increment minutes routine
0407 3060
             MOVLW
                   60h
                                            if(Minutes >= 0x60) // check for hours overflow
0408 1283
             BCF
                    03.5
0409 0271
             SUBWF
                    71,W
040A 1C03
             BTFSS
                    03,0
040B 2C0D
             GOTO
                    040Dh
040C 2283
                    0283h
                                             IncHours();
                                                                  // increment hours routine
             CALL
040D 1283
             BCF
                    03,5
                                            TMR1H = 0x80;
                                                                  // Set Timer1 to 0x8000
040E 178F
             BSF
                    OF,7
                                                                  // + current time
040F 1426
             BSF
                    26,0
                                            Flags.UPDATE = 1;
                                                                  // Set UPDATE flag
0410 1F78
             BTFSS
                    78,6
                                            if(Mode.COLON)
                                                                  // Toggle whether the colon is
0411 2C14
             GOTO
                    0414h
0412 1378
             BCF
                    78,6
                                             Mode.COLON = 0;
                                                                  // on or off every second
0413 2C15
             GOTO
                    0415h
                                            else
0414 1778
             BSF
                    78,6
                                             Mode.COLON = 1;
0415 2C17
             GOTO
                    0417h
                                                                  // If in program mode
0416 0AA9
             INCF
                                            Ticks++;
                                                                  // inc Ticks, used for timeout
```

```
0417 1683
         BSF
                 03,5
                                    TRISA.THERM_GND = 0; // Apply power to thermistor
0418 1105
          BCF
                 05,2
0419 3002
          MOVLW 02h
                                    Delay_10xUs_4MHz(2); // Allow 20us for sampling
041A 243C
           CALL
                 043Ch
041B 1283
                                    ADCON0.GO = 1;
          BCF
                 03.5
                                                      // Start a temp A/D conversion
041C 151F
          BSF
                 1F,2
041D 0000
                                                      // Wait for charging cap to
         NOP
                                    NOP();
041E 0000
         NOP
                                                      // disconnect from pin
                                    TRISA.THERM_GND = 1; // Remove power from thermistor
                 03,5
041F 1683
         BSF
0420 1505
         BSF
                 05,2
0421 1283
          BCF
                 03,5
                                    PIR1.TMR1IF = 0; // Clear Timer1 interrupt flag
0422 100C
                 0C,0
           BCF
0423 1F0C
         BTFSS 0C,6
                                 if(PIR1.ADIF)
                                                      // A/D conversion complete
0424 2C2B GOTO
                 042Bh
0425
                                    TempC = ThermTable[ADRES];// Use converted value
0425 018A
         CLRF
0426 081E MOVF
                1E.W
                                                           // for table
         CALL
0427 2005
                 0005h
0428 1283
           BCF
                 03,5
0429 00F5
           MOVWF 75
042A 130C
           BCF
                 OC,6
                                    PIR1.ADIF = 0;
                                                      // lookup of temperature
                                                      // "pop" W and STATUS
                              #asm
042B 087F
                        movf
                               temp_FSR,W
042C 0084
                        movwf FSR
042D 0E7E
                        swapf
                               temp_STATUS,W
042E 0083
                        movwf
                               STATUS
042F 0EFA
                        swapf
                               temp_WREG,F
0430 0E7A
                        swapf
                               temp_WREG,W
                              #endasm
0431 0009
         RETFIE
                                 return;
                              }
                  void Delay_Ms_4MHz(registerw delay)
                                Clock\ Speed = 4MHz
                                Inst. Clock = 1MHz
                                Inst. dur. = lus */
0000
                              {
                              #asm
0432 1283
                            BCF
                                   STATUS, RP0
0433 00FB
                            MOVWF
                                   ___WImage
                     DLMS4M1
                            RADIX
                                   DEC
0434 30F9
                            MOVLW
                                   249
0435 0084
                            MOVWF
                                   FSR
                     DLMS4M2
0436 0000
                            NOP
0437 0B84
                            DECFSZ FSR
0438 2C36
                            GOTO
                                   DLMS4M2
0439 OBFB
                            DECFSZ __WImage
043A 2C34
                            GOTO
                                   DLMS4M1
                              #endasm
043B 0008
           RETURN
                  void Delay_10xUs_4MHz(registerw delay)
```

```
Clock Freq. = 4MHz
                                  Inst. Clock = 1MHz
                                  Inst. dur. = 1000ns */
0000
                                #asm
043C 1283
                              BCF
                                     STATUS, RP0
043D 00FB
                              MOVWF __WImage
                      DL10XMS4M
                      DL10XMS4M__ REPT 7
                             NOP
                      ENDM
043E 0000
043F 00 00
0440 00 00
0441 00 00
0442 00 00
0443 00 00
0444 00 00
0445 FB 0B
                         DECFSZ ___WImage
                          GOTO DL10XMS4M
0446 3E 2C
                           #endasm
0447 0008
            RETURN
                             }
                                    **************************************
0000 3003
           MOVLW 03h
0001 008A
           MOVWF 0A
0002 2B72
            GOTO 0372h
ROM USAGE MAP
   0000 to 0002 0004 to 0447
   Total ROM used 0447
Errors
Warnings
```

Note the following details of the code protection feature on PICmicro® MCUs.

- The PICmicro family meets the specifications contained in the Microchip Data Sheet.
- Microchip believes that its family of PICmicro microcontrollers is one of the most secure products of its kind on the market today, when used in the intended manner and under normal conditions.
- There are dishonest and possibly illegal methods used to breach the code protection feature. All of these methods, to our knowledge, require using the PICmicro microcontroller in a manner outside the operating specifications contained in the data sheet. The person doing so may be engaged in theft of intellectual property.
- · Microchip is willing to work with the customer who is concerned about the integrity of their code.
- Neither Microchip nor any other semiconductor manufacturer can guarantee the security of their code. Code protection does not mean that we are guaranteeing the product as "unbreakable".
- Code protection is constantly evolving. We at Microchip are committed to continuously improving the code protection features of our product.

If you have any further questions about this matter, please contact the local sales office nearest to you.

Information contained in this publication regarding device applications and the like is intended through suggestion only and may be superseded by updates. It is your responsibility to ensure that your application meets with your specifications. No representation or warranty is given and no liability is assumed by Microchip Technology Incorporated with respect to the accuracy or use of such information, or infringement of patents or other intellectual property rights arising from such use or otherwise. Use of Microchip's products as critical components in life support systems is not authorized except with express written approval by Microchip. No licenses are conveyed, implicitly or otherwise, under any intellectual property rights.

Trademarks

The Microchip name and logo, the Microchip logo, FilterLab, KEELOQ, microID, MPLAB, PIC, PICmicro, PICMASTER, PICSTART, PRO MATE, SEEVAL and The Embedded Control Solutions Company are registered trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

dsPIC, ECONOMONITOR, FanSense, FlexROM, fuzzyLAB, In-Circuit Serial Programming, ICSP, ICEPIC, microPort, Migratable Memory, MPASM, MPLIB, MPLINK, MPSIM, MXDEV, PICC, PICDEM, PICDEM.net, rfPIC, Select Mode and Total Endurance are trademarks of Microchip Technology Incorporated in the U.S.A.

Serialized Quick Turn Programming (SQTP) is a service mark of Microchip Technology Incorporated in the U.S.A.

All other trademarks mentioned herein are property of their respective companies.

© 2002, Microchip Technology Incorporated, Printed in the U.S.A., All Rights Reserved.





Microchip received QS-9000 quality system certification for its worldwide headquarters, design and wafer fabrication facilities in Chandler and Tempe, Arizona in July 1999. The Company's quality system processes and procedures are QS-9000 compliant for its PICmicro® 8-bit MCUs, KEELO© code hopping devices, Serial EEPROMs and microperipheral products. In addition, Microchip's quality system for the design and manufacture of development systems is ISO 9001 certified.



WORLDWIDE SALES AND SERVICE

AMERICAS

Corporate Office

2355 West Chandler Blvd. Chandler, AZ 85224-6199 Tel: 480-792-7200 Fax: 480-792-7277 Technical Support: 480-792-7627 Web Address: http://www.microchip.com

Rocky Mountain

2355 West Chandler Blvd. Chandler, AZ 85224-6199
Tel: 480-792-7966 Fax: 480-792-7456

Atlanta

500 Sugar Mill Road, Suite 200B Atlanta, GA 30350
Tel: 770-640-0034 Fax: 770-640-0307

Boston

2 Lan Drive, Suite 120 Westford, MA 01886 Tel: 978-692-3848 Fax: 978-692-3821

Chicago

333 Pierce Road, Suite 180 Itasca, IL 60143

Tel: 630-285-0071 Fax: 630-285-0075

Dallas

4570 Westgrove Drive, Suite 160 Addison, TX 75001 Tel: 972-818-7423 Fax: 972-818-2924

Detroit

Tri-Atria Office Building 32255 Northwestern Highway, Suite 190 Farmington Hills, MI 48334 Tel: 248-538-2250 Fax: 248-538-2260

Kokomo

2767 S. Albright Road Kokomo, Indiana 46902 Tel: 765-864-8360 Fax: 765-864-8387

Los Angeles

18201 Von Karman, Suite 1090 Irvine, CA 92612

Tel: 949-263-1888 Fax: 949-263-1338

New York

150 Motor Parkway, Suite 202 Hauppauge, NY 11788 Tel: 631-273-5305 Fax: 631-273-5335

San Jose

Microchip Technology Inc. 2107 North First Street, Suite 590 San Jose, CA 95131 Tel: 408-436-7950 Fax: 408-436-7955

Toronto

6285 Northam Drive, Suite 108 Mississauga, Ontario L4V 1X5, Canada Tel: 905-673-0699 Fax: 905-673-6509

ASIA/PACIFIC

Australia

Microchip Technology Australia Pty Ltd Suite 22, 41 Rawson Street Epping 2121, NSW Australia

Tel: 61-2-9868-6733 Fax: 61-2-9868-6755

China - Beijing

Microchip Technology Consulting (Shanghai) Co., Ltd., Beijing Liaison Office Unit 915

Bei Hai Wan Tai Bldg. No. 6 Chaoyangmen Beidajie Beijing, 100027, No. China Tel: 86-10-85282100 Fax: 86-10-85282104

China - Chengdu

Microchip Technology Consulting (Shanghai)
Co., Ltd., Chengdu Liaison Office
Rm. 2401, 24th Floor, Ming Xing Financial Tower No. 88 TIDU Street Chengdu 610016, China Tel: 86-28-6766200 Fax: 86-28-6766599

China - Fuzhou

Microchip Technology Consulting (Shanghai) Co., Ltd., Fuzhou Liaison Office Unit 28F, World Trade Plaza No. 71 Wusi Road Fuzhou 350001, China Tel: 86-591-7503506 Fax: 86-591-7503521

China - Shanghai

Microchip Technology Consulting (Shanghai) Co., Ltd. Room 701, Bldg. B

Far East International Plaza No. 317 Xian Xia Road Shanghai, 200051

Tel: 86-21-6275-5700 Fax: 86-21-6275-5060

China - Shenzhen

Microchip Technology Consulting (Shanghai) Co., Ltd., Shenzhen Liaison Office Rm. 1315, 13/F, Shenzhen Kerry Centre, Renminnan Lu Shenzhen 518001, China Tel: 86-755-2350361 Fax: 86-755-2366086

Hong Kong

Microchip Technology Hongkong Ltd. Unit 901-6, Tower 2, Metroplaza 223 Hing Fong Road Kwai Fong, N.T., Hong Kong Tel: 852-2401-1200 Fax: 852-2401-3431

India

Microchip Technology Inc. India Liaison Office Divvasree Chambers 1 Floor, Wing A (A3/A4) No. 11, O'Shaugnessey Road Bangalore, 560 025, India Tel: 91-80-2290061 Fax: 91-80-2290062

Japan

Microchip Technology Japan K.K. Benex S-1 6F 3-18-20, Shinyokohama Kohoku-Ku, Yokohama-shi Kanagawa, 222-0033, Japan

Tel: 81-45-471- 6166 Fax: 81-45-471-6122

Korea

Microchip Technology Korea 168-1, Youngbo Bldg. 3 Floor Samsung-Dong, Kangnam-Ku Seoul, Korea 135-882

Tel: 82-2-554-7200 Fax: 82-2-558-5934

Singapore

Microchip Technology Singapore Pte Ltd. 200 Middle Road #07-02 Prime Centre Singapore, 188980 Tel: 65-334-8870 Fax: 65-334-8850

Taiwan

Microchip Technology Taiwan 11F-3, No. 207 Tung Hua North Road Taipei, 105, Taiwan

Tel: 886-2-2717-7175 Fax: 886-2-2545-0139

EUROPE

Denmark

Microchip Technology Nordic ApS Regus Business Centre Lautrup hoj 1-3 Ballerup DK-2750 Denmark Tel: 45 4420 9895 Fax: 45 4420 9910

France

Microchip Technology SARL Parc d'Activite du Moulin de Massy 43 Rue du Saule Trapu Batiment A - Ier Etage 91300 Massy, France Tel: 33-1-69-53-63-20 Fax: 33-1-69-30-90-79

Germany Microchip Technology GmbH Gustav-Heinemann Ring 125 D-81739 Munich, Germany Tel: 49-89-627-144 0 Fax: 49-89-627-144-44

Italy

Microchip Technology SRL Centro Direzionale Colleoni Palazzo Taurus 1 V. Le Colleoni 1 20041 Agrate Brianza Milan, Italy Tel: 39-039-65791-1 Fax: 39-039-6899883

United Kingdom

Arizona Microchip Technology Ltd. 505 Eskdale Road Winnersh Triangle Wokingham Berkshire, England RG41 5TU Tel: 44 118 921 5869 Fax: 44-118 921-5820

01/18/02