Butterworth Filter (Z-domain)

Zbutter

Implementation of a lowpass or bandpass Butterworth filter using a z-domain technique to enabling modeling of a high-order and/or narrow bandwidth filter. Fixed time-step transient analysis must be used



Figure 1: A Butterworth (maximally-flat) Z-Domain filter element implemented as a voltage-controlled voltage source.

Form:

Zbutter: $\langle instance name \rangle n_1 n_2 n_3 n_4 \langle parameter list \rangle$

 $n_1, n_2 \cdots$ are the element nodes.

Parameters:

Parameter	Type	Default	Required?
flp: Lower Pass Frequency (Hz)	DOUBLE	0	reqd. if fo and pbw not specified
fhp: Upper Pass Frequency (Hz)	DOUBLE	0	reqd. if fo and pbw not specified
fo: Center Frequency (Hz)	DOUBLE	0	reqd. if flp and flp not specified
pbw: Passband bandwidth (Hz or %)	DOUBLE	0	reqd. if flp fhp are not specified
pbfdb: Passband Flatness (negative) (dB)	DOUBLE	-3	optional
fls: Lower Stop Frequency (Hz)	DOUBLE	0	reqd. if pord not specified
fhs: Upper Stop Frequency (Hz)	DOUBLE	0	reqd. if pord not specified
sbadb: Stopband Attenuation (negative) (dB)	DOUBLE	-10	reqd. if pord not specified
pord: Lowpass Prototype Filter Order	INTEGER	0	reqd. if fls & fls & sbadb not specified
ildb: Insertion Loss (negative) (dB)	DOUBLE	0	no
rep: Record filter design info in report	BOOLEAN	FALSE	optional

Notes on Parameters:

Lowpass filter is chosen if fo and pbw are not set, and flp = 0. Then fhp is the corner frequency of the lowpass filter. Note that fhs must be set.

Bandpass filter is chosen by setting either ((flp \neq 0) AND fhp) OR (fo AND pbw)

Description:

This is a v-to-v transducer implementing a unilateral Z-domain Butterworth lowpass or bandpass discretetime filter. The sampling frequency of the filter is fixed to the time-step, tstep, of transient simulation. Note that this filter will not work with variable time-stepping! Also, the 'DC gain' of the filter is 1.

The order of the filter is determined by the netlist specifications. Implementation of the filter is in cascade form of conjugate pole pair blocks for even order filters. Odd order filters put the single real pole block at the front of the cascade of pole pair blocks for best numerical properties.

Version: 2008.01.05

 ${ Credits: \atop {\rm Name} }$

Affiliation Date

Links
NC STATE UNIVERSITY Aug. 5, 2004 Frank P. Hart NC State University NC STATE UNIVERSITY Michael B. Steer NC State University Jan. 5, 2008

www.ncsu.edu