© 2016 John A. O **V011717**



RPi.GPIO Module Usage

Import the module:

import RPI.GPIO (as "whatever" if desired - as IO is assumed in the following)

Pin numbering: a choice is <u>required</u> to specify channel

designations:

IO.setmode(IO.BOARD)

or

IO.setmode(IO.BCM)

Setup: every channel that is to be used:

IO.setup(channel, IO.IN)
IO.setup(channel, IO.OUT)

You can specify an initial state for the pin:

IO.setup(channel, IO.OUT, initial=IO.HIGH)

Or setup a bunch at a time:

chan_list = [11,12] add multiple channels

can use tuples instead i.e.: chanlist = (11,12)

IO.setup(chan_list, IO.OUT)

Read or write (set) pins: (NOTE: a "pin" is the

same as a "channel")

IO.input(channel) (o=False=IO.Low,1=True=IO.High)

IO.output(channel, state) (states same as above)

Can <u>output</u> to several channels with one command:

chanlist = [11,12] <- this also works with tuples

IO.output(chanlist, IO.LOW) <- this sets all to IO.LOW

IO.output(chanlist, (IO.HIGH, IO.LOW)) <- this sets first

HIGH and the second LOW

Environmental information:

GPIO.RPI INFO about your RPi

GPIO.RPI_INFO['P1_REVISION'] Raspberry Pi board revision

GPIO.VERSION RPi.GPIO version number

Find the function of a channel:

func = IO.gpio_function(pin)

will return a value from:

IO.IN, IO.OUT, IO.SPI, IO.I2C, IO.HARD_PWM, IO.SERIAL,

IO.UNKNOWN

Pull UP / Pull DOWN:

Unconnected pins float.

Default values (High or Low) can be set in **software** or with **hardware**

Hardware:

Pull Up:

Input channel -> 10K resistor -> 3.3V

Pull Down:

Input channel -> 10K resistor -> oV

Software:

IO.setup (channel, IO.IN, pull_up_down = IO.PUD_UP) or

IO.PUD_DOWN) or

IO.PUD OFF)

Edge detection: change of state event – 3 ways to handle

1. wait_for_edge() function - stops everything until an edge is detected.

IO.wait_for_edge (channel, IO.RISING) can detect edges of type IO.RISING, IO.FALLING or IO.BOTH

2. event_detected() function - use in a loop with other activity — event triggers priority response. Example:

IO.add_event_detect(channel, IO.RISING) activity detection on a channel

[your loop activity here]

if IO.event_detected(channel):

print('Button pressed')

3. Threaded callbacks - RPi.GPIO runs a second thread for callback functions. This means that callback functions can be run at the same time as your main program, in immediate response to an edge. For example:

def my_callback(channel):

print('Edge detected on channel %s'%channel') print('This is run in a different thread to your main program')

IO.add_event_detect(channel, IO.RISING, callback=my_callback) add rising edge detection on a channel

...the rest of your program...

If you want more than one callback function:

def my_callback_one (channel):

print ('Callback one')

def my_callback_two (channel):

print ('Callback two')

IO.add_event_detect(channel, IO.RISING) IO.add_event_callback(channel,

my callback one)

IO.add_event_callback(channel, mv callback two)

Note that in this case, the callback functions are run sequentially, not concurrently. This is because there is only one thread used for callbacks, in which every callback is run in the order in which they have been defined.

Switch debounce: solutions to a button event causing multiple callbacks

Hardware: add a 0.1uF capacitor across your switch.

Software: add the bouncetime= parameter to a function where you specify a callback function. bouncetime= should be specified in milliseconds.

IO.add_event_detect(channel, IO.RISING, callback=my_callback, bouncetime=200)

IO.add_event_callback(channel, my_callback, bouncetime=200)

Remove Event Detection:

IO.remove event detect(channel)



V012117

TOOLBOX

Cleanup: resets all channels and clears pin num -bering system at the end of a program - just do it.

IO.cleanup()

Or cleanup just select pins:

GPIO9

SPIo-MOSO GPIO11

SPIo-SCLK

Ground

ID SD

2C ID EEPROM

GPI05

11

12

13

14

15

20

IO.cleanup(channel)

IO.cleanup((channel1, channel2)) IO.cleanup([channel1, channel2])

Raspberry Pi Model B+

<-tuple <-or list

5V 1 Power GPIO2 5V 2 Common breadboard numbering SDA1 12C Power **GPIO3** 3 Ground 5 SCL₁ 12C GPIO14 8 4 GPIO4 7 UARTO TXD **GP1015** 5 Ground 9 10 UARTO-RXD GPIO18 GPIO17 6 11 12 PCM-CLK 7 GPIO27 13 Ground 14 GPIO22 GPIO23 8 16 15 **3V** 18 **GPI024** 9 Power GPIO10 10 19 Ground 20 SPIo-MOSI

21

23

22

24

26

28

30

GPIO25

GPI08

GPI07

SPIo-CE1-N

ID_SC

2C ID EEPROM

Ground

GPI06 32 GPIO12 16 31 17 GPIO13 33 Ground 34

29

GPIO11 36 **GPI016** 18 35 PCM-FS **GPIO20** 38 **GPI026** 19 PCM-DIN

GPIO20 Ground PCM-DOUT

SERIAL PERIPHERAL INTERFACE PINS 19 MOSI-master output, slave input 21 MISO-mastter input, slave output

23 SCK-serial clock 24 & 26-slave select pins UART - UNIVERAL ASYNCHRONOUS RECEIEVER/TRANSMITTER pins 8 UART-TDX & 10 UART-RDX

PWM in RPi.GPIO is an analog signal, **P**ulse Width Modulation - available ONLY on one of the Pi's pins: board #12 = BCM #18; used mostly for audio To create a **software** instance of PWM on any in/out pin:

p = IO.PWM(channel, frequency)

To start PWM: **p.start(dc)** where dc is the duty cycle (0.0 <= dc <= 100.0)

To change the frequency:

p.ChangeFrequency(freq) freq is the new

frequency in Hz*


To change the duty cycle:

p.ChangeDutyCycle(dc) where 0.0 <= dc <= 100.0

To stop PWM:

p.stop()

*100 = 100 times a second, .5 = once every 2 seconds, .1 is every 10 seconds, .0167 = once a minute



270 Ω -> red, purple, brown 330Ω -> orange, orange, brown 10KΩ -> brown, black, yellow

Note: RPi maximum current to a single pin is 16ma, to all pins is 50ma

	† '		1
1st Digit	2nd Digit	Multiplier	Tolerance
0	0	1	
1	1	10	1%
2	2	100	2%
3	3	1 K	
4	4	10 K	
5	5	100 K	
6	6	1 M	
7	7	10M	
8	8		5% gold
9	9		10% silver

Shown below: 3600 Ω with 2% tolerance

