Okuma America Corporation

THINC-API Release Notes For Machining Center

Document No.: S5015-003-22

THINC-API	Version:	S5015-003-22
Release Notes For Machining Center	Date: 09/25/	2013

Revision History

-	Revision history			
Date	Version	Description	Author	
5/09/2007	S5015-003-00	Public release for Machining Center THINC-API Release 1.0.0.0	LHuynh	
5/11/2007	S5015-003-01	Revise Public release for Machining Center THINC-API Release 1.0.0.0:	LHuynh	
		 Remove section 3.0 Compatible and put in Installation Manual document 		
		 Remove section 4.0 Upgrades and put in THINC-API Help file. 		
		- Revise section 6.1 and 6.2		
		 Use <u>api@okuma.com</u> email instead of p100issues@okuma.com 		
5/21/2007	S5015-003-02	Revise General defect – Cannot support 0.1 Micron option. Revise 4.1 section	LHuynh	
06/04/2007	S5015-003-03	Public release for Machining Center THINC-API Release 1.1.0.0	LHuynh	
10/19/2007	S5015-003-04	Public release for Machining Center THINC-API Release 1.3.0.0	LHuynh	
2/22/2008	S5015-003-05	Public release for Machining Center THINC-API Release 1.6.0.0	LHuynh	
04/11/2008	S5015-003-06	Public release for Machining Center THINC-API Release 1.6.0.0	LHuynh	
06/27/2008	S5015-003-07	Public release for Machining Center THINC-API Release 1.6.3.0	LHuynh	
07/25/2008	S5015-003-08	Public release for Machining Center THINC-API Release 1.6.4.0	LHuynh	
10/27/2008	S5015-003-09	Public release for Machining Center THINC-API Release 1.7.00	LHuynh	
12/18/2008	S5015-003-010	Public release for Machining Center THINC-API Release 1.8.0.0	LHuynh	
04/30/2009	S5015-003-011	Public release for Machining Center THINC-API Release 1.9.1.0	LHuynh	
10/12/2009	S5015-003-012	Public release for Machining Center THINC-API Release 1.10.0.0	LHuynh	
4/28/2010	S5015-003-013	Public release for Machining Center THINC-API Release 1.11.0.0	LHuynh	
09/15/2010	S5015-003-014	Public release for Machining Center	LHuynh	

THINC-API Release notes	©Okuma America Corporation,	Page 2 of 14
	2013	

THINC-API	Version:	S5015-003-22
Release Notes For Machining Center	Date: 09/25/2	2013

		THINC-API Release 1.11.1.0	
12/15/2010	S5015-003-015	Public release for Machining Center THINC-API Release 1.12.0.0	LHuynh
02/02/2011	S5015-003-016	Public release for Machining Center THINC-API Release 1.12.1.0	LHuynh
11/16/2011	S5015-003-017	Beta release for Machining Center THINC-API Release 1.14.0.0	LHuynh
01/15/2012	S5015-003-018	Beta release for Machining Center THINC-API Release 1.14.1.0	LHuynh
09/21/2012	S5015-003-019	Beta release for Machining Center THINC- API Release 1.14.2.0	LHuynh
12/04//2012	S5015-003-020	Public release for Machining Center THINC-API Release 1.15.0.0	LHuynh
04/19/2013	S5015-003-021	Beta release for Machining Center THINC-API Release 1.15.3.0	LHuynh
09/25/2013	S5015-003-022	Public release for Machining Center THINC-API Release 1.16.0.0	ASlagle

THINC-API	Version:	S5015-003-22
Release Notes For Machining Center	Date: 09/25/2	2013

Table of Contents

1.	Introduction	
	1.1 Disclaimer of Warranty	5
	1.2 Purpose	5
	1.3 Scope	5
	1.4 Definitions, Acronyms, and Abbreviations	5
	1.5 References	5
2.	About This Release	5
3.	New Features	10
	3.1.1 DATA-API	10
	3.1.2 Command-API	11
	3.2 Changes	11
	3.2.1 DATA-API	11
	3.2.2 Command-API	13
4.	Known Bugs and Limitations	13
	4.1 Defect	13
	4.2 General Defect	13
	4.2.1 Data-API	14
	4.3 Defects Fixed in this Release	14

THINC-API	Version:	S5015-003-22
Release Notes For Machining Center	Date: 09/25/2	2013

Release Notes For Machining Center

1. Introduction

1.1 Disclaimer of Warranty

Okuma America Corporation makes no representations or warranties, either expressed or implied, by or with respect to anything in this document, and shall not be liable for any implied warranties of merchantability or fitness for a particular purpose or for any indirect, special or consequential damages.

Copyright © 2013, Okuma America Corporation. All rights reserved.

GOVERNMENT RIGHTS LEGEND: Use, duplication or disclosure by the U.S. Government is subject to restrictions set forth in the applicable Okuma America Corporation license agreement and as provided in DFARS 227.7202-1(a) and 227.7202-3(a) (1995), DFARS 252.227-7013(c)(1)(ii) (Oct 1988), FAR 12.212(a) (1995), FAR 52.227-19, or FAR 52.227-14, as applicable.

"Okuma America Corporation" and Okuma America Corporation's products are trademarks of Okuma America Corporation. References to other companies and their products use trademarks owned by the respective companies and are for reference purpose only.

1.2 Purpose

The purpose of the *Release Notes* document is to communicate major new features and changes in this release of the THINC-API for Machining Center libraries. It also documents known problems and workarounds.

1.3 Scope

This document describes Release 1.16.0.0 of THINC-API.

1.4 Definitions, Acronyms, and Abbreviations

GAC - Global Assembly Cache Windows folder located in 'C:\WINDOWS\assembly'

1.5 References

None

2. About This Release

All applications compiled with Beta Release from version 1.15.X.X must be compiled with Public Release version 1.16.0.0 when it is available.

In current version of THINC API, some of the existing functions related to ATC, Tool, TailStock, and Chuck Data from DATA-API or Command API might not function correctly on OSP-P300S (MP) and OSP-P300M control unless they have been revised as listed in the Change section 3.2.

Please refer to the help file for detail usage and compatibility information of each function. This version requires latest OSP system disk.

From this release and forward, THINC API libraries will check dependency libraries during installation and at runtime. THINC API will fail to install or load if version of dependency libraries cannot support current version of THINC API.

Version of Okuma.CMDATAPI.dll in Release 1.16.0.0 is 2.6.0.0

THINC-API Release notes	©Okuma America Corporation,	Page 5 of 14
	2013	

THINC-API	Version:	S5015-003-22
Release Notes For Machining Center	Date: 09/25/2	2013

Version of Okuma.CMCMDAPI.dll in Release 1.16.0.0 is 2.4.0.0

Version of APINotifierService.exe in Release 1.16.0.0 is 1.16.0.0

Version of APINotifierStatus.exe in Release 1.16.0.0 is 1.0.0.0

Version of Okuma.Flexnet.dll in Release 1.16.0.0 is 1.3.0.0

Version of Okuma. Apilog. dll in Release 1.16.0.0 is 1.4.0.0

The following functions of Okuma.CMDATAPI.dll library will be only available based on the version of NC control software:

Class	Interfaces
CTools2	Int32 GetMaxTools()
CTools2	Int32 GetToolNo(Int32 intPotNo)
CTools2	Int32 GetMaxPots()
CTools2	String* GetGroupNo(Int32 intPotNo)
CTools2	Int32 GetSerialNo(Int32 intPotNo)
CTools2	String* GetToolName(Int32 intPotNo)
CTools2	String* GetToolKind(Int32 intPotNo)
CTools2	Boolean IsToolInUse(Int32 intPotNo) void SetToolInUse(Int32 intPotNo, Boolean blnValue)
CTools2	Boolean IsStandardTool(Int32 intPotNo) void SetStandardTool(Int32 intPotNo, Boolean blnValue)
CTools2	Boolean IsAdjustmentTool(Int32 intPotNo) void SetAdjustmentTool(Int32 intPotNo, Boolean blnValue)
CTools2	CarrierStatusEnum GetCarrierStatus(Int32 intPotNo);
CTools2	ToolLifeModeEnum GetMode(Int32 intPotNo) void SetMode(Int32 intPotNo, ToolLifeModeEnum enValue)
CTools2	ToolLifeStatusEnum GetStatus(Int32 intPotNo)
CTools2	Int32 GetToolLife(Int32 intPotNo) void SetToolLife(Int32 intPotNo, Int32 intValue)
CTools2	Int32 GetToolLifeRemaining(Int32 intPotNo) void SetToolLifeRemaining(Int32 intPotNo, Int32 intValue)
CTools2	Int32 GetToolLifeRemainingTimeSecond(Int32 intPotNo)
CTools2	Double GetToolLengthOffset1(Int32 intPotNo) ArrayList* GetToolLengthOffset1(Int32 intFromPotIndex, Int32 intToPotIndex) void SetToolLengthOffset1(Int32 intPotNo, Double dblValue) void AddToolLengthOffset1(Int32 intPotNo, Double dblValue) void CalToolLengthOffset1(Int32 intPotNo, Double dblValue)
CTools2	Double GetToolLengthOffset2(Int32 intPotNo) ArrayList* GetToolLengthOffset(Int32 intFromPotIndex, Int32 intToPotIndex) void SetToolLengthOffset2(Int32 intPotNo, Double dblValue) void AddToolLengthOffset2(Int32 intPotNo, Double dblValue) void CalToolLengthOffset2(Int32 intPotNo, Double dblValue)

THINC-API Release notes	©Okuma America Corporation,	Page 6 of 14
	2013	

THINC-API	Version:	S5015-003-22
Release Notes For Machining Center	Date: 09/25/2	2013

	Double CotTooll on ath Offcot2 (Int22 int BotNo)
	Double GetToolLengthOffset3(Int32 intPotNo) ArrayList* GetToolLengthOffset3(Int32 intFromPotIndex, Int32
	intToPotIndex)
CTools2	void SetToolLengthOffset3(Int32 intPotNo, Double dblValue)
	void AddToolLengthOffset3(Int32 intPotNo, Double dblValue)
	void CalToolLengthOffset3(Int32 intPotNo, Double dblValue)
	Double GetCutterRCompOffset1(Int32 intPotNo)
	void SetCutterRCompOffset1(Int32 intPotNo, Double dblValue)
CTools2	void AddCutterRCompOffset1(Int32 intPotNo, Double dblValue)
0100132	ArrayList* GetCutterRCompOffset1(Int32 intFromPotIndex, Int32
	intToPotIndex)
	Double GetCutterRCompOffset2(Int32 intPotNo)
CToolog	void SetCutterRCompOffset2(Int32 intPotNo, Double dblValue)
CTools2	void AddCutterRCompOffset2(Int32 intPotNo, Double dblValue) ArrayList* GetCutterRCompOffset2(Int32 intFromPotIndex, Int32
	intToPotIndex)
	Double GetCutterRCompOffset3(Int32 intPotNo)
OTI-O	void SetCutterRCompOffset4(Int32 intPotNo, Double dblValue)
CTools2	void AddCutterRCompOffset3(Int32 intPotNo, Double dblValue)
	ArrayList* GetCutterRCompOffset3(Int32 intFromPotIndex, Int32 intToPotIndex)
	Double GetToolLengthWearOffset(Int32 intPotNo)
	void SetToolLengthWearOffset(Int32 intPotNo, Double dblValue)
CTools2	void AddToolLengthWearOffset(Int32 intPotNo, Double dblValue)
	ArrayList* GetToolLengthWearOffset(Int32 intFromPotIndex, Int32
	intToPotIndex)
	Double GetCutterRCompWearOffset(Int32 intPotNo)
	void SetCutterRCompWearOffset(Int32 intPotNo, Double dblValue)
CTools2	void AddCutterRCompWearOffset(Int32 intPotNo, Double dblValue)
	ArrayList* GetCutterRCompWearOffset(Int32 intFromPotIndex, Int32
	intToPotIndex)
	ToolTypeEnum GetToolType(Int32 intPotNo)
CTools2	void SetToolType(Int32 intPotNo, ToolTypeEnum enValue)
	ArrayList* GetToolType(Int32 intFromPotIndex, Int32 intToPotIndex)
	Double GetToolAngle(Int32 intPotNo)
CTools2	void SetToolAngle(Int32 intPotNo, Double dblValue)
0100132	void AddToolAngle(Int32 intPotNo, Double dblValue)
	ArrayList* GetToolAngle(Int32 intFromPotIndex, Int32 intToPotIndex)
	Double GetToolDiameter(Int32 intPotNo)
CTools2	void SetToolDiameter(Int32 intPotNo, Double dblValue)
Crooisz	void AddToolDiameter(Int32 intPotNo, Double dblValue)
	ArrayList* GetToolDiameter(Int32 intFromPotIndex, Int32 intToPotIndex)
	Double GetToolNoseDiameter(Int32 intPotNo)
	void SetToolNoseDiameter(Int32 intPotNo, Double dblValue)
CTools2	void AddToolNoseDiameter(Int32 intPotNo, Double dblValue)
	ArrayList* GetToolNoseDiameter(Int32 intFromPotIndex, Int32
	intToPotIndex)

THINC-API Release notes	©Okuma America Corporation,	Page 7 of 14
	2013	

THINC-API	Version:	S5015-003-22
Release Notes For Machining Center	Date: 09/25/	2013

The following functions of Okuma.CMCMDAPI.dll library will be only available based on the version of NC control software:

Class	Interfaces
CATC2	Sub UnRegisterToolPot(ByVal intPotNo As Integer, Optional ByVal intToolNo As Integer = 0, Optional ByVal blnRandomATC As Boolean = False)
CATC2	RegisterToolPot(ByVal intToolNo As Integer, ByVal intPotNo As Integer, ByVal intGroupNo As Integer, ByVal intSerialNo As Integer, Optional ByVal blnDummyTool As Boolean = False, Optional ByVal strToolName As String = "")
CATC2	RegisterToolPot(ByVal intPotNo As Integer, ByVal intGroupNo As Integer, ByVal intSerialNo As Integer, Optional ByVal blnDummyTool As Boolean = False, Optional ByVal strToolName As String = "")
CATC2	SetToolCarrierStatus(ByVal intPotNo As Integer, ByVal enCarrierStatus As CarrierStatusEnum)
CATC2	SetToolKind(ByVal intPotNo As Integer, ByVal enToolKind As ToolKindEnum)
CATC2	SetToolLifeStatus(ByVal intPotNo As Integer, ByVal enToolLifeStatus As ToolLifeStatusEnum)

The following functions of Okuma.CMDATAPI.dll library will be only available in OSP-P200 control machines:

Classes	Interfaces
CIO	OnOffStateEnum GetUserTaskIOVariable(IOTypeEnum enIO, Int32 intIndex);
CIO	void SetUserTaskOutputVariable(Int32 intIndex, OnOffStateEnum enValue);
CIO	OnOffStateEnum GetProtectedUserTaskOutputVariable(Int32 intIndex);
CIO	void SetProtectedUserTaskOutputVariable(Int32 intIndex, OnOffStateEnum enValue);
CTools2	All functions in CTools2 class

The following functions of Okuma.CMCMDAPI.dll library will be only available in OSP-P200 control machines:

Classes	Interfaces
CATC2	All functions in CATC2 class
CMachine	SetUserAlarm(ByVal enAlarm As UserAlarmEnum, Optional ByVal strAlarmMessage As String = "")
CMachine	ClearUserAlarmD()

Note: User Alarm will require OKUMA.MC.UserAlarm license feature in order to function on OSP-P200 machine if machine can support.

THINC-API Release notes	©Okuma America Corporation,	Page 8 of 14
	2013	

THINC-API	Version:	S5015-003-22
Release Notes For Machining Center	Date: 09/25/	2013

For questions about these functions, please consult with your Okuma representatives.

THINC-API Release notes	©Okuma America Corporation,	Page 9 of 14
	2013	

THINC-API	Version:	S5015-003-22
Release Notes For Machining Center	Date: 09/25/2	2013

3. New Features

3.1.1 DATA-API

OSP Control	Classes	Interfaces
P300M/SMP	CSpec	ControlTypeEnum GetControlType()
P300M/SMP	CTools	Double GetToolOffset(Int32 intToolNo, ToolCompensationEnum enToolCompensation) void SetToolOffset(Int32 intToolNo, ToolCompensationEnum enToolCompensation, Double dblValue) void AddToolOffset(Int32 intToolNo, ToolCompensationEnum enToolCompensation, Double dblValue) void CalToolOffset(Int32 intToolNo, ToolCompensationEnum enToolCompensation, Double dblValue)
P300M/SMP	CTools	Double GetToolWearOffset(Int32 intToolNo, ToolCompensationEnum enToolCompensation) void SetToolWearOffset(Int32 intToolNo, ToolCompensationEnum enToolCompensation, Double dblValue) void AddToolWearOffset(Int32 intToolNo, ToolCompensationEnum enToolCompensation, Double dblValue) void CalToolWearOffset(Int32 intToolNo, ToolCompensationEnum enToolCompensation, Double dblValue)
P300M/SMP	CTools	Double GetCutterROffset(Int32 intToolNo, ToolCompensationEnum enToolCompensation) void SetCutterROffset(Int32 intToolNo, ToolCompensationEnum enToolCompensation, Double dblValue) void AddCutterROffset(Int32 intToolNo, ToolCompensationEnum enToolCompensation, Double dblValue)
P300M/SMP	CTools	Double GetCutterRWearOffset(Int32 intToolNo, ToolCompensationEnum enToolCompensation) void SetCutterRWearOffset(Int32 intToolNo, ToolCompensationEnum enToolCompensation, Double dblValue) void AddCutterRWearOffset(Int32 intToolNo, ToolCompensationEnum enToolCompensation, Double dblValue)
P300M P300SMP	CTools	String GetToolType(Int32 intToolNo)

THINC-API Release notes	©Okuma America Corporation,	Page 10 of 14
	2013	

THINC-API	Version:	S5015-003-22
Release Notes For Machining Center	Date: 09/25/	/2013

P300M P300SMP	CTools	void SetStatus(Int32 intToolNo,ToolLifeStatusEnum enToolLifeStatus)
------------------	--------	---

3.1.2 Command-API

OSP Control	Classes	Interfaces
P300M P300SMP	CATC	AttachTool(ByVal intToolNo As Integer, ByVal intPotNo As Integer)
P300M P300SMP	CATC	DeleteTool(ByVal intToolNo As Integer)
P300M P300SMP	CATC	RegisterToolPot(ByVal intPotNo As Integer, ByVal intToolNo As Integer)
P300M P300SMP	CATC	Public Sub RegisterTool(ByVal intToolNo As Integer, Optional ByVal intPotNo As Integer = 0, Optional ByVal enToolKind As ToolKind2Enum = ToolKind2Enum.Normal, Optional ByVal enDiameterKind As DiameterKindEnum = DiameterKindEnum.Normal, Optional ByVal enWeightKind As WeightKindEnum = WeightKindEnum.Normal, Optional ByVal enHeightKind As HeightKindEnum = HeightKindEnum.Normal, Optional ByVal blnThroughCoolantTool As Boolean = False, Optional ByVal intMaxToolSpeed As Integer = 0, Optional ByVal blnManualAttachmentToolATCType As Boolean = False)

3.2 Changes

3.2.1 DATA-API

The following functions have been modified to support data items on OSP-P300 control types.

Please refer to the help file for detail usage and compatibility information of each function.

OSP Control	Classes	Interfaces
P100II P200 P300M P300SMP	CATC	String GetNextTool()

THINC-API Release notes	©Okuma America Corporation,	Page 11 of 14
	2013	

THINC-API	Version:	S5015-003-22
Release Notes For Machining Center	Date: 09/25/	2013

	1	T. C.
P100II P200 P300M P300SMP	CATC	ToolProperty GetPotTool(Int32 intPotNo)
P100II P200 P300M P300SMP	CATC	String GetActualTool()
P100II P200 P300M P300SMP	CTools	Int32 GetCurrentCutterRCompOffsetNumber()
P100II P200 P300M P300SMP	CTools	Int32 GetCurrentToolLengthOffsetNumber()
P100II P200 P300M P300SMP	CTools	Int32 GetCurrentToolNumber()
P100II P200 P300M P300SMP	CTools	Int32 GetGroupNo(Int32 intToolNo) void SetGroupNo(Int32 intToolNo, Int32 intToolGroupNo)
P100II P200 P300M P300SMP	CTools	ToolLifeModeEnum GetMode(Int32 intToolNo) void SetMode(Int32 intToolNo, ToolLifeModeEnum enValue)
P100II P200 P300M P300SMP	CTools	Int32 GetPotNo(Int32 intToolNo)
P100II P200 P300M P300SMP	CTools	ToolLifeStatusEnum GetStatus(Int32 intToolNo) void SetStatus(Int32 intToolNo, Boolean blnOK)
P100II P200 P300M P300SMP	CTools	String GetToolKind(Int32 intToolNo)
P100II P200 P300M P300SMP	CTools	Int32 GetToolLife(Int32 intToolNo) void SetToolLife(Int32 intToolNo, Int32 intValue)
P100II P200 P300M P300SMP	CTools	Int32 GetToolLifeRemaining(Int32 intToolNo); void SetToolLifeRemaining(Int32 intToolNo, Int32 intValue);

THINC-API Release notes	©Okuma America Corporation,	Page 12 of 14
	2013	

THINC-API	Version:	S5015-003-22
Release Notes For Machining Center	Date: 09/25/2	2013

P300M P300SMP	CTools	String GetToolType(Int32 intToolNo)	
			ı

3.2.2 Command-API

The following functions have been modified to support data items on OSP-P300 control types.

Please refer to the help file for detail usage and compatibility information of each function.

OSP Control	Classes	Interfaces
P100II P200 P300M P300SMP	CATC	SetActualTool(ByVal intToolNo As Integer, Optional ByVal enToolAttribute As ToolAttributeEnum = ToolAttributeEnum.None)
P100II P200 P300M P300SMP	CATC	SetNextTool(ByVal intToolNo As Integer)
P100II P200 P300M P300SMP	CATC	RegisterToolPot(ByVal intPotNo As Integer, ByVal intToolNo As Integer)
P100II P200 P300M P300SMP	CATC	RegisterToolPot(ByVal intPotNo As Integer, ByVal intToolNo As Integer, ByVal enToolAttribute As ToolAttributeEnum)
P100II P200 P300M P300SMP	CATC	UnRegisterToolPot(ByVal intPotNo As Integer)

4. Known Bugs and Limitations

This section identifies known and existing problems in Release 1.16.0.0 and describes any work-arounds.

4.1 Defect

4.2 General Defect

DATA-API library, Okuma.CMDATAPI.dll, cannot create directly under VS2003 ASP.NET web application.

Solution/Work-arounds: Create and initialize DATA-API in a separate thread. All function calls must be called from objects created inside separated thread mentioned above.

DATA-API library can only support applications designed with single-threaded apartment of COM threading model.

Solution/Work-arounds: None

THINC-API Release notes	©Okuma America Corporation,	Page 13 of 14
	2013	

THINC-API	Version:	S5015-003-22
Release Notes For Machining Center	Date: 09/25/2	2013

4.2.1 Data-API

4.2.1.1 CAxis class

Function: AxisTypeEnum GetAxisType (AxisIndexEnum enValue)

Symptom: Failed to access machine data for YS axis. YS axis is available in NC-HMI.

Solution/Work around: None.

All functions having YS axis as input parameter are affected by GetAxisType function and fail to get/set NC data.

Function: String* GetAxisName (AxisIndexEnum enValue)

Symptom: Failed to access machine data for YS axis. YS axis is available in NC-HMI.

Solution/Work around: None.

4.2.1.2 CMOPTool class

Function: GetToolDataNumber(ByVal intToolNo As Integer, ByVal intClassNo As Integer) As Integer

Symptom: This function cannot get tool data number given tool number greater than 300.

Solution/Work around: None.

4.2.1.3 CSpindle class

Function: Double SpindleStateEnum GetSpindleState()

Symptom: Function return incorrect state - When machine is in Manual mode, the spindle is set to ORIENTATION mode.

NC-HMI and THINC-API library returns the same state. Then, machine mode is changed to either AUTO or MDI,

NC_HMI still report the same state as before, but THINC-API library reports spindle in stop mode.

Solution/Work around: None

4.3 Defects Fixed in this Release

None

THINC-API Release notes	©Okuma America Corporation,	Page 14 of 14
	2013	