Day 3: Autonomy

Before we begin:

- Revisit any substantial issues related to the communications homework.
- I have pushed my solutions to the branch post-homework2


While Goby is primarily a communications project, we want to be able to build autonomous systems with it. This is the second point of the robotics triad as I showed on the first day of the course.

(Switch to slides).

Frontseat/Backseat State machines


The state of the <code>goby_frontseat_interface</code> is effectively governed by the inferred state of the Helm (initially <code>phelmivp</code> from the MOOS-IvP project, but you could change this to your "helm" which we'll do in the homework), and the state of the frontseat system. Each driver must implement its interpretation of the frontseat states based on the manufacturer's interface.


Helm:



- park: Helm is running but not actively producing desired setpoints
- drive: Helm is in control


FrontSeat:





- idle: frontseat is on but not in a mission
- frontseat_mission: frontseat is running under manufacturer control (payload may be able to listen in on data feeds)
- accepting_commands: payload (Helm) is in control

goby_frontseat_interface:



- idle:standby: waiting on data from frontseat
- running:listen: not commanding frontseat (either frontseat is in control via frontseat_mission or helm is in park)
- running:command: payload is commanding frontseat (this is the typical operating state)
- error:helm: Helm has an error
- error:fs: Frontseat has an error.

Hands-on with goby_frontseat_interface

Let's turn the time warp off to see what's happening at a more reasonable pace.

```
# launch/trail/config/common/sim.py
warp=1
```

Then launch it

```
cd launch trail
./all.launch
```

Publish / subscribe interface

If we open the <code>goby_liaison</code> scope on the USV http://localhost:50001/? =/scope, we can see all the frontseat messages (<code>goby::middleware::frontseat::*</code> groups).

Let's look at these one at a time:

- data_from_frontseat: This is a message that encompasses all the data coming from the frontseat. As we're running the basic_simulator plugin, this just includes the node_status field (navigation), which is the minimum amount of data the frontseat needs to provide.
- desired_course: The desired heading and speed for the surface vehicle (from pHelmIvP). This is converted into a full command request which we'll look at in a bit.
- helm_state: The state of the Helm (DRIVE or PARK).
- node_status: The node_status field (when set) of data_from_frontseatis also published on this variable as a convenience.
- raw_in: The raw data in to the payload from the frontseat in whatever format the frontseat/backseat interface uses (e.g. NMEA-0183, custom protocol, etc.).
- raw out: The raw data sent from the payload to the frontseat.
- **status**: The state of goby_frontseat_interface, the frontseat state, and the helm state aggregated into a single message.

The full API contains a few more messages:

```
# all scheme: PROTOBUF so that's removed for clarity here.
# also namespaces removed
application: goby frontseat interface
interprocess:
  publishes:
    # response (ack) to command request messages that have response requested: true
    - group: command response
      type: protobuf::CommandResponse
     thread: FrontSeatInterface
    - group: data_from_frontseat
      type: protobuf::InterfaceData
     thread: FrontSeatInterface
    - group: node_status
      type: protobuf::NodeStatus
      thread: FrontSeatInterface
    - group: raw in
     type: protobuf::Raw
      thread: FrontSeatInterface
    - group: raw_out
     type: protobuf::Raw
      thread: FrontSeatInterface
    - group: status
      type: protobuf::InterfaceStatus
      thread: FrontSeatInterface
    - group: helm state
```

```
type: HelmStateReport
    thread: FrontSeatTranslation
subscribes:
  # full command message (can include vehicle-specific extensions)
  - group: command request
    type: protobuf::CommandRequest
    thread: FrontSeatInterface
  - group: data to frontseat
    type: protobuf::InterfaceData
    thread: FrontSeatInterface
  - group: desired course
    type: protobuf::DesiredCourse
    thread: FrontSeatInterface
  - group: helm_state
    type: protobuf::HelmStateReport
    thread: FrontSeatInterface
  # "backdoor" for applications to send raw commands directly through to the frontseat
  # (generally for debugging or temporary new application development)
  - group: raw send request
    type: protobuf::Raw
    thread: FrontSeatInterface
  - group: node_status
    type: protobuf::NodeStatus
    thread: FrontSeatTranslation
```

Basic Simulator driver

Now let's take a look at a simple implementation of a driver.

Each driver is an implementation of goby::middleware::frontseat::InterfaceBase in middleware/frontseat/interface.h.

The driver must implement five virtual methods:

```
// goby3/src/middleware/frontseat.h
    virtual void send_command_to_frontseat(const protobuf::CommandRequest& command) = 0;
    virtual void send_data_to_frontseat(const protobuf::InterfaceData& data) = 0;
    virtual void send_raw_to_frontseat(const protobuf::Raw& data) = 0;

    virtual protobuf::FrontSeatState frontseat_state() const = 0;
    virtual bool frontseat_providing_data() const = 0;
    virtual void loop() = 0;
```

• send_command_to_frontseat: Given a command from the payload (at a minimum this is the DesiredCourse: heading, speed, possibly depth, pitch, roll, and z_rate (dive rate)), convert this into a form to send to the frontseat and send it. This is called in response to data from the command request (or desired course) group.

- send_data_to_frontseat: Send some data to the frontseat. Not all drivers will have any meaningful data to provide to the frontseat, but this is here for cases when data from sensors attached to the payload is needed by the frontseat. For example if the payload has a USBL array and the frontseat needs that data to update its navigation estimate, the USBL data could be provided through this function. This is called in response to data from the data_to_frontseat group.
- send_raw_to_frontseat: Directly send a raw message to the frontseat. This is triggered by data from the raw send request group.
- **frontseat_state**: Must return the frontseat state, as inferred by the driver from messages received from the frontseat.
- **frontseat_providing_data**: Is the frontseat providing us data. This is vaguely defined to allow drivers to support a wide array of vehicles, but essentially this should be true if we're receiving the expected "core" data set, or false if we're not receiving anything (or not receiving the critical data messages).
- **loop** (): Called at 10 Hz.

Along with these virtual methods, the driver has access to a variety of signals (callbacks) it can or must trigger:

```
boost::signals2::signal<void(const protobuf::CommandResponse& data)> signal_command_response;
boost::signals2::signal<void(const protobuf::InterfaceData& data)> signal_data_from_frontseat;
boost::signals2::signal<void(const protobuf::Raw& data)> signal_raw_from_frontseat;
boost::signals2::signal<void(const protobuf::Raw& data)> signal_raw_to_frontseat;
```

- signal command response: Called by the driver when the frontseat responds (acks) a command
- signal data from frontseat: Called by the driver when the frontseat provides data.
- signal_raw_from_frontseat: Called by the driver for every raw message from the frontseat.
- signal raw to frontseat: Called by the driver when it sends a raw message to the frontseat.

The <code>goby_basic_frontseat_simulator</code> is a standalone C++ application that implements a very simple dynamic simulator combined with an ASCII payload API for use with <code>goby_frontseat_interface</code>.

The API is as follows:

```
> means message from goby_frontseat_interface (backseat) to goby_basic_frontseat_simulator (frontseat)
< means message from goby_basic_frontseat_simulator (frontseat) to goby_frontseat_interface (backseat)
- goby_basic_frontseat_simulator runs a TCP server.
- all messages are "\r\n" terminated

1. simulator init message (duration = 0 means no timeout) (duration, freq, accel, hdg_rate, z_rate, warp are optional)
FREQ = control loop frequency in hertz
ACCEL = vehicle acceleration in m/s
HDG_RATE = vehicle turn rate in deg/s
Z_RATE = vehicle dive rate in m/s
WARP = run this factor faster than real time
> START,LAT:42.1234,LON:-72,DURATION:600,FREQ:10,ACCEL:0.5,HDG_RATE:45,Z_RATE:1,WARP:1
2. frontseat state messages
```

```
sent after successful START command

< CTRL,STATE:PAYLOAD
    sent after DURATION is up in START command

< CTRL,STATE:IDLE

3. frontseat nav command
    generated from primitive dynamics model

< NAV,LAT:42.1234,LON:-72.5435,DEPTH:200,HEADING:223,SPEED:1.4

4. backseat desired course command


> CMD,HEADING:260,SPEED:1.5,DEPTH:100


5. frontseat response to backseat CMD
    CMD is good

< CMD,RESULT:OK
    error in the CMD

< CMD,RESULT:ERROR</pre>
```

Given this, we can see how the implementation of the driver is done. We can examine the code (goby3/src/middleware/frontseat/simulator/basic/basic_simulator_frontseat_driver.*) while we look at this sequence diagram:






The goby_frontseat_interface requires exactly one driver, defined a shared library path in the environmental variable FRONTSEAT DRIVER LIBRARY.

For convenience, we build wrapper scripts, such as <code>goby_frontseat_interface_basic_simulator</code>, which is simply defined (on my computer) as

```
> cat $(which goby_frontseat_interface_basic_simulator)
#!/bin/bash
LD_LIBRARY_PATH=/home/toby/goby3/build/lib:${LD_LIBRARY_PATH}
FRONTSEAT_DRIVER_LIBRARY=libgoby_frontseat_basic_simulator.so.30 exec goby_frontseat_interface $@
```

Graphically, this is how the plugin model works:




Goby / MOOS interface


pHelmIvP (in the open source MOOS-IvP project) is a useful multi-objective (e.g. heading, speed, depth) behavior-based decision engine (or "robotic captain" if you're so inclined). Since it's based on the MOOS middleware, we have to create a "bridge" to couple the MOOS middleware to the Goby3 interprocess layer. We do this by defining <code>goby::moos::Translator</code> threads, and running them either directly within any MultiThreadApplication, or with the <code>goby moos gateway</code> application.

goby::moos::Translator

goby::moos::Translator is a shorthand (typedef) for
BasicTranslator<goby::middleware::SimpleThread>. In short, it's a Goby Thread containing a
CMOOSCommClient, which roughly the equivalent in MOOS to a Goby InterProcessPortal.



You can have multiple Translators within a given application for different purposes if you want:




Let's take a look at the interface for the BasicTranslator https://goby.software/3.0/classgoby 1 1moos 1 1BasicTranslator.html:

```
SimpleThread<goby::apps::moos::protobuf::GobyMOOSGatewayConfig>& goby()
std::string translator_name()
MOOSInterface& moos()
void loop()
```

Pretty straightforward: when we want to get call Goby stuff we call **goby ()** and MOOS stuff is in **moos ()**. The Goby side we should be fairly familiar at this point. On the MOOS side we have a few options:

Now that we have that, let's look at it in action with the **FrontSeatTranslation** that interfaces the core **PHelmIvP** messages with Goby. This resides in

goby3/src/moos/middleware/frontseat/frontseat_gateway_plugin.h.




Much like goby_frontseat_interface, goby_moos_gateway uses an environmental variable (GOBY_MOOS_GATEWAY_PLUGINS) to load a list of plugin libraries (delimited by any of ";;,"), for example:

```
GOBY_MOOS_GATEWAY_PLUGINS=liblamss_goby3_gateway_plugin.so.0:libgoby_coroner_moos_gateway_plugin.so.

30 goby_moos_gateway
```

Since FrontSeatTranslation is just a Goby Thread, we can simplify this for a common scenario by also including it in goby_frontseat_interface. This is done if we include the [goby.moos.protobuf.moos_helm] {} block of the goby_frontseat_interface configuration (see goby_frontseat_interface_basic_simulator --example_config).

In this case (which is what we're running in the Trail example), the structure looks like this:



Command pHelmIvP through Goby

Yesterday, I had you add a command message from the topside to the USV. Now we'll walk through how to get that command over to pHelmIvP and actually change the vehicle's behavior.

First let's take a look at the command message that I designed (yours may look slightly different):

```
// src/lib/messages/command_dccl.proto
syntax = "proto2";
import "dccl/option_extensions.proto";
package goby3_course.dccl;
```

```
message USVCommand
{
    option (.dccl.msg) = {
       codec_version: 3
       id: 126
       max bytes: 32
        unit_system: "si"
    };
    required double time = 1 [(.dccl.field) = {
       codec: "dccl.time2",
       units {derived_dimensions: "time"}
    11:
    enum AutonomyState
        WAYPOINTS = 1;
       POLYGON = 2;
    required AutonomyState desired_state = 2;
    optional int32 polygon sides = 3 [(.dccl.field) = {min: 3 max: 10}];
    optional int32 polygon radius = 4
        [(.dccl.field) = {min: 100 max: 2000 precision: -1}];
}
```

Now in goby3_course_usv_manager I've subscribed to this message coming from the topside:

Let's run this and see how it works. First let's enable VERBOSE glog output on the USV manager:

```
# usv.launch
# ...
goby3_course_usv_manager <(config/usv.pb.cfg.py goby3_course_usv_manager) -v -n</pre>
```

Then run the code:

```
goby_launch -P topside.launch
goby3_course_n_auvs=0 goby_launch -P usv.launch
screen -r usv.goby3_course_usv_manager
```


Then if we open Goby Liaison http://localhost:50000/? =/commander we can send the command.

After we wait until the next comms cycle, we get an ACK and we see the command show up at goby3 course usv manager.

We could now proceed in a few different ways:

- subscribe directly in our plugin on intervehicle to <u>usv_command</u>. This is a reasonable approach, though I've been finding it helpful to keep most of the intervehicle subscriptions to a single application.
- run the <code>goby::moos::Translator</code> subclass as a thread directly within <code>usvManager</code> (after converting <code>usvManager</code> to a MultiThreadApplication). Also a reasonable approach, and this is similar to how <code>goby_frontseat_interface</code> is handling the MOOS translations. It depends on how much you want to spread out or consolidate the entry/exit points between Goby and MOOS.
- republish the command on interprocess from goby3_course_usv_manager so we can subscribe to it from our goby moos gateway plugin (based on goby::moos::Translator).

We'll choose the last technique:



So, republish the command on **interprocess** within the USV:

```
// src/bin/manager/usv/app.cpp
void goby3_course::apps::USVManager::subscribe_commands()
{
    using goby3_course::groups::usv_command;
    auto on_command = [this](const USVCommand& command_msg) {
        // ...
        interprocess().publish<usv_command>(command_msg);
    };
}
```

Then, we can create our plugin library. We already have one (src/lib/moos_gateway/goby3_course_gateway_plugin.*) that is in use by the AUVs (to publish the usv_nav as a NODE_REPORT for the pHelmIvP trail behavior), so we can augment it with our additional data for the commands.

Let's add our new Translation thread:

```
#include "goby3-course/messages/command dccl.pb.h"
// src/lib/moos_gateway/goby3_course_gateway_plugin.cpp
extern "C"
    void goby3_moos_gateway_load(
        goby::zeromq::MultiThreadApplication<goby::apps::moos::protobuf::GobyMOOSGatewayConfig>*
            handler)
    1
 //...
        handler->launch thread<goby3 course::moos::CommandTranslation>();
    }
    void goby3 moos gateway unload(
        goby::zeromq::MultiThreadApplication<goby::apps::moos::protobuf::GobyMOOSGatewayConfig>*
           handler)
    {
 //...
        handler->join_thread<goby3_course::moos::CommandTranslation>();
}
// ...
goby3_course::moos::CommandTranslation::CommandTranslation(const
goby::apps::moos::protobuf::GobyMOOSGatewayConfig& cfg)
        : goby::moos::Translator(cfg)
{
    using goby3_course::dccl::USVCommand;
    using goby3_course::groups::usv_command;
    auto on_usv_command = [this](const USVCommand& command) {
        // send update first
        if (command.desired_state() == USVCommand::POLYGON)
            std::stringstream update_ss;
            update_ss << "polygon=radial::x=0,y=0,radius=" << command.polygon_radius()
                      << ",pts=" << command.polygon_sides();</pre>
```

Reference https://oceanai.mit.edu/ivpman/pmwiki/pmwiki.php?n=Helm.BehaviorLoiter for the Loiter behavior. Update the behavior file for the USV:

Add goby_moos_gateway to usv.launch:

```
# usv.launch

[env=LD_LIBRARY_PATH=${LD_LIBRARY_PATH}:$HOME/goby3-
course/build/lib,env=GOBY_MOOS_GATEWAY_PLUGINS=libgoby3_course_moos_gateway_plugin.so]
goby_moos_gateway <(config/usv.pb.cfg.py_goby_moos_gateway) -vv</pre>
```

And finally, add generation in usv.pb.cfg.py:

Now we can rerun the topside and the USV.

Open uMS to port 9001 to see what is published to the MOOSDB, and send a "WAYPOINTS" command from Liaison.

Let's bump up the WARP again:

```
# launch/trail/config/common/sim.py
warp=20
```

And then run it all: ./all.launch.