

Table 2. Instruction Set Summary

Mnemonic and Description	Instruction Code			
DATA TRANSFER	<u>'</u>			
MOV = Move:	76543210	76543210	76543210	76543210
Register/Memory to/from Register	100010dw	mod reg r/m		
Immediate to Register/Memory	1100011w	mod 0 0 0 r/m	data	data if w = 1
Immediate to Register	1 0 1 1 w reg	data	data if w = 1	
Memory to Accumulator	1010000w	addr-low	addr-high]
Accumulator to Memory	1010001w	addr-low	addr-high	
Register/Memory to Segment Register	10001110	mod 0 reg r/m		
Segment Register to Register/Memory	10001100	mod 0 reg r/m		
PUSH = Push:				
Register/Memory	11111111	mod 1 1 0 r/m		
Register	0 1 0 1 0 reg]		
Segment Register	0 0 0 reg 1 1 0			
POP = Pop:				
Register/Memory	10001111	mod 0 0 0 r/m		
Register	0 1 0 1 1 reg]		
Segment Register	0 0 0 reg 1 1 1]		
XCHG = Exchange:				
Register/Memory with Register	1000011w	mod reg r/m		
Register with Accumulator	1 0 0 1 0 reg]		
IN = Input from:				
Fixed Port	1110010w	port		
Variable Port	1110110w]		
OUT = Output to:				
Fixed Port	1110011w	port		
Variable Port	1110111w]		
XLAT = Translate Byte to AL	11010111]		
LEA = Load EA to Register	10001101	mod reg r/m		
LDS = Load Pointer to DS	11000101	mod reg r/m		
LES = Load Pointer to ES	11000100	mod reg r/m		
LAHF = Load AH with Flags	10011111]		
SAHF = Store AH into Flags	10011110]		
PUSHF = Push Flags	10011100			
POPF = Pop Flags	10011101			

Mnemonics © Intel, 1978



Table 2. Instruction Set Summary (Continued)

Mnemonic and	ble 2. Instruction Set Summary (Continued)			
Description	Instruction Code			
ARITHMETIC ADD = Add:	76543210	76543210	76543210	76543210
Reg./Memory with Register to Either	00000dw	mod reg r/m		
Immediate to Register/Memory	100000sw	mod 0 0 0 r/m	data	data if s: w = 01
Immediate to Accumulator	0000010w	data	data if w = 1]
ADC = Add with Carry:				
Reg./Memory with Register to Either	000100dw	mod reg r/m		
Immediate to Register/Memory	100000sw	mod 0 1 0 r/m	data	data if s: w = 01
Immediate to Accumulator	0001010w	data	data if w = 1]
INC = Increment:				
Register/Memory	1111111w	mod 0 0 0 r/m		
Register	0 1 0 0 0 reg]		
AAA = ASCII Adjust for Add	00110111			
BAA = Decimal Adjust for Add	00100111	j		
SUB = Subtract:		•		
Reg./Memory and Register to Either	001010dw	mod reg r/m		
Immediate from Register/Memory	100000sw	mod 1 0 1 r/m	data	data if s w = 01
Immediate from Accumulator	0010110w	data	data if w = 1]
SSB = Subtract with Borrow				
Reg./Memory and Register to Either	000110dw	mod reg r/m		
Immediate from Register/Memory	100000sw	mod 0 1 1 r/m	data	data if s w = 01
Immediate from Accumulator	000111w	data	data if w = 1]
DEC = Decrement:				-
Register/memory	1111111w	mod 0 0 1 r/m		
Register	01001 reg]		
NEG = Change sign	1111011w	mod 0 1 1 r/m		
CMP = Compare:				
Register/Memory and Register	001110dw	mod reg r/m		
Immediate with Register/Memory	100000sw	mod 1 1 1 r/m	data	data if s w = 01
Immediate with Accumulator	0011110w	data	data if w = 1]
AAS = ASCII Adjust for Subtract	00111111]		
DAS = Decimal Adjust for Subtract	00101111]		
MUL = Multiply (Unsigned)	1111011w	mod 1 0 0 r/m		
IMUL = Integer Multiply (Signed)	1111011w	mod 1 0 1 r/m		
AAM = ASCII Adjust for Multiply	11010100	00001010		
DIV = Divide (Unsigned)	1111011w	mod 1 1 0 r/m		
IDIV = Integer Divide (Signed)	1111011w	mod 1 1 1 r/m		
AAD = ASCII Adjust for Divide	11010101	00001010		
CBW = Convert Byte to Word	10011000			
CWD = Convert Word to Double Word	10011001			

Mnemonics © Intel, 1978

27



Table 2. Instruction Set Summary (Continued)

Mnemonic and Description	Instruction Code			
LOGIC	76543210	76543210	76543210	76543210
NOT = Invert	1111011w	mod 0 1 0 r/m		
SHL/SAL = Shift Logical/Arithmetic Left	110100vw	mod 1 0 0 r/m		
SHR = Shift Logical Right	110100vw	mod 1 0 1 r/m		
SAR = Shift Arithmetic Right	110100vw	mod 1 1 1 r/m		
ROL = Rotate Left	110100vw	mod 0 0 0 r/m		
ROR = Rotate Right	110100vw	mod 0 0 1 r/m		
RCL = Rotate Through Carry Flag Left	110100vw	mod 0 1 0 r/m		
RCR = Rotate Through Carry Right	110100vw	mod 0 1 1 r/m		
AND = And:				
Reg./Memory and Register to Either	001000dw	mod reg r/m		
Immediate to Register/Memory	1000000w	mod 1 0 0 r/m	data	data if w = 1
Immediate to Accumulator	0010010w	data	data if w = 1	
TEST = And Function to Flags, No Result:				
Register/Memory and Register	1000010w	mod reg r/m		
Immediate Data and Register/Memory	1111011w	mod 0 0 0 r/m	data	data if w = 1
Immediate Data and Accumulator	1010100w	data	data if w = 1	
OR = Or:				
Reg./Memory and Register to Either	000010dw	mod reg r/m		
Immediate to Register/Memory	1000000w	mod 0 0 1 r/m	data	data if w = 1
Immediate to Accumulator	0000110w	data	data if w = 1	
XOR = Exclusive or:				
Reg./Memory and Register to Either	001100dw	mod reg r/m		
Immediate to Register/Memory	1000000w	mod 1 1 0 r/m	data	data if w = 1
Immediate to Accumulator	0011010w	data	data if w = 1	
STRING MANIPULATION				
REP = Repeat	1111001z			
MOVS = Move Byte/Word	1010010w			
CMPS = Compare Byte/Word	1010011w			
SCAS = Scan Byte/Word	1010111w			
LODS = Load Byte/Wd to AL/AX	1010111W			
STOS = Stor Byte/Wd from AL/A	1010101w			
CONTROL TRANSFER		ı		
CONTROL TRANSFER CALL = Call:				
Direct within Segment	11101000	disp-low	disp-high	
Indirect within Segment	11111111	mod 0 1 0 r/m	alok man	
Direct Intersegment	10011010	offset-low	offset-high	
		seg-low	seg-high	
Indirect Intersegment	11111111	mod 0 1 1 r/m	0099	
		11100 0 1 117111	<u> </u>	

Mnemonics © Intel, 1978



Table 2. Instruction Set Summary (Continued)

Mnemonic and Description	Instruction Code		
JMP = Unconditional Jump:	76543210	76543210	76543210
Direct within Segment	11101001	disp-low	disp-high
Direct within Segment-Short	11101011	disp	
ndirect within Segment	11111111	mod 1 0 0 r/m	
lirect Intersegment	11101010	offset-low	offset-high
		seg-low	seg-high
direct Intersegment	11111111	mod 1 0 1 r/m	
ET = Return from CALL:			
Vithin Segment	11000011		
ithin Seg Adding Immed to SP	11000010	data-low	data-high
tersegment	11001011		
itersegment Adding Immediate to SP	11001010	data-low	data-high
Z/JZ = Jump on Equal/Zero	01110100	disp	
_/JNGE = Jump on Less/Not Greater or Equal	01111100	disp	
LE/JNG = Jump on Less or Equal/ Not Greater	01111110	disp	
/JNAE = Jump on Below/Not Above or Equal	01110010	disp	
BE/JNA = Jump on Below or Equal/ Not Above	01110110	disp	
P/JPE = Jump on Parity/Parity Even	01111010	disp	
D = Jump on Overflow	01110000	disp	
S = Jump on Sign	01111000	disp	
NE/JNZ = Jump on Not Equal/Not Zero	01110101	disp	
NL/JGE = Jump on Not Less/Greater or Equal	01111101	disp	
NLE/JG = Jump on Not Less or Equal/ Greater	01111111	disp	
NB/JAE = Jump on Not Below/Above or Equal	01110011	disp	
NBE/JA = Jump on Not Below or Equal/Above	01110111	disp	
NP/JPO = Jump on Not Par/Par Odd	01111011	disp	
IO = Jump on Not Overflow	01110001	disp	
NS = Jump on Not Sign	01111001	disp	
OOP = Loop CX Times	11100010	disp	
OOPZ/LOOPE = Loop While Zero/Equal	11100001	disp	
OOPNZ/LOOPNE = Loop While Not Zero/Equal	11100000	disp	
CXZ = Jump on CX Zero	11100011	disp	
NT = Interrupt			
pe Specified	11001101	type	
уре 3	11001100]	
NTO = Interrupt on Overflow	11001110]	
RET = Interrupt Return	11001111		



Table 2. Instruction Set Summary (Continued)

Mnemonic and Description	Instruction Code	
	76543210	76543210
PROCESSOR CONTROL		
CLC = Clear Carry	11111000	
CMC = Complement Carry	11110101	
STC = Set Carry	11111001	
CLD = Clear Direction	11111100	
STD = Set Direction	11111101	
CLI = Clear Interrupt	11111010	
STI = Set Interrupt	11111011	
HLT = Halt	11110100	
WAIT = Wait	10011011	
ESC = Escape (to External Device)	11011xxx	mod x x x r/m
LOCK = Bus Lock Prefix	11110000	

NOTES:

AL = 8-bit accumulator AX = 16-bit accumulator

CX = Count register

DS = Data segment ES = Extra segment Above/below refers to unsigned value

Greater = more positive;

Less = less positive (more negative) signed values if d=1 then "to" reg; if d=0 then "from" reg if w=1 then word instruction; if w=0 then byte instruction

if mod = 11 then r/m is treated as a REG field

if mod = 00 then DISP = 0*, disp-low and disp-high are absent

if mod = 01 then DISP = disp-low sign-extended to 16 bits, disp-high is absent

if mod = 10 then DISP = disp-high; disp-low if r/m = 000 then EA = (BX) + (SI) + DISP if r/m = 001 then EA = (BX) + (DI) + DISP if r/m = 001 then EA = (BP) + (SI) + DISP if r/m = 010 then EA = (BP) + (SI) + DISP

if r/m = 011 then EA = (BP) + (DI) + DISP if r/m = 100 then EA = (SI) + DISP if r/m = 101 then EA = (DI) + DISP

if r/m = 110 then EA = (BP) + DISP*

if r/m = 111 then EA = (BX) + DISP DISP follows 2nd byte of instruction (before data if required)

*except if mod = 00 and r/m = 110 then EA = disp-high;

DATA SHEET REVISION REVIEW

disp-low.

Mnemonics © Intel, 1978

- if s w = 01 then 16 bits of immediate data form the operand
- if s w = 11 then an immediate data byte is sign extended to form the 16-bit operand
- if v=0 then "count" = 1; if v=1 then "count" in (CL) x= don't care
- z is used for string primitives for comparison with ZF FLAG

SEGMENT OVERRIDE PREFIX

001 reg 110

REG is assigned according to the following table:

16-Bit (w = 1)	8-Bit (w = 0)	Segment
000 AX	000 AL	00 ES
001 CX	001 CL	01 CS
010 DX	010 DL	10 SS
011 BX	011 BL	11 DS
100 SP	100 AH	
101 BP	101 CH	
110 SI	110 DH	
111 DI	111 BH	

Instructions which reference the flag register file as a 16-bit object use the symbol FLAGS to represent the file: $\mathsf{FLAGS} \ = \ \mathsf{X} : \mathsf{X} : \mathsf{X} : \mathsf{X} : \mathsf{(OF)} : \mathsf{(DF)} : \mathsf{(IF)} : \mathsf{(SF)} : \mathsf{(SF)} : \mathsf{X} : \mathsf{(AF)} : \mathsf{X} : \mathsf{(PF)} : \mathsf{X} : \mathsf{(CF)}$

The following list represents key differences between this and the -004 data sheet. Please review this summary carefully.

- 1. The Intel 8086 implementation technology (HMOS) has been changed to (HMOS-III).
- 2. Delete all "changes from 1985 Handbook Specification" sentences.