Chapter 2 Instructions: Language of the Computer

Computer Architecture (Spring 2016)

Instruction Set

- Instruction = Language of the Machine
 - More primitive than higher level languages
 (ex) no sophisticated control flow
 - Very restrictive (ex) limited number of operands
- Instruction Set = the repertoire of instructions of a computer
- Different *ISA* have different instruction sets
 - But many aspects are found common
- Complexity of the instruction set
 - Early computers had very simple (limited) instruction sets
 - Instruction sets had become more complex ⇒ CISC(Complex Instruction Set Computer)
 - Many modern computers also have simple instruction sets ⇒ RISC(Reduced Instruction Set Computer)

2.1 Introduction 컴퓨터구조 2-2

The MIPS Instruction Set

- Used as the example throughout the book
- Stanford MIPS commercialized by MIPS Technologies
 - Typical of many modern ISAs
- Large share of embedded core market
 - Applications in consumer electronics, network/storage equipment, cameras, printers, ...
- Operands
 - 32 registers
 - -2^{30} memory words
- Operations (refer to the textbook)
 - Arithmetic operations

–

 2.1 Introduction
 컴퓨터구조
 2-3

Arithmetic Instructions

- Add and subtract, three operands
 - Two sources and one destination
- An Example
 - C code

$$a = b + c$$
;

- MIPS instruction

add a, b, c # a gets b + c

2.2 Operations of the Computer Hardware

컴퓨터구조 2-4

Design Principle 1

- *Simplicity favors regularity*
 - Regularity makes implementation simpler
 - Simplicity enables higher performance at lower cost
- Why?
 - It helps make hardware design simple

2.2 Operations of the Computer Hardware

컴퓨터구조 2-5

Arithmetic Instructions: Example

C code

$$f = (g + h) - (i + j);$$

Compiled MIPS code

```
add t0, g, h # temp t0 = g + h
add t1, i, j # temp t1 = i + j
sub f, t0, t1 # f = t0 - t1
```

2.2 Operations of the Computer Hardware

Register Operands

- Arithmetic instructions use register operands
- MIPS has a 32×32 -bit register file
 - Used for frequently accessed data
 - Numbered as 0 to 31
 - 32-bit data called a "word"
- Assembler names
 - \$t0, \$t1, ..., \$t9 for temporary values
 - \$s0, \$s1, ..., \$s7 for saved variables

2.3 Operands of the Computer Hardware

컴퓨터구조 :

2-7

Register Operands: Example

C code:

$$f = (g + h) - (i + j);$$

- f, g, h, i, j are kept in \$s0, \$s1, \$s2, \$s3, and \$s4
- Compiled MIPS code:

```
add $t0, $s1, $s2  # temp $t0 = g + h add $t1, $s3, $s4  # temp <math>$t1 = i + j sub $s0, $t0, $t1  # f = $t0 - $t1
```

2.3 Operands of the Computer Hardware

컴퓨터구조

2-8

Design Principle 2

- Smaller is faster
 - Only 32 registers are provided
 - A small register set brings fast execution
 cf. main memory: millions of locations
- Why?
 - It helps execute individual instructions faster
 - A large register set increases the clock cycle time

2.3 Operands of the Computer Hardware

컴퓨터구조

2 0


Memory Operands

- Main memory used for composite data
 - Arrays, structures, dynamic data
- To execute arithmetic operations in registers, we have to
 - Load values from memory into registers
 - Store result from register to memory
- Memory is *byte addressed*
 - Each address identifies an 8-bit byte
- Words are *aligned* in memory
 - Address must be a multiple of 4
- MIPS is *Big Endian*
 - Most-significant byte is stored at the least (first) address of a word

cf. Little Endian: least-significant byte at least address

2.3 Operands of the Computer Hardware


Byte Addressing



2.3 Operands of the Computer Hardware

컴퓨터구조 2-11

Big Endian vs. Little Endian



2.3 Operands of the Computer Hardware

2-12

Memory Operands: Example 1

C code:

$$g = h + A[8];$$

■ Compiled MIPS code:

```
Iw $t0, 32($s3)  # load word, A[8]
add $s1, $s2, $t0
```

2.3 Operands of the Computer Hardware

컴퓨터구조 2-13

Memory Operands: Example 2

C code:

$$A[12] = h + A[8];$$

■ Compiled MIPS code:

```
Iw $t0, 32($s3)  # load word
add $t0, $s2, $t0
sw $t0, 48($s3)  # store word
```

2.3 Operands of the Computer Hardware

Registers vs. Memory Operand

- Registers are faster to access than memory
- Operating on memory data requires loads and stores
 - More instructions to be executed
- Compiler must use registers for variables as much as possible
 - Only spill to memory for less frequently used variables
 - Register optimization is important!

2.3 Operands of the Computer Hardware

컴퓨터구조 2-15

Immediate Operands

• C code of using a constant 4

$$g = g + 4;$$

■ With an immediate operand

■ Without an immediate operand

2.3 Operands of the Computer Hardware

Utilizing Immediate Operands

- No 'subtract immediate' instruction
 - Just use a negative constant

```
addi $s2, $s1, -1
```

- MIPS register 0 (\$zero) is reserved to keep the constant 0
 - Hardwired to the value zero
 - Cannot be overwritten
- Utilizing the 'constant zero'
 - No additional 'move' instruction to move between registers

```
add $t2, $s1, $zero
```

컴퓨터구조 2-17

Another Design Principle

- Make the common case fast
 - Small constants are common
 - Immediate operand avoids a load instruction

```
Iw $t0, AddrConstant4($s1)
add $s3, $s3, $t0
... ...
somewhere: 4 # AddrConstant4($s1)
```

2.3 Operands of the Computer Hardware

Unsigned Binary Integers

■ Given an n-bit number

$$x = x_{n-1}2^{n-1} + x_{n-2}2^{n-2} + \dots + x_12^1 + x_02^0$$

- Range: $0 \text{ to } +2^{n}-1$
 - Case of 32 bits: 0 to +4,294,967,295
- Example
 - $\begin{array}{l} -\ 0000\ 0000\ 0000\ 0000\ 0000\ 0000\ 0000\ 1011_2 \\ = 0+\ldots+1\times2^3+0\times2^2+1\times2^1+1\times2^0 \\ = 0+\ldots+8+0+2+1=11_{10} \end{array}$

2.4 Signed and Unsigned Numbers

컴퓨터구조 2-19

Signed Binary Integers

■ Given an n-bit number

$$x = -x_{n-1}2^{n-1} + x_{n-2}2^{n-2} + \dots + x_12^1 + x_02^0$$

- Range: -2^{n-1} to $+2^{n-1}-1$
 - Case of 32 bits:-2,147,483,648 to +2,147,483,647
- Bit 31 is sign bit with 2's complement representation
 - 1 for negative numbers
- Example
 - $\begin{array}{l} -1111\ 1111\ 1111\ 1111\ 1111\ 1111\ 1111\ 1111\ 11100_2\\ =-1\times2^{31}+1\times2^{30}+\ldots+1\times2^2+0\times2^1+0\times2^0\\ =-2,147,483,648+2,147,483,644=-4_{10}\\ \hline \\ \textit{cf.}\ 1111\ 1111\ 1111\ 1111\ 1111\ 1111\ 1111\ 1111\ 1111\ 1111\ 1111\ 11100_2\\ =-\left(2^{32}-\left(1\times2^{31}+1\times2^{30}+\ldots+1\times2^2+0\times2^1+0\times2^0\right)\right)\\ =-1\times2^{31}+1\times2^{30}+\ldots+1\times2^2+0\times2^1+0\times2^0\\ \end{array}$

2.4 Signed and Unsigned Numbers

Sign Extension

- Representing a number using more bits
 - Preserve the numeric value
- Example cases
 - addi : extend immediate value
 - I b, I h: extend loaded byte/halfword
 - beg, bne: extend the displacement
- Replicate the sign bit to the left *cf.* unsigned values are extended with 0s
- Examples: 8-bit to 16-bit
 - +2: 0000 0010 => 0000 0000 0000 0010
 - -2: 1111 1110 => 1111 1111 1111 1110

2.4 Signed and Unsigned Numbers

컴퓨터구조 2-21

Instruction Formats

- Instructions are kept in the computer
- Instructions are encoded in binary
 - Each piece can be considered as an individual number
- Registers are referred as another number
 - \$t0 ~ \$t7 are registers 8 ~ 15
 - \$t8 \sim \$t9 are registers 24 \sim 25
 - \$s0 ~ \$s7 are registers $16 \sim 23$
- *Instruction format*
 - Layout of the instruction
 - Instruction formats encodes operation code (opcode) and operands kept in a register or memory
 - All MIPS instructions are 32 bits long (the same length as data)
 - Regularity!

2.5 Representing Instructions in the Computer

컴퓨터구조 2-22

R-format Instructions



- Instruction fields
 - op: operation code (opcode)
 - rs: first source register number
 - rt: second source register number
 - rd: destination register number
 - shamt: shift amount (00000 for now)
 - funct: <u>function</u> code (extends opcode)

2.5 Representing Instructions in the Computer

컴퓨터구조 2-23

R-format Instructions: Example

ор	rs	rt	rd	shamt	funct
6 bits	5 bits	5 bits	5 bits	5 bits	6 bits

add \$t0, \$s1, \$s2

special	\$s1	\$s2	\$t0	0	add
0	17	18	8	0	32
000000	10001	10010	01000	00000	100000

0000 0010 0011 0010 0100 0000 0010 0000 $_2$ = 02324020 $_{16}$


2.5 Representing Instructions in the Computer

I-format Instructions



- Immediate arithmetic and load/store instructions
 - rt: destination or source register number
 - Constant: -2^{15} to $+2^{15}-1$
 - Address: offset added to base address in rs

addi \$s2, \$s3, 4



Iw \$s2, 4(\$s3)

I w	\$s3	\$s2	4

2.5 Representing Instructions in the Computer

컴퓨터구조 2-25


Design Principle 3

- Good design demands good compromises
 - Keep all instructions the same length
 - Allow different formats for different kinds of instructions
 - Different formats may complicate decoding
- Considerations
 - Keep formats as similar as possible

2.5 Representing Instructions in the Computer

'Stored Program' Computers





- Instructions are represented as numbers
- Programs are stored in memory to be read or written, just like data
- Programs are shipped as files of binary numbers
- Binary compatibility allows compiled programs to work on different computers

2.5 Representing Instructions in the Computer

컴퓨터구조 2-27

Logical Instructions

	special	rs	rt	rd	shamt	funct
Ī	6 bits	5 bits	5 bits	5 bits	5 bits	6 bits

Instructions for bitwise manipulation

Operation	С	Java	MIPS
Shift left	<<	<<	sH
Shift right	>>	>>>	srl
Bitwise AND	&	&	and, andi
Bitwise OR			or, ori
Bitwise NOT	~	~	nor

Useful for extracting and inserting groups of bits in a word

2.6 Logical Operations

AND Instruction

- Useful to mask bits in a word
 - Select some bits, clear others to 0

```
and $t0, $t1, $t2
```

- \$t2 | 0000 0000 0000 0000 1101 1100 0000
- \$t1 | 0000 0000 0000 0000 0011 1100 0000 0000
- \$t0 | 0000 0000 0000 0000 1100 0000 0000

2.6 Logical Operations

컴퓨터구조 2-29

OR Instruction

- Useful to include bits in a word
 - Set some bits to 1, leave others unchanged

- \$t2 | 0000 0000 0000 0000 1101 1100 0000
- \$t1 | 0000 0000 0000 0000 0011 1100 0000 0000
- \$t0 | 0000 0000 0000 0001 1100 0000 0000

2.6 Logical Operations

NOT Instruction

- Useful to invert bits in a word
 - Change 0 to 1, and 1 to 0
- MIPS has 3-operand NOR instruction
 - a NOR b == NOT (a OR b)
 - a NOR 0 == NOT (a OR 0) = NOT a

nor \$t0, \$t1, \$zero

\$t1 | 0000 0000 0000 0000 0011 1100 0000 0000

\$t0 | 1111 1111 1111 1100 0011 1111 1111

2.6 Logical Operations

컴퓨터구조 2-31

Shift Instructions



- Shift amout (shamt)
 - Specifies how many positions to shift
- Shift left logical
 - Shift left and fill with 0 bits
 - sII by *i* bits multiplies by 2^i
- Shift right logical
 - Shift right and fill with 0 bits
 - srI by *i* bits divides by 2^i (unsigned only)

2.6 Logical Operations

컴퓨터구조 2-32

Branch Instruction & Jump Instruction

- Moves the control to another location
- Conditional operation (control transfer)
 - Depends on the condition
 - if (rs == rt) branch to instruction labeled L1

if (rs != rt) branch to instruction labeled L1

- Unconditional operation (control transfer)
 - unconditional jump to instruction labeled L1


2.7 Instruction for Making Decisions

컴퓨터구조 2-33

Compiling If Statements

C code

- Register usage
 - f,g,h \rightarrow \$s0, \$s1, \$s2
 - $-i,j \rightarrow $s3,$s4$



Compiled MIPS code

```
bne $s3, $s4, Else # i != j ?
add $s0, $s1, $s2 # f = g-h
j Exit
Else: sub $s0, $s1, $s2 # f = g+h
Exit: ...
```

2.7 Instruction for Making Decisions

컴퓨터구조 2-34

Compiling Loop Statements

C code

```
while (save[i] == k) i += 1;
```

■ Compiled MIPS code:


```
Loop: sll $t1, $s3, 2
add $t1, $t1, $s6
lw $t0, 0($t1)
bne $t0, $s5, Exit
addi $s3, $s3, 1
j Loop
Exit: ...
```

2.7 Instruction for Making Decisions

컴퓨터구조 2-35

Basic Blocks

- A basic block is a sequence of instructions with
 - No embedded branches (except at end)
 - No branch targets (except at beginning)
- A compiler breaks the program into the basic blocks



 An advanced processor can utilize the basic block for optimization purpose

2.7 Instruction for Making Decisions

컴퓨터구조 2-36

Why Limited Branch Instructions?

- Both beg and bne are the common case
- Why not bl t, bge, etc?
- Hardware for <, \ge , ... slower than =, \ne
 - Combining with branch involves more work per instruction, requiring a slower clock
 - All instructions penalized!
- This is a good design compromise

2.7 Instruction for Making Decisions

컴퓨터구조 2-37

Test Instructions

- Test for equality
 - Set result to 1 if a condition is true
 - Otherwise, set to 0
 - if (rs < rt) rd = 1; else rd = 0;

```
slt rd, rs, rt
```

- if (rs < constant) rt = 1; else rt = 0;

```
slti rt, rs, constant
```

■ Typical example of using the test instruction

```
slt $t0, $s1, $s2  # if ($s1 < $s2)
bne $t0, $zero, L  # branch to L
```

2.7 Instruction for Making Decisions

컴퓨터구조 2-38

Signed vs. Unsigned Test Instructions

- Signed comparison: sl t, sl ti
- Unsigned comparison: sl tu, sl tui
- Example
 - $\$s0 = 1111 \ 1111 \ 1111 \ 1111 \ 1111 \ 1111 \ 1111$
 - $\$s1 = 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0001$
 - slt \$t0, \$s0, \$s1 assigns 1 to \$t0
 - sl tu \$t0, \$s0, \$s1 assigns 0 to \$t0

2.7 Instruction for Making Decisions

컴퓨터구조 2-39

Supporting Procedures in Hardware

- Six steps to support procedures
 - 1. Place parameters in a place where the procedure can access them (\$a0-\$a3)
 - 2. Transfer control to the procedure (jal ProcedureAddress)
 - 3. Acquire the storage resources needed for the procedure
 - 4. Perform the desired task
 - 5. Release the acquired storage resources
 - 6. Place the result value in a place where the calling program can access it (\$v0-\$v1)
 - 7. Return control to the point of origin (jr \$ra)

2.8 Supporting Procedures in Computer Hardware

Register Usage Convention

Registers	Usage	Remark
\$a0-\$a3	Arguments	
\$v0, \$v1	Result values	
\$t0-\$t9	Temporaries	Can be overwritten by called
\$s0 - \$s7	Saved	Must be saved/restored by callee
\$gp	Global pointer for static data	
\$sp	Stack pointer	
\$fp	Frame pointer	
\$ra	Return address	

2.8 Supporting Procedures in Computer Hardware

컴퓨터구조 2-41

Procedure Call Instructions

■ Procedure call: jump and link

jal ProcedureLabel

- Puts the address of following instruction (program counter) in \$ra
- Jumps to target address
- Procedure return: jump register

jr \$ra

- Copies \$ra to program counter
- Can also be used for computed jumps (ex) case/switch statements

2.8 Supporting Procedures in Computer Hardware

Leaf Procedure Example

C code

```
int leaf_example (int g, h, i, j)
{    int f;
    f = (g + h) - (i + j);
    return f;
}
```

- Register usage
 - Arguments g, ..., j in \$a0, ..., \$a3
 - f in \$s0 (hence, need to save \$s0 on stack)
 - Result in \$v0

2.8 Supporting Procedures in Computer Hardware

컴퓨터구조 2-43

Leaf Procedure Example

MIPS code

```
leaf_example:
    addi $sp, $sp, -4
    sw $s0, 0($sp)
    add $t0, $a0, $a1
    add $t1, $a2, $a3
    sub $s0, $t0, $t1
    add $v0, $s0, $zero
    lw $s0, 0($sp)
    addi $sp, $sp, 4
    jr $ra
```

2.8 Supporting Procedures in Computer Hardware

Non-Leaf Procedures

- Procedures that call other procedures
- For nested call, caller needs to save on the stack:
 - Its return address
 - Any arguments and temporaries needed after the call
- Restore from the stack after the call

2.8 Supporting Procedures in Computer Hardware

컴퓨터구조 2-45

Non-Leaf Procedure Example

C code

```
int fact (int n)
{
  if (n < 1) return 1;
  else return n * fact(n - 1);
}</pre>
```

- Register usage
 - Argument n in \$a0
 - Result in \$v0

2.8 Supporting Procedures in Computer Hardware

Non-Leaf Procedure Example


MIPS code

```
fact:
       addi $sp, $sp, -8
                             # adjust stack for 2 items
            $ra, 4($sp)
                             # save return address
       SW
            $a0, 0($sp)
                             # save argument
       slti $t0, $a0, 1
                             \# test for n < 1
       beq
            $t0, $zero, L1
       addi $v0, $zero, 1
                             # if so, result is 1
       I w
            $a0, 0($sp)
       I w
            $ra, 4($sp)
       addi $sp, $sp, 8
                                 pop 2 items from stack
       jr
            $ra
                                 and return
       addi $a0, $a0, -1
 L1:
                             # else decrement n
       j al
            fact
                                 recursive call
            $a0, 0($sp)
                               restore original n
      I w
      I w
            $ra, 4($sp)
                                and return address
      addi $sp, $sp, 8
                                 pop 2 items from stack
      mul
            $v0,
                $a0, $v0
                                 multiply to get result
      jr
            $ra
                                 and return
```

2.8 Supporting Procedures in Computer Hardware

컴퓨터구조 2-47

Local Data on the Stack




- Local data allocated by callee
 - Example: C automatic variables
- Procedure frame (activation record)
 - Used by some compilers to manage stack storage

2.8 Supporting Procedures in Computer Hardware

Memory Layout

- Text: program code
- Static data: global variables
 - static variables in C
 - constant arrays and strings
 - \$gp points to the middle of 64K block, which is combined with ±offsets for easy access
- Dynamic data: heap
 - malloc in C
 - new in Java
- Stack: local variables
 - saved registers



2.8 Supporting Procedures in Computer Hardware

컴퓨터구조 2-49

32-bit Immediate Operands

- 16-bit immediate constant
 - 16 bits are sufficient for most constants since they are small
- MIPS instruction to support 32-bit immediate constant

lui rt, constant

- Copies 16-bit constant to left 16 bits of rt
- Clears right 16 bits of rt to 0
- 32-bit immediate constant

2.9 MIPS Addressing for 32-bit Immediates and Addresses

Addressing in Branches

- Branch instructions specify
 - Opcode, two registers, target address
- Most branch targets are near branch
 - Forward or backward




- PC-relative addressing
 - Target address = $PC + offset \times 4$
 - PC already incremented by 4 by this time

2.9 MIPS Addressing for 32-bit Immediates and Addresses

컴퓨터구조 2-51

Addressing in Jumps

- Jump (j and j al) targets could be anywhere in text segment
 - Encode full address in instruction



- (Pseudo) Direct jump addressing
 - Target address = $PC_{31...28}$: (address × 4)

2.9 MIPS Addressing for 32-bit Immediates and Addresses

Target Addressing Example

- Loop code from earlier example
 - Assume Loop at location 80000

```
80000
Loop: sll
            $t1, $s3, 2
                                               19
                                                          4
                                                               0
           $t1, $t1, $s6
                             80004
                                               22
                                                          0
                                                              32
      add
                                      0
                                           9
                                                     9
            $t0, 0($t1)
                                                          0
      l w
                             80008
                                     35
                                                8
                                                          2
      bne $t0, $s5, Exit 80012
                                      5
                                           8
                                               21
      addi $s3, $s3, 1
                             80016
                                      8
                                          19
                                               19
                                                          1
            Loop
                             80020
                                                   20000
Exit: ...
                             80024
```

2.9 MIPS Addressing for 32-bit Immediates and Addresses

컴퓨터구조 2-53

Branching Far Away

- If branch target is too far to encode with 16-bit offset, assembler rewrites the code
- Example

```
beq $s0, $s1, L1

bne $s0, $s1, L2

j L1


L2: ...
```

2.9 MIPS Addressing for 32-bit Immediates and Addresses

컴퓨터구조 2-54

Addressing Mode Summary (1)


1. Immediate addressing



2. Register addressing



3. Base addressing




2.9 MIPS Addressing for 32-bit Immediates and Addresses


컴퓨터구조 2-55

Addressing Mode Summary (2)

4. PC-relative addressing



5. Pseudodirect addressing



2.9 MIPS Addressing for 32-bit Immediates and Addresses

x86 Addressing Modes

■ Two operands per instruction


Source/dest operand	Second source operand	
Register	Register	
Register	Immediate	
Register	Memory	
Memory	Register	
Memory	Immediate	

- Memory addressing modes
 - Address in register
 - Address = R_{base} + displacement
 - Address = $R_{\text{base}}^{\text{scale}} + 2^{\text{scale}} \times R_{\text{index}} \text{ (scale = 0, 1, 2, or 3)}$
 - $Address = R_{base} + 2^{scale} \times R_{index} + displacement$

2.15 Real Stuff: x86 instructions

컴퓨터구조 2-57

x86 Instruction Encoding



2.15 Real Stuff: x86 instructions

컴퓨터구조 2-58

Fallacies on Instruction Set


- Powerful instruction \Rightarrow higher performance
 - Fewer instructions required
 - But complex instructions are hard to implement and may slow down all instructions, including simple ones
 - Compilers are good at making fast code from simple instructions
- Use assembly code for high performance
 - But modern compilers are better at dealing with modern processors
 - More lines of code ⇒ more errors and less productivity

2.17 Fallacies and Pitfalls

컴퓨터구조 2-59

Fallacies on Instruction Set

- Binary compatibility ⇒ instruction set doesn't change
 - Backwards binary compatibility is just okay
 - So the architecture has grown dramatically



2.17 Fallacies and Pitfalls

Pitfalls

- With byte addressing, sequential 'word addresses' do not increment by one
 - Increment by 4 with 32 bit words
 - Even with byte addressing, word addresses are unavoidable
- Using a pointer to an automatic variable outside its defined procedure
 - To pass back a pointer to an array that is local to some procedure after leaving the procedure
 - Pointer becomes invalid when stack popped

2.17 Fallacies and Pitfalls 컴퓨터구조 2-61