



https://de.aliexpress.com/item/4000200361035.html

Holes: 55mm x 38.5mm





Copyright Gorm Rose 2022.

This documentation describes Open Hardware and is licensed


SSH1106 128X64 1.3 I2C DISPLAY MODULE


You may redistribute and modify this documentation under the terms of the CERN-OHL-S-2.0. (http://ohwr.org/cernohl). This documentation is distributed WITHOUT ANY EXPRESS OR IMPLIED WARRANTY, INCLUDING OF MERCHANTABILITY, SATISFACTORY QUALITY AND FITNESS FOR A PARTICULAR PURPOSE. Please see the CERN-OHL-S-2.0 for applicable conditions.


TITLE: **Controller of Water Heater** REV: 1.1 Companyhttps://github.com/gormr Sheet: 1/2 **EasyEDA** Date: 2022-12-06 Drawn By: GoRoNb

under the CERN-OHL-S-2.0.


Three Phase Setup








Single Phase Setup







Triac with Mounting Plate, Temperature Sensor and Flow Meter

Low voltage

non-insulated


Example uses ST BTA40-600 Triac with Mounting Plate, Temperature Sensor and Flow Meter

Mounting Plate must be connected to Protective Earth!

Unmount all inner and outer plastic parts before soldering the mounting plate in the signal wire: Lx/A1

purple power wire + signal wire: Lx/A1

purple power wire + blue signal wire: A2



TITLE:

EasyEDA

the terms of the CERN-OHL-S-2.0. (http://ohwr.org/cernohl). This documentation is distributed WITHOUT ANY EXPRESS OR IMPLIED WARRANTY, INCLUDING OF MERCHANTABILITY, SATISFACTORY QUALITY AND FITNESS FOR A PARTICULAR PURPOSE. Please see the

Companyhttps://github.com/gormr

Date: 2022-12-06 Drawn By: GoRoNb

REV: 1.1

Sheet: 2/2

CERN-OHL-S-2.0 for applicable conditions.

AC Interface of Water Heater

Triac Driver / Zero Cross Detection