Cache Memory

BIT211: Computer Systems Organization



Characteristics

- Location
- Capacity
- Unit of transfer
- Access method
- Performance
- Physical type
- Physical characteristics
- Organisation



Location

- CPU
- Internal
- External



- Word size
 - The natural unit of organisation
- Number of words
 - or Bytes



Unit of Transfer

- Internal
 - Usually governed by data bus width
- External
 - Usually a block which is much larger than a word
- Addressable unit
 - Smallest location which can be uniquely addressed
 - Word internally
 - Cluster on M\$ disks



Access Methods

Sequential

- Start at the beginning and read through in order
- Access time depends on location of data and previous location
- e.g. tape

Direct

- Individual blocks have unique address
- Access is by jumping to vicinity plus sequential search
- Access time depends on location and previous location
- e.g. disk

Access Methods contd.

Random

- Individual addresses identify locations exactly
- Access time is independent of location or previous access
- e.g. RAM

Associative

- Data is located by a comparison with contents of a portion of the store
- Access time is independent of location or previous access
- e.g. cache




Memory Hierarchy

- Registers
 - In CPU
- Internal or Main memory
 - May include one or more levels of cache
 - "RAM"
- External memory
 - Backing store



Memory Hierarchy -Diagram





Access time

- Time between presenting the address and getting the valid data
- Memory Cycle time
 - Time may be required for the memory to "recover" before next access
 - Cycle time is access + recovery
- Transfer Rate
 - Rate at which data can be moved



Physical Types

- Semiconductor
 - RAM
- Magnetic
 - Disk & Tape
- Optical
 - CD & DVD
- Others
 - Bubble
 - Hologram



Physical Characteristics

- Decay
- Volatility
- Erasable
- Power consumption



Organisation

- Physical arrangement of bits into words
- Not always obvious
- e.g. interleaved



The Bottom Line

- How much?
 - Capacity
- How fast?
 - Time is money
- How expensive?



Hierarchy List

- Registers
- L1 Cache
- L2 Cache
- Main memory
- Disk cache
- Disk
- Optical
- Tape



So you want fast?

- It is possible to build a computer which uses only static RAM (see later)
- This would be very fast
- This would need no cache
 - How can you cache cache?
- This would cost a very large amount





Locality of Reference

- During the course of the execution of a program, memory references tend to cluster
- e.g. loops




- Small amount of fast memory
- Sits between normal main memory and CPU
- May be located on CPU chip or module






Cache/Main Memory Structure





Cache operation – overview

- CPU requests contents of memory location
- Check cache for this data
- If present, get from cache (fast)
- If not present, read required block from main memory to cache
- Then deliver from cache to CPU
- Cache includes tags to identify which block of main memory is in each cache slot





Cache Design


- Size
- Mapping Function
- Replacement Algorithm
- Write Policy
- Block Size
- Number of Caches



Size does matter

- Cost
 - More cache is expensive
- Speed
 - More cache is faster (up to a point)
 - Checking cache for data takes time

Typical Cache Organization



Comparison of Cache Sizes

Year of Processor Type Landing L1 cachea L2 cache L3 cache								
110008801	Туре	Introduction	Li Cacilea	Liz Cache	L5 Cache			
I <mark>BM 3</mark> 60/85	Mainframe	1968	16 to 32 KB					
PDP-11/70	Minicomputer	1975	1 KB	_				
VAX 11/780	Minicomputer	1978	16 KB	_	_			
IBM 3033	Mainframe	1978	64 KB					
IBM 3090	Mainframe	1985	128 to 256 KB					
Intel 80486	PC	1989	8 KB	_	<u> </u>			
Pentium	PC	1993	8 KB/8 KB	256 to 512 KB	<u> </u>			
PowerPC 601	PC	1993	32 KB	_	<u> </u>			
PowerPC 620	PC	1996	32 KB/32 KB	_	<u> </u>			
PowerPC G4	PC/server	1999	32 KB/32 KB	256 KB to 1 MB	2 MB			
IBM-S/390 G4	Mainframe	1997	32 KB	256 KB	2 MB			
IBM-S/390 G6	Mainframe	1999	256 KB	8 MB	<u> </u>			
Pentium 4	PC/server	2000	8 KB/8 KB	256 KB				
IBM SP	High-end server/ supercomputer	2000	64 KB/32 KB	8 MB	<u></u>			
CRAY MTAb	Supercomputer	2000	8 KB	2 MB	_			
Itanium	PC/server	2001	16 KB/16 KB	96 KB	4 MB			
SGI Origin 2001	High-end server	2001	32 KB/32 KB	4 MB				
Itanium 2	PC/server	2002	32 KB	256 KB	6 MB			
IBM POWER5	High-end server	2003	64 KB	1.9 MB	36 MB			
CRAY XD-1	Supercomputer	2004	64 KB/64 KB	1MB	_ 25			



Mapping Function

- Cache of 64kByte
- Cache block of 4 bytes
 - i.e. cache is 16k (2¹⁴) lines of 4 bytes
- 16MBytes main memory
- 24 bit address
 - $(2^{24}=16M)$



- Each block of main memory maps to only one cache line
 - i.e. if a block is in cache, it must be in one specific place
- Address is in two parts
- Least Significant w bits identify unique word
- Most Significant s bits specify one memory block
- The MSBs are split into a cache line field r and a tag of s-r (most significant)

Direct Mapping Address Structure

Tag s-r	Line or Slot r	
8	14	Word w

- 24 bit address
- 2 bit word identifier (4 byte block)
- 22 bit block identifier
 - 8 bit tag (=22-14)
 - 14 bit slot or line
- No two blocks in the same line have the same Tag field
- Check contents of cache by finding line and checking Tag

Direct Mapping Cache Line Table



- Cache line
- **0**
- **1**
- m-1


Main Memory blocks held


0, m, 2m, 3m...2s-m

1,m+1, 2m+1...2s-m+1

m-1, 2m-1,3m-1...2s-1

Direct Mapping Cache Organization





	Tag	Line	Wor
Main memory address =	8	14	31 2

Direct Mapping Summary

- Address length = (s + w) bits
- Number of addressable units = 2s+w words or bytes
- Block size = line size = 2w words or bytes
- Number of blocks in main memory = 2s+ w/2w = 2s
- Number of lines in cache = m = 2r
- Size of tag = (s r) bits



Direct Mapping pros & cons


- Simple
- Inexpensive
- Fixed location for given block
 - If a program accesses 2 blocks that map to the same line repeatedly, cache misses are very high





Associative Mapping

- A main memory block can load into any line of cache
- Memory address is interpreted as tag and word
- Tag uniquely identifies block of memory
- Every line's tag is examined for a match
- Cache searching gets expensive

Fully Associative Cache Organization







Associative Mapping Address Structure

Tag 22 bit

Word 2 bit

- 22 bit tag stored with each 32 bit block of data
- Compare tag field with tag entry in cache to check for hit
- Least significant 2 bits of address identify which 16 bit word is required from 32 bit data block
- e.g.

Address
 Tag
 Data
 Cache line

FFFFFC FFFFFC 24682468 3FFF

Associative Mapping Summary

- Address length = (s + w) bits
- Number of addressable units = 2s+w words or bytes
- Block size = line size = 2w words or bytes
- Number of blocks in main memory = 2s+ w/2w = 2s
- Number of lines in cache = undetermined
- Size of tag = s bits

Set Associative Mapping


- Cache is divided into a number of sets
- Each set contains a number of lines
- A given block maps to any line in a given set
 - e.g. Block B can be in any line of set i
- e.g. 2 lines per set
 - 2 way associative mapping
 - A given block can be in one of 2 lines in only one set



Set Associative Mapping Example

- 13 bit set number
- Block number in main memory is modulo 2¹³
- 000000, 00A000, 00B000, 00C000 ...
 map to same set

Two Way Set Associative Cache Organization




Set Associative Mapping Address Structure

Address Structure
Word
2 bit

- Use set field to determine cache set to look in
- Compare tag field to see if we have a hit
- e.g

Address	Tag	Data	Set
number			

- 1FF 7FFC 1FF 12345678 1FFF
- 001 7FFC 001 11223344 1FFF



 Tag
 Set
 Word
 43

 Main Memory Address =
 9
 13
 2

Set Associative Mapping Summary

- Address length = (s + w) bits
- Number of addressable units = 2s+w words or bytes
- Block size = line size = 2w words or bytes
- Number of blocks in main memory = 2d
- Number of lines in set = k
- Number of sets = v = 2d
- Number of lines in cache = kv = k * 2d
- Size of tag = (s d) bits



Replacement Algorithms (1) Direct mapping

- No choice
- Each block only maps to one line
- Replace that line

Replacement Algorithms (2) Associative & Set Associative

- Hardware implemented algorithm (speed)
- Least Recently used (LRU)
- e.g. in 2 way set associative
 - Which of the 2 block is Iru?
- First in first out (FIFO)
 - replace block that has been in cache longest
- Least frequently used
 - replace block which has had fewest hits
- Random



Write Policy

- Must not overwrite a cache block unless main memory is up to date
- Multiple CPUs may have individual caches
- I/O may address main memory directly

Write through

- All writes go to main memory as well as cache
- Multiple CPUs can monitor main memory traffic to keep local (to CPU) cache up to date
- Lots of traffic
- Slows down writes
- Remember bogus write through caches!

Write back

- Updates initially made in cache only
- Update bit for cache slot is set when update occurs
- If block is to be replaced, write to main memory only if update bit is set
- Other caches get out of sync
- I/O must access main memory through cache
- N.B. 15% of memory references are writes

Pentium 4 Cache

- **80**386 no on chip cache
- 80486 8k using 16 byte lines and four way set associative organization
- Pentium (all versions) two on chip L1 caches
 - Data & instructions
- Pentium III L3 cache added off chip
- Pentium 4
 - L1 caches
 - 8k bytes
 - 64 byte lines
 - four way set associative
 - L2 cache
 - Feeding both L1 caches
 - 256k
 - 128 byte lines
 - 8 way set associative
 - L3 cache on chip

Intel Cache Evolution			
Problem	Solution		
External memory slower than the system bus.	Add external cache using faster		

Processor on which feature first appears

Add external cache using faster memory technology.

Move external cache on-chip, operating at the same speed as the

486

386

processor. Add external L2 cache using faster

486

technology than main memory Create separate data and instruction caches.

Pentium

Contention occurs when both the Instruction Prefetcher and the Execution Unit simultaneously require access to the cache. In that case, the Prefetcher is stalled while the

Create separate back-side bus that runs at higher speed than the main

Pentium Pro

Increased processor speed results in external bus becoming a bottleneck for L2 cache access. Some applications deal with massive databases and must

Execution Unit's data access takes place.

Increased processor speed results in external bus becoming a

Internal cache is rather small, due to limited space on chip

bottleneck for cache access.

(front-side) external bus. The BSB is dedicated to the L2 cache.

Pentium II

Move L2 cache on to the processor

Move L3 cache on-chip.

chip.

51


Pentium III

Pentium 4

have rapid access to large amounts of data. The on-chip caches are too small

Add external L3 cache.

Pentium 4 Block Diagram



Pentium 4 Core Processor

- Fetch/Decode Unit
 - Fetches instructions from L2 cache
 - Decode into micro-ops
 - Store micro-ops in L1 cache
- Out of order execution logic
 - Schedules micro-ops
 - Based on data dependence and resources
 - May speculatively execute
- Execution units
 - Execute micro-ops
 - Data from L1 cache
 - Results in registers
- Memory subsystem
 - L2 cache and systems bus


Pentium 4 Design Reasoning

- Decodes instructions into RISC like micro-ops before L1 cache
- Micro-ops fixed length
 - Superscalar pipelining and scheduling
- Pentium instructions long & complex
- Performance improved by separating decoding from scheduling & pipelining
 - (More later ch14)
- Data cache is write back
 - Can be configured to write through
- L1 cache controlled by 2 bits in register
 - CD = cache disable
 - NW = not write through
 - 2 instructions to invalidate (flush) cache and write back then invalidate
- L2 and L3 8-way set-associative
 - Line size 128 bytes

PowerPC Cache Organization

- 601 single 32kb 8 way set associative
- 603 16kb (2 x 8kb) two way set associative
- 604 32kb
- 620 64kb
- G3 & G4
 - 64kb L1 cache
 - 8 way set associative
 - 256k, 512k or 1M L2 cache
 - two way set associative
- G5
 - 32kB instruction cache
 - 64kB data cache

PowerPC G5 Block Diagram





Internet Sources

- Manufacturer sites
 - Intel
 - IBM/Motorola
- Search on cache