## MIPS32® Instruction Set Quick Reference

 $\begin{array}{lll} R_D & & - & D_{\text{ESTINATION REGISTER}} \\ R_S, R_T & & - & S_{\text{OURCE OPERAND REGISTERS}} \\ R_A & & - & R_{\text{ETURN ADDRESS REGISTER}} \left( R31 \right) \end{array}$ 

PC — PROGRAM COUNTER
ACC — 64-BIT ACCUMULATOR

Lo, HI — Accumulator low (Acc<sub>31:0</sub>) and high (Acc<sub>63:32</sub>) parts

± — Signed operand or sign extension

Ø — Unsigned operand or zero extension

∷ — Concatenation of bit fields

R2 — MIPS32 Release 2 instruction

DOTTED — Assembler pseudo-instruction

PLEASE REFER TO "MIPS32 ARCHITECTURE FOR PROGRAMMERS VOLUME II: THE MIPS32 INSTRUCTION SET" FOR COMPLETE INSTRUCTION SET INFORMATION.

	Arithmetic Operations				
(	ADD	RD, Rs, RT	$R_D = R_S + R_T$ (OVERFLOW TRAP)		
K	ADDI	Rd, Rs, const16	$R_D = R_S + const 16^{\pm}$ (overflow trap)		
(	ADDIU	Rd, Rs, const16	$R_D = R_S + const 16^{\pm}$		
(	ADDU	Rd, Rs, Rt	$R_D = R_S + R_T$		
	CLO	RD, RS	RD = COUNTLEADINGONES(Rs)		
	CLZ	RD, RS	$R_D = C_{OUNT}L_{EADING}Z_{EROS}(R_S)$		
	LA	Rd, label	$R_D = A_{DDRESS}(LABEL)$		
	LI	RD, імм32	$R_D = IMM32$		
	LUI	Rd, const16	$R_D = const16 \ll 16$		
	MOVE	Rd, Rs	$R_D = R_S$		
	NEGU	Rd, Rs	$R_D = -R_S$		
	SEB <sup>R2</sup>	RD, Rs	$R_D = R_{S_{7:0}}^{\pm}$		
	SEH <sup>R2</sup>	Rd, Rs	$R_{\rm D} = R_{\rm S_{15:0}}^{\pm}$		
	SUB	RD, Rs, RT	$R_D = R_S - R_T$ (OVERFLOW TRAP)		
	SUBU	RD, Rs, RT	$R_D = R_S - R_T$		

	Shift and Rotate Operations			
	ROTR <sup>R2</sup>	Rd, Rs, bits5	$R_D = R_{S_{BITS5-1:0}} :: R_{S_{31:BITS5}}$	
	$ROTRV^{R2} \\$	Rd, Rs, Rt	$R_D = R_{S_{RT4:0-1:0}} :: R_{S_{31:RT4:0}}$	
X	SLL	Rd, Rs, shift5	$R_D = R_S << shift 5$	
	SLLV	Rd, Rs, Rt	$R_D = R_S << R_{T_{4:0}}$	
	SRA	Rd, Rs, shift5	$R_D = R_S^{\pm} >> _{SHIFT}5$	
	SRAV	Rd, Rs, Rt	$R_D = R_S^{\pm} >> R_{T_{4:0}}$	
	SRL	Rd, Rs, shift5	$R_D = R_S^{\varnothing} >> _{SHIFT}5$	
	SRLV	Rd, Rs, Rt	$R_D = R_S^{\varnothing} >> R_{T_{4:0}}$	

	Logical and Bit-Field Operations			
	AND RD, RS, RT		$R_D = R_S \& R_T$	
	ANDI	Rd, Rs, const16	$R_D = R_S \& const 16^{\emptyset}$	
	EXT <sup>R2</sup>	RD, Rs, P, S	$R_S = R_{S_{P+S-1:P}}^{\varnothing}$	
	INS <sup>R2</sup> RD, Rs, P, S		$R_{D_{P+S-1:P}} = R_{S_{S-1:0}}$	
	NOP		No-ор	
	NOR	Rd, Rs, Rt	$R_D = \sim (R_S \mid R_T)$	
	NOT	RD, Rs	$R_D = \sim R_S$	
Χ	OR	Rd, Rs, Rt	$R_D = R_S \mid R_T$	
X	ORI	Rd, Rs, const16	$R_D = R_S \mid \text{const} 16^{\varnothing}$	
	WSBH <sup>R2</sup>	RD, Rs	$R_D = R_{S_{23:16}} :: R_{S_{31:24}} :: R_{S_{7:0}} :: R_{S_{15:8}}$	
	XOR	Rd, Rs, Rt	$R_D = R_S \oplus R_T$	
	XORI	Rd, Rs, const16	$R_D = R_S \oplus const16^{\emptyset}$	

	C	CONDITION TESTING AND CONDITIONAL MOVE OPERATIONS			
	MOVN RD, Rs, RT IF $RT \neq 0$ , $RD = Rs$		$_{\rm IF}$ $R_{\rm T} \neq 0$ , $R_{\rm D} = R_{\rm S}$		
	MOVZ RD, Rs, RT		$_{\mathrm{IF}}$ $\mathrm{R}_{\mathrm{T}}=0$ , $\mathrm{R}_{\mathrm{D}}=\mathrm{R}_{\mathrm{S}}$		
X	SLT	Rd, Rs, Rt	$R_D = (R_S^{\pm} < R_T^{\pm}) ? 1 : 0$		
х	SLTI	Rd, Rs, const16	$R_D = (R_S^{\pm} < const16^{\pm}) ? 1 : 0$		
х	SLTIU	Rd, Rs, const16	$R_D = (R_S^{\varnothing} < _{CONST}16^{\varnothing})?1:0$		
X	SLTU	Rd, Rs, Rt	$R_D = (R_S^{\varnothing} < R_T^{\varnothing}) ? 1 : 0$		

	Multiply and Divide Operations			
DIV	Rs, RT	$Lo = Rs^{\pm} / RT^{\pm}$ ; $HI = Rs^{\pm} MOD RT^{\pm}$		
DIVU	Rs, Rt	$L_0 = R_S^{\varnothing} / R_T^{\varnothing}; H_I = R_S^{\varnothing} \mod R_T^{\varnothing}$		
MADD	Rs, Rt	$A_{CC} += R_S^{\pm} \times R_T^{\pm}$		
MADDU	Rs, Rt	$A_{CC} += R_S^{\varnothing} \times R_T^{\varnothing}$		
MSUB	Rs, Rt	$A_{CC} = R_S^{\pm} \times R_T^{\pm}$		
MSUBU	Rs, Rt	$Acc = Rs^{\varnothing} \times Rt^{\varnothing}$		
MUL	Rd, Rs, Rt	$R_{\rm D} = R_{\rm S}^{\pm} \times R_{\rm T}^{\pm}$		
MULT	Rs, Rt	$Acc = Rs^{\pm} \times Rr^{\pm}$		
MULTU	Rs, Rt	$Acc = Rs^{\varnothing} \times Rr^{\varnothing}$		

	ACCUMULATOR ACCESS OPERATIONS		
MFHI	Rd	$R_D = H_I$	
MFLO	RD	$R_D = L_O$	
MTHI	Rs	$H_I = R_S$	
MTLO	Rs	$L_0 = R_S$	

JUMPS AND BRANCHES (NOTE: ONE DELAY SLOT)			HES (NOTE: ONE DELAY SLOT)
	<u>B</u>	OFF18	$PC += OFF18^{\pm}$
	BAL	OFF18	$R_A = PC + 8$ , $PC += OFF18^{\pm}$
X	BEQ	Rs, Rt, off18	IF $R_S = R_T$ , $PC += OFF18^{\pm}$
	BEQZ	Rs, off18	IF $R_S = 0$ , $PC += OFF18^{\pm}$
	BGEZ	Rs, off18	IF Rs $\geq 0$ , PC $+=$ OFF $18^{\pm}$
	BGEZAL	Rs, off18	$R_A = PC + 8$ ; IF $R_S \ge 0$ , $PC += OFF18^{\pm}$
	BGTZ	Rs, off18	IF Rs > 0, PC $+=$ OFF $18^{\pm}$
	BLEZ	Rs, off18	IF Rs $\leq 0$ , PC $+=$ OFF $18^{\pm}$
	BLTZ	Rs, off18	IF $R_S < 0$ , $PC += OFF 18^{\pm}$
	BLTZAL	Rs, off18	$R_A = PC + 8$ ; IF $R_S < 0$ , $PC += OFF18^{\pm}$
X	BNE	Rs, Rt, off18	IF Rs $\neq$ RT, PC $+=$ OFF $18^{\pm}$
	BNEZ	Rs, off18	IF Rs $\neq$ 0, PC += OFF 18 <sup>±</sup>
X	J	ADDR28	$PC = PC_{31:28} :: ADDR28^{\varnothing}$
	JAL	ADDR28	$R_A = PC + 8$ ; $PC = PC_{31:28} :: ADDR 28^{\emptyset}$
	JALR	Rd, Rs	$R_D = PC + 8; PC = R_S$
	JR	Rs	PC = Rs

	Load and Store Operations				
	LB	Rd, off16(Rs)	$R_D = \text{MEM}8(R_S + \text{OFF}16^{\pm})^{\pm}$		
	LBU	Rd, off16(Rs)	$R_{\rm D} = {\rm MEM8}(R_{\rm S} + {\rm OFF}16^{\pm})^{\varnothing}$		
	LH	Rd, off16(Rs)	$R_D = MEM 16(R_S + OFF 16^{\pm})^{\pm}$		
	LHU	Rd, off16(Rs)	$R_{\rm D} = _{\rm MEM} 16 (R_{\rm S} + _{\rm OFF} 16^{\pm})^{\varnothing}$		
X	LW	Rd, off16(Rs)	$R_D = \text{MEM}32(R_S + \text{OFF}16^{\pm})$		
	LWL	RD, OFF16(Rs)	$R_D = L_{OAD}W_{ORD}L_{EFT}(R_S + off 16^{\pm})$		
	LWR	Rd, off16(Rs)	$R_D = L_{OAD}W_{ORD}R_{IGHT}(R_S + off 16^{\pm})$		
	SB	Rs, off16(Rt)	$_{\text{MEM8}}(R_{\text{T}} + _{\text{OFF}}16^{\pm}) = R_{S_{7:0}}$		
	SH	Rs, off16(Rt)	$_{\text{MEM}}16(R_{\text{T}} + _{\text{OFF}}16^{\pm}) = R_{S_{15:0}}$		
X	SW	Rs, off16(Rt)	$_{\text{MEM}}32(R_{\text{T}} + _{\text{OFF}}16^{\pm}) = R_{\text{S}}$		
	SWL	Rs, off16(Rt)	StoreWordLeft(Rt + off16 <sup>±</sup> , Rs)		
	SWR	Rs, off16(Rt)	StoreWordRight(Rt + off $16^{\pm}$ , Rs)		
	ULW	Rd, off16(Rs)	$R_D = UNALIGNED\_MEM32(R_S + OFF16^{\pm})$		
	USW	Rs, off16(Rt)	UNALIGNED_MEM $32(R_T + off16^{\pm}) = R_S$		

	Atomic Read-Modify-Write Operations			
LL RD, OFF16(Rs)		$R_D = \text{MEM}32(R_S + \text{OFF}16^{\pm}); \text{LINK}$		
SC	Rd, off16(Rs)	IF ATOMIC, MEM $32(R_S + off16^{\pm}) = R_D;$ $R_D = A_{TOMIC} ? 1 : 0$		

	REGISTERS			
0	0 zero Always equal to zero			
1	at	Assembler temporary; used by the assembler		
2-3	v0-v1	Return value from a function call		
4-7	a0-a3	First four parameters for a function call		
8-15	t0-t7	Temporary variables; need not be preserved		
16-23	s0-s7	Function variables; must be preserved		
24-25	t8-t9	Two more temporary variables		
26-27	k0-k1	Kernel use registers; may change unexpectedly		
28	28 gp Global pointer			
29 sp Stack pointer		Stack pointer		
30	fp/s8	Stack frame pointer or subroutine variable		
31	ra	Return address of the last subroutine call		

#### DEFAULT C CALLING CONVENTION (O32)

#### **Stack Management**

- The stack grows down.
  - Subtract from \$sp to allocate local storage space.
- Restore \$sp by adding the same amount at function exit.
- The stack must be 8-byte aligned.
  - Modify \$sp only in multiples of eight.

#### **Function Parameters**

- Every parameter smaller than 32 bits is promoted to 32 bits.
- First four parameters are passed in registers \$a0-\$a3.
- 64-bit parameters are passed in register pairs:
  - Little-endian mode: \$a1:\$a0 or \$a3:\$a2.
  - Big-endian mode: \$a0:\$a1 or \$a2:\$a3.
- Every subsequent parameter is passed through the stack.
- First 16 bytes on the stack are not used.
- Assuming \$sp was not modified at function entry:
  - The 1<sup>st</sup> stack parameter is located at 16(\$sp).
  - The 2<sup>nd</sup> stack parameter is located at 20(\$sp), etc.
- 64-bit parameters are 8-byte aligned.

#### **Return Values**

- 32-bit and smaller values are returned in register \$v0.
- 64-bit values are returned in registers \$v0 and \$v1:
- Little-endian mode: \$v1:\$v0.
- Big-endian mode: \$v0:\$v1.

	MIPS32 Virtual Address Space				
kseg3	0xE000.0000	0xFFFF.FFFF	Mapped	Cached	
ksseg	0xC000.0000	0xDFFF.FFFF	Mapped	Cached	
kseg1	0xA000.0000	0xBFFF.FFFF	Unmapped	Uncached	
kseg0	0x8000.0000	0x9FFF.FFFF	Unmapped	Cached	
useg	0x0000.0000	0x7FFF.FFFF	Mapped	Cached	

#### READING THE CYCLE COUNT REGISTER FROM C

```
unsigned mips_cycle_counter_read()
{
    unsigned cc;
    asm volatile("mfc0 %0, $9" : "=r" (cc));
    return (cc << 1);
}</pre>
```

```
ASSEMBLY-LANGUAGE FUNCTION EXAMPLE
# int asm max(int a, int b)
# {
  int r = (a < b) ? b : a;
   return r;
# }
    .text
    .set
             nomacro
             noreorder
    .set
    .global asm max
    .ent
             asm max
asm max:
             $v0, $a0
    move
    slt
             $t0, $a0, $a1
                             # a < b ?
             $ra
                              # return
    ήr
    movn
             $v0, $a1, $t0
                            # if ves, r = b
    .end
             asm max
```

#### C / ASSEMBLY-LANGUAGE FUNCTION INTERFACE

```
#include <stdio.h>
int asm_max(int a, int b);
int main()
{
   int x = asm_max(10, 100);
   int y = asm_max(200, 20);
   printf("%d %d\n", x, y);
}
```

### INVOKING MULT AND MADD INSTRUCTIONS FROM C

```
int dp(int a[], int b[], int n)
{
    int i;
    long long acc = (long long) a[0] * b[0];
    for (i = 1; i < n; i++)
        acc += (long long) a[i] * b[i];
    return (acc >> 31);
}
```

#### ATOMIC READ-MODIFY-WRITE EXAMPLE

```
atomic_inc:

11  $t0, 0($a0)  # load linked
addiu  $t1, $t0, 1  # increment
sc  $t1, 0($a0)  # store cond'l
beqz  $t1, atomic_inc  # loop if failed
nop
```

#### ACCESSING UNALIGNED DATA NOTE: ULW AND USW AUTOMATICALLY GENERATE APPROPRIATE CODE LITTLE-ENDIAN MODE BIG-ENDIAN MODE LWR LWL RD, OFF16(Rs) RD, OFF16(Rs) LWL RD, OFF16+3(Rs) LWR RD, OFF16+3(Rs) SWR RD, OFF16(Rs) SWL RD, OFF16(Rs) SWL RD. OFF16+3(Rs) **SWR** RD. OFF16+3(Rs)

# typedef struct { int u; } \_\_attribute\_\_((packed)) unaligned; int unaligned\_load(void \*ptr) { unaligned \*uptr = (unaligned \*)ptr; return uptr->u; }

MIPS SDE-GCC Compiler Defines		
mips	MIPS ISA (= 32 for MIPS32)	
mips_isa_rev	MIPS ISA Revision (= 2 for MIPS32 R2)	
mips_dsp	DSP ASE extensions enabled	
_MIPSEB	Big-endian target CPU	
_MIPSEL	Little-endian target CPU	
_MIPS_ARCH_CPU	Target CPU specified by -march=CPU	
_MIPS_TUNE_CPU	Pipeline tuning selected by -mtune=CPU	

#### Notes

- Many assembler pseudo-instructions and some rarely used machine instructions are omitted.
- The C calling convention is simplified. Additional rules apply when passing complex data structures as function parameters.
- The examples illustrate syntax used by GCC compilers.
- Most MIPS processors increment the cycle counter every other cycle. Please check your processor documentation.