$$V_{ACLM} = \frac{A_{bulk}E_{sat}L_{eff} + V_{gsteff}}{P_{CLM}A_{bulk}E_{sat}\ litl} (V_{ds} - V_{dseff})$$

Similarly, Eq. (3.5.7) now becomes

$$\frac{1}{V_{ASCBE}} = \frac{P_{scbe2}}{L_{eff}} \exp\left(\frac{-P_{scbe1} \, litl}{V_{ds} - V_{dseff}}\right)$$
(3.6.3)

The V_{dseff} expression is written as

$$V_{dseff} = V_{dsat} - \frac{1}{2} \left(V_{dsat} - V_{ds} - \delta + \sqrt{(V_{dsat} - V_{ds} - \delta)^2 + 4\delta V_{dsat}} \right)$$
(3.6.4)

The expression for V_{dsat} is that given under Section 3.4. The parameter δ in the unit of volts can be extracted. The dependence of V_{dseff} on V_{ds} is given in Figure 3-3. The V_{dseff} function follows V_{ds} in the linear region and tends to V_{dsat} in the saturation region. Figure 3-4 shows the effect of δ on the transition region between linear and saturation regimes.