# HWRS 505: Vadose Zone Hydrology

Lecture 20

11/5/2024

Today:

Parameter estimation/Inverse modeling

## Review of Lecture 19

#### Measurement methods to estimate parameters

- 1. Laboratory methods
  - SWC (Pressure cell method)
  - Ksat (Constant head permeameter; Falling head permeameter)
  - K(θ) (Steady-state flux method; Instantaneous profile method)
- 2. Field methods
  - Water content (Neutron probes; Time domain reflectometry)
  - Water pressure head (Tensiometer)
  - K(θ) (Instantaneous profile method)

## Inverse Modeling

### Forward modeling

Known parameters → Process-based model → Predicted data

### Examples:

 Use Richards' equation to predict water saturation and water pressure head.

### **Inverse modeling**

Unknown parameters Process-based model Measured data


### Examples:

 All of the measurement methods discussed in Lecture 19.

## Inverse Modeling with One Parameter

## Classical Parameter estimation

## Single-objective optimization



**Goal:** searching through parameter space to find *the parameter* that gives the best predictions.


### **Complications:**

- Measurement errors
- Calibration errors
- Scaling errors
- Determine a single error surface for multiple measurements

## Inverse Modeling with Multiple Parameters

## Classical Parameter estimation

Single-objective optimization



**Goal:** searching through parameter space to find the <u>parameter set</u> that gives the best predictions.

#### **Complications:**

- Measurement errors
- Calibration errors
- Scaling errors
- Determine a single error surface for multiple measurements

## Inverse modeling using the spreadsheet models

Use the spreadsheet model (1d-unsat – inverse.xls) to perform inverse modeling under various conditions

#### **Exercises:**

- 1. Manual inverse modeling (w/o and w/ noises in the data)
- 2. Automatic inverse modeling (w/o noises, reduced data and w/ noises, part of the data w/ noises)