

COMPUTER ORGANIZATION AND DE

The Hardware/Software Interface



Chapter 2

Instructions: Language of the Computer

Instruction Set

- The repertoire of instructions of a computer
- Different computers have different instruction sets
 - But with many aspects in common
- Early computers had very simple instruction sets
 - Simplified implementation
- Many modern computers also have simple instruction sets



The RISC-V Instruction Set

- Used as the example throughout the book
- Developed at UC Berkeley as open ISA
- Now managed by the RISC-V Foundation (<u>riscv.org</u>)
- Typical of many modern ISAs
- Similar ISAs have a large share of embedded core market
 - Applications in consumer electronics, network/storage equipment, cameras, printers, ...

Arithmetic Operations

- Add and subtract, three operands
 - Two sources and one destination
 - add a, b, c // a gets b + c
- All arithmetic operations have this form
- Design Principle 1: Simplicity favors regularity
 - Regularity makes implementation simpler
 - Simplicity enables higher performance at lower cost



Arithmetic Example

C code:

```
f = (g + h) - (i + j);
```

Compiled RISC-V code:

```
add t0, g, h // temp t0 = g + h add t1, i, j // temp t1 = i + j sub f, t0, t1 // f = t0 - t1
```

Register Operands

- Arithmetic instructions use register operands
- RISC-V has a 32 x 64-bit register file
 - Use for frequently accessed data
 - 64-bit data is called a "doubleword"
 - 32 x 64-bit general purpose registers x0 to x31
 - 32-bit data is called a "word"
- Design Principle 2: Smaller is faster
 - c.f. main memory: millions of locations



RISC-V Registers

- x0: the constant value 0
- x1: return address
- x2: stack pointer
- x3: global pointer
- x4: thread pointer
- x5 x7, x28 x31: temporaries
- x8: frame pointer
- x9, x18 x27: saved registers
- x10 x11: function arguments/results
- x12 x17: function arguments

Register Operand Example

C code:

$$f = (g + h) - (i + j);$$

• f, ..., j in x19, x20, ..., x23

Compiled RISC-V code:

```
add x5, x20, x21
add x6, x22, x23
sub x19, x5, x6
```

Memory Operands

- Main memory used for composite data
 - Arrays, structures, dynamic data
- To apply arithmetic operations
 - Load values from memory into registers
 - Store result from register to memory
- Memory is byte addressed
 - Each address identifies an 8-bit byte
- RISC-V is Little Endian
 - Least-significant byte at least address of a word
 - c.f. Big Endian: most-significant byte at least address
- RISC-V does not require words to be aligned in memory
 - Unlike some other ISAs



Memory Operand Example

C code:

```
A[12] = h + A[8];
```

- h in x21, base address of A in x22
- Compiled RISC-V code:
 - Index 8 requires offset of 64
 - 8 bytes per doubleword

```
1d x9, 64(x22)
add x9, x21, x9
sd x9, 96(x22)
```

Registers vs. Memory

- Registers are faster to access than memory
- Operating on memory data requires loads and stores
 - More instructions to be executed
- Compiler must use registers for variables as much as possible
 - Only spill to memory for less frequently used variables
 - Register optimization is important!

Immediate Operands

 Constant data specified in an instruction addi x22, x22, 4

- Make the common case fast
 - Small constants are common
 - Immediate operand avoids a load instruction

Unsigned Binary Integers

Given an n-bit number

$$x = x_{n-1}2^{n-1} + x_{n-2}2^{n-2} + \dots + x_12^1 + x_02^0$$

- Range: 0 to +2ⁿ 1
- Example
 - $0000 0000 \dots 0000 1011_2$ = 0 + ... + 1×2³ + 0×2² +1×2¹ +1×2⁰
 = 0 + ... + 8 + 0 + 2 + 1 = 11₁₀
- Using 64 bits: 0 to +18,446,774,073,709,551,615

2s-Complement Signed Integers

Given an n-bit number

$$x = -x_{n-1}2^{n-1} + x_{n-2}2^{n-2} + \dots + x_12^1 + x_02^0$$

- Range: -2ⁿ⁻¹ to +2ⁿ⁻¹ 1
- Example
 - 1111 1111 ... 1111 1100_2 = $-1 \times 2^{31} + 1 \times 2^{30} + ... + 1 \times 2^2 + 0 \times 2^1 + 0 \times 2^0$ = $-2,147,483,648 + 2,147,483,644 = -4_{10}$
- Using 64 bits: −9,223,372,036,854,775,808 to 9,223,372,036,854,775,807

2s-Complement Signed Integers

- Bit 63 is sign bit
 - 1 for negative numbers
 - 0 for non-negative numbers
- $-(-2^{n-1})$ can't be represented
- Non-negative numbers have the same unsigned and 2s-complement representation
- Some specific numbers
 - 0: 0000 0000 ... 0000
 - —1: 1111 1111 ... 1111
 - Most-negative: 1000 0000 ... 0000
 - Most-positive: 0111 1111 ... 1111



Signed Negation

- Complement and add 1
 - Complement means 1 → 0, 0 → 1

$$x + x = 11111...111_2 = -1$$

 $x + 1 = -x$

Example: negate +2

$$- +2 = 0000 \ 0000 \ \dots \ 0010_{two}$$

$$-2 = 1111 \ 1111 \ \dots \ 1101_{two} + 1$$

= 1111 \ 1111 \ \dots \ 1110_{two}

Sign Extension

- Representing a number using more bits
 - Preserve the numeric value
- Replicate the sign bit to the left
 - c.f. unsigned values: extend with 0s
- Examples: 8-bit to 16-bit
 - +2: 0000 0010 => 0000 0000 0000 0010
 - -2: 1111 1110 => 1111 1111 1111 1110
- In RISC-V instruction set
 - 1b: sign-extend loaded byte
 - 1bu: zero-extend loaded byte



Representing Instructions

- Instructions are encoded in binary
 - Called machine code
- RISC-V instructions
 - Encoded as 32-bit instruction words
 - Small number of formats encoding operation code (opcode), register numbers, ...
 - Regularity!



Hexadecimal

- Base 16
 - Compact representation of bit strings
 - 4 bits per hex digit

0	0000	4	0100	8	1000	С	1100
1	0001	5	0101	9	1001	d	1101
2	0010	6	0110	a	1010	е	1110
3	0011	7	0111	b	1011	f	1111

- Example: eca8 6420
 - 1110 1100 1010 1000 0110 0100 0010 0000

RISC-V R-format Instructions

funct7	rs2	rs1	funct3	rd	opcode
7 bits	5 bits	5 bits	3 bits	5 bits	7 bits

Instruction fields

- opcode: operation code
- rd: destination register number
- funct3: 3-bit function code (additional opcode)
- rs1: the first source register number
- rs2: the second source register number
- funct7: 7-bit function code (additional opcode)



R-format Example

funct7	rs2	rs1	funct3	rd	opcode
7 bits	5 bits	5 bits	3 bits	5 bits	7 bits

add x9, x20, x21

0	21	20	0	9	51
0000000	10101	10100	000	01001	0110011

0000 0001 0101 1010 0000 0100 1011 $0011_{two} = 015A04B3_{16}$

RISC-V I-format Instructions

immediate	rs1	funct3	rd	opcode
12 bits	5 bits	3 bits	5 bits	7 bits

- Immediate arithmetic and load instructions
 - rs1: source or base address register number
 - immediate: constant operand, or offset added to base address
 - 2s-complement, sign extended
- Design Principle 3: Good design demands good compromises
 - Different formats complicate decoding, but allow 32-bit instructions uniformly
 - Keep formats as similar as possible


RISC-V S-format Instructions




- Different immediate format for store instructions
 - rs1: base address register number
 - rs2: source operand register number
 - immediate: offset added to base address
 - Split so that rs1 and rs2 fields always in the same place

Stored Program Computers

The BIG Picture





- Instructions represented in binary, just like data
- Instructions and data stored in memory
- Programs can operate on programs
 - e.g., compilers, linkers, ...
- Binary compatibility allows compiled programs to work on different computers
 - Standardized ISAs

Logical Operations

Instructions for bitwise manipulation

Operation	С	Java	RISC-V
Shift left	<<	<<	slli
Shift right	>>	>>>	srli
Bit-by-bit AND	&	&	and, andi
Bit-by-bit OR			or, ori
Bit-by-bit XOR	^	٨	xor, xori
Bit-by-bit NOT	~	~	

- not rd, rs : implemented by xori rd, rs, -1
- Useful for extracting and inserting groups of bits in a word

Shift Operations

funct6	immed	rs1	funct3	rd	opcode
6 bits	6 bits	5 bits	3 bits	5 bits	7 bits

- immediate: how many positions to shift
- Shift left logical
 - Shift left and fill with 0 bits
 - slli by i bits multiplies by 2i
- Shift right logical
 - Shift right and fill with 0 bits
 - srli by i bits divides by 2i (unsigned only)

AND Operations


- Useful to mask bits in a word
 - Select some bits, clear others to 0

and x9, x10, x11

OR Operations

- Useful to include bits in a word
 - Set some bits to 1, leave others unchanged

or x9, x10, x11



XOR Operations

- XOR creates 0 when bits are the same, 1 if they are different
 - xor 111...111 : equivalent to NOT

```
xor x9, x10, x12 // NOT operation
```

Conditional Operations


- Branch to a labeled instruction if a condition is true
 - Otherwise, continue sequentially
- beq rs1, rs2, L1
 - if (rs1 == rs2) branch to instruction labeled L1
- bne rs1, rs2, L1
 - if (rs1 != rs2) branch to instruction labeled L1



Compiling If Statements

C code:

- f, g, ... in x19, x20, ...
- Compiled RISC-V code:



```
bne x22, x23, Else
add x19, x20, x21
beq x0,x0,Exit // unconditional
```

Else: sub x19, x20, x21

Exit: ... ←

Assembler calculates addresses

Compiling Loop Statements

C code:

```
while (save[i] == k) i += 1;
```


- i in x22, k in x24, address of save in x25
- Compiled RISC-V code:

```
Loop: slli x10, x22, 3
add x10, x10, x25
ld x9, 0(x10)
bne x9, x24, Exit
addi x22, x22, 1
beq x0, x0, Loop
Exit: ...
```



Basic Blocks

- A basic block is a sequence of instructions with
 - No embedded branches (except at end)
 - No branch targets (except at beginning)



- A compiler identifies basic blocks for optimization
- An advanced processor can accelerate execution of basic blocks

More Conditional Operations

- blt rs1, rs2, L1
 - if (rs1 < rs2) branch to instruction labeled L1</p>
- bge rs1, rs2, L1
 - if (rs1 >= rs2) branch to instruction labeled L1
- Example
 - if (a > b) a += 1;
 - a in x22, b in x23
 bge x23, x22, Exit // branch if b >= a
 addi x22, x22, 1

Exit:



Signed vs. Unsigned

- Signed comparison: blt, bge
- Unsigned comparison: bltu, bgeu
- Example

 - $x23 = 0000\ 0000\ 0000\ 0000\ 0000\ 0000\ 0000\ 0001$
 - x22 < x23 // signed
 -1 < +1</pre>
 - x22 > x23 // unsigned
 - +4,294,967,295 > +1

Procedure Calling

- Steps required
 - 1. Place parameters in registers x10 to x17
 - 2. Transfer control to procedure
 - 3. Acquire storage for procedure
 - 4. Perform procedure's operations
 - 5. Place result in register for caller
 - 6. Return to place of call (address in x1)

Procedure Call Instructions

- Procedure call: jump and link jal x1, ProcedureLabel
 - Address of following instruction put in x1
 - Jumps to target address
- Procedure return: jump and link register jalr x0, 0(x1)
 - Like jal, but jumps to 0 + address in x1
 - Use x0 as rd (x0 cannot be changed, no return address)
 - Can also be used for computed jumps
 - e.g., for case/switch statements

Leaf Procedure Example

C code:

```
long long int leaf_example (
    long long int g, long long int h,
    long long int i, long long int j) {
    long long int f;
    f = (g + h) - (i + j);
    return f;
}
```

- Arguments g, ..., j in x10, ..., x13 (func argument reg)
- f in x20 (saved reg)
- temporaries x5, x6
- Need to save x5, x6, x20 on stack (usually temporary reg not stored on stack)

Leaf Procedure Example

RISC-V code:

leaf_example:

```
addi sp, sp, -24
x5,16(sp)
x6,8(sp)
x20,0(sp)
add x5,x10,x11
add x6, x12, x13
sub x20,x5,x6
addi x10,x20,0
1d \times 20,0(sp)
1d \times 6.8(sp)
1d x5, 16(sp)
addi sp, sp, 24
jalr x0,0(x1)
```

Save x5, x6, x20 on stack

$$x5 = g + h$$

$$x6 = i + j$$


$$f = x5 - x6$$

copy f to return register x10

Resore x5, x6, x20 from stack

Return to caller, x1: return address

Local Data on the Stack



Register Usage

- x5 x7, x28 x31: temporary registers
 - Not preserved by the callee

- x8 x9, x18 x27: saved registers
 - If used, the callee saves and restores them

Non-Leaf Procedures

- Procedures that call other procedures
- For nested call, caller needs to save on the stack:
 - Its return address
 - Any arguments and temporaries needed after the call
- Restore from the stack after the call

Non-Leaf Procedure Example

C code:

```
long long int fact (long long int n)
{
  if (n < 1) return 1;
  else return n * fact(n - 1);
}</pre>
```

- Argument n in x10
- Result in x10

Non-Leaf Procedure Example


RISC-V code:

```
fact:
    addi sp,sp,-16
                                     Save return address and n on stack
    x1,8(sp)
                                    x1: return address
    x10,0(sp)
                                    x10: argument n
                                    x5 = n - 1
    addi x5,x10,-1
                                     if n >= 1, go to L1
    bge x5,x0,L1
    addi x10, x0, 1
                                    Else, set return value to 1
    addi sp, sp, 16
                                    Pop stack, don't bother restoring values
    jalr x0,0(x1)
                                    Return
L1: addi x10,x10,-1
                                    n = n - 1
    jal x1, fact
                                    call fact(n-1)
    addi x6,x10,0
                                     move result of fact(n - 1) to x6
     1d \times 10,0(sp)
                                    Restore caller's n
    1d x1,8(sp)
                                    Restore caller's return address
    addi sp,sp,16
                                    Pop stack
    mul x10, x10, x6
                                     return n * fact(n-1)
    jalr x0,0(x1)
                                     return
```




Memory Layout

- Text: program code
- Static data: global variables
 - e.g., static variables in C, constant arrays and strings
 - x3 (global pointer) initialized to address allowing ±offsets into this segment
- Dynamic data: heap
 - E.g., malloc in C, new in Java
- Stack: automatic storage





Local Data on the Stack



- Local data allocated by callee
 - e.g., C automatic variables
- Procedure frame (activation record)
 - Used by some compilers to manage stack storage



Character Data

- Byte-encoded character sets
 - ASCII: 128 characters
 - 95 graphic, 33 control
 - Latin-1: 256 characters
 - ASCII, +96 more graphic characters
- Unicode: 32-bit character set
 - Used in Java, C++ wide characters, ...
 - Most of the world's alphabets, plus symbols
 - UTF-8, UTF-16: variable-length encodings



Byte/Halfword/Word Operations

- RISC-V byte/halfword/word load/store
 - Load byte/halfword/word: Sign extend to 64 bits in rd
 - lb rd, offset(rs1)
 - Th rd, offset(rs1)
 - lw rd, offset(rs1)
 - Load byte/halfword/word unsigned: Zero extend to 64 bits in rd
 - lbu rd, offset(rs1)
 - lhu rd, offset(rs1)
 - lwu rd, offset(rs1)
 - Store byte/halfword/word: Store rightmost 8/16/32 bits
 - sb rs2, offset(rs1)
 - sh rs2, offset(rs1)
 - sw rs2, offset(rs1)

String Copy Example

C code:

Null-terminated string

```
void strcpy (char x[], char y[])
{    size_t i;
    i = 0;
    while ((x[i]=y[i])!='\0')
        i += 1;
}
```

String Copy Example

RISC-V code:

```
strcpy:
   addi sp,sp,-8
                    // adjust stack for 1 doubleword
   sd x19,0(sp) // push x19
   add x19, x0, x0 // i=0
L1: add x5,x19,x10  // x5 = addr of y[i]
   1bu x6,0(x5) // x6 = y[i]
   add x7,x19,x11 // x7 = addr of x[i]
   x6,0(x7)
                    // x[i] = y[i]
   beq x6,x0,L2
                    // if y[i] == 0 then exit
   addi x19, x19, 1 // i = i + 1
                    // next iteration of loop
   jal x0,L1
L2: ld x19,0(sp)
                    // restore saved x19
   addi sp,sp,8
                    // pop 1 doubleword from stack
   jalr x0,0(x1)
                    // and return
```

32-bit Constants

- Most constants are small
 - 12-bit immediate is sufficient
- For the occasional 32-bit constant
 lui rd, constant
 - Copies 20-bit constant to bits [31:12] of rd
 - Extends bit 31 to bits [63:32]
 - Clears bits [11:0] of rd to 0

```
lui x19, 976 // 0x003D0
```


```
addi x19,x19,1280 // 0x500
```

0000 0000 0000 0000 | 0000 0000 0000 0000 | 0000 0000 0011 1101 0000 | 0101 0000 0000



Branch Addressing

- Branch instructions specify
 - Opcode, two registers, target address
- Most branch targets are near branch
 - Forward or backward
- SB format:




- PC-relative addressing
 - Target address = PC + immediate x 2

(half word boundary: RISC-V allow 2bytes long inst)



Jump Addressing


- Jump and link (jal) target uses 20-bit immediate for larger range
- UJ format:



- For long jumps, eg, to 32-bit absolute address
 - lui: load address[31:12] to temp register (load upper immediate)
 - jalr: add address[11:0] and jump to target

RISC-V Addressing Summary


1. Immediate addressing




2. Register addressing



3. Base addressing




4. PC-relative addressing



RISC-V Encoding Summary

Name	Field						Comments
(Field Size)	7 bits	5 bits	5 bits	3 bits	5 bits	7 bits	
R-type	funct7	rs2	rs1	funct3	rd	opcode	Arithmetic instruction format
I-type	immediate[11:0]		rs1	funct3	rd	opcode	Loads & immediate arithmetic
S-type	immed[11:5]	rs2	rs1	funct3	immed[4:0]	opcode	Stores
SB-type	immed[12,10:5]	rs2	rs1	funct3	immed[4:1,11]	opcode	Conditional branch format
UJ-type	imme	,19:12]		rd	opcode	Unconditional jump format	
U-type		L2]		rd	opcode	Upper immediate format	

Translation and Startup





Producing an Object Module

- Assembler (or compiler) translates program into machine instructions
- Provides information for building a complete program from the pieces
 - Header: described contents of object module
 - Text segment: translated instructions
 - Static data segment: data allocated for the life of the program
 - Relocation info: for contents that depend on absolute location of loaded program
 - Symbol table: global definitions and external refs
 - Debug info: for associating with source code



Linking Object Modules

- Produces an executable image
 - 1. Merges segments
 - 2. Resolve labels (determine their addresses)
 - 3. Patch location-dependent and external refs
- Could leave location dependencies for fixing by a relocating loader
 - But with virtual memory, no need to do this
 - Program can be loaded into absolute location in virtual memory space

Loading a Program

- Load from image file on disk into memory
 - 1. Read header to determine segment sizes
 - 2. Create virtual address space
 - 3. Copy text and initialized data into memory
 - Or set page table entries so they can be faulted in
 - 4. Set up arguments on stack
 - 5. Initialize registers (including sp, fp, gp)
 - 6. Jump to startup routine
 - Copies arguments to x10, ... and calls main
 - When main returns, do exit syscall



Dynamic Linking

- Only link/load library procedure when it is called
 - Requires procedure code to be relocatable
 - Avoids image bloat caused by static linking of all (transitively) referenced libraries
 - Automatically picks up new library versions


Lazy Linkage


Indirection table

Stub: Loads routine ID, Jump to linker/loader

Linker/loader code

Dynamically mapped code






(a) First call to DLL routine

(b) Subsequent calls to DLL routine



Starting Java Applications





code for host

machine

C Sort Example

- Illustrates use of assembly instructions for a C bubble sort function
- Swap procedure (leaf)

v in x10, k in x11, temp in x5



The Procedure Swap

The Sort Procedure in C

Non-leaf (calls swap) void sort (long long int v[], size_t n) size_t i, j; for (i = 0; i < n; i += 1) { for (j = i - 1;j >= 0 & v[j] > v[j + 1];i -= 1) { swap(v,j);v in x10, n in x11, i in x19, j in x20

The Outer Loop

Skeleton of outer loop:

```
• for (i = 0; i < n; i += 1) {
  1i \times 19,0 // i = 0
for1tst:
  bge x19,x11,exit1 // go to exit1 if x19 \geq x11 (i\geqn)
  (body of outer for-loop)
  addi x19, x19, 1 // i += 1
               // branch to test of outer loop
      for1tst
exit1:
```

The Inner Loop

Skeleton of inner loop:

```
• for (j = i - 1; j >= 0 \&\& v[j] > v[j + 1]; j -= 1) {
      addi x20, x19, -1 // j = i -1
for2tst:
   blt x20,x0,exit2 // go to exit2 if x20 < 0 (j < 0)
   slli x5, x20,3 // reg x5 = j * 8
   add x5,x10,x5 // reg x5 = v + (j * 8)
   1d x6,0(x5) // reg x6 = v[j]
   1d x7,8(x5) // reg x7 = v[j + 1]
   ble x6,x7,exit2 // go to exit2 if x6 \leq x7
   mv x21, x10 // copy parameter x10 into x21
   mv x22, x11 // copy parameter x11 into x22
   mv \times x10, x21 // first swap parameter is v
        x11, x20 // second swap parameter is j
   ΜV
      jal x1, swap // call swap
      addi x20, x20, -1 // j -= 1
          for2tst // branch to test of inner loop
 exit2:
```

Preserving Registers

Preserve saved registers:

```
addi sp,sp,-40 // make room on stack for 5 regs sd x1,32(sp) // save x1 on stack sd x22,24(sp) // save x22 on stack sd x21,16(sp) // save x21 on stack sd x20,8(sp) // save x20 on stack sd x19,0(sp) // save x19 on stack
```


Restore saved registers:


```
exit1:
```


```
sd x19,0(sp) // restore x19 from stack
sd x20,8(sp) // restore x20 from stack
sd x21,16(sp) // restore x21 from stack
sd x22,24(sp) // restore x22 from stack
sd x1,32(sp) // restore x1 from stack
addi sp,sp, 40 // restore stack pointer
jalr x0,0(x1)
```


Effect of Compiler Optimization

Compiled with gcc for Pentium 4 under Linux












Effect of Language and Algorithm





Lessons Learnt

- Instruction count and CPI are not good performance indicators in isolation
- Compiler optimizations are sensitive to the algorithm
- Java/JIT compiled code is significantly faster than JVM interpreted
 - Comparable to optimized C in some cases
- Nothing can fix a dumb algorithm!

Arrays vs. Pointers

- Array indexing involves
 - Multiplying index by element size
 - Adding to array base address
- Pointers correspond directly to memory addresses
 - Can avoid indexing complexity



Example: Clearing an Array

```
clear1(int array[], int size) {
                                          clear2(int *array, int size) {
 int i;
                                            int *p;
  for (i = 0; i < size; i += 1)
                                            for (p = \&array[0]; p < \&array[size];
   array[i] = 0;
                                                 p = p + 1
                                              *p = 0:
                                          }
                  // i = 0
  lί
       x5.0
                                             mv \times 5, \times 10
                                                            // p = address
loop1:
                                                            // of array[0]
   slli x6, x5, 3 // x6 = i * 8
                                             slli x6, x11, 3 // x6 = size * 8
   add x7,x10,x6 // x7 = address
                                             add x7,x10,x6 // x7 = address
                   // of array[i]
                                                            // of array[size]
   x_0,0(x_7) // array[i] = 0
                                          loop2:
   addi x5, x5, 1 // i = i + 1
                                             x_0,0(x_5) // Memory[p] = 0
   blt x5,x11,loop1 // if (i<size)</pre>
                                             addi x5, x5, 8 // p = p + 8
                      // go to loop1
                                             bltu x5,x7,loop2
                                                            // if (p<&array[size])</pre>
                                                            // go to loop2
```

Comparison of Array vs. Ptr

- Multiply "strength reduced" to shift
- Array version requires shift to be inside loop
 - Part of index calculation for incremented i
 - c.f. incrementing pointer
- Compiler can achieve same effect as manual use of pointers
 - Induction variable elimination
 - Better to make program clearer and safer



MIPS Instructions

- MIPS: commercial predecessor to RISC-V
- Similar basic set of instructions
 - 32-bit instructions
 - 32 general purpose registers, register 0 is always 0
 - 32 floating-point registers
 - Memory accessed only by load/store instructions
 - Consistent use of addressing modes for all data sizes
- Different conditional branches
 - For <, <=, >, >=
 - RISC-V: blt, bge, bltu, bgeu
 - MIPS: slt, sltu (set less than, result is 0 or 1)
 - Then use beq, bne to complete the branch



Instruction Encoding

Register-re	egisteı	r													
	31		25	24	20	19		15	14	12	11	7	6	3	0
RISC-V		funct7(7)		rs2(5)		rs1(5)			funct3((3)		rd(5)		opcode(7)	
	31	26	25	21	20	1	16	15			11	10	6	5 5	0
MIPS		Op(6)		Rs1(5)		Rs2(5)			Rd(5)		Const(5)		Opx(6)	
Load															
	31				20	19		15	14	12	11	7	6	3	0
RISC-V		immed	iate(12)		rs1(5)			funct3((3)		rd(5)		opcode(7)	
	31	26	25	21	20	1	6	15							0
MIPS		Op(6)		Rs1(5)		Rs2(5)						Const(16	3)		
Store	31		25	24	20	19		15	14	12	11	7	6)	0
RISC-V		immediate(7)		rs2(5)		rs1(5)			funct3((3)	ir	nmediate(5)		opcode(7)	
	31	26	25	21	20	1	6	15							0
MIPS		Op(6)		Rs1(5)		Rs2(5)						Const(16	3)		
Branch															
	31		25	24	20	19		15	14	12	11	7	6	3	0
Branch RISC-V	31	immediate(7)	25	rs2(5)		rs1(5)		15	14 funct3(7 mmediate(5)	6	opcode(7)	0
	31	. ,	25 25	rs2(5)	20	rs1(5)		15 15	funct3(6		0



The Intel x86 ISA

- Evolution with backward compatibility
 - 8080 (1974): 8-bit microprocessor
 - Accumulator, plus 3 index-register pairs
 - 8086 (1978): 16-bit extension to 8080
 - Complex instruction set (CISC)
 - 8087 (1980): floating-point coprocessor
 - Adds FP instructions and register stack
 - 80286 (1982): 24-bit addresses, MMU
 - Segmented memory mapping and protection
 - 80386 (1985): 32-bit extension (now IA-32)
 - Additional addressing modes and operations
 - Paged memory mapping as well as segments



The Intel x86 ISA

- Further evolution...
 - i486 (1989): pipelined, on-chip caches and FPU
 - Compatible competitors: AMD, Cyrix, ...
 - Pentium (1993): superscalar, 64-bit datapath
 - Later versions added MMX (Multi-Media eXtension) instructions
 - The infamous FDIV bug
 - Pentium Pro (1995), Pentium II (1997)
 - New microarchitecture (see Colwell, The Pentium Chronicles)
 - Pentium III (1999)
 - Added SSE (Streaming SIMD Extensions) and associated registers
 - Pentium 4 (2001)
 - New microarchitecture
 - Added SSE2 instructions




The Intel x86 ISA

- And further...
 - AMD64 (2003): extended architecture to 64 bits
 - EM64T Extended Memory 64 Technology (2004)
 - AMD64 adopted by Intel (with refinements)
 - Added SSE3 instructions
 - Intel Core (2006)
 - Added SSE4 instructions, virtual machine support
 - AMD64 (announced 2007): SSE5 instructions
 - Intel declined to follow, instead...
 - Advanced Vector Extension (announced 2008)
 - Longer SSE registers, more instructions
- If Intel didn't extend with compatibility, its competitors would!
 - Technical elegance ≠ market success



Basic x86 Registers



Basic x86 Addressing Modes


Two operands per instruction

Source/dest operand	Second source operand						
Register	Register						
Register	Immediate						
Register	Memory						
Memory	Register						
Memory	Immediate						

Memory addressing modes

- Address in register
- Address = R_{base} + displacement
- Address = R_{base} + 2^{scale} × R_{index} (scale = 0, 1, 2, or 3)
- Address = R_{base} + 2^{scale} × R_{index} + displacement

x86 Instruction Encoding



- Variable length encoding
 - Postfix bytes specify addressing mode
 - Prefix bytes modify operation
 - Operand length, repetition, locking, ...

Implementing IA-32

- Complex instruction set makes implementation difficult
 - Hardware translates instructions to simpler microoperations
 - Simple instructions: 1–1
 - Complex instructions: 1—many
 - Microengine similar to RISC
 - Market share makes this economically viable
- Comparable performance to RISC
 - Compilers avoid complex instructions



Other RISC-V Instructions

- Base integer instructions (RV64I)
 - Those previously described, plus
 - auipc rd, immed // rd = (imm<<12) + pc</p>
 - follow by jalr (adds 12-bit immed) for long jump
 - slt, sltu, slti, sltui: set less than (like MIPS)
 - addw, subw, addiw: 32-bit add/sub
 - sllw, srlw, srlw, slliw, srliw, sraiw: 32-bit shift
- 32-bit variant: RV32I
 - registers are 32-bits wide, 32-bit operations



Instruction Set Extensions

- M: integer multiply, divide, remainder
- A: atomic memory operations
- F: single-precision floating point
- D: double-precision floating point
- C: compressed instructions
 - 16-bit encoding for frequently used instructions


Fallacies

- Powerful instruction ⇒ higher performance
 - Fewer instructions required
 - But complex instructions are hard to implement
 - May slow down all instructions, including simple ones
 - Compilers are good at making fast code from simple instructions
- Use assembly code for high performance
 - But modern compilers are better at dealing with modern processors
 - More lines of code ⇒ more errors and less productivity



Fallacies

- Backward compatibility ⇒ instruction set doesn't change
 - But they do accrete more instructions



x86 instruction set



Pitfalls

- Sequential words are not at sequential addresses
 - Increment by 4, not by 1!
- Keeping a pointer to an automatic variable after procedure returns
 - e.g., passing pointer back via an argument
 - Pointer becomes invalid when stack popped

Concluding Remarks

- Design principles
 - 1. Simplicity favors regularity
 - 2. Smaller is faster
 - 3. Good design demands good compromises
- Make the common case fast
- Layers of software/hardware
 - Compiler, assembler, hardware
- RISC-V: typical of RISC ISAs
 - c.f. x86

