2020-09-22 CH4 pt2


Thursday, September 24, 2020 7:12 AM

	how to	s instruct preset input	how to	s instruct preset input	This bit selects between + / And	This bit inst. how to postset out	Resulting ALU output
	zx	nx	zy	ny	f	no	out=
	if zx then x=0	if nx then x=!x	if zy then y=0	if ny then y=!y	if f then out=x+y else out=x&y	if no then out=!out	f(x,y)=
Г	1	0	1	0	1	0	0
	1	1	1	1	1	1	1
	1	1	1	0	1	0	-1
	0	0	1	1	0	0	x
	1	1	0	0	0	0	у
	0	0	1	1	0	1	!x
	1	1	0	0	0	1	!y
	0	0	1	1	1	1	-x
	1	1	0	0	1	1	-у
	0	1	1	1	1	1	x+1
	1	1	0	1	1	1	y+1
	0	0	1	1	1	0	x-1
	1	1	0	0	1	0	y-1
	0	0	0	0	1	0	x+y
	0	1	0	0	1	1	x-y
	0	0	0	1	1	1	y-x
	0	0	0	0	0	0	x&y
	0	1	0	1	0	1	x y

Machine Language

(when a=0) comp mnemonic	c1	c2	с3	c4	c5	c 6	(when a=1) comp mnemonic
0	1	0	1	0	1	0	
1	1	1	1	1	1	1	
-1	1	1	1	0	1	0	
D	0	0	1	1	0	0	
A	1	1	0	0	0	0	М
!D	0	0	1	1	0	1	
!A	1	1	0	0	0	1	! M
-D	0	0	1	1	1	1	
-A	1	1	0	0	1	1	-M
D+1	0	1	1	1	1	1	
A+1	1	1	0	1	1	1	M+1
D-1	0	0	1	1	1	0	
A-1	1	1	0	0	1	0	M-1
D+A	0	0	0	0	1	0	D+M
D-A	0	1	0	0	1	1	D-M
A-D	0	0	0	1	1	1	M-D
D&A	0	0	0	0	0	0	D&M
D A	0	1	0	1	0	1	D M

Figure 4.3 The *compute* field of the *C*-instruction. D and A are names of registers. M refers to the memory location addressed by A, namely, to Memory[A]. The symbols + and - denote 16-bit 2's complement addition and subtraction, while !, |, and & denote the 16-bit bit-wise Boolean operators Not, Or, and And, respectively. Note the similarity between this instruction set and the ALU specification given in figure 2.6.



$\begin{array}{c} \mathbf{j1}\\ (out<0) \end{array}$	$\mathbf{j2}\\(out=0)$	$\begin{array}{c} \mathbf{j3}\\ (out>0) \end{array}$	Mnemonic	Effect
0	0	0	null	No jump
0	0	1	JGT	If $qui > 0$ jump
0	1	0	JEQ	If $out = 0$ jump
0	1	1	JGE	If $out \ge 0$ jump
1	0	0	JLT	If $out < 0$ jump
1	0	1	JNE	If $out \neq 0$ jump
1	1	0	JLE	If $out \le 0$ jump
1	1	1	JMP	Jump

Figure 4.5 The jump field of the C-instruction. Out refers to the ALU output (resulting from the instruction's comp part), and jump implies "continue execution with the instruction addressed by the A register."

- Jump specifications are used to manipulate the next instruction to be executed from the ROM (our program)
- Jumps are necessary for the construction of non-linear behavior
 - \circ IF
 - o WHILE
 - o FOR
 - o FUNCTIONS

Jump Pattern in Hack ASM

- 1. Compute some interesting result, store in D
- 2. Load some instruction value into A
- 3. Use a jump to determine whether or not the program should branch

D = M - D @LessThan D;JLE

(LessThan)