# Lecture Notes: ARM64 Architecture and Programming for Raspberry Pi 4B

# Ji, Yong-Hyeon

# October 1, 2024

## **Contents**

1	Intr	oduction to ARM64 Architecture					
	1.1	1.1 Key Features					
	1.2	Intege	er Representation in Computer Systems				
		1.2.1	Binary Representation of Unsigned Integers				
		1.2.2	Signed Integers: Two's Complement Representation	,			
		1.2.3	Detecting Overflow in Two's Complement Addition	,			
		1.2.4	Summary	,			
	1.3	Memo	ory Layout in Computer Systems				
		1.3.1	Memory Segments				
		1.3.2	The Stack Segment	Į			
		1.3.3	The Heap Segment	,			
		1.3.4	The .text Segment	,			
		1.3.5	The .data Segment	,			
		1.3.6	The .bss Segment	(			
		1.3.7	The .rodata Segment				
		1.3.8	Memory Layout Table				
		1.3.9	Summary	(			
	1.4	Perfor	rmance Metrics in Computer Systems				
		1.4.1	Response Time and Throughput				
		1.4.2	Elapsed Time and CPU Time				
		1.4.3	Instruction Count and Clock Cycles				
		1.4.4	CPU Clock and Its Impact on Performance				
		1.4.5	Amdahl's Law				
		1.4.6	Interrelation of Metrics	(			
		1.4.7	Summary				
2	GN	U Asse	embly Syntax	10			

## 1 Introduction to ARM64 Architecture

ARM64 (AArch64) is a 64-bit architecture developed by ARM Holdings, widely used in modern mobile devices and servers. ARM64 offers a significant register file structure, with 31 general-purpose registers and special-purpose registers such as the Program Counter (PC) and Stack Pointer (SP). These registers provide flexibility for performing low-level operations efficiently.

### 1.1 Key Features

- 64-bit general-purpose registers (X0-X30).
- Special-purpose registers for the stack, program control, and more.
- Optimized function calling convention.

## 1.2 Integer Representation in Computer Systems

In computer systems, integers are represented using a fixed number of bits, typically grouped into bytes. This section discusses how integers are encoded, with a focus on binary representation, signed integers, and the implications of overflow.

#### 1.2.1 Binary Representation of Unsigned Integers

An *unsigned integer* of n bits is an integer value that can take on values in the range  $[0, 2^n - 1]$ . In binary form, such an integer is expressed as a sum of powers of two:

$$I = \sum_{i=0}^{n-1} b_i \cdot 2^i,$$

where  $b_i \in \{0, 1\}$  represents the *i*-th bit of the integer, with  $b_0$  being the least significant bit (LSB) and  $b_{n-1}$  the most significant bit (MSB).

For example, a 4-bit unsigned integer can be represented as:

$$I = b_3 \cdot 2^3 + b_2 \cdot 2^2 + b_1 \cdot 2^1 + b_0 \cdot 2^0,$$

which results in possible values in the range [0, 15].

Binary	Decimal	Explanation
0000	0	All bits are zero
0001	1	$1\cdot 2^0$
0010	2	$1 \cdot 2^1$
0111	7	$1 \cdot 2^2 + 1 \cdot 2^1 + 1 \cdot 2^0$
1111	15	Maximum 4-bit unsigned integer

Table 1: Example values for 4-bit unsigned integers.

#### 1.2.2 Signed Integers: Two's Complement Representation

In practice, computers often need to represent signed integers, i.e., integers that can be both positive and negative. One of the most widely used methods for representing signed integers is the *two's complement* notation. In this system, an *n*-bit signed integer *I* is expressed as:

$$I = -b_{n-1} \cdot 2^{n-1} + \sum_{i=0}^{n-2} b_i \cdot 2^i.$$

Here,  $b_{n-1}$  is the sign bit, with  $b_{n-1} = 0$  representing a non-negative integer, and  $b_{n-1} = 1$  representing a negative integer.

Binary (4-bit)	Decimal	Explanation
0000	0	Zero, all bits are zero
0111	7	Largest positive number $(2^2 + 2^1 + 2^0)$
1000	-8	Smallest negative number $(-2^3)$
1101	-3	$-2^3 + 2^2 + 2^0$
1111	-1	All bits are one $(-2^3 + 2^2 + 2^1 + 2^0)$

Table 2: Example values for 4-bit signed integers using two's complement.

#### 1.2.3 Detecting Overflow in Two's Complement Addition

For two signed integers *x* and *y* represented in two's complement, overflow in addition occurs if:

$$x > 0$$
 and  $y > 0$  and  $x + y < 0$ , or  $x < 0$  and  $y < 0$  and  $x + y > 0$ .

This can be efficiently detected by examining the sign bit of the result compared to the sign bits of the operands.

x (Binary)	y (Binary)	Sum (Binary)	Overflow?
0110 (6)	0101 (5)	1011 (-5)	Yes (Positive overflow)
1001 (-7)	1110 (-2)	0111 (7)	Yes (Negative overflow)
0011 (3)	0010 (2)	0101 (5)	No
1101 (-3)	1100 (-4)	1001 (-7)	No

Table 3: Overflow detection in two's complement addition.

#### 1.2.4 Summary

The representation of integers on a computer is constrained by the finite number of bits available. Unsigned integers use all bits to represent non-negative values, while signed integers often employ two's complement to encode both positive and negative values. Careful handling of overflow is essential in arithmetic operations to ensure correct computational results.

## 1.3 Memory Layout in Computer Systems

In modern computer systems, memory is divided into several distinct segments that each serve a different purpose in the execution of a program. These segments include the stack, heap, and various regions that hold code and data. This section provides a mathematical description of the layout of memory in a typical system and explains the role of each memory segment.

#### 1.3.1 Memory Segments

A typical program is divided into the following memory segments:

Stack	Used for local variables, function call management, and control flow. It grows downward in memory.
Цоан	Used for dynamic memory allocation (e.g., via malloc).
Heap	It grows upward in memory.
.text	Stores the program's executable instructions (machine code).
.data	Stores initialized global and static variables.
.bss	Stores uninitialized global and static variables.
.035	This segment is initialized to zero at runtime.
.rodata	Stores read-only data, such as string literals or constant variables.

The memory layout in a typical process can be visualized as:

Higher Memory Addresses

Grows Down

Heap (grows up)

Uninitialized Data (.bss)
Initialized Data (.data)
Read-Only Data (.rodata)

Program Code (.text)

**Lower Memory Addresses** 

#### 1.3.2 The Stack Segment

The *stack* is used to store local variables, function parameters, return addresses, and control flow information during program execution. For each function call, a *stack frame* is allocated, which contains the function's local variables and bookkeeping information (such as the return address). The stack grows downward, meaning that memory addresses decrease as more data is added to the stack.

Mathematically, the size of the stack at any given time can be described as:

$$S(t) = S_0 - \sum_{i=1}^n f_i,$$

where  $S_0$  is the initial stack pointer, n is the number of function calls made, and  $f_i$  represents the size of the i-th function's stack frame.

#### 1.3.3 The Heap Segment

The *heap* is used for dynamic memory allocation, typically requested via system calls such as malloc or new. Memory in the heap is managed manually by the programmer and persists until it is explicitly deallocated. The heap grows upward in memory.

At any point in time, the size of the heap H(t) can be expressed as:

$$H(t) = H_0 + \sum_{i=1}^{m} d_i - \sum_{j=1}^{k} r_j,$$

where  $H_0$  is the base address of the heap,  $d_i$  represents the size of the i-th dynamically allocated block, and  $r_j$  represents the size of the j-th deallocated block. The heap size grows with allocations and shrinks with deallocations.

#### 1.3.4 The .text Segment

The .text segment contains the program's machine code instructions. It is typically read-only, and any attempt to write to this segment will result in an error. The size of the .text segment is constant after the program is loaded into memory.

Let the .text segment size be denoted by T. If the program contains n instructions, each requiring  $b_i$  bytes of memory, the total size of the .text segment is:

$$T = \sum_{i=1}^{n} b_i.$$

#### 1.3.5 The .data Segment

The .data segment contains initialized global and static variables. It is writable and persistent throughout the program's execution. Each variable in this segment has an initial value, set by the program's code. The size of the .data segment is determined by the number and size of initialized global variables.

If a program has n initialized global or static variables, and each variable  $v_i$  requires  $s_i$  bytes, the size of the .data segment is:

$$D = \sum_{i=1}^{n} s_i.$$

#### 1.3.6 The .bss Segment

The .bss segment contains uninitialized global and static variables, which are automatically initialized to zero by the system at runtime. This segment does not require any space in the executable file but consumes memory at runtime.

Let the number of uninitialized variables be n and let each variable  $v_i$  require  $s_i$  bytes. The size of the .bss segment is:

$$B = \sum_{i=1}^{n} s_i.$$

#### 1.3.7 The .rodata Segment

The .rodata segment contains read-only data, such as constant literals and string constants. This data cannot be modified during program execution. The size of the .rodata segment is determined by the size of the constants stored within it.

If a program has n read-only constants, and each constant  $c_i$  requires  $r_i$  bytes, the total size of the .rodata segment is:

$$R = \sum_{i=1}^{n} r_i.$$

#### 1.3.8 Memory Layout Table

To summarize the properties of each memory segment, the following table presents a comparison of the key characteristics of each section in the memory layout:

Segment	Purpose	<b>Growth Direction</b>	Writable?
.text	Stores executable instructions	N/A	No
.data	Stores initialized global/static variables	N/A	Yes
.bss	Stores uninitialized global/static variables	N/A	Yes
.rodata	Stores read-only constants	N/A	No
Неар	Dynamic memory allocation	Upward	Yes
Stack	Function call management, local variables	Downward	Yes

Table 4: Summary of memory segments in a typical program.

#### 1.3.9 Summary

The memory layout in a computer is divided into distinct segments, each with a specific role. The stack and heap are used for dynamic and local memory management, respectively, while the .text, .data, .bss, and .rodata segments store the program's instructions, global variables, and constants. Understanding the characteristics of each segment is crucial for efficient memory management and debugging in system-level programming.

## 1.4 Performance Metrics in Computer Systems

The performance of a computer system can be rigorously measured and analyzed using several key metrics. These metrics provide a quantitative way to evaluate the efficiency of the system in executing tasks. In this section, we will define and interrelate fundamental performance metrics such as response time, throughput, elapsed time, CPU time, instruction count, clock cycles, and discuss performance optimization via Amdahl's Law.

#### 1.4.1 Response Time and Throughput

The *response time* of a system, also referred to as *execution time*, is the time required to complete a single task or process. Mathematically, let  $T_r$  denote the response time for a task P:

$$T_r = T_{elapsed}(P)$$

where  $T_{elapsed}$  represents the total time elapsed from the start to the completion of task P. This includes not only the time the CPU spends on P, but also the time the task spends waiting for I/O or other resources.

While response time measures how long a single task takes, *throughput* is concerned with the system's overall capacity to process tasks. It is defined as the number of tasks completed per unit of time. Let X(t) represent the throughput over a period of time t, and n be the number of tasks completed during this time. Then throughput is given by:

$$X = \frac{n}{t}$$
.

Throughput and response time are inversely related in many systems, with higher throughput often implying lower response time under certain conditions.

#### 1.4.2 Elapsed Time and CPU Time

The total time to execute a task, known as *elapsed time*, includes both the time spent actively executing on the CPU and the time spent waiting for other resources (e.g., I/O). Let  $T_{cpu}(P)$  represent the CPU time for task P, and  $T_{io}(P)$  represent the time spent waiting for I/O. The total elapsed time  $T_{elapsed}(P)$  can be written as:

$$T_{elapsed}(P) = T_{cpu}(P) + T_{io}(P).$$

The *CPU time* is the time during which the CPU is actively executing the instructions of the program. It can be divided into two components: *user CPU time*,  $T_{user}$ , which represents the time spent executing the program itself, and *system CPU time*,  $T_{system}$ , which accounts for time spent executing system calls and operating system code. The total CPU time for a task P is:

$$T_{cpu}(P) = T_{user}(P) + T_{system}(P).$$

A key factor influencing CPU time is the number of instructions executed and the efficiency of instruction processing, as discussed next.

#### 1.4.3 Instruction Count and Clock Cycles

The time required for a task to complete is dependent on the number of instructions executed and the number of *clock cycles* needed to execute each instruction. Let I(P) represent the *instruction count*—the total number of instructions executed for a task P. The efficiency of instruction execution is typically measured by the *clock cycles per instruction* (CPI), which denotes the average number of clock cycles required to execute one instruction.

The total number of clock cycles  $C_{total}$  required to execute a program P is:

$$C_{total}(P) = I(P) \cdot \text{CPI}.$$

The CPU operates at a certain clock frequency f, typically measured in cycles per second (Hz). Given the total number of clock cycles  $C_{total}(P)$ , the CPU time  $T_{cpu}(P)$  for task P can be expressed as:

$$T_{cpu}(P) = \frac{C_{total}(P)}{f} = \frac{I(P) \cdot \text{CPI}}{f}.$$

Here, the total CPU time is directly proportional to the number of instructions, the CPI, and inversely proportional to the clock frequency.

#### 1.4.4 CPU Clock and Its Impact on Performance

The *CPU clock* frequency f determines the rate at which the *CPU* executes instructions. Each clock cycle represents a discrete time step in which the *CPU* processes a small unit of work. Let  $T_{clock}$  represent the duration of a single clock cycle, which is the reciprocal of the clock frequency:

$$T_{clock} = \frac{1}{f}.$$

Thus, the total time to complete a program *P* can be expressed in terms of clock cycles and frequency, further emphasizing the critical role of the clock frequency in determining system performance.

#### 1.4.5 Amdahl's Law

In practice, performance improvements often focus on optimizing certain parts of a program or task. However, the potential benefit from such optimization is limited by the fraction of the program that cannot be improved. This limitation is formalized by *Amdahl's Law*, which provides an upper bound on the speedup that can be achieved by enhancing a portion of a program.

Let p be the fraction of the task P that can benefit from improvement, and let k represent the factor by which this portion can be sped up. The overall speedup S is given by:

$$S = \frac{1}{(1-p) + \frac{p}{L}}.$$

In the case where  $k \to \infty$  (i.e., the improved part is infinitely fast), the maximum theoretical speedup  $S_{max}$  is:

$$S_{max} = \frac{1}{1 - p}.$$

Amdahl's Law highlights the diminishing returns of optimization when a significant fraction of the task remains unaffected by the improvement.

#### 1.4.6 Interrelation of Metrics

These performance metrics—response time, throughput, CPU time, instruction count, clock cycles, and the CPU clock—are deeply interconnected. The response time of a program depends directly on its CPU time, which in turn depends on the number of instructions executed and the clock cycles per instruction. Throughput is inversely related to response time, as it reflects the system's ability to process multiple tasks in a given period.

Optimizing system performance often involves improving the CPI (through hard-ware efficiency), increasing the clock frequency, or reducing the number of instructions in a program. Amdahl's Law serves as a reminder that the overall system speedup is constrained by the fraction of the task that can be optimized.

#### 1.4.7 Summary

The performance of a computer system can be understood through the interplay of several fundamental metrics. Response time, throughput, CPU time, and elapsed time provide different perspectives on performance. These metrics are influenced by the instruction count, clock cycles, and clock frequency, which together determine how efficiently a program is executed. Amdahl's Law further illustrates the limitations of performance improvements when only a portion of the task can be optimized. By considering these metrics in unison, we gain a comprehensive understanding of computer performance.

# 2 GNU Assembly Syntax

# References

- [1] ARM Holdings, ARM64 Architecture Reference Manual, 2020.
- [2] ARM Compiler Reference, Using the ARM64 calling convention.
- [3] Brian W. Kernighan, Dennis M. Ritchie, *The C Programming Language*, 2nd Edition.