# **Chapter-1**

- Chapter-1
  - Introduction
    - Stress
      - Normal Stress
      - Tangential Stress
    - Fluid
  - 1-1 The No-Slip Condition
    - Definition
  - 1-2 System and Control Volume
    - Definition
    - Classifications
      - Closed System
      - Open System

## Introduction

#### **Stress**

Stress is defined as the force per unit area

#### **Normal Stress**

$$\sigma = \frac{\mathrm{d}F_n}{\mathrm{d}A}$$

In a fluid at rest, the **normal stress** is called **pressure P** 

#### **Tangential Stress**

$$\tau = \frac{\mathrm{d}F_t}{\mathrm{d}A}$$

#### Fluid

A substance in the liquid or gas phase is referred to as a fluid


A fluid **deforms continuously** under the influence of a shear stress, no matter how small and approaches a certain rate of strain

## 1-1 The No-Slip Condition

#### **Definition**

A fluid in direct contact with a solid "sticks" to the surface due to viscous effects

The fluid property responsible for the no-slip condition and the development of the boundary layer is viscosity



## 1-2 System and Control Volume

### **Definition**

A **system** is defined as a quantity of matter or a region in space chosen for study

The mass or region outside the system is called the **surroundings** 

The real or imaginary surface that separates the system from its surroundings is called the **boundary** 

### **Classifications**

#### **Closed System**

a system consists of a fixed amount of mass and no mass can cross its boundary

#### **Open System**

a system where both mass and energy can cross the boundary of a control volume