## **CH\_3**

### **Hooke's Law**

$$\sigma = E\varepsilon$$

• E: the modulus of elasticity of Youngs' modulus, which has the stress units


## **Poison Ratio**

$$\nu = -\frac{\varepsilon'}{\varepsilon}$$

- $\nu$ : Poison Ratio
- $\varepsilon$ : axial strain
- $\varepsilon'$ : lateral strain

## **Shear Stress**

the stress component that act in the plane of the sectioned area



## **Average Bearing Stress**

$$\sigma_b = \frac{F_b}{A_b}$$


- $F_b$ : bearing force
- $A_b$ : bearing area

Average Shear Stress at Section


$$\tau_{aver} = \frac{V}{A}$$

- *V*: internal shear force at section determined from equations of equilibrium
- A: area of section

#### **Single Shear**



#### **Double Shear**



- Positive strain is when the angle between two positive faces is reduced
- Negative strain is when the angle between two positive faces is increased

#### **Hooke's Law for Shear**

$$\tau = G\gamma$$

$$G = \frac{E}{2(1+\nu)}$$

• G: shear modulus of elasticity

## **Allowable Stresses and Allowance Loads**

When designing a structural member or mechanical element, the design interest is **strength**, that is *the capacity of the object to support or transmit loads* 

• factor of safety (F.S.)

$$n = \frac{\textit{Actual Strength}}{\textit{Required Strength}}$$

allowable strength

$$\sigma_{
m allow} = rac{\sigma_{
m Y}}{n_1}$$
  $au_{
m allow} =$ 

- $\sigma_Y$  and  $\tau_Y$  are yield stresses
- $n_1$  and  $n_2$  are the corresponding factors of safety.

# **Design for Axial Loads and Direct Shear**

• determine the area of section subjected to a normal force

$$A = \frac{P}{\sigma_{allow}}$$

• determine the area of section subjected to a shear force

$$A = \frac{V}{\tau_{allow}}$$