Name: HARSHIT PRAKASH SHETTY

Class:TY-AIEC-B

Enrollment No: MITU22BTCS0321

Roll No: 2223617

Edge Computing Lab

Class: TY-AIEC

School of Computing, MIT Art Design Technology University

Academic Year: 2024-25
Experiment No. 10

Introduction

Study of Transfer Learning (Images) on Edge Computing Devices

Objective: Build a project to apply Transfer Learning of MobileNetV1 & V2 architectures trained on an ImageNet dataset Tasks:

- Understand Transfer learning
- Understanding of MobileNetV1 & V2 Architectures
- Configure Edge Impulse for Object Detection
- Apply a pre-trained network for you to fine-tune your specific application
- Building and Training a Model
- Deploy on Edge Computing Devices

Introduction

Edge Impulse is a development platform for machine learning on edge devices, targeted at developers who want to create intelligent device solutions. The "Camera "sensor reading equivalent in Edge Impulse would typically involve creating a simple machine learning model that can run on an edge device, like classifying sensor data or recognizing a basic pattern.

Materials Required

Nano BLE Sense Board

Theory

GPIO (General Purpose Input/Output) pins on the Raspberry Pi are used for interfacing with other electronic components. BCM numbering refers to the pin numbers in the Broadcom SOC channel, which is a more consistent way to refer to the GPIO pins across different versions of the


Here's a high-level overview of steps you'd follow to create a "Hello World" project on Edge Impulse:


Steps to Configure the Edge Impulse:

- 1. Create an Account and New Project:
 - Sign up for an Edge Impulse account.
 - Create a new project from the dashboard.
- 2. Connect a Device:
 - You can use a supported development board or your smartphone as a sensor device.
 - Follow the instructions to connect your device to your Edge Impulse project.
- 3. Collect Data:
 - Use the Edge Impulse mobile app or the Web interface to collect data from the onboard sensors.
 - For a "Hello World" project, you could collect accelerometer data, for instance.
- 4. Create an Impulse:
 - Go to the 'Create impulse' page.
 - Add a processing block (e.g., time-series data) and a learning block (e.g., classification).
 - Save the impulse, which defines the machine learning pipeline.
- 5. Design a Neural Network:
 - Navigate to the 'NN Classifier' under the 'Learning blocks'.
 - Design a simple neural network. Edge Impulse provides a default architecture that works well for most basic tasks.
- 6. Train the Model:
 - ☐ Click on the 'Start training' button to train your machine learning model with the collected data.
- 7. Test the Model:
 - ☐ Once the model is trained, you can test its performance with new data in the 'Model Testing' tab.


8. Deploy	the Model:
•	Go to the 'Deployment' tab.
•	Select the deployment method that suits your edge device (e.g., Arduino library, WebAssembly, container, etc.).
•	Follow the instructions to deploy the model to your device.
9. Run Inference:	
ا ت	With the model deployed, run inference on the edge device to see it classifying data in real-time.
10. Monitor:	
ٔ ۵	You can monitor the performance of your device through the Edge Impulse studio.
Paste your Edge Impulse project's Results:	

1) Dataset Image






3) Accuracy / Loss - Confusion Matrix - image



4) Validation Result - Image



5) Copy the code of Arduino Sketch

```
/* Edge Impulse ingestion SDK
* Copyright (c) 2022 EdgeImpulse
Inc.
* Licensed under the Apache License,
Version 2.0 (the "License");
* you may not use this file except
in compliance with the License.
* You may obtain a copy of the
License at
http://www.apache.org/licenses/LICENS
                                          **
E-2.0
* Unless required by applicable law
or agreed to in writing, software
* distributed under the License is
distributed on an "AS IS" BASIS,
* WITHOUT WARRANTIES OR CONDITIONS
                                         **
OF ANY KIND, either express or
implied.
* See the License for the specific
language governing permissions and
* limitations under the License.
                                          **
*/
/* Includes -----
   #include <Image_MFA_inferencing.h>
                                         **
#include <Arduino_OV767X.h> //Click
here to get the library:
https://www.arduino.cc/reference/en/l
ibraries/arduino_ov767x/
                                         */
#include <stdint.h>
#include <stdlib.h>
/* Constant variables -----
--- */
#define
                                  1
EI CAMERA RAW FRAME BUFFER COLS
```

```
#define
EI_CAMERA_RAW_FRAME_BUFFER_ROWS
#define DWORD_ALIGN_PTR(a)
                           ((a &
0x3) ?(((uintptr_t)a + 0x4) &
\sim(uintptr t)0x3) : a)
** NOTE: If you run into TFLite
arena allocation issue.
** This may be due to may dynamic
memory fragmentation.
** Try defining "-
DEI CLASSIFIER ALLOCATION STATIC" in
boards.local.txt (create
** if it doesn't exist) and copy
this file to
`<ARDUINO CORE INSTALL PATH>/arduino/
hardware/<mbed core>/<core version>/`
** See
(https://support.arduino.cc/hc/en-
us/articles/360012076960-Where-are-
the-installed-cores-located-)
** to find where Arduino installs
cores on your machine.
** If the problem persists then
there's not enough memory for this
model and application.
/* Edge Impulse -----
______
--- */
class OV7675 : public OV767X {
   public:
       int begin(int resolution, int
format, int fps);
       void readFrame(void* buffer);
```

private:

```
int vsyncPin;
        int hrefPin;
        int pclkPin;
        int xclkPin;
       volatile uint32_t* vsyncPort;
        uint32 t vsyncMask;
       volatile uint32 t* hrefPort;
       uint32_t hrefMask;
        volatile uint32_t* pclkPort;
        uint32_t pclkMask;
       uint16_t width;
       uint16 t height;
       uint8_t bytes_per_pixel;
       uint16 t bytes per row;
       uint8 t buf rows;
       uint16_t buf_size;
       uint8_t resize_height;
       uint8 t *raw buf;
       void *buf mem;
        uint8_t *intrp_buf;
       uint8_t *buf_limit;
       void readBuf();
       int allocate scratch buffs();
       int
deallocate_scratch_buffs();
};
typedef struct {
size_t width;
 size t height;
} ei_device_resize_resolutions_t;
* @brief Check if new serial
data is available
* @return Returns number of
available bytes
*/
int ei get serial available(void) {
   return Serial.available();
}
* @brief Get next available
byte
```

```
* @return
             bvte
*/
char ei_get_serial_byte(void) {
   return Serial.read();
/* Private variables -----
-- */
static OV767X Cam;
static bool is_initialised = false;
/*
** @brief points to the output of the
capture
*/
static uint8_t *ei_camera_capture_out
= NULL;
uint32 t resize col sz;
uint32 t resize row sz;
bool do_resize = false;
bool do crop = false;
static bool debug nn = false; // Set
this to true to see e.g. features
generated from the raw signal
/* Function definitions -----
bool ei_camera_init(void);
void ei camera deinit(void);
bool ei camera capture(uint32 t
img_width, uint32_t img_height,
uint8_t *out_buf);
int
calculate resize dimensions(uint32 t
out_width, uint32_t out_height,
uint32 t *resize col sz, uint32 t
*resize row sz, bool *do resize);
void resizeImage(int srcWidth, int
srcHeight, uint8_t *srcImage, int
dstWidth, int dstHeight, uint8 t
*dstImage, int iBpp);
void cropImage(int srcWidth, int
srcHeight, uint8_t *srcImage, int
startX, int startY, int dstWidth, int
```

```
dstHeight, uint8 t *dstImage, int
iBpp);
/**
             Arduino setup function
* @brief
*/
void setup()
   // put your setup code here, to
run once:
   Serial.begin(115200);
   // comment out the below line to
cancel the wait for USB connection
(needed for native USB)
   while (!Serial);
    Serial.println("Edge Impulse
Inferencing Demo");
    // summary of inferencing
settings (from model metadata.h)
    ei_printf("Inferencing
settings:\n");
    ei printf("\tImage resolution:
%dx%d\n", EI CLASSIFIER INPUT WIDTH,
EI CLASSIFIER INPUT HEIGHT);
    ei_printf("\tFrame size: %d\n",
EI CLASSIFIER DSP INPUT FRAME SIZE);
    ei_printf("\tNo. of classes:
%d\n",
sizeof(ei_classifier_inferencing_cate
gories) /
sizeof(ei_classifier_inferencing_cate
gories[0]));
}
/**
             Get data and run
* @brief
inferencing
* @param[in] debug Get debug info
if true
*/
void loop()
    bool stop inferencing = false;
   while(stop inferencing == false)
```

```
ei printf("\nStarting
inferencing in 2 seconds...\n");
        // instead of wait ms, we'll
wait on the signal, this allows
threads to cancel us...
       if (ei sleep(2000) !=
EI IMPULSE OK) {
            break;
        }
       ei_printf("Taking
photo...\n");
        if (ei camera init() ==
false) {
            ei printf("ERR: Failed to
initialize image sensor\r\n");
            break;
       }
       // choose resize dimensions
       uint32 t resize col sz;
       uint32_t resize_row_sz;
       bool do_resize = false;
        int res =
calculate resize dimensions(EI CLASSI
FIER INPUT WIDTH,
EI_CLASSIFIER_INPUT_HEIGHT,
&resize col sz, &resize row sz,
&do resize);
       if (res) {
            ei printf("ERR: Failed to
calculate resize dimensions
(%d)\r\n", res);
            break;
        }
       void *snapshot_mem = NULL;
       uint8 t *snapshot buf = NULL;
        snapshot mem =
ei_malloc(resize_col_sz*resize_row_sz
*2);
       if(snapshot_mem == NULL) {
            ei_printf("failed to
create snapshot_mem\r\n");
           break;
       }
```

```
snapshot buf = (uint8 t
*)DWORD ALIGN PTR((uintptr t)snapshot
mem);
(ei_camera_capture(EI_CLASSIFIER_INPU
T WIDTH, EI CLASSIFIER INPUT HEIGHT,
snapshot_buf) == false) {
            ei_printf("Failed to
capture image\r\n");
            if (snapshot mem)
ei_free(snapshot_mem);
            break;
        }
        ei::signal_t signal;
        signal.total length =
EI_CLASSIFIER_INPUT_WIDTH *
EI_CLASSIFIER_INPUT_HEIGHT;
        signal.get data =
&ei_camera_cutout_get_data;
        // run the impulse: DSP,
neural network and the Anomaly
algorithm
        ei_impulse_result_t result =
{ 0 };
        EI IMPULSE ERROR ei error =
run classifier(&signal, &result,
debug nn);
        if (ei_error !=
EI IMPULSE OK) {
            ei_printf("Failed to run
impulse (%d)\n", ei_error);
            ei_free(snapshot_mem);
            break;
        }
        // print the predictions
        ei printf("Predictions (DSP:
%d ms., Classification: %d ms.,
Anomaly: %d ms.): \n",
                  result.timing.dsp,
result.timing.classification,
result.timing.anomaly);
#if EI CLASSIFIER OBJECT DETECTION ==
1
```

```
ei printf("Object detection
bounding boxes:\r\n");
        for (uint32_t i = 0; i <</pre>
result.bounding boxes count; i++) {
            ei_impulse_result_boundin
g_box_t bb =
result.bounding_boxes[i];
            if (bb.value == 0) {
                continue;
            ei_printf(" %s (%f) [ x:
%u, y: %u, width: %u, height: %u
]\r\n",
                    bb.label.
                    bb.value,
                    bb.x, bb.y,
                    bb.width,
                    bb.height);
        }
   // Print the prediction results
(classification)
#else
        ei_printf("Predictions:\r\n")
        for (uint16 t i = 0; i <
EI_CLASSIFIER_LABEL_COUNT; i++) {
            ei printf(" %s: ",
ei classifier inferencing categories[
i]);
            ei_printf("%.5f\r\n",
result.classification[i].value);
#endif
    // Print anomaly result (if it
exists)
#if EI CLASSIFIER HAS ANOMALY
        ei printf("Anomaly
prediction: %.3f\r\n",
result.anomaly);
#endif
#if EI_CLASSIFIER_HAS_VISUAL_ANOMALY
        ei_printf("Visual
anomalies:\r\n");
        for (uint32_t i = 0; i <</pre>
result.visual_ad_count; i++) {
```

```
ei impulse result boundin
g box t bb =
result.visual_ad_grid_cells[i];
            if (bb.value == 0) {
                continue;
            }
            ei_printf(" %s (%f) [ x:
%u, y: %u, width: %u, height: %u
]\r\n",
                    bb.label.
                    bb.value,
                    bb.x, bb.y,
                    bb.width,
                    bb.height);
        }
#endif
       while
(ei_get_serial_available() > 0) {
            if (ei_get_serial_byte()
== 'b') {
                ei printf("Inferencin
g stopped by user\r\n");
                stop_inferencing =
true;
            }
        if (snapshot mem)
ei_free(snapshot_mem);
   ei_camera_deinit();
}
* @brief
              Determine whether to
resize and to which dimension
* @param[in] out width
                             width of
output image
* @param[in] out_height
                             height
of output image
* @param[out]
resize col sz
                  pointer to frame
buffer's column/width value
* @param[out]
resize row sz
                  pointer to frame
buffer's rows/height value
```

```
* # @param[out] do resize
                              returns
whether to resize (or not)
*/
int
calculate_resize_dimensions(uint32_t
out_width, uint32_t out_height,
uint32 t *resize col sz, uint32 t
*resize_row_sz, bool *do_resize)
    size t list size = 2;
   const
ei_device_resize_resolutions_t
list[list size] = { {42,32}, {128,96}
};
    // (default) conditions
    *resize col sz =
EI_CAMERA_RAW_FRAME_BUFFER_COLS;
    *resize row sz =
EI CAMERA RAW FRAME BUFFER ROWS;
    *do_resize = false;
    for (size t ix = 0; ix <</pre>
list size; ix++) {
if ((out width <=</pre>
list[ix].width) && (out height <=</pre>
list[ix].height)) {
            *resize_col_sz =
list[ix].width;
            *resize_row_sz =
list[ix].height;
            *do resize = true;
            break;
        }
    }
    return 0;
}
/**
* @brief Setup image sensor &
start streaming
* @retval false if initialisation
failed
*/
bool ei_camera_init(void) {
    if (is_initialised) return true;
```

```
if (!Cam.begin(QQVGA, RGB565, 1))
{ // VGA downsampled to QQVGA
(OV7675)
       ei_printf("ERR: Failed to
initialize camera\r\n");
       return false;
   is_initialised = true;
   return true;
}
* @brief
              Stop streaming of
sensor data
void ei_camera_deinit(void) {
    if (is_initialised) {
       Cam.end();
       is_initialised = false;
}
* @brief
              Capture, rescale and
crop image
* @param[in] img_width
                            width of
output image
* @param[in] img_height
                            height
of output image
* @param[in] out buf
                             pointer
to store output image, NULL may be
used
                             when
full resolution is expected.
* @retval
             false if not
initialised, image captured, rescaled
or cropped failed
*
*/
bool ei_camera_capture(uint32_t
img_width, uint32_t img_height,
uint8_t *out_buf)
    if (!is_initialised) {
```

```
ei printf("ERR: Camera is not
initialized\r\n");
       return false;
   }
   if (!out_buf) {
       ei printf("ERR: invalid
parameters\r\n");
       return false;
   }
   // choose resize dimensions
   int res =
calculate resize dimensions(img width
, img_height, &resize_col_sz,
&resize_row_sz, &do_resize);
   if (res) {
       ei_printf("ERR: Failed to
calculate resize dimensions
(%d)\r\n", res);
       return false;
   }
   if ((img width != resize col sz)
       || (img_height !=
resize_row_sz)) {
       do crop = true;
   Cam.readFrame(out_buf); //
captures image and resizes
   if (do crop) {
       uint32_t crop_col_sz;
       uint32_t crop_row_sz;
       uint32_t crop_col_start;
       uint32 t crop row start;
       crop_row_start =
(resize_row_sz - img_height) / 2;
crop col start =
(resize_col_sz - img_width) / 2;
crop_col_sz = img_width;
crop_row_sz = img_height;
        //ei_printf("crop cols: %d,
rows: %d\r\n",
crop_col_sz,crop_row_sz);
       cropImage(resize_col_sz,
resize_row_sz,
```

```
out buf,
                crop_col_start,
crop_row_start,
                crop_col_sz,
crop_row_sz,
                out_buf,
                16);
    }
   // The following variables should
always be assigned
   // if this routine is to return
true
   // cutout values
   //ei camera snapshot is resized =
do resize;
   //ei camera snapshot is cropped =
do_crop;
   ei_camera_capture_out = out_buf;
   return true;
}
* @brief
              Convert RGB565 raw
camera buffer to RGB888
* @param[in] offset
                             pixel
offset of raw buffer
* @param[in] length
                             number
of pixels to convert
* @param[out] out buf
                             pointer
to store output image
*/
int ei_camera_cutout_get_data(size_t
offset, size_t length, float
*out ptr) {
    size t pixel ix = offset * 2;
    size_t bytes_left = length;
    size t out ptr ix = 0;
   // read byte for byte
   while (bytes left != 0) {
        // grab the value and convert
to r/g/b
        uint16_t pixel =
(ei_camera_capture_out[pixel_ix] <</pre>
8) |
ei_camera_capture_out[pixel_ix+1];
```

```
uint8 t r, g, b;
        r = ((pixel >> 11) \& 0x1f) <<
3;
        g = ((pixel >> 5) \& 0x3f) <<
2;
        b = (pixel \& 0x1f) << 3;
        // then convert to out ptr
format
        float pixel f = (r << 16) +
(g << 8) + b;
        out_ptr[out_ptr_ix] =
pixel f;
        // and go to the next pixel
        out ptr ix++;
        pixel ix+=2;
        bytes_left--;
    }
    // and done!
    return 0;
}
// This include file works in the
Arduino environment
// to define the Cortex-M intrinsics
#ifdef ARM FEATURE SIMD32
#include <device.h>
#endif
// This needs to be < 16 or it won't
fit. Cortex-M4 only has SIMD for
signed multiplies
#define FRAC BITS 14
#define FRAC VAL (1<<FRAC BITS)</pre>
#define FRAC_MASK (FRAC_VAL - 1)
//
// Resize
//
// Assumes that the destination
buffer is dword-aligned
// Can be used to resize the image
smaller or larger
// If resizing much smaller than 1/3
size, then a more rubust algorithm
should average all of the pixels
// This algorithm uses bilinear
interpolation - averages a 2x2 region
to generate each new pixel
```

```
// Optimized for 32-bit MCUs
// supports 8 and 16-bit pixels
void resizeImage(int srcWidth, int
srcHeight, uint8_t *srcImage, int
dstWidth, int dstHeight, uint8_t
*dstImage, int iBpp)
    uint32_t src_x_accum,
src y accum; // accumulators and
fractions for scaling the image
    uint32_t x_frac, nx_frac, y_frac,
ny_frac;
   int x, y, ty, tx;
    if (iBpp != 8 && iBpp != 16)
        return;
src_y_accum = FRAC_VAL/2; //
start at 1/2 pixel in to account for
integer downsampling which might miss
pixels
    const uint32_t src_x_frac =
(srcWidth * FRAC VAL) / dstWidth;
    const uint32 t src y frac =
(srcHeight * FRAC VAL) / dstHeight;
    const uint32_t r_mask =
0xf800f800;
    const uint32_t g_mask =
0x07e007e0;
    const uint32 t b mask =
0x001f001f;
    uint8_t *s, *d;
    uint16 t *s16, *d16;
    uint32_t x_frac2, y_frac2; // for
16-bit SIMD
   for (y=0; y < dstHeight; y++) {
        ty = src y accum >>
FRAC BITS; // src y
       y_frac = src_y_accum &
FRAC MASK;
        src_y_accum += src_y_frac;
        ny_frac = FRAC_VAL - y_frac;
// y fraction and 1.0 - y fraction
        y_frac2 = ny_frac | (y_frac
<< 16); // for M4/M4 SIMD
s = &srcImage[ty * srcWidth];
s16 = (uint16 t)
*)&srcImage[ty * srcWidth * 2];
        d = &dstImage[y * dstWidth];
```

```
d16 = (uint16 t *)&dstImage[y
* dstWidth * 2];
src_x_accum = FRAC_VAL/2; //
start at 1/2 pixel in to account for
integer downsampling which might miss
pixels
        if (iBpp == 8) {
        for (x=0; x < dstWidth; x++)
            uint32 t tx,
p00,p01,p10,p11;
            tx = src_x_accum >>
FRAC BITS;
            x frac = src x accum &
FRAC MASK;
            nx_frac = FRAC_VAL -
x_{frac}; // x fraction and 1.0 - x
fraction
            x_frac2 = nx_frac |
(x_frac << 16);
            src_x_accum +=
src_x_frac;
            p00 = s[tx]; p10 =
s[tx+1];
            p01 = s[tx+srcWidth]; p11
= s[tx+srcWidth+1];
    #ifdef ARM FEATURE SIMD32
            p00 = \_SMLAD(p00 |
(p10<<16), x_frac2, FRAC_VAL/2) >>
FRAC BITS; // top line
            p01 = SMLAD(p01)
(p11<<16), x_frac2, FRAC_VAL/2) >>
FRAC BITS; // bottom line
            p00 = SMLAD(p00)
(p01<<16), y_frac2, FRAC_VAL/2) >>
FRAC_BITS; // combine
    #else // generic C code
            p00 = ((p00 * nx_frac) +
(p10 * x_frac) + FRAC_VAL/2) >>
FRAC BITS; // top line
            p01 = ((p01 * nx_frac) +
(p11 * x_frac) + FRAC_VAL/2) >>
FRAC_BITS; // bottom line
           p00 = ((p00 * ny_frac) +
(p01 * y_frac) + FRAC_VAL/2) >>
FRAC_BITS; // combine top + bottom
    #endif // Cortex-M4/M7
            *d++ = (uint8_t)p00; //
store new pixel
```

```
} // for x } // 8-bpp else {
        // RGB565 for (x=0; x)
       dstWidth; x++)
{
            uint32 t tx,
p00,p01,p10,p11;
            uint32_t r00, r01, r10,
r11, g00, g01, g10, g11, b00, b01,
b10, b11;
           tx = src_x_accum >>
FRAC BITS;
            x_frac = src_x_accum &
FRAC_MASK;
            nx_frac = FRAC_VAL -
x_frac; // x fraction and 1.0 - x
fraction
            x_frac2 = nx_frac |
(x_frac << 16);
            src_x_accum +=
src_x_frac;
            p00 =
 builtin_bswap16(s16[tx]); p10 =
__builtin_bswap16(s16[tx+1]);
p01 =
builtin bswap16(s16[tx+srcWidth]);
builtin bswap16(s16[tx+srcWidth+1])
   #ifdef __ARM_FEATURE_SIMD32
            p00 |= (p10 << 16);
            p01 |= (p11 << 16);
            r00 = (p00 \& r_mask) >>
1; g00 = p00 & g_mask; b00 = p00 &
b mask;
            r01 = (p01 \& r_mask) >>
1; g01 = p01 & g_mask; b01 = p01 &
b mask;
            r00 = \__SMLAD(r00)
x_frac2, FRAC_VAL/2) >> FRAC_BITS; //
top line
            r01 = SMLAD(r01,
x_frac2, FRAC_VAL/2) >> FRAC_BITS; //
bottom line
           r00 = SMLAD(r00)
(r01<<16), y_frac2, FRAC_VAL/2) >>
FRAC_BITS; // combine
```

```
g00 = SMLAD(g00)
x_frac2, FRAC_VAL/2) >> FRAC_BITS; //
top line
            g01 = \_SMLAD(g01,
x_frac2, FRAC_VAL/2) >> FRAC_BITS; //
bottom line
            g00 = SMLAD(g00)
(g01<<16), y_frac2, FRAC_VAL/2) >>
FRAC_BITS; // combine
            b00 = \_SMLAD(b00)
x frac2, FRAC VAL/2) >> FRAC BITS; //
top line
            b01 = \_SMLAD(b01,
x frac2, FRAC VAL/2) >> FRAC BITS; //
bottom line
           b00 = SMLAD(b00)
(b01<<16), y_frac2, FRAC_VAL/2) >>
FRAC BITS; // combine
   #else // generic C code
            r00 = (p00 \& r_mask) >>
1; g00 = p00 & g mask; b00 = p00 &
b mask;
            r10 = (p10 \& r mask) >>
1; g10 = p10 & g_mask; b10 = p10 &
b mask;
            r01 = (p01 \& r_mask) >>
1; g01 = p01 & g_mask; b01 = p01 &
b mask;
           r11 = (p11 \& r_mask) >>
1; g11 = p11 & g_mask; b11 = p11 &
b mask;
            r00 = ((r00 * nx frac) +
(r10 * x_frac) + FRAC_VAL/2) >>
FRAC_BITS; // top line
            r01 = ((r01 * nx_frac) +
(r11 * x_frac) + FRAC_VAL/2) >>
FRAC_BITS; // bottom line
            r00 = ((r00 * ny frac) +
(r01 * y_frac) + FRAC_VAL/2) >>
FRAC_BITS; // combine top + bottom
            g00 = ((g00 * nx_frac) +
(g10 * x_frac) + FRAC_VAL/2) >>
FRAC_BITS; // top line
            g01 = ((g01 * nx_frac) +
(g11 * x_frac) + FRAC_VAL/2) >>
FRAC_BITS; // bottom line
```

```
g00 = ((g00 * ny frac) +
(g01 * y_frac) + FRAC_VAL/2) >>
FRAC_BITS; // combine top + bottom
            b00 = ((b00 * nx_frac) +
(b10 * x_frac) + FRAC_VAL/2) >>
FRAC_BITS; // top line
            b01 = ((b01 * nx_frac) +
(b11 * x frac) + FRAC VAL/2) >>
FRAC_BITS; // bottom line
            b00 = ((b00 * ny frac) +
(b01 * y frac) + FRAC VAL/2) >>
FRAC_BITS; // combine top + bottom
            }
    #endif // Cortex-M4/M7
            r00 = (r00 << 1) &
r_mask;
            g00 = g00 & g mask; b00 =
            b00 \& b mask; p00 = (r00)
            | g00 | b00);
// re-combine color components
            *d16++ =
(uint16_t)__builtin_bswap16(p00); //
store new pixel
        } // for x
        } // 16-bpp
    } // for y
} /* resizeImage() */
//
// Crop
// Assumes that the destination
buffer is dword-aligned
// optimized for 32-bit MCUs
// Supports 8 and 16-bit pixels
void cropImage(int srcWidth, int
srcHeight, uint8_t *srcImage, int
startX, int startY, int dstWidth, int
dstHeight, uint8_t *dstImage, int
iBpp)
{
   uint32_t *s32, *d32;
   int x, y;
if (startX < 0 || startX >=
srcWidth || startY < 0 || startY >=
srcHeight || (startX + dstWidth) >
srcWidth || (startY + dstHeight) >
srcHeight)
```

```
return; // invalid parameters
    if (iBpp != 8 && iBpp != 16)
       return;
    if (iBpp == 8) {
      uint8_t *s, *d;
      for (y=0; y<dstHeight; y++) {</pre>
        s = &srcImage[srcWidth * (y +
startY) + startX];
        d = &dstImage[(dstWidth *
y)];
        x = 0;
        if ((intptr_t)s & 3 ||
(intptr_t)d & 3) { // either src or
dst pointer is not aligned
          for (; x<dstWidth; x++) {</pre>
             *d++ = *s++; // have to
do it byte-by-byte
        } else {
          // move 4 bytes at a time
if aligned or alignment not enforced
          s32 = (uint32_t *)s;
          d32 = (uint32 t *)d;
          for (; x<dstWidth-3; x+= 4)</pre>
{
            *d32++ = *s32++;
          }
          // any remaining
stragglers?
          s = (uint8_t *)s32;
          d = (uint8_t *)d32;
          for (; x<dstWidth; x++) {</pre>
            *d++ = *s++;
        }
      } // for y
    } // 8-bpp
    else
    {
      uint16_t *s, *d;
      for (y=0; y<dstHeight; y++) {</pre>
        s = (uint16_t *)&srcImage[2 *
srcWidth * (y + startY) + startX *
2];
        d = (uint16_t
*)&dstImage[(dstWidth * y * 2)];
        x = 0;
```

```
if ((intptr t)s & 2 ||
(intptr t)d & 2) { // either src or
dst pointer is not aligned
           for (; x<dstWidth; x++) {</pre>
            *d++ = *s++; // have to
do it 16-bits at a time
          }
        } else {
           // move 4 bytes at a time
if aligned or alignment no enforced
          s32 = (uint32 t *)s; d32 =
          (uint32 t *)d; for (;
          x < dstWidth-1; x+= 2)
{ // we can move 2 pixels at a time
            *d32++ = *s32++;
          }
          // any remaining
stragglers?
          s = (uint16_t *)s32; d =
          (uint16 t *)d32; for (;
          x<dstWidth; x++) {</pre>
            *d++ = *s++;
          }
        }
      } // for y
    } // 16-bpp case
} /* cropImage() */
#if !defined(EI_CLASSIFIER_SENSOR) ||
EI CLASSIFIER SENSOR !=
EI CLASSIFIER SENSOR CAMERA
#error "Invalid model for current
sensor"
#endif
// OV767X camera library override
#include <Arduino.h>
#include <Wire.h>
#define digitalPinToBitMask(P) (1 <<</pre>
(digitalPinToPinName(P) % 32))
#define portInputRegister(P) ((P ==
0) ? &NRF P0->IN : &NRF P1->IN)
//
// OV7675::begin()
```

```
// Extends the OV767X library
function. Some private variables are
needed
// to use the OV7675::readFrame
function.
//
int OV7675::begin(int resolution, int
format, int fps)
    pinMode(OV7670 VSYNC, INPUT);
    pinMode(OV7670 HREF, INPUT);
    pinMode(OV7670_PLK, INPUT);
    pinMode(OV7670_XCLK, OUTPUT);
    vsyncPort =
portInputRegister(digitalPinToPort(OV)
7670 VSYNC));
    vsyncMask =
digitalPinToBitMask(OV7670_VSYNC);
    hrefPort =
portInputRegister(digitalPinToPort(OV)
7670_HREF));
    hrefMask =
digitalPinToBitMask(OV7670 HREF);
    pclkPort =
portInputRegister(digitalPinToPort(OV)
7670 PLK));
    pclkMask =
digitalPinToBitMask(OV7670_PLK);
    // init driver to use full image
sensor size
    bool ret = OV767X::begin(VGA,
format, fps);
    width = OV767X::width(); // full
sensor width
    height = 0V767X::height(); //
full sensor height
    bytes_per_pixel =
OV767X::bytesPerPixel();
    bytes_per_row = width *
bytes_per_pixel; // each pixel is 2
bytes
    resize_height = 2;
    buf_mem = NULL;
    raw buf = NULL;
    intrp_buf = NULL;
    //allocate scratch buffs();
```

```
return ret;
} /* OV7675::begin() */
int OV7675::allocate_scratch_buffs()
    //ei printf("allocating
buffers..\r\n");
    buf_rows = height / resize_row_sz
* resize height;
    buf size = bytes per row *
buf rows;
    buf_mem = ei_malloc(buf_size);
    if(buf mem == NULL) {
        ei_printf("failed to create
buf mem\r\n");
        return false;
    raw buf = (uint8 t
*)DWORD ALIGN PTR((uintptr t)buf mem)
    //ei printf("allocating buffers
OK\r\n");
    return 0;
}
OV7675::deallocate scratch buffs()
    //ei_printf("deallocating
buffers...\r\n");
   ei free(buf mem);
   buf_mem = NULL;
    //ei printf("deallocating buffers
OK\r\n");
    return 0;
}
// OV7675::readFrame()
// Overrides the OV767X library
function. Fixes the camera output to
// a far more desirable image. This
image utilizes the full sensor size
```

```
// and has the correct aspect ratio.
Since there is limited memory on the
// Nano we bring in only part of the
entire sensor at a time and then //
interpolate to a lower resolution. //
void OV7675::readFrame(void* buffer) {
    allocate_scratch_buffs();
    uint8 t* out = (uint8 t*)buffer;
    noInterrupts();
   // Falling edge indicates start
of frame
   while ((*vsyncPort & vsyncMask)
== 0); // wait for HIGH
   while ((*vsyncPort & vsyncMask)
!= 0); // wait for LOW
    int out row = 0;
    for (int raw height = 0;
raw height < height; raw height +=
buf rows) {
       // read in 640xbuf rows
buffer to work with
       readBuf();
        resizeImage(width, buf_rows,
                    raw buf,
                    resize_col_sz,
resize_height,
                    &(out[out row]),
                    16);
       out_row += resize_col_sz *
resize_height * bytes_per_pixel; /*
resize col sz * 2 * 2 */
    interrupts();
   deallocate scratch buffs();
} /* OV7675::readFrame() */
// OV7675::readBuf()
//
```

```
// Extends the OV767X library
                                                         // rising edges clock
function. Reads buf rows VGA rows
                                            each data byte
from the
                                                        while ((*pclkPort &
// image sensor.
                                             pclkMask) != 0); // wait for LOW
void OV7675::readBuf()
                                                         uint32_t in = port->IN;
                                             // read all bits in parallel
    int offset = 0;
                                                         in >>= 2; // place bits 0
    uint32 t ulPin = 33; // P1.xx set
                                             and 1 at the "bottom" of the register
of GPIO is in 'pin' 32 and above
                                                         in \&= 0x3f03; // isolate
    NRF_GPIO_Type * port;
                                             the 8 bits we care about
                                                         in |= (in >> 6); //
                                             combine the upper 6 and lower 2 bits
    port =
nrf_gpio_pin_port_decode(&ulPin);
                                                         raw_buf[offset++] = in;
    for (int i = 0; i < buf_rows;</pre>
                                                        while ((*pclkPort &
i++) {
        // rising edge indicates
                                             pclkMask) == 0); // wait for HIGH
start of line
                                                     }
       while ((*hrefPort & hrefMask)
== 0); // wait for HIGH
                                                     while ((*hrefPort & hrefMask)
                                             != 0); // wait for LOW
        for (int col = 0; col <</pre>
                                             } /* OV7675
bytes_per_row; col++) {
::readBuf() */
```

6) Screen shot of Arduino Terminal - Result

