- 1. A neutral atom with atomic number 6 will have 6 electrons and 6 protons.
- **2.** The maximum number of electrons that can exist in an given atom shell n is calculated by the formula

$$N = 2n^2$$

This means that the maximum number of electronics in the third shell of an atom is

$$2 \cdot 3^2 = 2 \cdot 9 = 18$$

- 3. Materials are categorized into three groups called isolators, semiconductors, and conductors. Isolators have the largest band gap between the conduction band and valence band. Semiconductors will have a smaller band gap than isolators. Conductors have an overlap between the conduction band and the valence band.
- **4.** There are several types of atoms that have four valence electrons, for example silicon and germanium. These types of atoms are classified as semiconductors.
- **5.** A single atom in a silicon crystal forms four covalent bounds.
- **6.** Adding heat to silicon will cause valence electrons to become free electrons, this increases the conductivity.
- **7.** The valencen band and the conduction band are the two energy bands at which current is produced in silicon.
- 8. Doping intentionally introduces impurities into an extremely pure intrinsic semiconductor for the purpose of modulating its electrical properties. N-doping increases the number of free electrons by adding impurity atoms that have five valence electrons. P-doping increases the number of holes by adding impurity atoms that have three valence electrons.