

# HPE Synergy Image Streamer RHEL 7.2 Artifact Bundle Documentation

Edition: 1

Published: March 2017



# **Notices**

The information contained herein is subject to change without notice. The only warranties for Hewlett Packard Enterprise products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty.

Hewlett Packard Enterprise shall not be liable for technical or editorial errors or omissions contained herein. Confidential computer software. Valid license from Hewlett Packard Enterprise required for possession, use, or copying. Consistent with FAR 12.211 and 12.212, Commercial Computer Software, Computer Software Documentation, and Technical Data for Commercial Items are licensed to the U.S. Government under vendor's standard commercial license.

Links to third-party websites take you outside the Hewlett Packard Enterprise website. Hewlett Packard Enterprise has no control over and is not responsible for information outside the Hewlett Packard Enterprise website.

# **Table of contents**

1 HPE Synergy Image Streamer Artifact Bundle of RHEL 7.2	4
1.1.1 Artifact Bundle: HPE-RHEL-7.2-artifacts	4
1.1.2 4	
1.2 Prerequisite	4
1.2.1 Filesystem	4
1.2.2 LogicalVolumeMangement (LVM):	4
1.2.3 NIC Teaming	4
1.2.4 Adding Multiple NIC's:	
1.2.5 Adding the user:	4
1.3 Build Plans	5
1.3.1 Build Plan: RHEL-7.2-personalize-and-configure-NICs-reg-rh	nel-LVM-BP .5
1.3.2 Build Plan: RHEL-7.2-personalize-and-NIC-teamings-reg-rhe	el-LVM-BP6
1.4 Plan Scripts	7
1.4.1 Plan Script: RHEL-7.2-mount-and-validate	7
1.4.2 Plan Script: RHEL-7.2-configure-multiple-NICs	7
1.4.3 Plan Script: RHEL-7.2-configure-multiple-NIC-teaming	8
1.4.4 8	
1.4.5 Plan Script: RHEL-7.2-configure-hostname	10
1.4.6 Plan Script: RHEL-7.2-configure-users	11
1.4.7 Plan Script: RHEL-7.2-configure-partition-using-LVM	
1.4.8 Plan Script: RHEL-7.2-manage-services	
1.4.9 Plan Script: RHEL-7.2-unmount	14
1.5 Procedure for creating a Linux Golden Image	14

# 1 HPE Synergy Image Streamer Artifact Bundle of RHEL 7.2

The HPE Synergy Image Streamer Artifact Bundle of RHEL 7.2 includes artifact which is helpful to personalize the RHEL 7.2 OS.

#### 1.1.1 Artifact Bundle: HPE-RHEL-7.2-artifacts

#### 1.1.2

This artifact personalizes the RHEL 7.2 OS environment based on user input. It contains 2 Build Plan and 9 Plan Scripts.

## 1.2 Prerequisite:

## 1.2.1 Filesystem:

The filesystem of RHEL 7.2 image should be ext3 or ext4.

We assume that root partition (/) is mounted on /dev/sda3 or /dev/rhel/root. If the root partition is not on the mentioned device the user has to edit RHEL-7.2-mount-and-validate Plan Script before proceeding.

## 1.2.2 LogicalVolumeMangement (LVM):

User has to add a local drive for LVM type partitioning, while creating the server profile user should edit "Integrated storage controller mode" option of local storage to add a local drive for the server. There will be only two partitions done. Ensure that the disk is in a clean state before you start using it.

## 1.2.3 NIC Teaming:

For NIC teaming the user should add two network connection with same VLAN ID for teaming in the add network section of server profile. And while selecting the **Team0NIC1** and **Team0NIC2** the network should be of same VLAN ID

## 1.2.4 Adding Multiple NIC's:

While selecting the **MgmtNIC1**, **MgmtNIC2**, **MgmtNIC3** and **MgmtNIC4** the user should select a different network. User should not use the same network for selecting the MgmtNIC's.

## 1.2.5 Adding the user:

The user can add one or more users. User can add more users either with comma separated or semicolon separated or space separated and the password will be same for all the user. User can change password on their first login, though it is not enforced.

## 1.3 Build Plans

## 1.3.1 Build Plan: RHEL-7.2-personalize-and-configure-NICs-LVM-BP

Build Plan personalizes the RHEL 7.2 server by creating a new users, applying multiple nic configuration, allowing the network to access from outside world, updating the hostname, creating partition on the disk, enabling SELINUX service, server hardening and changing the root password as per user parameters.

Steps: Plan Script Names	Attributes
RHEL-7.2-mount-and-validate	
RHEL-7.2-configure-multiple-NICs	MgmtNIC1(NIC)
	MgmtNIC2(NIC)
	MgmtNIC3(NIC)
	MgmtNIC4(NIC)
	TotalMgmtNICs(Option)
RHEL-7.2-configure-hostname	DomainName(FQDN)
RHEL-7.2-configure-users	NewRootPassword(Password)
	NewUserName(String)
	NewUserPassword(Password)
RHEL-7.2-configure-partition-using-LVM	DiskName(String)
	FirstPartitionSize(Number)
	LogicalVolumeGroupName(String)
	LogicalVolumeName(String)
	LogicalVolumeSize(Number)
	SecondPartitionSize(Number)
RHEL-7.2-manage-services	SSH(Option)

RHEL-7.2-unmount	

## 1.3.2 Build Plan: RHEL-7.2-personalize-and-NIC-teamings-LVM-BP

Build Plan personalizes the RHEL 7.2 server by creating a new users, creating multiple nic teaming, allowing the network to access from outside world, updating the hostname, creating partition on the disk, enabling SELINUX service, server hardening and changing the root password as per user parameters.

Steps: Plan Script Names	Attributes
RHEL-7.2-mount-and-validate	
RHEL-7.2-configure-multiple-NIC-teaming	FirstNicTeamName(String)  SecondNicTeamName(String)  Team0NIC1(NIC)  Team0NIC2(NIC)  Team1NIC1(NIC)  Team1NIC2(NIC)  TotalNicTeamings(Option)
RHEL-7.2-configure-hostname	DomainName(FQDN)
RHEL-7.2-configure-users	NewRootPassword(Password)  NewUserName(String)  NewUserPassword(Password)

DiskName(String)
FirstPartitionSize(Number)
LogicalVolumeGroupName(String)
LogicalVolumeName(String)
LogicalVolumeSize(Number)
SecondPartitionSize(Number)
SSH(Option)

## 1.4 Plan Scripts

## 1.4.1 Plan Script: RHEL-7.2-mount-and-validate

This Plan Script lists all mount partitions and mounts the root partition of the image.

After the mount script validates golden image to check whether it is appropriate image to use. And verifies whether the image was captured by the HPE Synergy Image Streamer or not.

## 1.4.2 Plan Script: RHEL-7.2-configure-multiple-NICs

This script gives the user an option of configuring four NICs and user as to select the total number of NICs to configure as DHCP or Static as per their requirement. User has to add public network while creating server profile.

#### Attributes:

MgmtNIC1 (NIC)

This attribute is of type NIC and has the following four sub-attributes:

- MgmtNIC1.dhcp
- MgmtNIC1.gateway
- MgmtNIC1.ipaddress
- MgmtNIC1.mac
- MgmtNIC1.netmask

These sub-attributes are used to edit the network file of the first NIC in RHEL 7.2.

MgmtNIC2 (NIC)

This attribute is of type NIC and has the following four sub-attributes:

- MgmtNIC2.dhcp
- MgmtNIC2.gateway
- MgmtNIC2.ipaddress

- MgmtNIC2.mac
- MgmtNIC2.netmask

These sub-attributes are used to edit the network file of the second NIC in RHEL 7.2.

#### MgmtNIC3 (NIC)

This attribute is of type NIC and has the following four sub-attributes:

- MgmtNIC3.dhcp
- MgmtNIC3.gateway
- MgmtNIC3.ipaddress MgmtNIC3.mac
- MgmtNIC3.netmask

These sub-attributes are used to edit the network file of the third NIC in RHEL 7.2.

#### MgmtNIC4 (NIC)

This attribute is of type NIC and has the following four sub-attributes:

- MgmtNIC4.dhcp
- MgmtNIC4.gateway
- MgmtNIC4.ipaddress
- MgmtNIC4.mac
- MgmtNIC4.netmask

These sub-attributes are used to edit the network file of the fourth NIC in RHEL 7.2.

TotalMgmtNICs (Option)

This attribute is of type option where user must select the number of NICs to configure the server.

## 1.4.3 Plan Script: RHEL-7.2-configure-multiple-NIC-teaming

#### 1.4.4

This script gives the user an option of configure two NIC teaming and user as to select the total number of NICs for teaming as DHCP or Static as per their requirement. User has to add public network while creating server profile and can also specify the name for teaming the NICs.

#### Attributes:

FirstNicTeamName (String)

User can specify the name for first NIC teaming.

SecondNicTeamName (String)

It is of type string and can specify the name for second NIC teaming.

Team0NIC1 (NIC)

This attribute is of type NIC which has three sub attribute

- Team0NIC1.gateway,
- Team0NIC1.ipaddress
- Team0NIC1.mac

All these attributes are used for network teaming Team0NIC1 and Team0NIC2 as static or dhcp.

#### Team0NIC2 (NIC)

This attribute is of type NIC which has three sub attribute

- Team0NIC2.gateway, Team0NIC2.ipaddress
- Team0NIC2.mac

All these attributes are used for network teaming Team0NIC1 and Team0NIC2 as static or dhcp.

#### Team1NIC1

This attribute is of type NIC which has three sub attribute

- Team1NIC3.gateway,
- Team1NIC3.ipaddress
- Team1NIC3.mac

All these attributes are used for network teaming Team1NIC1 and Team1NIC2 as static or dhcp.

#### Team1NIC2

- Team1NIC3.mac

All these attributes are used for network teaming Team1NIC1 and Team1NIC2 as static or dhcp.

TotalNicTeamings (Option)

Gives option to select either one or two NIC teaming for the server.

## 1.4.4.1 Sample test screenshot

(Note: The screenshot has been captured through SSH console)

```
[root@myhost ~]# nmcli connection show
             UUID
NAME
                                                      TYPE
                                                                       DEVICE
team0
             699cce37-da3e-4e53-937f-e89858ea7d81
                                                                       team0
ibft0
             72d8c878-e0ad-475a-bace-5b5b968c6460
                                                                       ibft0
                                                      802-3-ethernet
iBFT ibft0
             c4764f86-d025-3d0e-8ec4-fd2d98246ade
                                                     802-3-ethernet
virbr0-nic
             d9080ba0-3e1b-4319-88dd-e0f332bb40a7
                                                      generic
                                                                       virbr0-nic
             3dbdeed6-099f-4491-b6be-06121a6cae1d
                                                                       virbr0
virbr0
                                                     bridge
team0-port2 a6204f55-4cc4-4309-9dc6-7bb0f827d7da 802-3-ethernet ens3f4
team0-port1 2ce887a5-7b88-479a-aa2c-dae38c1f3180 802-3-ethernet ens3f1
[root@myhost ~]# teamdctl team0 state
 runner: roundrobin
ports:
 ens3f1
   link watches:
  link summary: up
  instance[link_watch_0]:
        name: ethtool
        link: up
        down count: 0
  ens3f4
    link watches:
      link summary: up
      instance[link_watch_0]:
        name: ethtool
        link: up
        down count: 0
[root@myhost ~]# nmcli connection down team0-port1
.
Connection 'team0-port1' successfully deactivated (D-Bus active path: /org/freedesktop/NetworkManager/ActiveConnection/2)
[root@myhost ~]# teamdctl team0 state
setup:
 runner: roundrobin
ports:
 ens3f4
    link watches:
      link summary: up
instance[link_watch_0]:
        name: ethtool
        link: up
        down count: 0
[root@myhost ~]# nmcli connection show
NAME
                                                                       DEVICE
             UUTD
             699cce37-da3e-4e53-937f-e89858ea7d81 team 72d8c878-e0ad-475a-bace-5b5b968c6460 802-3
team0
                                                                       team0
ibft0
                                                      802-3-ethernet
                                                                       ibft0
             c4764f86-d025-3d0e-8ec4-fd2d98246ade
iBFT ibft0
                                                     802-3-ethernet
             d9080ba0-3e1b-4319-88dd-e0f332bb40a7
virbr0-nic
                                                      generic
                                                                       virbr0-nic
             3dbdeed6-099f-4491-b6be-06121a6cae1d
virbr0
                                                                       virbr0
                                                     bridge
team0-port2 a6204f55-4cc4-4309-9dc6-7bb0f827d7da 802-3-ethernet
                                                                      ens3f4
team0-port1 2ce887a5-7b88-479a-aa2c-dae38c1f3180 802-3-ethernet
```

## 1.4.5 Plan Script: RHEL-7.2-configure-hostname

This scripts assigns the hostname given by user, adds the alias in /etc/hosts file with respective to the interface name present in the /tmp/interface name file and also delete the default gateway so that the network can be accessible from the outside world.

The hostname assignment is done in HPE Synergy Image Streamer only, but updating /etc/hosts should be done when the host is up. So the script for updating hosts is added in **rc.local** file which is present in /etc/rc.d folder. And this script has to be added next either to the Plan Script RHEL-7.2-configure-multiple-NIC-teaming or RHEL-7.2-configure-multiple-NICs.

Attributes:

DomainName (FQDN)

This attribute is of type FQDN the user must specify the full domain name to which the network should belong.

## 1.4.6 Plan Script: RHEL-7.2-configure-users

Changes the root password and adds new users with data given by the user while creating the server profile. This scripts are executed in the **rc.local** file to do the operations. Script takes new root password and new user details as parameters.

Attributes:

NewRootPassword (Password)

Attribute is used to change the root password of the server based on user input.

NewUserName (String)

String used to create a new users to the server. And multiple user name can also give by either comma separated or semicolon separated.

NewUserPassword (Password)

This attribute is of type Password and used to set for the newly created user. Same password is assigned to the multiple users given by the users.

## 1.4.7 Plan Script: RHEL-7.2-configure-partition-using-LVM

Script partitions the newly added disk (example /dev/sda) into to two partitions (example /dev/sda1 /dev/sda2) of given size. Creates a logical volume group and logical volume and create ext4 file system and mounts the given directory to the new logical volume and adds the entry to /etc/fstab. User have to add local disk while creating server profile.

Attributes:

DiskName (String)

It is a string which takes the name of the disk to partition.

HPE Synergy Image Streamer RHEL 7.2 Artifact Bundle Documentation

FirstPartitionSize (Number)

This attribute take the size of the first partition to be in GiB. This is a special attribute which is recognized by the HPE Synergy Image Streamer.

LogicalVolumeGroupName (String)

This attribute is of type string it takes the name of logical volume group to create in the disk.

LogicalVolumeName (String)

The new logical volume to be create in the disk. It is of the type string.

LogicalVolumeSize (Number)

Size of the logical volume to be create will be in GiB unit.

SecondPartitionSize (Number)

This attribute take the size of the second partition to be in GiB. This is a special attribute which is recognized by the HPE Synergy Image Streamer.

## 1.4.7.1 Sample test screenshot:

(Note: The screenshot has been captured through SSH console)

```
[root@host -]# lsblk
NAME
                                                            MAJ:MIN RM SIZE RO TYPE MOUNTPOINT

8:0 0 279.4G 0 disk

8:1 0 10G 0 pert

253:2 0 15G 0 lvm /root/LVM-I

8:2 0 10G 0 pert

253:2 0 15G 0 lvm /root/LVM-I

8:16 0 20G 0 disk
  sda
       Lnew_vol_group-new_vol 253:2

tda2 8:2

Lnew_vol_group-new_vol 253:2
                                                                                                                        /root/LVM-Datal
       sda2
                                                                                                                        /root/LVM-Datal
                                                                 8:16
8:17
8:18
    db
                                                                                       200M
500M
19.3G
2G
17.3G
                                                                                                      0 part /boot,
0 part /boot
0 part
0 lvm [SWAP]
0 lvm /
     -sdb1
-sdb2
-sdb3
                                                                                                                        /boot/efi
                                                                                 00000
                                                                 8:19
       -rhel-swap
-rhel-root
                                                             253:0
                                                                                                                        [SWAP]
                                                             253:1
    root@host -l# clear
root@host -l# lsblk
                                                                                RM SIZE RO TYPE MOUNTPOINT
0 279.4G 0 disk
0 10G 0 pert
0 15G 0 lvm /root/LVM-[
0 10G 0 pert
0 15G 0 lvm /root/LVM-[
0 20G 0 disk
0 200M 0 pert /boot/efi
0 500M 0 pert /boot
0 19.3G 0 pert
0 2G 0 lvm [SWAP]
0 17.3G 0 lvm /
                                                             MAJ:MIN RM
   i da
                                                                  8:0
     -sda1 8:1

-inew_vol_group-new_vol 253:2

-sda2 8:2

-new_vol_group-new_vol 253:2
                                                                                                                        /root/LVM-Datal
                                                                                                                        /root/LVM-Datal
                                                                 8:16
8:17
8:18
     -sdb1
-sdb2
-sdb3
8:19
                                                            253:0
253:1
                                                                                             Used Avail Use% Mounted on

3.2G 15G 19% /

0 16G 0% /dev

96K 16G 1% /dev/shm

9.7M 16G 1% /run

0 16G 0% /sys/fs/cgroup

154M 343M 31% /boot

9.5M 191M 5% /boot/efi

41M 14G 1% /root/LVM-Datal

20K 3.2G 1% /run/user/002

0 3.2G 0% /run/user/0
                                                                                 18G
16G
16G
16G
16G
                                                                                              154M
9.5M
41M
20K
0
                                                                                                            343M
191M
14G
3.2G
3.2G
    dev/sdb2
dev/sdb1
                                                                                 497M
                                                                                  200M
                                                                                 15G
3.2G
3.2G
    /dev/mapper/new_vol_group-new_vol
   tmpfs
tmpfs
    mprs
root@host -l# vgs
VG #PV #LV #SN Attr
new_vol_group 2 1 0 wz--r
1 2 0 wz--r
                                                                                                                             0% /run/user/0
                                                            5N Attr VSize VFree
0 wz--n- 19.99g 4.99g
0 wz--n- 19.31g 40.00m
     root@host -l# lvs
                                                        Attr LSize Pool Origin Data% Meta% Move Log Cpy%Sync Convert -wi-ao---- 15.00g -wi-ao---- 17.27g -wi-ao---- 2.00g
   LV VG A
new_vol new_vol_group -
root rhel -
swap rhel -
[root@host -]# pvdisplay
--- Physical volume ---
PV Name /
VG Name n
PV Size 1
Allocatable y
PE Size 4
Total PE 2
Free PE 6
      LV
                        ۷G
                                                        -W1-80----
                                                       new vol group
10.80 GIB / not useble 4.00 MiB
yes (but full)
4.00 MiB
                                                        /dev/sdal
                                                        2559
      Free PE
Allocated PE
PV UUID
                                                        qPpF0y-xQwM-ptbX-2qvj-mwwT-GrXI-Cjtwyv
       --- Physical volume ---
     --- Physical
PV Name
VG Name
PV Size
Allocatable
PE Size
Total PE
                                                        /dev/sde2
new_vol_group
10.00 GIB / not usable 4.00 MiB
                                                        yes
4.00 MiB
2559
      Free PE
Allocated PE
                                                         1278
                                                         1281
                                                        d0q19u-yrow-iBUL-ceZ6-91wT-DWXs-6hfrwt
      PV IIIITD
      --- Physical volume ---
PV Name /
VG Name r
PV Size 1
Allocatable y
                                                        /dev/sdb3
rhel
19.31 GiB / not usable 2.00 MiB
                                                        yes
4.00 MiB
      PE Size
Total PE
                                                        4944
                                                        10
      Free PE
Allocated PE
      PV UUID
                                                        IGTRZY-eGWA-Pidb-TI4K-U0tF-BZ40-42Ahr9
    root@host -l#
```

## 1.4.8 Plan Script: RHEL-7.2-manage-services

This script enables the SELINUX service which supports access control security policies and also performs server hardening operations such as enabling the SSH service and disabling the firewall service so that the network is accessible through external network. It also gives the user an option to enable or disable the SSH.

Attributes:

SSH (Option)

This attribute is a user option to enable or disable the SSH service of the server.

## 1.4.9 Plan Script: RHEL-7.2-unmount

This Plan Script sets up **rc.local** file, removes the temporary directory created during mount operation and unmounts the root partition.

## 1.5 Procedure for creating a Linux Golden Image

The following process explains how to create an RHEL 7.2 golden image using HPE Synergy Image Streamer.

- 1. Ensure that you have access to RHEL 7.2 ISO installation file containing iSCSI device drivers.
- 2. Create a server profile with "HPE Foundation 1.0 create empty OS Volume" as OS Deployment plan and any available server hardware. Set an appropriate value for volume size in MiB units. The HPE Synergy Server will be configured for access to this empty OS Volume.
- Launch iLO Integrated Remote Console of this server and set RHEL 7.2 ISO file as virtual CD-ROM/DVD image file. Power on the server.
- 4. RHEL installation starts and RHEL installer detects the configured empty OS Volume as an iSCSI disk device. Select this iSCSI disk device as the target for RHEL installation.
- 5. Follow onscreen instructions and complete the RHEL installation.
- 6. Power off the server.
- 7. Navigate to HPE Synergy Image Streamer -> Golden Images and Click 'Create Golden image'
- 8. Select the OS volume corresponding to the server profile created for empty OS volume and choose "RHEL-7.2-generalize" as the capture build plan.
- 9. HPE Synergy Image Streamer generalizes and captures RHEL image and adds it as a golden image.