
MULTIPLE CHOICES

- 1. What are the design principles for modern computers? [a, b, c, d]
 - (a) Instructions directly executed by hardware
 - (b) Provide plenty of registers
 - (c) Instructions should be easy to decode
 - (d) Only loads, stores should reference memory
 - (e) Minimize rate at which instructions are issued
- 2. Which of following is true for the cell? [a]
 - (a) Memories consist of a number of cells
 - (b) A cell with k bits can hold one of 2^k different values
 - (c) If an address has m bits, the maximum number of cells addressable is 2m
- 3. Which of following is true about byte? [a, c]
 - (a) 1 byte is 8-bit
 - (b) 1 byte is 4-bit
 - (c) 64-bit Word: 8 bytes per word
 - (d) 32-bit Word: 8 bytes per word
- 4. The von Neumann model of a computer consists of three major components: the central processing unit (CPU), main memory, and input-output. In which of these components might we find the 32 registers of a MIPS processor?
- A. CPU
- B. Main memory
- C. Input-output
- D. CPU as well as main memory
- E. Main memory as well as input-output

Correct answer is A. The registers are in the CPU, not in the memory.


5. Consider the sequence of four instructions shown below.

In the space provided below, show the binary representation of each of the four instructions in this sequence. Clearly mark the instruction fields and show their decimal equivalent.




31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0


add \$7, \$7, \$6




addi \$5, \$5, -4




bne \$5, \$7, loop




6. The following diagram gives the organization of a simple computer with one CPU and two I/O devices. Is it correct? If not, please correct it in the diagram.



Central processing unit (CPU)



7. How many bits are sufficient for an address to reference the memory of Figs (a), (b), (c)?



Solution:

4, 3, 3

8. Instruction Set Design

As discussed in the book, the four princples of instruction set design are:

- 1. Simplicity favors regularity.
- 2. Smaller is faster.
- 3. Good design demands good compromises.
- 4. Make the common case fast.

A number of design decisions in the MIPS Architecture are listed below. Fill in the blank with the design principles which were applied in making each decision.

(a)	The opcode field is in the same position in all instructions	<u>1</u>
(b)	All instructions are exactly 32 bits long	<u>1</u>
(c)	Immediate instructions allow the use of small constants	4,(3)
(d)	The lui instruction allows the use of larger constants	4,(3)
(e)	The rs and rt fields are in the same position in R-type and I-type instructions	_1
(f)	A linkage register is used to store the return address for "leaf procedures"(instead of the stack) 链接寄存器用于存储"叶过程"的返回地址。(而不是堆栈)因为	_4_
(g)	<mark>大部分叶</mark> 过程都会用到返回地址,而如果把地址放在堆栈则不方便 Only 32 general purpose registers are used for R-type instructions	2