This is Google's cache of http://sdk.rethinkrobotics.com/intera/Workstation Setup. It is a snapshot of the page as it appeared on Oct 7, 2019 17:24:54 GMT. The current page could have changed in the meantime. Learn more.

Full version Text-only version View source

Tip: To quickly find your search term on this page, press Ctrl+F or ℋ-F (Mac) and use the find bar.

Create accountLog in Search Intera SDK Search

- More
 - View source
 - History
- Page

Workstation Setup

- Installation & Configuration
 - o Robot Setup
 - Workstation Setup
 - Networking
 - o Hello Robot!
 - Hardware Components
 - o SDK Workstation Requirements
 - Robot Workspace Guidelines
 - Field Service Menu (FSM)
 - Time and NTP
 - SDK Software UpdateSDK Release Notes
- Concepts
 - SDK Robot-Workstation Overview
 - E-STOP and Enable Robot
 - Arm Calibration
 - o Arm Control Systems
 - API Reference
- · Tutorials
 - Interaction Control Tutorial
 - Motion Interface Tutorial
 - o MoveIt! Tutorial
 - o Gazebo Tutorial
- Code Examples
 - Running Examples Overview
 - o Camera Image Display Example

 - Gripper Example
 Gripper Cuff Control Example
 - o Head Display Image Example
 - Head Movement Example
 - Lights Blinking Example
 - IK Service Example
 - Joint Position Example
 - Joint Position Waypoint Example
 - Joint Torque Springs Example
 - o Joint Trajectory Playback Example
 - Set Interaction Options Example
 - o Motion Interface Go-To-Joint Angles
- Support
 - User Forum
- · Tools
 - o All Pages
 - o Print
 - <u>Upload File</u>
 - What Links Here?

Jump to: navigation, search

This tutorial describes the setup of a development workstation

Contents

- 1 Required Hardware
 - 1.1 Workstation Requirements
- 2 Install Ubuntu
- 3 Open Terminal App
- 4 Install ROS
- 5 Create Development Workspace

- 6 Install Intera SDK Dependencies
- 7 Install Intera Robot SDK
- 8 Configure Robot Communication/ROS Workspace
 - 8.1 intera.sh ROS Environment Setup
 - 8.2 Copy the intera.sh script
 - 8.3 Customize the intera.sh script
 - o 8.4 Edit the 'robot hostname' field
 - o 8.5 Edit the 'your ip' field
 - o <u>8.6 Verify 'ros_version' field</u>
 - 8.7 Save and Close intera.sh script
 - 8.8 Initialize your SDK environment
- 9 Verify Environment
- 10 Setup Rviz

Required Hardware

· Sawyer Robot & Developer Workstation

Workstation Requirements

- A development workstation capable of running Ubuntu 16.04 LTS and ROS Kinetic (or Ubuntu 14.04 LTS and ROS Indigo), with the following minimum specifications:
 - o Intel i5 or above
 - 4GB Memory or above
 - o At least 7 GB of free disk space
 - Ethernet port
 - If any visualization (RViz) or simulation (Gazebo) is required for your application, a <u>dedicated NVidia graphics card</u> with proprietary NVidia drivers is recommended

Install Ubuntu

Ubuntu 16.04 (Recommended)
 Ubuntu 14.04

Follow the standard Ubuntu Installation Instructions for 16.04 (Desktop):

- Download the Installer Image file, by picking the "Desktop CD" image appropriate for your machine:
 - o 64-bit (AMD64) .iso image (recommended) / 32-bit (Intel x86) .iso image
- Create an Ubuntu LiveUSB installer by burning the installer image onto a USB stick.
 - Windows / Mac OS X / Ubuntu
- Follow the **Ubuntu Installation Instructions**

Follow the standard Ubuntu Installation Instructions for 14.04 (Desktop):

- Download the Installer Image file, by picking the "Desktop CD" image appropriate for your machine:
 - o 64-bit (AMD64) .iso image (recommended) / 32-bit (Intel x86) .iso image
- Create an Ubuntu LiveUSB installer by burning the installer image onto a USB stick.
 - Windows / Mac OS X / Ubuntu
- Follow the <u>Ubuntu Installation Instructions</u>

Open Terminal App

Search your computer for the Terminal package, and open it:



The rest of the workstation setup tutorial will take place in by typing commands in this terminal prompt.

Install ROS

● ○ ROS Kinetic for Ubuntu 16.04 (Recommended) ○ ROS Indigo for Ubuntu 14.04

Configure Ubuntu repositories

Configure your Ubuntu repositories to allow "restricted," "universe," and "multiverse." You can follow the Ubuntu guide for instructions on doing this.

Likely, they are already configured properly, and you only need to confirm the configuration.

Setup your sources.list

\$ sudo sh -c 'echo "deb http://packages.ros.org/ros/ubuntu xenial main" > /etc/apt/sources.list.d/ros-latest.list'

Setup your keys

\$ sudo apt-key adv --keyserver hkp://ha.pool.sks-keyservers.net:80 --recv-key 421C365BD9FF1F717815A3895523BAEEB01FA116

Update to Latest Software Lists

\$ sudo apt-get update

Install ROS Kinetic Desktop Full

\$ sudo apt-get install ros-kinetic-desktop-full

Initialize rosdep

rosdep enables you to easily install system dependencies for source you want to compile and is required to run some core components in ROS.

- \$ sudo rosdep init
- \$ rosdep update

Install rosinstall

\$ sudo apt-get install python-rosinstall

Configure Ubuntu repositories

Configure your Ubuntu repositories to allow "restricted," "universe," and "multiverse." You can follow the Ubuntu guide for instructions on doing this.

Likely, they are already configured properly, and you only need to confirm the configuration.

Setup your sources.list

\$ sudo sh -c 'echo "deb http://packages.ros.org/ros/ubuntu trusty main" > /etc/apt/sources.list.d/ros-latest.list'

Setup your keys

\$ sudo apt-key adv --keyserver hkp://ha.pool.sks-keyservers.net:80 --recv-key 421C365BD9FF1F717815A3895523BAEEB01FA116

Update to Latest Software Lists

\$ sudo apt-get update

Install ROS Indigo Desktop Full

\$ sudo apt-get install ros-indigo-desktop-full

NOTE: You may get a prompt about 'hddtemp' during the installation. You can safely answer 'No'.

Initialize rosdep

rosdep enables you to easily install system dependencies for source you want to compile and is required to run some core components in ROS.

- \$ sudo rosdep init
- \$ rosdep update

Install rosinstall

\$ sudo apt-get install python-rosinstall

Create Development Workspace

Create ROS Workspace

```
$ mkdir -p ~/ros_ws/src
# ros_ws (short for ROS Workspace)
```

Source ROS and Build

ROS Kinetic

Source ROS Setup

\$ source /opt/ros/kinetic/setup.bash

Build

```
$ cd ~/ros_ws
$ catkin_make
```

Create ROS Workspace

```
$ mkdir -p ~/ros_ws/src
# ros_ws (short for ROS Workspace)
```

Source ROS and Build

ROS Indigo (Supported)

Source ROS Setup

\$ source /opt/ros/indigo/setup.bash

Build

```
$ cd ~/ros_ws
$ catkin_make
```

Install Intera SDK Dependencies

Install SDK Dependencies

```
$ sudo apt-get update
```

\$ sudo apt-get install git-core python-argparse python-wstool python-vcstools python-rosdep ros-kinetic-control-msgs ros-kinetic-joystick-drivers ros-kinetic

Install SDK Dependencies

```
$ sudo apt-get update
```

\$ sudo apt-get install git-core python-argparse python-wstool python-vcstools python-rosdep ros-indigo-control-msgs ros-indigo-joystick-drivers ros-indigo-xa

Install Intera Robot SDK

● Intera 5.3 ROS Kinetic for Ubuntu 16.04 (Recommended)

O Intera 5.3 ROS Indigo for Ubuntu 14.04

Download the SDK on your Workstation

Checkout all required Github Repositories into your ROS workspace source directory: Use git clone or download the packages directly from Github:

```
$ cd ~/ros_ws/src
$ wstool init .
$ git clone https://github.com/RethinkRobotics/sawyer_robot.git
$ wstool merge sawyer_robot/sawyer_robot.rosinstall
$ wstool update
```

Source ROS Setup

To use ROS Kinetic to use RSDK, use command below:

```
# ROS Kinetic
$ source /opt/ros/kinetic/setup.bash
```

Build

```
$ cd ~/ros_ws
$ catkin_make
```

Download the SDK on your Workstation

Checkout all required Github Repositories into your ROS workspace source directory: Use git clone or download the packages directly from Github:

```
$ cd ~/ros_ws/src
$ wstool init .
$ git clone https://github.com/RethinkRobotics/sawyer_robot.git
$ wstool merge sawyer_robot/sawyer_robot.rosinstall
$ wstool update
```

Source ROS Setup

To use ROS Kinetic to use RSDK, use command below:

```
# ROS Kinetic
$ source /opt/ros/indigo/setup.bash
```

Build

```
$ cd ~/ros_ws
$ catkin_make
```

Configure Robot Communication/ROS Workspace

This step describes the configuration and setup of your ROS environment. This section assumes you have linked your workstation to the robot via Ethernet.

Important Note: Connect to the robot via the ethernet port on the outside of the Controller. Connecting to the ethernet port inside the Controller door will not work (this is a diagnostic port that is only accessible by Rethink Employees).



See Network Setup for recommended network configurations.

intera.sh ROS Environment Setup

The intera.sh script is a convenience script which allows for intuitive modification of the core ROS environment components. This user edited script will allow for the quickest and easiest ROS setup.

Further information and a detailed description is available on the **SDK_Shell** page.

Copy the intera.sh script

The intera.sh file already exists in intera sdk repo, copy the file into your ros workspace.

```
$ cp ~/ros_ws/src/intera_sdk/intera.sh ~/ros_ws
```

Customize the intera.sh script

Please edit the intera.sh shell script making the necessary modifications to describe your development PC.

Using your favorite editor (gedit used for example)

```
$ cd ~/ros_ws
$ gedit intera.sh
```

Edit the 'robot hostname' field

Your robot's hostname is defaulted as the **Controller's Serial Number** and NOT the Robot's Serial Number. The serial number can be located on the back of the robot's controller box. Unless you intend to modify the default Networking configuration, leave the ".local" suffix on the end of the Controller's Serial Number in the **robot_hostname.local** field.

Edit the 'your ip' field

Modify where 'your ip' is either your computer's hostname or the IP address of your PC. We advise against using WiFi connections between your robot and workstation.

```
your_ip="192.168.XXX.XXX"
```

Useful command for identifying your IP address:

```
$ ifconfig
# Result will be contained in the 'inet addr' field (Ubuntu).
```

Alternatively, you may choose to use the hostname of your development PC rather than the PC's IP address. For instructions, press Expand on the right.

You may edit the 'your hostname' field (only if not using 'your ip'):

```
your_hostname="my_computer.local
```

Important: This hostname must be resolvable to Sawyer. To test if your hostname is resolvable to Sawyer, please visit the development PC Hostname Validation page.

Important: Only set either ROS_IP *OR* ROS_HOSTNAME.

Setting of both ROS_IP and ROS_HOSTNAME will result in ROS_HOSTNAME taking priority, resulting in confusing environment setups. Comment out the unused method using the '#' as leading character.

Verify 'ros version' field

Verify that the the 'ros version' field matches the ROS version you are running:

This field will default to "indigo". To use another ROS version, update:

● ROS Kinetic for Ubuntu 16.04 (Recommended) ROS Indigo for Ubuntu 14.04

ros version="kinetic"

ros_version="indigo"

Save and Close intera.sh script

Please save and close the intera.sh script.

Initialize your SDK environment

From this point forward, your ROS environment setup should be as simple as sourcing the intera.sh script from the root of your Catkin workspace:

\$ cd ~/ros_ws
\$./intera.sh

Verify Environment

A useful command for viewing and validating your ROS environment setup is:

\$ env | grep ROS

The important fields at this point:

ROS_MASTER_URI - This should now contain your robot's hostname.

ROS_IP - This should contain your workstation's IP address.

or

ROS_HOSTNAME - If not using the workstation's IP address, the ROS_HOSTNAME field should contain your PC's hostname. Otherwise, this field should not be available.

Try to get rostopic list from robot by typing following command:

\$ rostopic list

You can see the rostopic list from the command line output similar as following:

Rostopic list.png

Setup Rviz

We can also setup Rviz to view robot model, start Rviz from a properly initialized environment using:

\$ rosrun rviz rviz

Set the Fixed Frame as /base

Info: The 'Fixed Frame' provides a static, base reference for your visualization. Any sensor data that comes in to rviz will be transformed into that reference frame so it can be properly displayed in the virtual world.

Rviz Fixed Frame.png

Add robot model into Rviz by clicking add button, then select robot model in the list, press OK to add.

Rviz Add Model.png

Now you can visualize your robot on Rivz! Next : Hello Robot

Retrieved from "http://sdk.rethinkrobotics.com/intera/a/index.php?title=Workstation_Setup&oldid=1578"

Powered by MediaWiki

- © 2019 Rethink Robotics. All rights reserved.
- Special page
- Privacy policy
- About Intera SDK
- <u>Disclaimers</u>