

# ROB - Basics lab

Adam Fabo

Brno University of Technology, Faculty of Information Technology  
Božetěchova 1/2. 612 66 Brno - Královo Pole  
[xfaboa00@fit.vutbr.cz](mailto:xfaboa00@fit.vutbr.cz)




January 30, 2023

Today's lab will be focused on **Basics of Arduino**. You will learn


- Creating and uploading code for Arduino
- Prototyping electronic circuits using breadboard
- Reading and Writing **digital** signal
- Reading and Writing **analog** signal

- Arduino is set of open source hardware and software projects used for fast prototyping of electronics circuits
- Lots of boards - Arduino Mega, Arduino Uno, Arduino Nano, Arduino Micro, Arduino Zero ...
- Supports a lot of kits, shields, sensors, tools, accessories.
- <https://www.arduino.cc>




Arduino board used in this lab is [Arduino Mega](#). It consists of:

- 16MHz ATmega2560 processor
- 54 Digital I/O Pins (of which 15 provide PWM output)
- 16 Analog Input Pins
- 256 KB Flash, 8 KB SRAM, 4 KB EEPROM
- Built in LED at pin 13



- <https://store.arduino.cc/products/arduino-mega-2560-rev3>



- For programming Arduino boards, you need to know [c/c++](#)
- <https://www.arduino.cc/reference/en/>

// If condition

```
int x = 0;  
if(x == 10){  
    do_something();  
}else{  
    do_something_else();  
}
```

// For loop

```
for(int i=0; i < 10; i++){  
    do_something();  
}
```

// While loop

```
int i = 0;  
while(i < 10){  
    do_something();  
    i++;  
}
```


- Arduino IDE is used for programming Arduino boards.
- Old looking but well functional
- Good for fast prototyping, but harder to use for bigger projects.

The screenshot shows the Arduino IDE interface. The main window displays the code for the 'Blink' example sketch. The code is as follows:


```
1 // 
2 // Blink
3 //
4 // Turns an LED on for one second, then off for one second, repeatedly.
5 //
6 // Most Arduinos have an on-board LED you can control. On the Uno, Mega and ZERO
7 // it is attached to digital pin 13, on MEGA2560 on pin 6. LED_BUILTIN is set to
8 // the correct LED pin independent of which board is used.
9 // If you want to know what pin the on-board LED is connected to on your Arduino
10 // model, check the Technical Specs of your board at
11 // https://www.arduino.cc/en/Main/Products
12 //
13 // modified 8 May 2014
14 // by Scott Fitzgerald
15 // modified 2 Sep 2016
16 // by Arturo Guadalupi
17 // modified 8 Sep 2016
18 // by Colby Neeman
19 //
20 // This example code is in the public domain.
21 //
22 // https://www.arduino.cc/en/Tutorial/BuiltInExamples/Blink
23 */
24 //
25 // the setup function runs once when you press reset or power the board
26 void setup() {
27     // initialize digital pin LED_BUILTIN as an output.
28     pinMode(LED_BUILTIN, OUTPUT);
29 }
```

The top menu bar shows 'File', 'Edit', 'Sketch', 'Tools', and 'Help'. The 'File' menu has 'Open...', 'Save', and 'Save As...' options. The 'Tools' menu includes 'Board', 'Processor', 'Serial Monitor', 'USB Port', 'Upload Method', 'Upload Using', and 'Upload Using'. The 'Help' menu has 'About' and 'Check for Updates'.


- Better looking than classic Arduino IDE
- Newer but still little bit buggy



- Before uploading, check if there is correct Port and Board selected. Otherwise, you won't be able to upload code to Arduino.
- For this lab, you should have selected **Arduino Mega**




- Breadboard is used for prototyping electrical circuits
- Does not need soldering
- Every standard "trough hole" component can be fit into breadboard
- Does not support SMD



# Breadboard - How it works


- Breadboard consists of 2 types of rails: Horizontal and Vertical
- Horizontal rails are used for any electrical parts
- Vertical rails are used for power supply and ground



Parts used in this lab:

- Resistor
- Variable resistor (Potentiometer)
- LED - Light Emitting Diode
- Button


- Passive electrical component
- Limits flow of a current
- Unit of ohm ( $\Omega$ )





mirro

- Basic electrical law
- $U = R * I$
- Current flow through a conductor between two points is directly proportional to the voltage across the two points

## OHM'S LAW





- Passive electrical component
- Same as resistor but its resistance can be changed
- Usage - for example volume control



miro

- Light Emitting Diode - diode that emits light when current flows through it
- Diode allows flow of current only in one direction
- 2 pins: positive **Anode** and negative **Cathode**
- Usage - light indication


## What is a LED?



- Simple electrical component
- Connects or disconnects electrical circuit
- Usage - ON/OFF button




Pin 1 & 3 are connected  
Pin 2 & 4 are connected




# Pull-up / pull-down resistor

- Used to ensure a known state for a signal
- Pull-up ensures default Logic **1** signal and Pull-down ensures logic **0**

Pull-up Resistor



Pull-down Resistor




miro

There are 3 types of signal that will be explored in this lab:

- Digital signal
- PWM
- Analog signal


Digital signal consists of 2 possible states

- 1 - High - 5 Volts
- 0 - Low - 0 Volts




PWM or Pulse Width Modulation is

- method of reducing the average power delivered by an electrical signal
- Uses a repeating digital signal
- 2 attributes - **frequency** (or period) and **duty cycle**



Analog signal is a continuous signal that can have any value from a given range

- Range in volts for Arduino: **<0V, 5V>**
- Arduino uses a 10 bit analog to digital converter to read the value
- Read value is in range **<0, 1023>**



Each Arduino code consists of 2 functions:

- **void setup()** - code in this function will run only once, used for setup
- **void loop()** - code in this function will run infinitely, place where you write main part of your code

```
1 void setup() {  
2     // put your setup code here, to run once:  
3  
4 }  
5  
6 void loop() {  
7     // put your main code here, to run repeatedly:  
8  
9 }  
10  
11
```

- Before reading/writing signal from/to a pin there is need for that pin to be initialized
- `pinMode(pin, INPUT/OUTPUT)`
- Sets up given pin to be input or output
- Use this function before using any read or write functions
- Usually used in `setup()` function

- `digitalWrite(pin, HIGH/LOW)` - writes digital signal to given pin
- `digitalRead(pin)` - reads digital signal from given pin, returns its value 1 or 0

- `analogWrite(pin, value)` - writes analog value to given pin
  - Value can be from range **<0, 255>** which corresponds to range in voltage **<0V, 5V>**
  - Uses PWM
- 
- `analogRead(pin)` - reads analog value from given pin
  - Return value can be from range **<0, 1023>** which corresponds to range in voltage **<0V, 5V>**

# Exercises

Following exercises will focus on following:

- Creating electrical circuits on breadboard
- Outputting digital signal
- Reading digital signal
- Creating PWM (analog output)
- Reading analog signal
- Measurements with oscilloscope

Check if your Arduino is "Alive" and upload your first code.

- Open file [Blinking\\_LED.ino](#)
- Take a look at the code
- Specify correct port and board in Arduino IDE in tools-board and tools-port
- Upload the code by clicking at  or pressing **Ctrl+u**
- Built in LED on Arduino board should be blinking in 1 second intervals

Make your own circuit with LED on breadboard.

- Open file [Blinking\\_LED\\_Breadboard.ino](#)
- Take a look at scheme [LED\\_scheme.png](#) and create circuit as it shown at the image
- Upload the code by clicking at or pressing **Ctrl+U**
- LED should be blinking in one second intervals

- Continue working with the same code and scheme.
- Modify the time intervals that are stored in constants `TIME_ON` and `TIME_OFF` as it is described in table below
- After each change upload code to Arduino
- What behavior of the LED do you observe?

	TIME_ON	TIME_OFF
1.	100	100
2.	30	30
3.	1	1
4.	1	10
5.	1	20

Create PWM waves using knowledge from the last 2 exercises.


- Open file [PWM\\_custom\\_method.ino](#)
- Reuse circuit from previous exercise
- Upload the code
- Try and modify constant `DUTY_CYCLE_PERCENTAGE` and set it to values 1, 2, 5, 10, 100
- Observe behavior of the LED
- How would you do it, if you would have to blink two LEDs with different duty cycles?

Use built-in Arduino function to create PWM wave.

- Open file [PWM\\_proper\\_method.ino](#)
- Reuse circuit from previous exercise
- Upload the code
- Try and modify integer **brightness** and set it to values 0, 1, 5, 10, 50, 100, 255
- Observe behavior of a LED

Write a code that will continually brighten and dim a LED

- Open file [PWM\\_fading\\_LED.ino](#)
- Reuse circuit from previous exercise
- Follow the instructions and implement brightening and dimming of the LED
- Upload the code
- Test your implementation by uploading your code and observing LED



Control LED using serial communication.

- Open file `Serial_Demo.ino`
- Reuse circuit from previous exercise
- Upload the code
- Open Serial Plotter (or Serial Monitor), select "No Line Ending" and send values in range <0,255> to control brightness of the LED

Sending signals is only half of the knowledge. The other half is to know how to read them.

- Open file [Serial\\_Demo.ino](#)
- Take a look at scheme [Button\\_scheme.png](#) and create the circuit as it shown in the image
- Upload the code
- Press the button and observe the behavior using Serial Plotter (or Serial Monitor)

Read analog signal from potentiometer.

- Open file [Serial\\_Demo.ino](#)
- Take a look at scheme [Potentiometer\\_scheme.png](#) and create the circuit as it shown in the image
- Upload the code
- Rotate the potentiometer and observe the behavior using Serial Plotter (or Serial Monitor)

Thank You For Your Attention !