## Chip Multiprocessors

Todd Davies

May 24, 2016

### Overview

Due to technological limitations, it is proving increasingly difficult to maintain a continual increase in the performance of individual processors. Therefore, the current trend is to integrate multiple processors on to a single chip and exploit the resulting parallel resources to achieve higher computing power. However, this may require significantly different approaches to both hardware and software particularly for general purpose applications. This course will explore these issues in detail.

## **Syllabus**

Introduction Trends in technology, limitations and consequences. The move to multi-core parallelism in programs, ILP, Thread Level, Data Parallelism.

Parallel Architectures SIMD, MIMD, Shared Memory, Distributed Memory, strengths and weaknesses.

**Parallel Programming** Multithreaded programming, Data parallel programming, Explicit vs Implicit parallelism, automatic parallelisation. The Case for Shared Memory. When to share?

**Shared Memory Multiprocessors** Basic structures, the cache coherence problem. The MESI protocol. Limitations. Directory based coherence.

Programming with Locks and Barriers The need for synchronisation. Problems with explicit synchronisation

Other Parallel Programming Approaches MPI and OpenMP

**Speculation** The easy route to automatic parallelisation?

Transactional Memory Principles. Hardware and Software approaches

Memory Issues Memory system design. Memory consistency

Other Architectures and Programming Approaches GPGPUs, CUDA

Data Driven Parallelism Dataflow principles and Functional Programming

### Attribution

These notes are based off of both the course notes (http://studentnet.cs.manchester.ac.uk/ugt/2015/COMP35112/). Thanks to John Gurd for such a good course! If you find any errors, then I'd love to hear about them!

### Contribution

Pull requests are very welcome: https://github.com/Todd-Davies/third-year-notes

Commit: aba4e7cd54b16295f3273e2a8e4b5a27ea3120d6

Build: 52

# Contents

## 1 The need for parallelism

Even though we've been unable to increase the clock speed of processors since around 2005, we have seen the 'power' of processors roughly double every 18-24 months since then in line with Moore's Law<sup>1</sup>. The reason why, is that we have been able to increase the amount of transistors in chips (due to the feature size decreasing), and use the extra ones to provide more processing cores, which are able to process data in parallel. The degree of parallelism is increasing as time progresses.

In an ideal world providing a greater degree of parallelism would merely entail chip designers copy and pasting multiple processor cores onto the silicon, and programmers getting linear performance increases. In practice, there are lots of architectural issues (such as how processors are connected and how they're organised) as well as software issues (how do we make our app run on multiple cores).

As transistors are becoming smaller, we can also make them switch faster. The switching speed is determined by R \* C, where R is the resistance and C is the capacitance. When we reduce the area of the transistor, C decreases, so in doing so, we make the circuit able to compute faster.

This was fine until 2005, at which point we started to see three problems which stopped transistors from becoming smaller and faster:

Interconnect capacitance: the capacitance between neighbouring wires).

**Power density**: As the power density increased, cooling became a serious problem; each transistor produces heat as it switches and the number of transistors per unit area dictates how much heat is produced.

**Impurities**: As we approach the theoretical limit of one atom per transistor, any impurity in the silicon becomes a major issue.

We have tried using extra transistors to build more complex single core processors (using Instruction Level Parallelism (ILP)) and by adding bigger caches so that they exhibit lower miss rates, however both of these techniques suffer from diminishing returns. Control statements such as **branches** make us have to periodically throw away all the partially completed instructions in a pipeline, and caches already have hit-rate percentages in the high 90's.

Though we might be able to increase the number of cores on a chip, how does a programmer utilise this extra power? It is relatively easy for an operating system to schedule programs so that they can run on different cores and therefore have true multi-tasking (process level parallelism), but what if we want to make one program run faster by running it over many cores?

### 1.1 ILP vs TLP

Instruction Level Parallelism and Thread Level Parallelism are two different approaches to utilising parallel hardware, and both can be used at the same time.

In ILP, the processor is able to execute instructions out of order and in parallel, meaning that fewer clock cycles are needed to execute the same number of instructions. This form of parallelism is very limited, and can only be used in certain situations. Vector parallelism is similar, and lets you do things like do four 8-bit additions in one instruction (by splitting a 32-bit word into four 8-bit parts). In both cases, the end result of the execution is the same as if all the instructions were executed in order.

In TLP, a program can be composed of separate threads, each being its own sequence of instructions. Many threads can be executing in parallel and since their instructions are independent of each other, can be interleaved on the processor (or run on multiple cores). If it often desirable for the output of threaded programs to be deterministic, i.e. for all possible sequences of execution, the output must be the same.

<sup>&</sup>lt;sup>1</sup>An observation that the number of transistors in processor chips doubles approximately every two years.

TLP is far more general purpose than ILP (and much more so than vector parallelism, which is only really useful in simple operations like array addition). While ILP is applied automatically to the instruction stream issued to the  $CPU^2$ , whereas TLP relies on the programmer finding a way to express an algorithm in a parallel manner; something that is not always achievable for all programs.

### 1.2 Data and instruction parallelism

Flynn [?] classified parallelism as **instruction stream** and **data stream** parallelism, both of which can come into effect at the same time.

Data parallelism is when the same computation can be carried out on multiple elements of some dataset, usually an array. Vector parallelism is an example of this. Only certain problems are amenable to data parallelism and can be sped up in this manner, but doing so is often very easy<sup>3</sup>.

Instruction parallelism is when multiple instructions can be executed in parallel (with no side effects that cause problems to each other), this is often implemented automatically.

Flynn gave different combinations of these types of parallelism have different names:

- **SISD**: Single Instruction Single Data is like a normal program. A serial sequence of executions working on a stream of data, one word at a time.
- MIMD: Multiple Instruction Multiple Data is the most parallel one, where there are multiple instruction streams and they can all operate on their own independent stream of data. This is what happens on most modern computer chips, where the operating system will schedule processes on different cores at the same time.
- SIMD: Single Instruction Multiple Data is stuff like when you use instructions like ADD8 to process multiple data elements at once with the same instruction, or a GPU<sup>4</sup> processing lots of pixels at once with the same filter. If it's not a vector instruction, then it's one or more processors working in lockstep to process elements of an array or something.
- **SPMD**: Single Program Multiple Data is a generalisation of SIMD, where different processors execute the same code but don't need to be in lockstep. This is most often how parallel programs are written for CPU's.

For any given problem, the complexity of parallelising it is proportional to how irregular the parallelism is, and how much data sharing there is between threads of execution (particularly if the threads are writing to the shared data).

#### 1.3 Connecting processors

In order to make them work in parallel, multiple cores of a processor need to be connected to each other, and to memory. There are lots of different ways to do this, and the best way depends on the use case.

- The processors can be laid out in a grid. In this case, each processor can communicate with its neighbours, and memory is usually private to each core. In order for cores to access memory in other cores, they must send messages through the grid.
- A Torus is a variation of the grid, where each edge is linked to the opposite edge. This makes a doughnut shape (in a logical, not physical sense) and means that fewer steps are needed to communicate between cores.

<sup>&</sup>lt;sup>2</sup>Either the compiler can make use of ILP (e.g. instruction reordering at compile time), or the CPU can do it automatically using a technique such as scoreboarding.

 $<sup>^3</sup>$ E.g. vector addition can be easily parallelised by splitting the vector up into n chunks and assigning each one to a thread, where you have n threads.

<sup>&</sup>lt;sup>4</sup>GPU's often have upwards of hundreds or even thousands of processing cores, and in order to manage the complexity of assigning work to these cores, will use a combination of SIMD and SPMD techniques. The same program usually runs on each core, but groups of cores execute in lock-step on the same data.

A bus can be used to connect multiple cores. The memory is usually situated on the bus, and all cores have access to it (though they may also have their own memory instead). Time slicing is used to give equal access to the bus, but can make the bus become a processing bottleneck. All memory accesses have equal access time so long as there isn't too much contention.

There are, of course, more types of interconnects. Crossbars are where each node is connected to each other node (which has a complexity of n(n-1)), but the best ones are usually tree structures or hierarchical busses where the complexity is logarithmic (nlog(n)).

### 1.4 Shared and distributed memory

Shared memory is accessible from all of the cores and every part of the computation, while distributed memory is spread out in different components, and is usually only accessible by the component that owns it. We are considering systems that are either one of these, or the other. Either one of these can emulate the other from a software point of view; it is fairly easy to provide abstraction layers that make a distributed memory behave like a shared one, or impose restrictions on shared memory so that parts are unavailable to certain components. Imposing a foreign memory layout onto the hardware comes at a performance penalty.

More explicitly, **data sharing** is when a program with shared memory space facilitates interthread communication by having threads read and write to the shared memory. **Message passing** is when separate parts of the program communicate by sharing messages (e.g. using a socket).

Most supercomputers use distributed memory, since its easier to build, provides a higher total communication bandwidth and is more suited to many data-parallel problems. However, programs using data sharing (shared memory) are widely seen to be easier to code than programs using message passing (distributed memory), so there is an overhead involved with distributed memory; unfortunately, most 'normal' computing problems are irregular and dynamic.

## 2 Using threads

A thread is a flow of control executing a program, and a process can consist of one or more threads. Each thread inside a process has access to the same address space, and most programming languages provide some method of using threads.

Now, go and look up Java threads (https://docs.oracle.com/javase/tutorial/essential/concurrency/) and C's pThreads (https://computing.llnl.gov/tutorials/pthreads/).

The easiest form of parallelism to find and exploit using threads is data parallelism. This is where computation is divided into roughly equal chunks, where hopefully, each chunk is independent of the next.

An example of this is multiplying two  $n \times n$  matrices. We could use  $n^2$  threads, each computing one element (remember the area of the output matrix is going to be  $n^2$ ), or we could use n threads and have each thread compute a whole row or column. If we didn't have that many threads (or perhaps making more threads is inefficient), then we could make p threads and have each one compute q columns or rows, where  $p \times q = n$ .

In Fortran, DOALL statements let us execute the body of a loop in parallel.

There are two types of parallelism:

**Implicit:** This is when the system works out how the parallelise something for itself. This is particularly relevant to functional languages, since many operations (map, reduce etc) are inherently parallelisable.

**Explicit:** Here, the programmer must have a mental model of the parallelism in his or her head, and specifies exactly what should be done.

A lot of the time, parallel programs are made in a way that blends the two (so you might not have to specify everything explicitly, but you have to give hints to the system as to what should be parallelised and how). An example of this is the DOALL statement mentioned above.

In an ideal world, we would have computers that would automatically parallelise programs. However, since dependency analysis is hard to do, this approach is limited. Computers do automatic parallelisation to an extent (e.g. instruction reordering), but must be 100% sure that an operation is safe to parallelise, and the results will be correct.

## 3 Caches in shared memory multiprocessors

Obviously caches are vital to the efficient functioning of processors. Without them, every memory access would cause the CPU to wait around 200 cycles, and so having a cache is vital to having the CPU run at close to full speed.

However, caches don't just fix the problem; we need to work out how to populate them, and keep the data in them correct. Data that we write to a cache must eventually be written back to memory, and new memory locations need to be loaded into the cache when they're required by the CPU.

We solved these problems in COMP25111, however, more problems arise when you consider a multi-core processor. In most multi-core processors, each core has its own cache, and since each cache can potentially hold its own copy of the same memory location, we need to make sure that they agree with each other about the values of these locations. This is the **cache coherence problem.** 

An easy solution to this would be to require that every write would go through to memory straight away, and the other cache(s) in other cores would load the value. This is obviously slow though and there may be bus bandwidth problems. Furthermore, we'd only be getting a benefit from cache-reads, which defeats (half of) the object of the cache!

We can overcome this by making the caches talk to each other. When a new value is written to one cache, the others should invalidate their own cache lines containing this value. This means a write to a cache doesn't need to go straight through to memory, but just flips a bit inside the other caches.

However, when we introduce more state to our caches (such as invalidated cache lines) we also increase the complexity, and need a model to make sure things don't go wrong. Each cache line can be in three states:

Invalid; There might be an address math on this line, but the data is not valid any more. It needs to be fetched from memory again.

Dirty; The cache line is valid, and has been update in the cache since it was loaded from memory. It must be written to memory at some point in the future.

Valid; The cache line matches what's currently in memory.

In order to let caches know what other core's caches are doing, we have them do **bus snooping**. This involves having hardware watch each core's cache and modify the cache independently of the core so that the flags on the cache lines are correct.

Given two cores, the following states are valid and invalid:

Notice how the table is a mirror image of itself. We can't have two dirty states, since then we won't know which we should write to memory, and we can't have a dirty and valid state (since then, by definition, the valid state is not valid).

There are two types of messages between cores; read requests for a cache line (one core hopes that another core's cache has the cache line so that it doesn't have to go to memory), and invalidate messages.

We can easily extend the protocol we've described beyond two cores; any core with a valid value can respond to read requests (the bus will decide who 'wins'), and invalidate requests work as normal, invalidating the cache line on all cores.

The only extra requirement is that invalidation must happen in one cycle, since we want all cores to have the same view of memory, and if one core receives the invalidation message after another, there will be a period of time where their views of memory will be inconsistent. This gets harder as we increase the number of cores; the bus gets longer and so slows down (signals take longer to propagate, and the clock will have to be reduced).

The impact from this is that the consistency protocol is the biggest limitation when trying to add more cores to a processor. The protocol we have described is called the MSI protocol (modified, shared, invalid).

### 3.1 Other cache coherence protocols

In the previous cache coherence protocols we have discussed, we came across situations where there was unnecessary bus usage (e.g. when one core writes to its cache and makes a cache line dirty, other cores would write their copies back to memory, even though that value would never be used since there was a newer dirty version).

However, the bus is a *critical shared resource*, and we certainly don't want to waste bandwidth on messages that have no effect. We can distinguish between two cases of writing to a cache:

- When the cache holds the only copy of a value, and it's not dirty (if it was dirty, we'd just update it).
- When the cache holds a copy of the value, but there are other copies in other caches.

It is only the first case where we don't need to send an invalidate message, but this is nevertheless a common case. In most multithreaded programs, only a minority of memory locations are shared between threads (and a smaller minority are both read and written to by multiple threads), so the majority of memory locations are unshared. If we split the 'V' (valid) state into two more states, we can account for this case:

- E Exclusive to one cache
- S Shared between multiple caches

This gives us the MESI protocol (as opposed to the MSI protocol). This is easy to implement on top of the MSI protocol; simply set the state to E if the value was read from memory, and to S if it was read from another cache.

Though minor changes in the protocol are required, the only inconsistency is that if all E/S lines are evicted from other caches except one S line, then the S line is now exclusive (even though it is marked as S). This isn't a problem in practice, since it doesn't happen often, and since it's hard to detect, it's just ignored.

The MOSEI protocol is a further optimisation, where the M state is split into:

- M Modified; the cache contains a copy which differs from memory, and no other caches contain a copy.
- O Owned; the cache contains a copy which differs from the one in memory, and some
  other caches also contains a copy, but those are in state S and have the same value as the
  owner.

With the additional O state, we can share the latest value and don't have to write it back to memory straight away. Only when a cache line in the O or M states is evicted, will any writing to memory be done.

### 3.2 Directory based coherence

So far, we've looked at methods for letting multiple cores communicate over a single bus, and have assumed that bus communication happens instantaneously. However, as the number of cores increases, the bus capacitance increases and you have to slow it down. This limit is at around 32 cores.

A directory based coherence method is an attempt to make everything less directly connected to get around this limitation. A centralised directory is created that holds information about each cache line (which contains multiple words) in memory.

For each cache line, the directory contains a bit map for which core has a copy, and whether that copy is dirty, which is another bit map (though only one bit is true). Each cache has its own valid and dirty bits, which are used to dictate whether to write back to memory or not. If a core whats to make a memory access, we have the following cases:

#### Read hit in local cache:

Just read the local value!

#### Read miss in the local cache:

Ask the directory:

#### Directory dirty bit is false:

Read the data from main memory into the cache, set the directory presence and local valid bit for that core.

#### Directory dirty bit is true:

Cause the owner to write back the value to memory, which is also sent to the cache that was asking. The directory dirty bit is cleared, but the directory presence bits are set, as is the local valid bit.

#### Write miss in the local cache:

- Set the local cache to dirty.
- Depending on the directory dirty bit:

#### It's false:

Invalidate any cores that are valid for this cache line, set the present bit for that core and set the dirty bit for the directory.

#### It's true:

Send a message to the core marked as O (owner) to write back (note, this can be optimised out). Clear the owner's present bit, and set if for the writing core. Leave the dirty bit set.

### Write hit in local cache:

- If the local dirty bit is set, just update the value,
- Otherwise, update the local cache and dirty bit then:

#### If the directory bit is not dirty:

Invalidate any cores with the cache line present, then clear the present bits. After that, set the present bit for the writing core and set the directory dirty bit to true

If the directory dirty bit is set: Send a message to the owner to update core memory (again, this can be optimised out), clear the owner's present bit and set the writing cache's present bit. Keep the directory bit set.

In this architecture, the directory becomes the bottleneck. To avoid this, we can distribute the directory between different caches, and make each part responsible for part of the address space.

Sometimes in multi-processor systems, the memory is not all in one place and is spread over multiple chips.

Since chips with a directory based protocol are often heavily networked (inside the chip) in order to connect all the sub-components, messages can take variable amounts of time to send, requiring handshake protocols. This means that the CPU can sometimes waste a significant number of cycles waiting for responses from messages.

### 4 Barriers and locks

#### 4.1 Barrier

The idea of a barrier is that a number of threads should all meet up at the same point. When all threads reach the point, they can continue, but until then, they all wait. It's natural when threads are used to implement data parallelism.

Barriers are often used when there are data dependence (we need to wait for the whole answer before continuing). Take a look at java.util.concurrent.CyclicBarrier.

#### 4.2 Locks

Any object can be locked in Java by using as the target of a synchronised block, or calling an instance method that is declared as being synchronised. Only one thread can lock an object at any given time, and other threads must wait to acquire the lock, or the lock holder executes wait.

We want to lock objects so that we can achieve 'correctness'. If two code blocks take a lock on the same object, one should complete before the other starts, which means two threads won't be mutating the same object at the same time, and the normal meaning of the code blocks is preserved.

#### Sequential Consistency is when:

- Method calls should appear to happen one at a time in sequential order.
- Method calls should appear to take effect in the order a thread performs them.

Deadlocks can occur in cases where code tries to acquire more than one lock. 'Lost WakeUp' can happen if one thread sends a notify message that is not properly received by other threads, one way to avoid this is by using notifyAll instead of notify in Java.

The **granularity** of the lock depends on how big the chunk of code that depends on a lock is. If the chunk is large, then it's coarse grained and the parallelism is more limited, and if its too small, then its fine grained, and you may spend too much time obtaining and releasing locks.

Java also has <code>java.util.concurrency.locks.Lock</code> for explicit locks, since there are situations where the implicit object locking is not adequate. An example of this is when doing 'hand over hand' locking (e.g. lock one item, obtain the next, lock the newly obtained one, unlock the first etc). This is impossible using the implicit locks, since there is an implicit nesting structure (e.g. a synchronised call is either inside a synchronised block or in a synchronised method call, and you can only get out by exiting the whole block).

## 5 Hardware support for synchronisation

Most shared memory parallel Programming models require that the programmer implements some sort of synchronisation logic in order to control how threads access the shared memory.

This is a common interpretation of what it means to be 'correct', but not the only one. There are several different ways of doing this, all of which are closely related. Hardware support is usually required for shared memory multiprocessor systems.

### 5.1 Binary semaphores

A binary semaphore is essentially a boolean indicating whether some resource is free;  $(1 \to \text{free}, 0 \to \text{in use})$ .

There are two atomic operations that can be done on a semaphore; wait(s) and signal(s). wait will block until s is equal to 1 (i.e. wait until it's free), then set s to 0. signal sets s to be equal to 1. For example:

A broken implementation of wait could be:

```
# Move the address of the semaphore into R2
ADR R2, semaphore

...
wait:
    PUSH LR
    PUSH R1
loop: LDR R1, R2
    CMP R1, #0
    BEQ loop
    STR #0, R2
    POP R1
    POP PC
```

The reason why this wouldn't work, is that if another thread was to change the value of the memory address pointed to by R2 while were were inside loop, then we could get unpredictable results.

In order to prevent this from happening, we need to make sure that wait is indivisible, which requires special hardware instructions. Even then, if semaphore was cached, then even indivisible waiting methods might get confused, so we need coherence operations in the cache.

A simple solution (often implemented in older processors) is to provide an instruction called test and set, which is atomic. This takes a pointer as an argument, and tests if the memory location is 0. If it is, then the memory location is set to 1, and if its not, then the processors zero flag is cleared. Now our wait function becomes:

```
# Move the address of the semaphore into R2
ADR R2, semaphore
...
wait:
    PUSH LR
    PUSH R1
loop: TAS R2
    BNZ loop # loop while *R2 != 0
    POP R1
    POP PC
```

Note that this is the logical opposite of how we defined the semaphore before, but it doesn't matter. Furthermore, though it looks like we've reduced the number of instructions, the TAS operation will be slow since it must read and possibly write a value in memory, which requires that memory location to be locked.

If semaphore is cached, (which is likely since its going to be a shared memory location), then we're going to be using a lot of bus bandwidth because the processor must lock the snoopy bus for every TAS operation since it cannot let other cores write to that memory location. If the value of the semaphore was 1, then the lock was wasted.

A simple solution is to sit in a loop reading the value of the semaphore until it seems to be free, then use a TAS operation to obtain the lock. If the TAS operation was successful, then return to the calling code, and if it wasn't, then another thread must have got there first and the current thread should continue looping:

```
# Move the address of the semaphore into R2
ADR R2, semaphore

...
wait:
    PUSH LR
    PUSH R1
loop: LDR R1, R2
    CMP R1, #1
    BEQ loop
    TAS R2
    BNZ loop
    POP R1
    POP PC
```

### 5.2 Other synchronisation primitives

There are other machine level primitives including fetch and add (get a memory location, add one and write back), and compare and swap (compare a memory location to a value and exchange it for another value if it was as expected). These are read-modify-write instructions and require the snoopy bus to be locked while they execute.

The trouble with these operations, is that they are quite complicated (i.e. like CISC instructions, not RISC instructions), and as a consequence, they don't fit well with modern pipelined processors.

### 6 Lock-free datastructures

We have seen datastrucutres that employ locks, barriers and other synchronisation primitives in order to serialise multithreaded access to them, but instructions such as compare and set can be used to make sure that updates to datastructures happen in a serial manner, while removing the need for locks.

Let us take the example of an unbounded queue, implemented using a linked list. A locking implementation might use two locks; one for pushing and one for popping (though these locks must be aware of each other when the queue is empty); implementation details are covered in the lecture notes (but not here). Only one thread can push and one pop from the queue at the same time, which obviously becomes a bottleneck when multiple threads are accessing the queue.

With Java's java.util.concurrent.atomic.AtomicReference and compareAndSet features, we can make the same datastructure with no locks. Though there is still an overhead associated with multiple threads accessing the queue, they are held in busy-loop style constructs made from RMW<sup>5</sup> instructions such as Compare and Set. Though an awareness of lock-free datastructures is required for the course, understanding an implementation is not.

<sup>&</sup>lt;sup>5</sup>Read, Modify, Write

## 7 OpenMP & MPI

OpenMP and MPI<sup>6</sup> are two common ways of parallelising programs, usually with C, C++ or Fortran.

### 7.1 OpenMP

OpenMP is a set of compiler directives and library functions that let the programmer give hints to the compiler and OpenMP framework about how to parallelise the program. OpenMP has a fork-join model of threading, and tries to provide sequential equivalence<sup>7</sup> and incremental parallelism<sup>8</sup>.

Parallelising with OpenMP is really quite easy, only one compiler directive is needed to parallelise a code block, for example:

```
int i = ...;
#pragma omp parallel num_threads 3
for (i = 0; i < n; i++) {
  loop_body;
}</pre>
```

As is usually the case with C/C++, and variables declared inside the parallel block are private are scoped solely within the block, but since the block is initialised on many threads, these variables are private to each thread too. Variables declared before the parallel block are shared. All code blocks parallelised with directives must have a single start and end point, and an implicit thread barrier is used at the end to ensure that all threads have finished before the program moves on from the block.

#### 7.1.1 Worksharing

Running a program with multiple threads is pointless if all the threads do the same thing; instead, we want to split the total work as evenly as possible between them. An easy way to do this is by using *loop splitting*, where a time consuming loop is restructured to make each iteration independent of each other, and then all the iterations are split between all of the available threads.

Many loops will have some kind of updating happen on each iteration of the loop, such as an addition or finding the minimum of the results of the iterations. Many of these updates are associative; i.e. they can be applied in any order, and as such, OpenMP has directives to apply them in a thread-safe manner (called a reduction clause). If we wanted to sum an array we could do:

```
int[] myArray = ...
int sum = 0;
#pragma omp parallel for private(x) reduction(+:sum)
for (int i = 0; i < n; i++) {
   sum += myArray[i];
}</pre>
```

OpenMP has other synchronisation constructs too, such as flush which ensures memory consistency between threads, critical which indicates a critical section, barrier which is an explicit barrier for the threads, and more.

N.b. If you have each thread returning a result (maybe you're adding a number to a sum on each iteration), then you should store these results in an array and then combine them (e.g. do the summation) once the parallelised loop has finished. Writing to the same memory locations in a parallel block will cause memory consistency problems.

 $<sup>^6{\</sup>rm Message~Passing~Interface}$ 

<sup>&</sup>lt;sup>7</sup>The result of the program should be the same running in parallel as it would be running on a single thread.

<sup>8</sup>Incremental parallelism is where you write the program as normal, and then gradually parallelise more and more of it.

#### 7.1.2 Loop Scheduling

Loop scheduling is deciding which iterations should be run on which threads. For efficiency reasons such as maximising cache usage, it is usually desirable to allocate iterations in chunks, however this can be done at runtime (dynamically), or at compile time (statically).

Static loop scheduling has three common methods:

- Block schedule is when the iterations are split into chunks of approximately equal size.
- A Cyclic schedule is when one iteration is given to threads in turn until all the iterations are assigned.
- A block-cyclic schedule is the same as a cyclic schedule, but *n* iterations are assigned to each thread each time. This is more cache friendly.

### 7.2 MPI

MPI (message passing interface) can be used to program a wider variety of architectures than OpenMP since it is able to distribute work between multiple computers (distributed memory systems). Like OpenMP, it is a library for C, Fortran and other programming languages.

MPI works by sending message between processes; each message is identified by a triple <send\_proc\_id, recv\_proc\_id, tag>. MPI has a concept of communicator contexts which are initialised to facilitate message passing between processes. The same message tag can be used between different contexts, but only once within a single context.

Perhaps the easiest to understand MPI commands are its blocking send and receive commands<sup>9</sup>, but MPI also has barriers, broadcast, scatter, gather and reduce constructs. As a result of having these more complex, higher level commands, many programs don't use 'send' and 'reduce' very much.

MPI also supports asynchronous commands, which do not block the sending/receiving thread, as well as persistent communication (i.e. the same connection is kept open to send multiple messages in a stream like fashion).

## 8 Speculation

Speculation is when a processor isn't sure whether an execution needs to be executed (i.e. the result of a branch or conditional operation isn't yet known), but since there are functional units free on the processor, the result can be computed speculatively and discarded if it is not needed. This assumes the 'recovery' cost of a wrong decision of what to speculatively execute isn't too high.

The only resource that is wasted by speculative execution is power, since the resources would otherwise be idle.

Sometimes, it is advantageous to speculatively parallelise programs. If we're not sure if a program can be safely parallelised, we could parallelise it anyway, and see if the result is still valid afterwards. Thread Level Speculation is a technique for doing this; the idea is to divide single threaded code into separate treads, run them in parallel and detect (with a view to resolving) any problems at runtime.

As you will know if you took the Compilers course, you'll know that loops can be trivially parallelised<sup>10</sup> if there are no dependencies between iterations of the loop. Simple dependencies can be recognised and in some cases (usually when there is a nested loop, and the dependency is in the inner loop), the code can be optimised so some operations can be parallelised.

<sup>&</sup>lt;sup>9</sup>These are listed in the course notes along with MPI examples, but I can't see much benefit to listing them here too.

<sup>&</sup>lt;sup>10</sup>Simply assign iterations of the loop to different threads.

However, if the loop is complex (usually when we don't know the index of an array access until runtime), then we could do loop based thread level speculation.

If the index of the array j we're accessing in the loop is less than the iteration count i, then we use a value that we've already computed. If the j is greater than i, we must use the value that was in the array before we started the computation. This is an issue because if multiple threads are updating the same array (and they could be updating any index in the array), then we will probably end up corrupting memory.

Lets say we have the following loop:

```
for (int i = 0; i < N; i++) {
   A[i] = A[g(i)] + 1
}</pre>
```

Here, we set the array value at i to the value of the index designated by the function g plus one. In order to parallelise this, we could have a single thread for each iteration, but only let the first thread (i = 0) update the original array. All the other threads must maintain their own copies of the array.

Each thread then maintains a tag on each of its array indexes, which can be in one of four states:

- Not accessed (N)
- Modified (M)
- Speculatively loaded (S)
- Speculatively loaded and later modified (M)

This information is usually held in a separate datastructure from the array itself which is visible to all threads. All threads write to their own data and mark the data item as 'M' (or 'SM' if it was already marked 'S'). Any thread reads its own data if the state is not 'N' (i.e. untouched), otherwise it looks at the tag that the threads 'below it' (iteration wise) for a value that is not 'N' (or until it reaches 0) and then reads the value into its own copy of the array, marking it 'S'.

Any write can cause a conflict, and if a higher numbered thread has the state of the written index as 'S' or 'SM' then they have speculatively read a thread before it was ready. The most simple solution to this is to abort all the threads above the offending thread and restart them.

At some point, the data from all of the speculative threads must be reconciled, which is done every time a thread completes, the thread after it becomes non-speculative and writes its modified values back to the main array. Eventually, all the threads will terminate and commit their data.

Of course, this all introduces an overhead on each memory access as well as the overhead of running multiple threads, yet with the right sort of programs, the speed up can be 2x faster on four cores or 3x faster on 8 cores.

In theory, we could make hardware support for this by using the cache for the speculative buffers. However since the cache size is very limited, this would only work for small buffers, and/or small numbers of threads. By modifying the cache protocols to make sure data is not written to memory too early, and to use snooping buffers to detect conflicts, this could be implemented efficiently.

#### 8.1 Procedure based TLS

If we limited ourselves to parallelising only loops, then we would only speed up a small portion of code. If we could parallelise functions/procedures, then we could potentially gain a lot of speed. This would work by executing the code serially, but splitting the execution into two threads when there is a procedure call. It is the **code after the procedure call** that is run in a new thread (and the body of the procedure is run in the main thread), since then it can be easily

abandoned if required. Validation is typically done at the end of the procedure call (to check if the threads had conflicting memory accesses). If the validation passes, then the speculative thread continues as the main thread.

#### 8.2 Sharing resources

We can also use speculation to allow multiple threads to access a resource. Classically, we would need to use a lock to make sure the threads access the resource in a mutually exclusive manner, but much of the time (e.g. writing to different parts of a file), the writes would not conflict.

## 9 Transactional Memory

Thread level Speculation (TLS) tries to guess if parallelism is possible and valid without help from the programmer. Transactional memory provides the programmer with transactions within a parallel sharing context. This means that the memory implements ACID:

- Atomicity; all or nothing
- Consistency; one valid state leads to another
- Isolation; each transaction is isolated from all others
- Durability; once committed, the outcome is persistent

Only atomicity and isolation are relevant to TM.

Transactions are indivisible, so that a transaction executes either completely, or not at all. While it is executing, none of the transaction's changes are visible outside the transaction.

When it completes, the changes will all happen at the same time.

Essentially, you can use transactions where you would previously have used locks:

```
atomic {
   i += 2;
   j *= 5;
}
```

Locks are fine if you're only using one, but if there are multiple, then the potential for deadlock is always there. Transactions do away with the potential for deadlock, since they are composable (where locks are not).

The format of a transaction is as follows:

- The transaction starts
- Some shared variables are read
- Some writes are made
- The transaction tries to commit
- This will succeed if there's nothing wrong...
- ... or will abort if it cannot commit, and then the whole transaction must be repeated.

There are two reasons why the transaction may abort; either there has been a read-write clash, or a write-write clash. These clashes cannot be tolerated, since they would allow programs to get results that would violate either atomicity or consistency.

To implement transactions, the the variables that have been read need to be kept track of (the readset) and the variables that have been written to need to be kept track of too (the writeset). These two set are used to determine clashes with other transactions.

### 9.1 Hardware support

There are implementations of transactional memory in Java and C (and probably other languages), but when there is lots of sharing, the performance isn't great. However, in situations where you really don't want to use barriers and locks, this might be an acceptable trade off.

Implementing transactions in hardware could alleviate the performance penalties, and all of the big processor developers (Intel, AMD, ARM) are looking into it. The idea is that certain portions of the program would be declared to be atomic, and all memory accesses in that portion would be emulated using two sets; a *readset* and a *writeset*. If another thread writes to something in the readset, then abort the current transaction, and if the end of the transaction is successfully reached, then commit the writeset to memory.

The load-linked an store-conditional commands are essential a transaction, since the readset is the single memory location being read-modify-write accessed and bus snooping is used to detect if changes were made to the register during the transaction (clearing the load linked flag if so). The store-conditional operation 'commits' the transaction if no conflict was detected, and otherwise, a jump instruction will be used to abort and restart.

In order to extrapolate the approach to multiple memory locations, we can use the cache as a buffer to keep track of the readset and writeset. This requires extra cache flags to indicate the data was read or written inside an atomic block, a modified writeback behaviour (only write back if the transaction commits), and an altered snooping protocol.

The snooping protocol must be changed so that when a transactional variable is written, the invalidate message is broadcast as usual, but if another core receives an invalidate message that matches a location in the readset, then it must invalidate the transaction. When the transaction terminates, the writeset is flushed to main memory. This latter stage may require synchronisation since the operation must be atomic.

Obviously, if we're using the cache to store or readsets and writesets, then the size of each is limited by the size of the cache. Furthermore, we must make sure that cache entries that are part of transactions are not evicted since otherwise the data will be lost (since it cannot yet be written back to memory). Livelock can occur if three or more transactions cause each other to abort in a cycle.j

Instead of using a cache-based implementation, we could use a snooping bus (which doesn't handle large numbers of cores well) or do away with cache coherence and make all accesses to memory transactional.

#### 9.1.1 Transactional Coherence and Consistency

TCC is a simple protocol designed to implement hardware transactions. Though it is simple, there are many possible optimisations, but as of yet, no implementations.

The idea is to have a local cache for each core that stores the readset (as well as other cached data), but the writes are stored in a separate buffer (such as in RAM). Writes to shared data can only occur in transactions, and are therefore locally buffered, meaning invalidations are not broadcast. It is only when the transaction completes that its writeset is written back to memory, and to do this, the addresses of its writeset are broadcast to other cores (in a single packet), and if other cores detect a conflict, the detecting core should restart its transaction.

The main disadvantage of this is that there needs to be some central lock to ensure that only one transaction is being committed at once, though transactions that do not overlap can be committed concurrently.

The advantages of TCC are:

- Lazy conflict detection.
- Livelock is impossible since one of the conflicting transactions always completes.
- Inter-core synchronisation only occurs at commit time.

- Instantaneous communication is not required.
- Less communication between cores (in many cases), meaning more cores could be supported.

#### 9.1.2 Hybrid Transactional Memory

The limited size caches and buffers are of limited size, so the current best practice is to keep transactions as small as possible so there is a high chance that they will by fulfilled entirely in hardware (and a low probability of conflict), but overflow to software if required.

### 9.2 Hardware support for Transactional Memory

Since transactional memory could significantly simplify the programming model, there is interest in a hardware implementation rather than emulation support with software (which becomes non-optimal for programs that do significant amounts of data sharing). Multiple hardware manufacturers are working on hardware TM.

The idea is to declare sections of code as atomic, probably using a special instruction, and then keep note of all the addresses loaded from (the readset) and buffer all the writes (the writeset) for the duration of the atomic section. If another thread writes to something in the readset of our atomic section, then the transaction must be aborted (simply get rid of the buffered writes) and restarted. If, on the other hand, the transaction successfully completes with no conflicts, then the writeset can be written back to memory (committed).

In fact, load-linked and store-conditional instructions are transactions, which is why they appear atomic. The readset is a single variable being RMW accessed, and the address is stored in a load-linked register. Bus snooping detects any writes to this address, and the load-linked flag is cleared if a conflict is detected (which causes the store-conditional operation to fail, and the program flow to be redirected to try the transaction again).

However, unlike using load-linked registers, complex transactions involve a significant number of variables to be read and written. We can regard the CPU cache as a buffer to store both the readset and the writeset. This requires the following:

- Adding extra tags to the cache entries to indicate whether data was accessed inside an atomic block
- Needing a modified writeback protocol to make sure that transactional data is only written back to memory if the transaction commits.
- Modifying the snooping protocol so that when an invalidate is received by a core, if the memory location was in the transaction's readset, then the transaction must be aborted and restarted.
- When the transaction terminates, it can commit its writeset to main memory. This may require synchronisation since the commit must be atomic.

It's not 'just that simple though'; these changes bring about some hard to solve problems in the real world. For instance, the cache size is limited, which means that there is a hard upper bound on the size of the readset and writeset. Furthermore, cache eviction must be careful not to evict transaction data, and there is always a risk of livelock:

```
B causes A to restart C causes B to restart A causes C to restart
```

If the hardware implementation uses a snooping bus, then they are likely to have similar extensibility problems to those found in software TM implementations and multiprocessor cache-coherency. Some people advocate dropping cache coherence all together and making all shared memory access transactional. If this were the case, then memory could be modified as to overcome the extensibility restrictions of multiple processors.

#### 9.2.1 Transactional Coherence and Consistency (TCC)

TCC was developed at Stanford, and its original proposal is very simple<sup>11</sup>. It has been simulated with encouraging results, but no practical implementation has been produced as of yet.

Each core has a local cache which stores its readset (along with the normal other tags), however the writeset is stored in a separate buffer (in a simple implementation, this could be a RAM based queue). Since writes to shared data only occur in transactions, and are buffered locally and there is no need for broadcast invalidations.

When a transaction is about to commit, it broadcasts all of the addresses in its write buffer to other cores in a single packet, and if the other cores have transactions that have at least one conflict, they will restart their transaction.

One significant bottleneck is that there must be a central resource that ensures only one commit occurs at once. If we know in advance that certain transactions will not overlap in terms of memory accesses (e.g. they are different processes and don't share an address space) then we wouldn't need to check whether the transactions conflict and they can occur concurrently.

The properties of TCC include:

- Lazy conflict detection
- No transaction aborts until another one is about to commit (no livelock)
- Less synchronisation is required since inter-core communication happens only at commit time.
- No cache coherence is required.
- Perhaps looser communication can be facilitated between cores.

#### 9.2.2 Hybrid Transactional Memory

Even TCC relies on caches and buffers which are always a fixed size. Though the consensus is that readsets and writesets should be kept small because it means there is less chance of conflict and less overhead related to conflict detection, it is not always easy to bound their size<sup>12</sup>.

Instead, hardware support can be integrated for small readsets and writesets, but for larger instances, then software can be used instead. This approach is taken by AMD's Advanced Synchronisation Facility, which only guarantees hardware support for up to four (i.e. not many) transactional cache lines.

## 10 Memory consistency

Cache coherency is something required of multi-core CPU's, but we want to implement is in an optimal manner. We have already made sure that if one core writes to a memory location, other cores will immediately see the value in the cache, but we've only done this for a single memory location.

If there is a store operation followed by n unrelated operations, then an unoptimised CPU would wait for the store operation to complete so that there are not any consistencies. However, there is no need to wait for a potentially long operation (especially if the memory was paged out or something). To get around this problem, we could add a hardware buffer between the CPU and memory which will do the waiting for the CPU, and return the last updated values in it if the CPU requests a memory location that has not yet been written.

<sup>&</sup>lt;sup>11</sup>Though the large amount of possible optimisations can increase its complexity.

<sup>&</sup>lt;sup>12</sup>Does the compiler do this? The programmer? The OS or the CPU?

This technique is referred to as 'store-to-load forwarding', and allows loads to overtake stores in terms of completion. We can have multiple buffers so that we can have multiple stores in progress without having to wait (this requires loads having to check them all).

#### 10.1 Multiple memory banks

When we have multiple cores, the increased memory traffic (from having more cores) can lead to the single-memory becoming a bottleneck. One solution is to use multiple memory banks, and split the address space between them. This gives a linear speed-up in terms of bandwidth, but brings additional problems too.

For example, lets say we execute STR A and STR B, but STR B completes first (on a different memory bank to the first store), and STR A is still in a buffer. This is a problem if there are multiple cores, since another core could read A and B and receive a value of B that is newer than A (which would not be expected).

In a real CPU, memory accesses would appear out of order due to a combination of factors, such as a multi-banked cache, and out of order execution. It is the simultaneous use of multiple apparently safe optimisations that cause inconsistencies to happen.

Though multi-threaded writes having a very slightly inconsistent view of memory may initially seem like a small issue, when a CPU is running at 3GHz, there are lots of opportunities for slight inconsistencies to mess things up. Locking is an example of it being vital that a consistent view of memory is obtained; if one thread holds a lock while it writes to memory and another thread is waiting for the lock to read the written data then the correctness of the computation relies on both threads having a consistent view of the lock. If the first thread takes the lock, but the second thread only 'sees' this part way through reading the data, then partially written data could be read.

### 10.2 Consistency models

A consistency model is a definition of how the system maintains the same view of memory between different threads, and what the threads know the system will guarantee.

**Sequential consistency** is the same as if the operations of all the processors were executed in some sequential order, and the operations of each individual processor appear in this sequence in the order specified by its program. This basically stops any out of order memory accesses, which is too restrictive.

**Release consistency** is when access to shared data is protected by a synchronisation mechanism which ensures atomicity of critical sections. Writes within the critical section can complete in any order, however they must all have completed before the synchronisation is finished. This allows for more flexibility and thus optimisation, especially then the critical sections are large.

Memory fence instructions are used to provide release consistency, and though they vary between instructions and architectures, the idea is that all loads and stores before the memory fence must complete before any of the loads and stores after it. This means that a fence can be placed before a lock is released so that all the writes that took place inside the locked region are visible when the lock is released.

Note that consistence is ensuring that the overall memory state is as desired when the instructions are executed concurrently, while coherence is ensuring that all cores have the same view of memory at all times.

#### 11 GPGPU's and CUDA

I did my third year project on parallelising text mining applications, with an emphasis on GPGPU (General Purpose GPU) computation. My dissertation covers lots of this part of the course (some in more detail, some in less) in Chapter 3.

Basically, modern GPU's are very powerful processors in their own right, since they have lots (thousands) of relatively simple processing cores and are able to perform computations in a 'massively parallel' manner.

Their original motivation was to reduce the load on the CPU caused by having to draw images to the screen many times per second. As such, their architecture is obviously optimised for graphics applications, which involves lots of parallelism, good floating point performance and a high memory bandwidth.

In the eighties and nineties, if you wanted to perform general purpose (as opposed to graphics) computations on the GPU, you had to essentially map the computation onto a set of image transformations which could then be performed by the GPU. In the early 2000's, the GPU instruction sets were opened up and API's released so that you could run arbitrary code on them.

The first architecture of these later GPU's was the Tesla architecture, which featured <sup>13</sup> multiple independent processor clusters, with each cluster having two Streaming Multiprocessors (SM's) and each SM having 8 Streaming Processors (SP's/cores). Data is re-circulated around the device to allow for variable length pipelines (and therefore the implementation of algorithms), and processing clusters are allocated dynamically to different processing tasks.

#### 11.1 CUDA

CUDA (Compute Unified Device Architecture) is an extension to the C programming language that provides the ability to compile code for execution on the GPU. A distinction is made between the host device (the CPU, main memory etc) and the GPU device (and its associated memory). The compiler separates the code to be run on each architecture.

The GPU 'device' code is run on data-parallel *kernels* that are instantiated on many (thousands to millions) threads at once. These threads are very lightweight, and implement zero-overhead context switching. Typically, all of the set-up is done on the CPU, then the data is copied to the GPU before the kernel(s) are started. When the kernels finish, then the CPU copies the results back to main memory and carries on processing.

```
/**
 * m and n are the input matrices
 * p is the product matrix
 * They are all of size width*width
 */
void matrixMultiply(float *m, float *n, float *p, int width) {
 // Allocate device memory
 float *d_m, *d_n, *d_p;
  int size = width * width * sizeof(float);
  cudaMalloc(&d_m, width);
  cudaMalloc(&d_m, width);
  cudaMalloc(&d_p, width);
  // Copy the data over
 cudaMemcpy(d_m, m, size, cudaMemcpyHostToDevice);
  cudaMemcpy(d_n, n, size, cudaMemcpyHostToDevice);
  // Run the computation
 matrixMultiplyKernel<<<dim3(1,1), dim3(width, width)>>>(d_m, d_n, d_p, width);
  // Get the result back
  cudaMemcpy(d_p, p, size, cudaMemcpyDeviceToHost);
  // Free the device memory
  cudaFree(d_m);
  cudaFree(d_n);
  cudaFree(d_p);
}
```

 $<sup>^{13}</sup>$ More recent GPU's have different numbers of processors etc, but the idea is the same.

```
__global___ void matrixMultiplyKernel(float *m, float *n, float p, width) {
  int x = threadIdx.x;
  int y = threadIdx.y;
  float product = 0;
  for (int k = 0; k < width; k++) {
    float mDel = m[y * width + k];
    float nDel = n[k * width + x];
    product += mDel * nDel;
  }
  p[y * width + x] = product;
}</pre>
```

Note that each CUDA function is prefixed by either \_\_device\_\_, \_\_global\_\_ or \_\_host\_\_ according to where it is ran. If the function is global, then it will be callable (i.e. in memory on) on both the CPU and the GPU, and the compiler will generate a separate function for each.

When the kernel is launched, it is executed on a grid of parallel threads, and the host controls the size of the grid (and therefore how many threads are launched).

### 11.2 OpenCL and OpenAAC

OpenCL and OpenACC are standardised languages for GPGPU computation and are cross platform. The former is heavily related to CUDA and the latter is a brand new design that is inspired by OpenMP's pragmas aimed at satisfying a broader range of GPGPU and other coprocessor architectures.

## References

[1] Michael J Flynn. Some computer organizations and their effectiveness. *Computers, IEEE Transactions on*, 100(9):948–960, 1972.