




MODULE-3


CPU Structure

- CPU must:
 - Fetch instructions
 - Interpret instructions
 - Fetch data
 - Process data
 - Write data

500



CPU Internal Structure



Registers



- CPU must have some working space (temporary storage)
- Called registers
- Number and function vary between processor designs
- One of the major design decisions
- Top level of memory hierarchy





Registers in the processor

User –Visible Registers -Referenced by means of Assembly or machine language. Optimizing these can reduce reference to main memory.

• Control & Statue Registers- To Control the operation of processor, not visible to user.

User Visible Registers

- General Purpose
- Data
- Address
- Condition Codes

Example Register Organizations

Data Registers				
D0				
D1				
D2				
D3				
D4				
D5				
D6				
D7				
Address Registers				
A0				
A1				
A2				
A3				
A4				
A5				
A6				
A7				
A7'				
	Program Status			
	Program Counter			

General Registers				
\mathbf{AX}	Accumulator	EAX		
BX	Base	EBX		
CX	Count	ECX		
DX	Data	EDX		
Pointer & Index ESP				
SP	Stack Pointer	EBP		
\mathbf{BP}	Base Pointer	ESI		
SI	Source Index	EDI		
DI	Dest Index			
Segment				
CS	Code			

	51			
	DI			
Program Status				
FLAGS Register				
Instruction Pointer				

(c) 80386 - Pentium II

General Registers

AX BX CX DX

SP BP

Program Status

Data

Stack

Extra

DS

SS

ES

Instr Ptr Flags

(b) 8086

Status Register

General Purpose Registers

- May be true general purpose
- May be restricted
- May be used for data or addressing
- Data
 - Accumulator
- Addressing
 - Segment

Why make them general purpose?

Increase flexibility and programmer options

Increase instruction size & complexity

K J Somaiya College of Engineer Why make them general purpose?

Increase flexibility and programmer options

Instruction size & complexity.

How big?

- Large enough to hold full address
- Large enough to hold full word
- Often possible to combine two data registers
 - C programming
 - double int a;
 - long int a;

Condition Code Registers(Flag Reg)

- Sets of individual bits
 - e.g. result of last operation was zero
- Can be read (implicitly) by programs
 - e.g. Jump if zero
- Can not (usually) be set by programs

Control & Status Registers

Program Counter (PC)

Instruction Decoding Register(IR)

Memory Address Register(MAR)

Memory Buffer Register(MBR)





Registers

- Memory Address Register (MAR)
 - Connected to address bus
 - Specifies address for read or write op
- Memory Buffer Register (MBR)
 - Connected to data bus
 - Holds data to write or last data read
- Program Counter (PC)
 - Holds address of next instruction to be fetched
- Instruction Register (IR)
 - Holds last instruction fetched/current instruction being executed

Program Status Word

- A set of bits
- Includes Condition Codes
- Sign of last result
- Zero
- Carry
- Equal
- Overflow
- Interrupt enable/disable
- Supervisor

General Registers

- ▶ AX is the primary accumulator; it is used in input/output and most arithmetic instructions. For example, in multiplication operation, one operand is stored in EAX or AX or AL register according to the size of the operand.
- ▶ BX is known as the base register, as it could be used in indexed addressing.
- ▶ CX is known as the count register, as the ECX, CX registers store the loop count in iterative operations.
- ▶ DX is known as the data register. It is also used in input/output operations.
 It is also used with AX register along with DX for multiply and divide operations involving large values.

Pointer Registers

- Instruction Pointer (IP) The 16-bit IP register stores the offset address of the
 next instruction to be executed. IP in association with the CS register (as CS:IP)
 gives the complete address of the current instruction in the code segment.
- Stack Pointer (SP) The 16-bit SP register provides the offset value within the
 program stack. SP in association with the SS register (SS:SP) refers to be current
 position of data or address within the program stack.
- Base Pointer (BP) The 16-bit BP register mainly helps in referencing the parameter variables passed to a subroutine. The address in SS register is combined with the offset in BP to get the location of the parameter. BP can also be combined with DI and SI as base register for special addressing.

Index Registers

SI and DI, are used for indexed addressing and sometimes used in addition and subtraction.

There are two sets of index pointers –


Source Index (SI) - It is used as source index for string operations.

Destination Index (DI) – It is used as destination index for string operations.

Control Registers

- The 32-bit instruction pointer register and the 32-bit flags register combined are considered as the control registers.
- Many instructions involve comparisons and mathematical calculations and change the status of the flags and some other conditional instructions test the value of these status flags to take the control flow to other location.
- The common flag bits are:

FLAG REGISTER 8086



- Overflow Flag (OF) It indicates the overflow of a high-order bit (leftmost bit) of data after a signed arithmetic operation.
- Direction Flag (DF) It determines left or right direction for
 moving or comparing string data. When the DF value is 0, the
 string operation takes left-to-right direction and when the value is
 set to 1, the string operation takes right-to-left direction.

- Trap Flag (TF) It allows setting the operation of the processor in single-step mode.
 The DEBUG program we used sets the trap flag, so we could step through the execution one instruction at a time.
- Sign Flag (SF) It shows the sign of the result of an arithmetic operation. This flag
 is set according to the sign of a data item following the arithmetic operation. The
 sign is indicated by the high-order of leftmost bit. A positive result clears the value
 of SF to 0 and negative result sets it to 1.
- Zero Flag (ZF) It indicates the result of an arithmetic or comparison operation. A
 nonzero result clears the zero flag to 0, and a zero result sets it to 1.

Т

Interrupt Flag (IF) – It determines whether the external
interrupts like keyboard entry, etc., are to be ignored or
processed. It disables the external interrupt when the value is
0 and enables interrupts when set to 1.

- Auxiliary Carry Flag (AF) It contains the carry from bit 3 to bit 4 following an
 arithmetic operation; used for specialized arithmetic. The AF is set when a 1byte arithmetic operation causes a carry from bit 3 into bit 4.
- Parity Flag (PF) It indicates the total number of 1-bits in the result obtained
 from an arithmetic operation. An even number of 1-bits clears the parity flag
 to 0 and an odd number of 1-bits sets the parity flag to 1.
- Carry Flag (CF) It contains the carry of 0 or 1 from a high-order bit (leftmost)
 after an arithmetic operation. It also stores the contents of last bit of
 a shift or rotate operation.

Segment Registers

- Segments are specific areas defined in a program for containing data, code and stack. There are three main segments –
- Code Segment It contains all the instructions to be executed. A 16-bit Code
 Segment register or CS register stores the starting address of the code segment.
- Data Segment(DS,ES) It contains data, constants and work areas. A 16-bit Data

 Segment register or DS register stores the starting address of the data segment.
- Stack Segment It contains data and return addresses of procedures or subroutines. It is implemented as a 'stack' data structure. The Stack Segment register or SS register stores the starting address of the stack.

Instruction Formats

- Layout of bits in an instruction
- Includes opcode
- Includes (implicit or explicit) operand(s)
- Usually more than one instruction format in an instruction set

Instruction Length


- Affected by and affects:
 - Memory size
 - Memory organization
 - Bus structure
 - CPU complexity
 - CPU speed

User wants more opcodes, operands, addressing modes, address range

Allocation of Bits

- Number of addressing modes
- Number of operands
- Register versus memory
- Number of register sets
- Address range
- Address Granularity

Pentium Instruction Format



PENTIUM INSTRUCTION FORMAT

- Instruction Prefixes-LOCK prefix or one of the REPEAT prefixes(REPE,REPNE,REPZ,REPNZ....)
- Segment Override-explicitly specifying segment register
- Address Size-16 or 32 bit (switch)
- Operand Size-16 or 32 bit (switch)

Т

PENTIUM INSTRUCTION FORMAT

- Opcode
- Mod R/m-addressing
 - Mod+ r/m (combined info of registers and addressing modes)
 - Register-register or opcode info

SIB

- Scale-scale factor for scaled indexing
- Index-specifies index register(SI,DI)
- Base-specifies base register(BX)
- Displacement-8 or 16 or 32 bit
- Immediate-provides the value of 8/16/32 bit operand





William Stallings Computer Organization and Architecture 6th Edition

Chapter 11

Instruction Sets:

Addressing Modes and Formats

Addressing Modes

- Immediate
- Direct
- Indirect
- Register
- Register Indirect
- Displacement (Indexed)
- Stack





Notations and Meanings

- In this section, we use the following notation:
- (X) = contents of memory location X or register X
- EA = actual (effective) address of the location containing the referenced operand
- R = contents of an address field in the instruction that refers to a register
- A = contents of an address field in the instruction





Immediate Addressing

 The simplest form of addressing is immediate addressing, in which the operand value is present in the instruction.

• This mode can be used to define and use constants or set initial values of variables.





Immediate Addressing

• The **advantage** of immediate addressing is that no memory reference other than the instruction fetch is required to obtain the operand, thus saving one memory or cache cycle in the instruction cycle.


• The **disadvantage** is that the size of the number is restricted to the size of the address field, which, in most instruction sets, is small compared with the word length.

Immediate Addressing

- In this mode data is present in address field of instruction.
- Designed like one address instruction format
 - Note:Limitation in the immediate mode is that the range of constants are restricted by size of address field.

FEATURES

- Operand is part of instruction
- Operand = address field
- No memory reference to fetch data
- Fast
- Limited range



MOV AX, 2000

MOV CL, 0A


ADD AL, 45

ADD AX, 0000


MOV CX, 4929 H

ADD AX, 2387 H,

MOV AL, FFH



Direct(M) Addressing Diagram



_

MOV AX, [DISP]

MOV AX, [0500]

ADD AL,[0301]




- The operand's offset is given in the instruction as an 8 bit or 16 bit displacement element.
- In this addressing mode the 16 bit effective address of the data is the part of the instruction.
- Here only one memory reference operation is required to access the data.

Direct Addressing

- Address field contains address of operand
- EFFECTIVE ADDRESS EA = address field (A)

- Look in memory at address value for operand
- Single memory reference to access data
- No additional calculations to work out effective address
- Limited address space

Indirect Addressing Diagram



 In this mode address field of instruction contains the address of effective address.

Here two references are required.
 1st reference to get effective address.

2nd reference to access the data.

Based on the availability of Effective address, Indirect mode is of two kind:

- REGISTER INDIRECT: In this mode effective
 address is in the register, and corresponding
 register name will be maintained in the
 address field of an instruction.
 - Here one register reference, one memory reference is required to access the data.

 MEMORY INDIRECT: In this mode effective address is in the memory, and corresponding memory address will be maintained in the address field of an instruction.

Here two memory reference is required to access the data


Indirect Addressing (1/2)

- Memory cell pointed to by address field contains the address of (pointer to) the operand
- EA =(A)
 - Look in A, find address (A) and look there for operand
- e.g. ADD AX, (A)
 - Add contents of cell pointed to by contents of A to accumulator

Indirect Addressing (2/2)

- Large address space
- 2ⁿ where n = word length
- May be nested, multilevel, cascaded
 - e.g. EA = (((A)))
 - · Draw the diagram yourself
- Multiple memory accesses to find operand
- Hence slower

Register Addressing Diagram



- In register addressing the operand is placed in one of 8 bit or
 16 bit general purpose registers.
- The data is in the register that is specified by the instruction.
 - Here one register reference is required to access the data.




Register Addressing (1/2)

- · Operand is held in register named in address filed
- EA = R
- Limited number of registers
- Very small address field needed
 - Shorter instructions
 - Faster instruction fetch
 - MOV AX, BX
 - ADD AX, BX

Register Addressing (2/2)

- No memory access
- Very fast execution
- Very limited address space
- Multiple registers helps performance
 - Requires good assembly programming or compiler writing
 - N.B. C programming
 - register int a;
- c.f. Direct addressing

Register Indirect Addressing Diagram



- In this addressing the operand's offset is placed in any one of the registers BX,BP,SI,DI as specified in the instruction.
- The effective address of the data is in the base register or an index register that is specified by the instruction.
 - Here two register reference is required to access the data.



Register Indirect Addressing

MOV AX, [BX]

(move the contents of memory location s addressed by the register BX to the register AX)


MOV AX, [DI]

ADD AL, [BX]

MOV AX, [SI]

- Operand is in memory cell pointed to by contents of register R
- Large address space (2ⁿ)
- One fewer memory access than indirect addressing

Displacement Addressing Diagram







Displacement Addressing

- EA = A + (R)
- Effective address=start address + displacement
- Effective address=Offset + (Segment Register)
- Use direct and register indirect
- Address field hold two values
 - A = base value
 - R = register that holds displacement
 - or vice versa



Base-Register Addressing

- Base register addressing mode is used to implement inter segment transfer of control.
- In this mode effective address is obtained by adding base register value to address field value.
- EA= Base register + Address field value.
- PC= Base register + Relative value.





Indexed Addressing

The operand's offset is the sum of the content of an

index register SI or DI and an 8 bit or 16 bit

displacement.

MOV AX, [SI +05]



Stack Addressing

- Operand is (implicitly) on top of stack
- e.g.
 - ADD Pop top two items from stack and add and push

