

- Two steps:
 - Fetch
 - Execute



Instruction Cycle with Interrupts





- It is the time in which a single instruction is fetched from memory, decoded, and executed
- An Instruction Cycle requires the following subcycle:
 - FETCH
 - EXECUTE
 - INDIRECT
 - INTERRUPT

Fetch

Read next instruction from memory into the processor

Indirect Cycle (Decode Cycle)


May require memory access to fetch operands, therefore more memory accesses.

Interrupt


Save current instruction and service the interrupt

Execute

Interpret the opcode and perform the indicated operation



Instruction Cycle State Diagram



Instruction Cycle State Diagram

- This illustrates more correctly the nature of the instruction cycle.
- Once an instruction is fetched, its operand specifiers must be identified.
- Each input operand in memory is then fetched, and this process may require indirect addressing.
- Register-based operands need not be fetched.
- Once the opcode is executed, a similar process may be needed to store the result in main memory.

Registers

- Memory Address Register (MAR)
 - Connected to address bus
 - Specifies address for read or write op
- Memory Buffer Register (MBR)
 - Connected to data bus
 - Holds data to write or last data read
- Program Counter (PC)
 - Holds address of next instruction to be fetched
- Instruction Register (IR)
 - Holds last instruction fetched/current instruction being executed

Fetch Cycle

- Program Counter (PC) holds address of next instruction to be fetched
- Processor fetches instruction from memory location pointed to by PC
- Increment PC
 - Unless told otherwise
- Instruction loaded into Instruction Register (IR)
- Processor interprets instruction and performs required actions




Fetch Sequence (symbolic)



The Fetch Cycle –

At the beginning of the fetch cycle, the address of the next instruction to be executed is in the *Program Counter*(PC).



BEGINNING




Step 1:

 The address in the program counter is moved to the memory address register(MAR), as this is the only register which is connected to address lines of the system bus.

MAR	000000001100100
MBR	
PC	000000001100100
IR	
AC	
	FIRST STEP

Step 2:

- The address in MAR is placed on the address bus, now the control unit issues a READ command on the control bus, and the result appears on the data bus and is then copied into the memory buffer register(MBR).
- Program counter is incremented by one, to get ready for the next instruction. (These two action can be performed simultaneously to save time)



SECOND STEP

Step 3:

 The content of the MBR is moved to the instruction register(IR)

MAR 000000001100100

MBR 000100000100000

PC 000000001100100

IR 0001000000100000

AC

THIRD STEP



Indirect Cycle

t1: MAR

t2: MBR

(IR(ADDRESS))

MEMORY

Step 1:

The address field of the instruction is transferred to the MAR.

This is used to fetch the address of the operand.

Step 2:

The address field of the IR is updated from the MBR. (So that it now contains a direct addressing rather than indirect addressing)

Step 3:

The IR is now in the state, as if indirect addressing has not been occurred.

Interrupt Cycle

- At the completion of the Execute Cycle, a test is made to determine whether any enabled interrupt has occurred or not.
- If an enabled interrupt has occurred then Interrupt Cycle occurs.
- The nature of this cycle varies greatly from one machine to another.



t1: MBR

t2: MAR

PC

t3: MEMORY ← (MBR)

← (PC)

→ SAVE ADDRESS

→ ROUTINE ADDRESS

 Step 1: Contents of the PC is transferred to the MBR, so that they can be saved for return.

Step 2: MAR is loaded with the address at which the contents of the PC are to be saved.

PC is loaded with the address of the start of the interruptprocessing routine.

Step 3: MBR, containing the old value of PC, is stored in memory.

Note: In step 2, two actions are implemented as one micro-operation. However,
most processor provide multiple types of interrupts, it may take one or more microoperation to obtain the save_address and the routine_address before they are
transferred to the MAR and PC respectively.a





Execute Cycle (ADD)

Different for each instruction


e.g. ADD R1,X - add the contents of location X to Register 1, result in R1

 $t_1: IR \rightarrow MAR$

 $t_2: MEMORY \rightarrow MDR$

 $t_3: MDR + R1 \rightarrow R1$

Constituent Elements of Program Execution



Micro-Operations

- A computer executes a program
- Fetch/execute cycle
- Each cycle has a number of steps
- Called micro-operations
- Each step does very little
- Atomic operation of CPU



Types of Micro-operation

Transfer data between registers

Transfer data from register to external

- Transfer data from external to register
- Perform arithmetic or logical ops