





## Fasteners

- M4 x 16 mm = 4 Qty
- M4 x 40 mm = 4 Qty
- M4 Hex Nuts = 4 Qty
  M4 T Nuts = 4 Qty

- M5 Hex Nuts = 5 Qty
- M4 T Nuts = 4





Align these 3 holes with the Extruded Studs of an actuator (RMD X8 Pro)

