## The Hong Kong Polytechnic University

# **Department of Electronic and Information Engineering**

### **EIE3105 Integrated Project**

**Laboratory Exercise: AVR and ARM Interfacing** 

(Deadline: Check the course information)

## **Objective:**

To develop C programs to cooperate with different external devices under AVR and ARM platforms.

### **Equipment:**

Atmel Studio 7 (software) Atmega328p (hardware) Keil uVision5 with ARM support (software) STM32F103RBT6 (hardware)

#### **Procedure:**

Section A: Generate a wave (PWM pulses) by using PWM (Pulse Width Modulation) in an Atmega328p (AVR) microcontroller.

Write a C program to send pulses (generate a wave) by using PWM mode. You should use Timer 0 in Fast PWM mode and the frequency of the generated wave should be 500 Hz. The duty cycle of the wave should be 50%. You may connect a LED to the pin which generates the wave. You can change the duty cycle to control the brightness of the LED. Note that you will not see the LED is flashing since the frequency is too high.

Section B: Generate a wave (PWM pulses) from the AVR microcontroller and capture it back to measure its pulse width.

You are required to write a C program and it has two parts.

- 1. It gets an integer from Tera Term and sets it as the pulse width (in clock cycles) of a wave generated by the AVR microcontroller (see Figure 1). The frequency of the wave should be 500 Hz. The received integer should be echoed in Tera Term. You can assume that the integer must be between 10 and 99.
- 2. It gets the wave from its ICP1 pin and measures the pulse width of the wave. Then it sends the value of the measured width to Tera Term again.

If your application can be executed properly, the setting of the pulse width should be equal or very close to the measured pulse width.




Figure 1

Section C: Generate a wave (PWM pulses) by using PWM (Pulse Width Modulation) in a STM32F103RBT6 (ARM) microcontroller.

Repeat Section A but this time you use the ARM microcontroller.

Section D: Generate PWM pulses (a wave) from the ARM microcontroller and capture it back to measure its pulse width.


Repeat Section B but this time you use the ARM microcontroller.

Section E: Generate a wave (PWM pulses) from the AVR microcontroller and capture it from the ARM microcontroller to measure its pulse width.

You are required to write two C programs.

- 1. The first C program gets an integer from Tera Term (PC1) and sets it as the pulse width (in clock cycles) of a wave generated by the AVR microcontroller (see Figure 2). The frequency of the wave should be 500 Hz. The received integer should be echoed in Tera Term. You can assume that the integer must be between 10 and 99.
- 2. The second C program gets the wave from its ICP1 pin and measures the pulse width of the wave. Then it sends the value of the measured width to Tera Term again.

If your application can be executed properly, the setting of the pulse width should be equal or very close to the measured pulse width.



*6* ... .

Section F: Generate a wave (PWM pulses) from the ARM microcontroller and capture it from the AVR microcontroller to measure its pulse width.

Repeat Section F but this time the ARM microcontroller generates a wave and the AVR microcontroller captures it and measure its pulse width.

Section G: Capture the light intensity of photo-resistors to control a Tri-color LED by using an AVR microcontroller.

A photo-resistor (see Figure 3 and 4) is a sensor that changes its resistance depending on the amount of light that hits them. It is also known as photocells or light-dependent resistors. You should connect one end of the resistor to the Arduino ADC pin then measure the change in resistance by checking the voltage on the pin. You should write a simple program to check whether you can identify the change of the voltage of the photo-resistor or not.

A tri-color LED (see Figure 3 and 5) with four legs is a common cathode RGB LED. The LED has separate red, green and blue elements inside and one common ground (the cathode). The brightness of its three colors can be changed by applying 500 Hz PWMs with different duty cycles on these three-color pins. You may freely choose which PWM pins to generate PWMs. Note that you should use AVR PWM pins to generate 500Hz-PWMs to the LED (i.e., you should not write a program to control the high and low of the output pin.).

The AVR microcontroller connects to the LED and three photo-resistors (see Figure 6). Write a C program to get the light intensity of those resistors through ADC (Analog-to-Digital Converter). Note that you should use an interrupt to get the data. Then use such data to generate three waves by using PWM (use Timer0, Timer1 and Timer2 in Fast PWM mode) to control the brightness of three colors of the LED. Note that the brightness of three colors of the LED is depended on the light intensity of those resistors. It means if the light (from the surrounding) received by those resistors is bright, the brightness of three colors of the LED is high and vice versa. For simplicity, you can set a threshold of the light received by those resistors. If the light received by a photo-resistor is bright (normal, higher than the threshold), you can set the duty cycle of the corresponding PWM signal as 100%; otherwise (e.g., the photo-resistor is covered by hand and the light intensity is lower than the threshold), yo can set the duty cycle as 0%.




Figure 3




Figure 6

Section H: Capture the light intensity of photo-resistors to control a Tri-color LED by using an ARM microcontroller.

Repeat Section G but this time you use the ARM microcontroller.

# **Instructions:**

- 1. You are required to make demonstration videos to demonstrate Section E, F, G and H.
- 2. Zip all programs (including the whole projects) for Section E, F, G and H and your demonstration videos to a single file, and submit it to Blackboard.
- 3. Deadline: <u>Check the course information</u>.

Lawrence Cheung January 2022