IBM ASSIGNMENT- 4

TEAM ID: PNT2022TMID26661

NAME:PAUL.V

Solution:

ROLL NO: 212919106062

Write Code and connections in wokwi for ultrasonic sensor. whatever distance is less than 100 cms send "Alert" to ibm cloud aand display in device recent events.

```
//Pins
const int TRIG_PIN = 7; const
int ECHO_PIN = 8;

//Anything over 400 cm (23200 us pulse) is "out of range" const
unsigned int MAX_DIST = 23200;

void setup() {

// The Trigger pin will tell the sensor to range find
```

Pin Mode(TRIG_PIN, OUTPUT); digital

Write(TRIG_PIN, LOW);

```
//Set Echo pin as input to measure the duration of
//pulses coming back from the distance sensor
pinMode(ECHO_PIN, INPUT );
// We'll use the serial monitor to view the sensor output
Serial.begin(9600);
void loop() { unsigned
long t1; unsigned
long t2; unsigned
long pulse_width;
float cm; float
inches:
// Hold the trigger pin high for at least 10 us
digitalWrite(TRIG PIN, HIGH);
delayMicroseconds(10);
digitalWrite(TRIG_PIN, LOW);
// Wait for pulse on echo pin while
(digitalRead( ECHO PIN )==0 );
// Measure how long the echo pin was held high (pulse width)
// Note: the micros() counter will overflow after-70 min t1=
micros ();
 while (digitalRead(ECHO PIN) == 1);
t2= micros (); pulse_width = t2-t1;
```

```
// Calculate distance in centimeters and inches. The constants
//are found in the datasheet, and calculated from the assumed speed
// of sound in air at sea level (- 340m/s)
cm=pulse_Width / 58; inches =
pulse_width/148.0;
    Print
            out results
                            if
(pulse_width >MAX _ DIST ){
Serial.println("Out of range");
} else {
Serial.println("********************************);
Serial.print("The Measured Distance in cm: ");
Serial.println(cm);
if( cm < 100 ){
   //while(true){
   Serial.println("Alert!!");
   //}
}
Serial.print("********************************);
}
//wait at least 1000ms before next measurement
Delay(1000);
}
```

Output:

1.If the distance is less than 100 cms ,it alerts.

```
WOKWI SAVE - SHARE
 hc-sr04.ino diagram json ◆ Library Manager ▼
                                                                                                             Simulation
          // Pins
const int TRIG_PIN = 7;
const int ECHO_PIN = 8;
                                                                                                                                                                                            ₫00:00.466 (%58%
                                                                                                            5 🗖 🕒
          // Anything over 400 cm (23200 us pulse) is "out of range" const unsigned int MAX_DIST = 23200;
          void setup() {
            // The Trigger pin will tell the sensor to range find
pinMode(TRIG_PIN, OUTPUT);
digitalWrite(TRIG_PIN, LOW);
                                                                                                                                     UNO UNO
            //Set Echo pin as input to measure the duration of
//pulses coming back from the distance sensor
pinMode(ECHO_PIN, IMPUT);
            // We'll use the serial monitor to view the sensor output
Serial.begin(9600);
                                                                                                                                          PER SES SUCCES
            unsigned long t1;
unsigned long t2;
unsigned long pulse_width;
float cm;
float inches;
                                                                                                         **********
                                                                                                         The Measured Distance in cm : 84.14
                                                                                                         // Hold the trigger pin high for at least 10 us
```

2.If the distance is more than 100 cms, it won't alert

```
WOKWI B SAVE
     hc-sr04.ino diagram.json ● Library Manager ▼
                                                                                                                                                                                                                                                                                                                                      Simulation
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  ₫00:00.599 (%62%
                            const int TRIG_PIN = 7;
                               const int ECHO_PIN = 8;
                               // Anything over 400 cm (23200 us pulse) is "out of range"
                               const unsigned int MAX_DIST = 23200;
                                       // The Trigger pin will tell the sensor to range find
                                       pinMode(TRIG_PIN, OUTPUT);
             12
                                       digitalWrite(TRIG_PIN, LOW);
            14
15
                                       //Set Echo pin as input to measure the duration of 
//pulses coming back from the distance sensor
                                       pinMode(ECHO_PIN, INPUT);
            17
18
                                       // We'll use the serial monitor to view the sensor output
             19
                                       Serial.begin(9600);
            20
21
                                                                                                                                                                                                                                                                                                                                                                                                                             MALOS IN ANALOS 
                                 void loop() {
                                       unsigned long t1;
                                       unsigned long t2;
                                                                                                                                                                                                                                                                                                                          The Measured Distance in cm : 227.10
                                       unsigned long pulse_width;
                                                                                                                                                                                                                                                                                                                           ***********************
             27
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                Activate Windows
             28
                                       float inches;
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                Go to Settings to activate Windows
```

3. Simulation and code execution





