## **Assignment -1**Python Programming

Assignment Date	9 NOVEMBER 2022
Student Name	SRINIVASAN D
Student Roll Number	110319106044
Maximum Marks	2 Marks

## QUESTION:

Make a home automation with tinker cad, add 2-3 sensors. led. buzzers and make a common code and circuit. multiple detections and alarms should be given

## CODE:

```
#include<Servo.h>
const int pingPin = 7;
int servoPin = 8;
int const gassensor=A1;
int thresh=600;
int const LDR=A2;
Servo servo1;

void setup() {
    Serial.begin(9600);
    servo1.attach(servoPin);
    pinMode(2,INPUT);
    pinMode(11,OUTPUT);
    pinMode(12,OUTPUT);
    pinMode(13,OUTPUT);
```

```
pinMode(A0,INPUT);
 pinMode(A1,INPUT);
 pinMode(A2,INPUT);
 pinMode(8,OUTPUT);
 pinMode(5,OUTPUT);
 digitalWrite(2,LOW);
 digitalWrite(11,HIGH);
}
void loop() {
long duration, inches, cm;
 pinMode(pingPin, OUTPUT);
 digitalWrite(pingPin, LOW);
 delayMicroseconds(2);
 digitalWrite(pingPin, HIGH);
 delayMicroseconds(5);
 digitalWrite(pingPin, LOW);
 pinMode(pingPin, INPUT);
 duration = pulseIn(pingPin, HIGH);
inches = microsecondsToInches(duration);
 cm = microsecondsToCentimeters(duration);
//Serial.print(inches);
//Serial.print("in, ");
//Serial.print(cm);
```

```
//Serial.print("cm");
//Serial.println();
//delay(100);
servo1.write(0);
if(cm < 40)
 servo1.write(90);
 delay(2000);
}
else
 servo1.write(0);
//Gas sensor
int val=analogRead(gassensor);
Serial.print("Gas sensor value");
Serial.print(val);
if(val>thresh)
 tone(9,800);
delay(300);
noTone(9);
//LIGHT
int val1=analogRead(LDR);
if(val1>500)
 digitalWrite(5,LOW);
 Serial.print("BULB ON");
```

```
Serial.print(val1);
}
else
{
 digitalWrite(5,HIGH);
 Serial.print("BULB OFF");
}
// PIR with LED starts
int pir = digitalRead(2);
if(pir == HIGH)
 digitalWrite(4,HIGH);
 delay(1000);
}
else if(pir == LOW)
 digitalWrite(4,LOW);
//temp with fan
float value=analogRead(A0);
float temperature=value*0.48;
Serial.println("temperature");
Serial.println(temperature);
if(temperature > 20)
 digitalWrite(12,HIGH);
```

```
digitalWrite(13,LOW);
}
else
{
    digitalWrite(12,LOW);
    digitalWrite(13,LOW);
}

long microsecondsToInches(long microseconds) {
    return microseconds / 74 / 2;
}

long microsecondsToCentimeters(long microseconds) {
    return microseconds / 29 / 2;
}
```

## HOME AUTOMATION

DIAGRAM OUTPUT:

