V.S.B. Engineering College Department of Computer Science And Engineering IOT Assignment

Topic: Assignment On Home Automation Using Arduino

Name: JAYAPRAKASH M

CIRCUIT DIAGRAM: T I N K E R C A D **CODE:** #include<Servo.h> const int pingPin = 7; int servoPin = 8; Servo servo1; void setup()

```
Serial.begin(9600);
  servo1.attach(servoPin);
  pinMode(2,INPUT);
  pinMode(4,OUTPUT);
  pinMode(11,OUTPUT);
  pinMode(12,OUTPUT);
  pinMode(13,OUTPUT);
  pinMode(A0,INPUT);
  digitalWrite(2,LOW);
  digitalWrite(11,HIGH);
void loop()
long duration, inches, cm;
pinMode(pingPin, OUTPUT);
digitalWrite(pingPin, LOW);
delayMicroseconds(2);
digitalWrite(pingPin, HIGH);
delayMicroseconds(5);
```

```
digitalWrite(pingPin, LOW);
pinMode(pingPin, INPUT);
duration = pulseIn(pingPin, HIGH);
inches = microsecondsToInches(duration);
cm = microsecondsToCentimeters(duration);
Serial.print(inches);
Serial.print("in, ");
Serial.print(cm);
Serial.print("cm");
Serial.println();
delay(100);
servo1.write(0);
if(cm < 40)
 servo1.write(90);
 delay(2000);
else
 servo1.write(0);
int pir = digitalRead(2);
if(pir == HIGH)
 digitalWrite(4,HIGH);
```

```
delay(1000);
else if(pir == LOW)
 digitalWrite(4,LOW);
float value=analogRead(A0);
float temperature=value*0.48;
Serial.println("temperature");
Serial.println(temperature);
if(temperature > 20)
 digitalWrite(12,HIGH);
 digitalWrite(13,LOW);
else
 digitalWrite(12,LOW);
 digitalWrite(13,LOW);
long microsecondsToInches(long microseconds)
return microseconds / 74 / 2;
long microsecondsToCentimeters(long microseconds)
 return microseconds / 29 / 2;
```

OUTPUT:

