MATLAB Assignment 7

Spring 2017, Section B

In this assignment, you will reinforce what we did in lecture today regarding MATLAB's filter toolbox. Please include all your work in a .m file. Send the file to nezin@cooper.edu.

For each of the following questions, generate filters using either fdatool or the filter design toolbox in the signal processing toolbox. Apply the filter to the signal using filter. Lastly, plot the Fourier Transform of the final result using fft and plot. Refer to the notes for the proper way to use fft and obtain the proper scaling

1. Generate a signal that consists of a sum of sine waves of frequencies 1 to 50 kHz. Set t to be from 0 to 2 seconds, using an interval of 0.001s.

$$signal = (\sum_{f=1}^{50000} sin(2\pi ft))$$

- 2. Create a Butterworth lowpass filter with a sampling frequency of Fs = 100 kHz, a passband frequency of Fpass = 10 kHz, a stopband frequency of Fstop = 20 kHz, a passband attenuation of Apass = 5 dB, and a stopband attenuation of Astop = 50 dB.
- 3. Create a Chebychev I highpass filter with a sampling frequency of Fs = 100 kHz, a passband frequency of Fpass = 35 kHz, a stopband frequency of Fstop = 15 kHz, a passband attenuation of Apass = 2 dB, and a stopband attenuation of Astop = 40 dB.
- 4. Create a Chebychev II bandstop filter with a sampling frequency of Fs = 100 kHz, a passband frequency of below the frequency Fpass1 = 5 kHz and above Fpass2 = 45 kHz, a stopband frequency of between Fstop1 = 15 kHz Fstop2 = 35 kHz, a passband attenuation of Apass = 5 dB, and a stopband attenuation of Astop = 50 dB.
- 4. Create a Elliptic bandpass filter with a sampling frequency of Fs = 100 kHz, a stopband frequency of below the frequency Fstop1 = 15 kHz and above Fstop2 = 35 kHz, a passband frequency of between Fpass1 = 20 kHz Fpass2 = 30 kHz, a passband attenuation of Apass = 5 dB, and a stopband attenuation of Astop = 50 dB.