

FabulaTech Webcam for Remote Desktop



Getting Started with FabulaTech Webcam for Remote Desktop on IGEL OS

- (i) You have the following options to edit the configuration of your IGEL OS 12 device:
 - via the IGEL UMS Web App:
 - Configuration > Create new profile (Use the App Selector to select one or several apps which will be configured by the profile.)
 - Apps > [name of the app] > Create new profile (used to quickly configure a profile for the selected app. It is also possible to add other apps which will be configured by this profile)
 - **Devices > [name of the device] > Edit Configuration** (In the device configurator, all installed apps are displayed under the tab **Apps**.)
 - via IGEL Setup locally on the device (shows all installed apps. Apps are displayed under the tab **Apps**)

The best practice to configure your devices is via profiles. For details on how to create profiles, see How to Create and Assign Profiles in the IGEL UMS Web App.

More detailed information about the function can be found on the Fabulatech partner site: http://www.usb-over-network.com/partners/igel/.


Dependencies

To use the FabulaTech Webcam redirection, the following apps must be installed and configured as well:

FabulaTech Plugins

How to Disable or Enable the Webcam Redirection

1. In the profile configurator, go to Apps > FabulaTech Webcam for Remote Desktop > Settings.





2. Change the settings as required.

FabulaTech Webcam for Remote Desktop
$\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $
☐ Fabulatech Webcam redirection is disabled.
Maximum framerate
The maximum framerate can be defined on a 1-30 scale. (Default: 30)
Increased log output
✓ The information written into the log file is increased.
\square The information written into the log file is set to minimal. (Default)