CS601: Software Development for Scientific Computing

Programming assignment 2: Finite Element Method

November 10, 2023


1 Problem statement

Consider a rod with cross sectional area A(x) and length L. The rod is subjected to a constant load P = 5000N at x = 0. At x = L the rod is fixed. The length of the rod is 0.5m and the Young's modulus of the material of the rod is E = 70GPa. Consider two sub problems:

- 1. The cross section of the rod is uniform with area $A(x) = A_0 = 12.5 * 10^{-4} m^2$.
- 2. The cross sectional area is given by the formula $A(x) = A_0(1 + x/L)$ Here the cross section is not uniform, it increases linearly with x.
- 3. Write an Finite Element code to find the displacement at the nodal points on the rod. You need to discretize the rod into N = 2, 8, 32, 128 elements of equal length for problems in 1 and 2.
- 4. Plot your numerical slution. Write your observations. Apart from this, the source code must be reorganized into folders. Report throughput and execution time for each implementation.

2 Method

This is a 1D structural problem. The rod is fixed at one end and a force is applied on the other end. The goal is to find approximate displacement of different points (denoted by u(x)) on the rod.



Strong From PDE

$$EA\frac{d^2u}{dx^2}+F=0$$

$$u=\begin{cases} EA\frac{du}{dx} & \text{if } x=0, \text{Neumann}\\ 0 & \text{if } x=L, \text{Dirichlet} \end{cases}$$

These are equilibrium equations and boundary conditions for the rod. These PDEs can be converted to weak from using Galerkin approach.

$$EA\frac{d^2\tilde{u}}{dx^2} + F = R$$

$$\int \omega R = 0$$

$$\int \omega [EA\frac{d^2\tilde{u}}{dx^2} + F] = 0$$

here ω is called weight function, \tilde{u} is approximate displacement, and R is residual due to approximation.


Weak from PDE

By rearranging and simplifying above equations we get weak from of PDE. This will be used for FEM calculations.

$$\left[\omega EA\frac{d\tilde{u}}{dx}\right]_{0}^{L} + \int_{0}^{L} \omega F \, dx = \int_{0}^{L} EA\frac{d\omega}{dx} \frac{d\tilde{u}}{dx} \, dx$$

Discretization (Element)

Consider an element with 2 nodes, let u^e be approximate solution for the element and $h^e = x_b - x_a$ be the length of element.



$$u^{e}(x) = c_1 + c_2 x$$

$$u^{e}(x) = N_i u^{e}(x_a) + N_j u^{e}(x_b)$$

$$N_i(x) = \frac{x_b - x}{h^e}$$

$$N_j(x) = \frac{x - x_a}{h^e}$$

Now on simplifying weak from equations for for each node in the i^{th} element we get,

$$\begin{bmatrix} K_{ii} & K_{ij} \\ K_{ji} & K_{jj} \end{bmatrix} \times \begin{bmatrix} u_i \\ u_j \end{bmatrix} = \begin{bmatrix} g(i) \\ g(j) \end{bmatrix}$$

Here j = i + 1, $K_{pq} = \int_{x_a}^{x_b} EA(x_a) \frac{N_p}{dx} \frac{N_q}{dx} dx$ and $g(p) = \left[N_p EA(x_a) \frac{d\tilde{u}}{dx} \right]_{x_a}^{x_b} + \int_{x_a}^{x_b} N_p F dx$ Area is approximated as $A = A(x_a)$, *i.e.* area of left end of the element. Now using 1 point Gauss quadrature we can approximate integrals as follows

$$K_{pq} = EA(x_a) \sum_{t=1}^{1} w_t (-1)^{p+q}, \text{ where } w = \{1\}$$

Assembling

Computing and simplifying weak form equations for every element we the global stiffness matrix, displacement vector, and force vector as follows. There are total n + 1 nodes and n elements.

$$\begin{bmatrix} A_1\frac{E}{l} & -A_1\frac{E}{l} & 0 & 0 & \dots & 0 & 0 & 0 & 0 \\ -A_1\frac{E}{l} & A_1\frac{E}{l} + A_2\frac{E}{l} & -A_2\frac{E}{l} & 0 & \dots & 0 & 0 & 0 & 0 \\ 0 & -A_2\frac{E}{l} & A_2\frac{E}{l} + A_3\frac{E}{l} & -A_3\frac{E}{l} & \dots & 0 & 0 & 0 & 0 \\ \vdots & \ddots & \vdots \\ 0 & 0 & 0 & 0 & \dots & -A_{n-2}\frac{E}{l} & A_{n-2}\frac{E}{l} + A_{n-1}\frac{E}{l} & -A_{n-1}\frac{E}{l} & 0 \\ 0 & 0 & 0 & 0 & \dots & 0 & -A_{n-1}\frac{E}{l} & A_{n-1}\frac{E}{l} + A_n\frac{E}{l} & -A_n\frac{E}{l} \\ 0 & 0 & 0 & 0 & \dots & 0 & 0 & -A_n\frac{E}{l} & A_n\frac{E}{l} \end{bmatrix}$$

$$\times \begin{bmatrix} u_1 \\ u_2 \\ u_3 \\ \vdots \\ u_{n-1} \\ u_n \\ u_{n+1} \end{bmatrix} = \begin{bmatrix} P \\ 0 \\ 0 \\ \vdots \\ 0 \\ 0 \\ -P \end{bmatrix}$$

```
Here, l = \text{length of element},

u_i = \text{displacement at } i^{th} \text{ node},

A_i = \text{Area at } i^{th} \text{ node}
```

Above set of equations are of the form Ax = b, so a simple solution would be to compute displacements using $x = A^{-1}b$, but we know that $u_{n+1} = 0$ (boundary condition) and the matrix A is banded (tridiagonal). Thus we can get a linear time solution.

```
Algorithm 1 Calculating Displacements

Consider the rod divided into n elements (n+1 node points)

Let M be stiffness matrix, with entries M_{i,j} \triangleright it is a n+1*n+1 matrix

Let F be force vector, with entries F_i \triangleright length is n+1

Let u_i denote displacement value at i^{th} node.

u_{n+1} \leftarrow 0 \triangleright Boundary condition

u_n \leftarrow F_{n+1}/M_{n+1,n}

i \leftarrow n

while i \neq 0 do

u_{i-1} \leftarrow \frac{F_i - u_i M_{i,i} - u_{i+1} M_{i,i+1}}{M_{i,i-1}}


i \leftarrow i-1


end while

return u
```

3 Results

Plots of displacement values for problem 1 and 2





Observations

- 1. In problem 1 the displacement values remains more or less the same on increasing the number of nodes.
- 2. We see that as we increase the number of elements the accuracy of the solution increases (or the solution converges) in case of problem 2 where the area is linearly increasing.
- 3. This happens because, we consider more number of points and use their area in calculations.
- 4. Higher the number of elements, higher is the computation time and cost.

4 Appendix

4.1 Execution

```
[cs601user7@hip CS601PA2]$ make PROB=1 N=2
g++ -Wall -g -std=c++17 -DPROB=1 -DNUM_ELE=2 -I inc/ -I /home/resiliente/cs601so
ftware/eigen-3.3.9 -c src/main.cpp -o obj/main.o
g++ -Wall -g -std=c++17 -DPROB=1 -DNUM_ELE=2 obj/main.o -o bin/FEM
./bin/FEM 70e9 12.5e-4 0.5 5000
Execution Time : 2.3e-05 sec
[cs601user7@hip CS601PA2]$
[cs601user7@hip CS601PA2]$ make PROB=1 N=8
rm -rf obj/* bin/*
g++ -Wall -g -std=c++17 -DPROB=1 -DNUM_ELE=8 -I inc/ -I /home/resiliente/cs601so
ftware/eigen-3.3.9 -c src/main.cpp -o obj/main.o
g++ -Wall -g -std=c++17 -DPROB=1 -DNUM_ELE=8 obj/main.o -o bin/FEM
./bin/FEM 70e9 12.5e-4 0.5 5000
Execution Time : 3.2e-05 sec
[cs601user7@hip CS601PA2]$
[cs601user7@hip CS601PA2]$ make PROB=1 N=32
rm -rf obj/* bin/*
g++ -Wall -g -std=c++17 -DPROB=1 -DNUM_ELE=32 -I inc/ -I /home/resiliente/cs601s
oftware/eigen-3.3.9 -c src/main.cpp -o obj/main.o
g++ -Wall -g -std=c++17 -DPROB=1 -DNUM_ELE=32 obj/main.o -o bin/FEM
./bin/FEM 70e9 12.5e-4 0.5 5000
Execution Time : 8.4e-05 sec
[cs601user7@hip CS601PA2]$
[cs601user7@hip CS601PA2]$ make PROB=1 N=128
rm -rf obj/* bin/*
g++ -Wall -g -std=c++17 -DPROB=1 -DNUM_ELE=128 -I inc/ -I /home/resiliente/cs601
software/eigen-3.3.9 -c src/main.cpp -o obj/main.o
g++ -Wall -g -std=c++17 -DPROB=1 -DNUM_ELE=128 obj/main.o -o bin/FEM
./bin/FEM 70e9 12.5e-4 0.5 5000
Execution Time : 0.000421 sec
[cs601user7@hip CS601PA2]$ ☐
```

Figure 1: Problem 1

```
[cs601user7@hip CS601PA2]$ make PROB=2 N=2
g++ -Wall -g -std=c++17 -DPROB=2 -DNUM_ELE=2 -I inc/ -I /home/resiliente/cs601so
ftware/eigen-3.3.9 -c src/main.cpp -o obj/main.o
g++ -Wall -g -std=c++17 -DPROB=2 -DNUM_ELE=2 obj/main.o -o bin/FEM
./bin/FEM 70e9 12.5e-4 0.5 5000
[cs601user7@hip CS601PA2]$ ☐
[cs601user7@hip CS601PA2]$ make PROB=2 N=8
rm -rf obj/* bin/*
g++ -Wall -g -std=c++17 -DPROB=2 -DNUM_ELE=8 -I inc/ -I /home/resiliente/cs601so
ftware/eigen-3.3.9 -c src/main.cpp -o obj/main.o
g++ -Wall -g -std=c++17 -DPROB=2 -DNUM_ELE=8 obj/main.o -o bin/FEM
./bin/FEM 70e9 12.5e-4 0.5 5000
Execution Time : 3.9e-05 sec
[cs601user7@hip CS601PA2]$ [
[cs601user7@hip CS601PA2]$ make PROB=2 N=32
rm -rf obj/* bin/*
g++ -Wall -g -std=c++17 -DPROB=2 -DNUM_ELE=32 -I inc/ -I /home/resiliente/cs601s
oftware/eigen-3.3.9 -c src/main.cpp -o obj/main.o
g++ -Wall -g -std=c++17 -DPROB=2 -DNUM_ELE=32 obj/main.o -o bin/FEM
./bin/FEM 70e9 12.5e-4 0.5 5000
Execution Time : 8e-05 sec
[cs601user7@hip CS601PA2]$ ☐
[cs601user7@hip CS601PA2]$ make PROB=2 N=128
rm -rf obj/* bin/*
g++ -Wall -g -std=c++17 -DPROB=2 -DNUM_ELE=128 -I inc/ -I /home/resiliente/cs601
software/eigen-3.3.9 -c src/main.cpp -o obj/main.o
g++ -Wall -g -std=c++17 -DPROB=2 -DNUM_ELE=128 obj/main.o -o bin/FEM
./bin/FEM 70e9 12.5e-4 0.5 5000
Execution Time : 0.000423 sec
[cs601user7@hip CS601PA2]$ ☐
```

Figure 2: Problem 2

4.2 Code

4.2.1 main.cpp

```
#include<iostream>
#include "Solution.h"
#include "time.h"

int main(int argc, char* argv[]) {
    clock_t start, end;
    start = clock();

    if(argc != 5) {
        std::cerr << "E, A, L, P" << std::endl;
        exit(1);
    }

    int prob = 0, N = 0;
#ifndef PROB
    std::cerr << "problem number not defined" << std::endl;</pre>
```

```
exit(1);
#else
   prob = (int)PROB;
#endif
#ifndef NUM_ELE
   std::cerr << "number of elements not defined" << std::endl;</pre>
   exit(1);
#else
   N = (int)NUM_ELE;
#endif
double E, A, L, P;
E = std::stod(argv[1]);
A = std::stod(argv[2]);
L = std::stod(argv[3]);
P = std::stod(argv[4]);
Domain<double> dom(N, E, A, L);
Solution<double> sol(dom, P, prob);
sol.solve();
end = clock();
double time_taken = double(end - start) / double(CLOCKS_PER_SEC);
// sol.show_displacement_vector();
std::cout << "\nExecution Time : "<< time_taken << " sec " << std::endl;</pre>
return 0;
```

}

4.2.2 Solution.h

```
#include "Domain.h"
#include <Eigen/Dense>
using namespace Eigen;
template<class T>
class Solution {
public:
   Solution(const Domain<T>& dom, T load, int prob);
   void generate_global_stiffness_matrix();
   void generate_force_vector();
   void solve();
   void show_displacement_vector() const;
    "Solution();
private:
   int prob;
   T load;
   Domain<T> dom;
   Matrix<T, Dynamic, Dynamic> global_stiffness_matrix;
   Matrix<T, Dynamic, 1> displacement_vector, force_vector;
    /* global_stiffness_matrix * displacement_vector = force_vector */
};
template < class T>
Solution<T>::Solution(const Domain<T>& dom, T load, int prob) {
   this->dom = dom;
   this->load = load;
   this->prob = prob;
   int n = dom.nodes_count();
   this->global_stiffness_matrix = Matrix<T, Dynamic, Dynamic>::Zero(n, n); // all values = 0
   this->force_vector = this->displacement_vector = Matrix<T, Dynamic, 1>::Zero(n, 1);
}
template<class T>
void Solution<T>::generate_global_stiffness_matrix() {
   for(int i = 0; i < dom.get_N(); i++) {</pre>
       /* first set the stiffness matrix for ith element */
       Element<T> element = this->dom.get_element(i);
       // printf("prob: %d\n", prob);
       if(this->prob == 1)
           element.set_stiffness_matrix(dom.get_E(), dom.get_A());
       else if(prob == 2)
           element.set_stiffness_matrix(dom.get_E(), dom.get_A() * (1 + i / T(dom.get_N())));
       // printf("\nvalue: %f", element.stiffness_matrix_cell(0,0));
       /* use this to find the global stiffness matrix */
       this->global_stiffness_matrix(i, i)
                                             += element.stiffness_matrix_cell(0, 0);
       this->global_stiffness_matrix(i, i + 1) += element.stiffness_matrix_cell(0, 1);
       this->global_stiffness_matrix(i + 1, i) += element.stiffness_matrix_cell(1, 0);
       this->global_stiffness_matrix(i + 1, i + 1) += element.stiffness_matrix_cell(1, 1);
   }
}
/* For compression force at x = 0 */
template<class T>
void Solution<T>::generate_force_vector() {
   this->force_vector(0, 0) = this->load;
```

```
this->force_vector(dom.nodes_count() - 1, 0) = -this->load;
}
/* finds the displacement vector */
/* For the given problem, it is not difficult to solve the system of linear equations */
template<class T>
void Solution<T>::solve() {
   this->generate_global_stiffness_matrix();
   this->generate_force_vector();
   int dim = this->displacement_vector.rows();
   /* boundary condition : u = 0 at x = L */
   displacement_vector(dim-1, 0) = 0;
   displacement_vector(dim-2, 0) = (this->force_vector(dim-1, 0) - 0)/
        this->global_stiffness_matrix(dim-1, dim-2);
   for (int i = this->displacement_vector.rows()-2; i > 0 ; i--) {
       displacement_vector(i-1, 0) =( this->force_vector(i, 0) -
           this->global_stiffness_matrix(i, i) * displacement_vector(i, 0) -
           this->global_stiffness_matrix(i, i+1)*this->displacement_vector(i+1)) /
           this->global_stiffness_matrix(i,i-1);
   }
}
template<class T>
void Solution<T>::show_displacement_vector() const {
   std::cout << "\nDISPLACEMENT VECTOR:\n" << this->displacement_vector << std::endl;</pre>
template<class T>
Solution<T>::~Solution() {}
```

4.2.3 Domain.h

```
#include "Element.h"
#include <vector>
template<class T>
class Domain {
public:
   Domain();
   Domain(int N, T E, T A, T L);
   Element<T> get_element(int i) const;
   int get_N() const;
   int nodes_count() const;
   T get_E() const;
   T get_A() const;
   T get_L() const;
   ~Domain();
private:
   int N; // number of elements
   T E, A, L;
   std::vector<Element<T>> elements;
};
template<class T>
Domain<T>::Domain() {}
/* parameterized constructor */
template<class T>
Domain<T>::Domain(int N, T E, T A, T L) {
   this -> N = N;
   this \rightarrow E = E;
   this -> A = A;
   this->L = L;
   this->elements.resize(N, Element<T>(L / N, 2));
/* fetches the ith element of the rod */
template<class T>
Element<T> Domain<T>::get_element(int i) const {
   return this->elements[i];
}
/* Get the number of elements */
template<class T>
int Domain<T>::get_N() const {
   return this->N;
/* count of total number of nodes */
template<class T>
int Domain<T>::nodes_count() const {
   return this->N + 1;
}
/* young's modulus of rod */
template<class T>
T Domain<T>::get_E() const {
   return this->E;
/* area constant A_0 */
```

```
template<class T>
T Domain<T>::get_A() const {
    return this->A;
}

/* length of the rod */
template<class T>
T Domain<T>::get_L() const {
    return this->L;
}

/* Destructor */
template<class T>
Domain<T>::~Domain() {}
```

4.2.4 Element.h

```
#include <Eigen/Dense>
using namespace Eigen;
template<class T>
class Element {
public:
Element();
Element(T length, int n);
T gauss_quad(T E, T A);
void set_stiffness_matrix(T E, T A);
T stiffness_matrix_cell(int i, int j) const;
~Element();
private:
   T length;
   Matrix<T, Dynamic, Dynamic> stiffness_matrix;
   int num_of_nodes;
};
template<class T>
Element<T>::Element() {}
template<class T>
Element<T>::Element(T length, int n) {
   this->length = length;
   this->num_of_nodes = n;
   stiffness_matrix = Matrix<T, Dynamic, Dynamic>::Zero(n, n);
}
/* one point gauss quadrature */
template<class T>
T Element<T>::gauss_quad(T E, T A) {
   return E * A / length;
template<class T>
void Element<T>::set_stiffness_matrix(T E, T A) {
   for(int i = 0; i < this->num_of_nodes; i++)
       for(int j = 0; j < this->num_of_nodes; j++)
           this->stiffness_matrix(i, j) = gauss_quad(E, A) * ((i + j) % 2 ? -1 : 1);
}
/* returns Kij */
template<class T>
T Element<T>::stiffness_matrix_cell(int i, int j) const {
   return this->stiffness_matrix(i, j);
}
template<class T>
Element<T>::~Element() {}
```

4.2.5 Makefile

```
CXX = g++
EIGEN_PATH = /home/resiliente/cs601software/eigen-3.3.9
# Variables for prob and N
PROB ?= 1
N ?= 2
E := 70e9
A := 12.5e-4
L := 0.5
P := 5000
# run 70 12.5e-4 0.5 5000
CXXFLAGS = -Wall -g -std=c++17 -DPROB=$(PROB) -DNUM_ELE=$(N)
INC_DIR = inc
SRC_DIR = src
OBJ_DIR = obj
BIN_DIR = bin
PROG_NAME = $(BIN_DIR)/FEM
# Default target
run: check clean $(PROG_NAME)
   ./$(PROG_NAME) $(E) $(A) $(L) $(P)
$(PROG_NAME): $(OBJ_DIR)/main.o
  $(CXX) $(CXXFLAGS) $^ -o $@
$(OBJ_DIR)/main.o: $(SRC_DIR)/main.cpp $(INC_DIR)/Solution.h $(INC_DIR)/Domain.h
    $(INC_DIR)/Element.h
  $(CXX) $(CXXFLAGS) -I $(INC_DIR)/ -I $(EIGEN_PATH) -c $< -o $@
  if [ ! -d $(BIN_DIR) ]; then mkdir $(BIN_DIR); fi
  if [ ! -d $(OBJ_DIR) ]; then mkdir $(OBJ_DIR); fi
  @echo Team Members:
  @echo 210010015 - Divy Jain
  @echo 210010022 - Karthik Hegde
clean:
  rm -rf $(OBJ_DIR)/* $(BIN_DIR)/*
.PHONY: clean
```

5 Team Members

- 1. Divy Jain (210010015)
- 2. Karthik Hegde (210010022)