

New Harvest in-incubator perfusion system – assembly instructions

Step 1

Screw two magnets into magnet seats on the bottom of the tray. Use 2 screws - TORX ISO7380 BN6404 M4x16.




Step 2Glue magnet using superglue onto part Leg 2.




Step 3


Screw two Legs into seats on the bottom of the tray. Use 2 screws - TORX ISO7380 BN6404 M4x16.




Step 4Snap two Legs 2 with magnet onto seats on the bottom of the tray.



Step 5Snap two Legs 2 with magnet onto seats on the bottom of the tray.




Step 6Screw mount 3 to mount 1 using two TORX ISO7380 BN6404 M4x16.




Step 7

Screw mount 2 to mount 1 using two TORX ISO7380 BN6404 M4x16.




Step 8

Screw mount assembly onto tray using two TORX ISO7380 BN6404 M4x16 and two DIN 7984 M6x10 screws.




Step 9

Screw peristaltic pump onto mount assembly using 3 TORX ISO7380 BN6404 M4x16 screws.



Step 10Screw Coupler onto NEMA 34 stepper motor using m4 set screw.



Step 11Screw NEMA 34 stepper motor onto mount assembly using 4 DIN 912 M6x20 screws.

