WiFiMCU Lua Reference Book



DoIT / LoBo

2015-12-10

Content

| Lua Basic Modules | 7 |
|------------------------------|----|
| MCU Module | 7 |
| Function List | 7 |
| Constant | 8 |
| System parameters & Watchdog | 8 |
| mcu.ver() | 9 |
| mcu.info() | 9 |
| mcu.reboot() | 9 |
| mcu.mem() | 10 |
| mcu.chipid() | 10 |
| mcu.bootreason() | 10 |
| mcu.getparams() | 11 |
| mcu.sgetparams() | 12 |
| mcu.setparams() | 12 |
| GPIO Module | 14 |
| Function List | 14 |
| Constant | 14 |
| GPIO Pin Table | 15 |
| gpio.mode() | 15 |
| gpio.read() | 16 |
| gpio.write() | 16 |
| gpio.toggle() | 17 |
| TIMER Module | 18 |
| Function List | 18 |
| Constant | 18 |
| tmr.start() | 18 |
| tmr.stop() | 19 |
| tmr.stopall() | 19 |
| tmr.tick() | 19 |
| tmr.delayms() | 20 |

| | tmr.delayus() | 20 |
|----------|---------------------|----|
| | tmr.wdclr() | 20 |
| WiFi Mo | dule | 22 |
| Fun | ction list | 22 |
| | Constant | 22 |
| | wifi.startap() | 22 |
| | wifi.startsta() | 23 |
| | wifi.scan() | 24 |
| | wifi.stop() | 24 |
| | wifi.powersave() | 24 |
| | wifi.ap.getip() | 25 |
| | wifi.ap.getipadv() | 25 |
| | wifi.ap.stop() | 26 |
| | wifi.sta.getip() | 26 |
| | wifi.sta.getipadv() | 26 |
| | wifi.sta.getlink() | 27 |
| | wifi.sta.stop() | 27 |
| | wifi.sta.ntptime() | 28 |
| Net Mod | lule | 29 |
| Fun | ction list | 29 |
| | Constant | 29 |
| | net.new() | 29 |
| | net.start() | 30 |
| | net.on() | 30 |
| | net.send() | 31 |
| | net.close() | 32 |
| | net.getip() | 32 |
| File Mod | dule | 33 |
| Fun | ction list | 33 |
| | Constant | 33 |
| | file.format() | 34 |
| | file.open() | 34 |

| | file.close() | 35 |
|--------|------------------|-----|
| | file.write() | 35 |
| | file.writeline() | 35 |
| | file.read() | 36 |
| | file.readline() | 36 |
| | file.list() | 37 |
| | file.slist() | 37 |
| | file.remove() | 37 |
| | file.seek() | 38 |
| | file.flush() | 38 |
| | file.rename() | .39 |
| | file.info() | 39 |
| | file.state() | 39 |
| | file.compile() | 40 |
| | file.recv() | 40 |
| | file.send() | 41 |
| | dofile() | 42 |
| PWM M | odule | 43 |
| Fun | ction list | 43 |
| | Constant | 43 |
| | Pin Table | 43 |
| | pwm.start() | .43 |
| | pwm.stop() | 44 |
| ADC Mo | dule | 45 |
| Fun | ction list | 45 |
| | Constant | 45 |
| | Pin Table | 45 |
| | adc.read() | 45 |
| | adc.readmv() | 46 |
| UART M | lodule | 47 |
| Fun | ction list | 47 |
| | Constant | 47 |

| | uart.setup() | . 47 |
|----------|--------------------------|------|
| | uart.on() | . 48 |
| | uart.send() | 48 |
| Bit Modu | ıle | . 49 |
| Fun | ction List | 49 |
| | Constant | 49 |
| | bit.bnot() | 49 |
| | bit.band() | 50 |
| | bit.bor() | . 50 |
| | bit.bxor() | 50 |
| | bit.lshift() | 51 |
| | bit.rshift() | . 51 |
| | bit.arshift() | . 51 |
| | bit.bit() | 52 |
| | bit.set() | 52 |
| | bit.clear() | . 53 |
| | bit.isset() | 53 |
| | bit.isclear() | 53 |
| Sensor N | Module | 55 |
| Fun | ction List | 55 |
| | Constant | 55 |
| | sensor.dht11.init() | 55 |
| | sensor.dht11.get() | 56 |
| | sensor.ds18b20.init() | 56 |
| | sensor.ds18b20.search() | . 56 |
| | sensor.ds18b20.gettemp() | . 57 |
| | sensor.ds18b20.setres() | . 57 |
| | sensor.ds18b20.getres() | 57 |
| | sensor.ds18b20.getrom() | 58 |
| | sensor.ow.init() | 58 |
| | sensor.ow.search() | . 59 |
| SPI Mod | lule | 60 |

| Function List | 60 |
|--------------------|----|
| Constant | 60 |
| spi.setup() | 60 |
| spi.write() | 61 |
| spi.read() | 61 |
| spi.deinit() | 62 |
| I2C Module | 63 |
| Function List | 63 |
| Constant | 63 |
| i2c.setup() | 63 |
| i2c.start() | 64 |
| i2c.stop() | 64 |
| i2c.address() | 64 |
| i2c.write() | 65 |
| i2c.read() | 65 |
| RTC Module | 66 |
| Function List | 66 |
| rtc.getasc() | 66 |
| rtc.getstrf() | 66 |
| rtc.get() | 68 |
| rtc.set() | 68 |
| rtc.standby() | 69 |
| rtc.standbyUntil() | 70 |
| OLED Module | 71 |
| Function List | 71 |
| oled.init() | 71 |
| oled.clear() | 72 |
| oled.write() | 72 |
| oled.writechar() | 72 |
| oled.fontsize() | 73 |
| oled.charspace() | 73 |
| oled.inverse() | 73 |

| ole | ed.fixedwidth() | 4 |
|------------|-------------------|---|
| LCD Module | le7! | 5 |
| Function | on List7! | 5 |
| Co | onstant7 | 5 |
| lcc | d.init() | 6 |
| lcc | d.clear()7 | 7 |
| lcc | d.off()7 | 7 |
| lcc | d.on()7 | 7 |
| lcc | d.invert()75 | 8 |
| lcc | d.setorient()73 | 8 |
| lcc | d.setrot() | 8 |
| lcc | d.settransp()79 | 9 |
| lcc | d.setcolor()79 | 9 |
| lcc | d.setfont()80 | 0 |
| lcc | d.getfontsize()80 | 0 |
| lcc | d.putpixel()8 | 1 |
| lcc | d.line() | 1 |
| lcc | d.rect()82 | 2 |
| lcc | d.circle()83 | 2 |
| lcc | d.triangle()83 | 3 |
| lcc | d.write()83 | 3 |
| lcc | d.image() | 4 |

Lua Basic Modules

The Lua interpreter in WiFiMCU is based on Lua 5.1.4. The following modules are supported:

| luaopen_base | Supported |
|-----------------|-----------|
| luaopen_package | Supported |
| luaopen_string | Supported |
| luaopen_table | Supported |
| luaopen_math | Supported |

'io' and 'debug' modules are not supported.

The functions description in supported modules can be found at: http://www.lua.org/manual/5.1/

MCU Module

Function List

| mcu.ver() | Get the WiFiMCU firmware version | |
|------------------|--|--|
| mcu.info() | Get the mxchipWNet library version, MAC address, WLAN driver version | |
| mcu.reboot() | Reboot WiFiMCU | |
| mcu.mem() | Get the memory status | |
| mcu.chipid() | Get the stm32 chip ID (96 bits) | |
| mcu.bootreason() | Get the WiFiMCU boot reason that caused its startup | |
| mcu.getparams() | Get system parameters to lua table | |
| mcu.sgetparams() | Print system parameters | |
| mcu.setparams() | Set system parameters | |

Constant

nil

System parameters & Watchdog

System parameters

There are a number of system parameters which can be modified to set the basic Lua system behavior. The parameters are saved in the parameter area of the WiFiMCU SPI Flash and are preserved between reboots/power cycles. The parameters are protected with CRC.

soft wdg selects software or hardware watchdog function

(default: 0 = hardware; 1 = software)

inbuf_size size of the Lua input buffer in bytes (default: 256) baud_rate baud_rate parity size of the Lua terminal (default: 115200) parity used in Lua terminal (default: 'n', no parity)

init_file name of the file which is executed on system start, if the name

is "", no file is executed. (default: "")

If some wrong parameters are set, and the system wont start, the parameters can be restored to the default values in **bootloader**, executing **3 -e** command.

Watchdog

The system is protected by the watchdog. If the watchdog is not reloaded before the watchdog timeout expires, the system is RESET. The watchdog is automatically refreshed during the waiting for user input. If you have some long running Lua program, you have to reload the watchdog using *tmr.wdclr()* function before the watchgog timeout expires..

There are two types of watchdog in WiFiMCU Lua:

Hardware watchdog (type 0) is *STM32F411CE* IWDG timer which is set on system start and cannot be disabled. The IWDG is enabled even in STOP mode, so you cannot use STOP power save mode if this type of watchdog is used.

Software watchdog (type 1) is simple RTOS timer. It does not run in STOP mode, so it is possible to use STOP power save mode with this watchdog type. The system will not be protected from some "Hard Fault" errors.

mcu.ver()

Description

Get the WiFiMCU firmware version.

Syntax

nv,bd=mcu.ver()

Parameters

nil

Returns

```
nv: string type, WiFiMCU firmware version bd: string type, build date of the firmware
```

Examples

```
> nv,bd=mcu.ver()
> print(nv,bd)
WiFiMCU 0.9.7 build 20151122
```

mcu.info()

Description

Get the mxchipWNet library version, MAC address, WLAN driver version.

Syntax libv,mac,drv=mcu.info()

Parameters nil

Returns

```
libv: mxchipWNet library version mac: MAC address of the module drv: WLAN driver version
```

Examples

```
> libv,mac,drv=mcu.info()
> print(libv,mac,drv)
31620002.031 C8:93:46:50:21:4C wl0: Dec 29 2014 14:07:06 version 5.90.230.10
FWID 01-9bdaad4d
```

mcu.reboot()

Description

Reboot WiFiMCU immediately.

Syntax

```
mcu.reboot()
```

Parameters

nil

Returns

nil

Examples

> mcu.reboot()

mcu.mem()

Description

Get the memory status.

Syntax fm,tas,mtas,fc=mcu.mem()

Parameters nil

Returns

fm: Total free space

tas: Total allocated space

mtas: Maximum total allocated space fc: Number of free chunks

Examples

- > fm,tas,mtas,fc=mcu.mem()
- > print(fm,tas,mtas,fc)
- > 35600 50416 86016 25

mcu.chipid()

Description

Get the stm32 chip ID (96 bits).

Syntax

chipid= mcu.chipid()

Parameters

nil

Returns

chipid: the stm32 chip product ID

Examples

- > chipid= mcu.chipid()
- > print(chipid)

0200C000FDFFFAE005DFF000

mcu.bootreason()

Description

Get the WiFiMCU boot reason that cause its startup.

Syntax

bootreason= mcu. bootreason()

Parameters

nil

Returns

bootreason: The boot reason should be one the followings:

"NONE": Fail to get the boot reason

"SOFT_RST": Software reset "PWRON_RST": Power on reset

"EXPIN_RST": Pin reset

"WDG_RST": Independent Watchdog reset
"WWDG_RST": Window Watchdog reset

"LOWPWR RST": Low Power reset

"BOR RST": POR/PDR or BOR reset

Examples

```
> mcu.bootreason()
SOFT_RST
```

mcu.getparams()

Description

Get system parameters as Lua table.

Syntax

```
param = mcu.getparams()
```

Parameters

nil

Returns

param: Lua table containing the system parameters

```
> param= mcu.getparams()
> for k,v in pairs(param) do print("param: "..k.." = "..v) end
param: inbuf_size = 256
param: stack_size = 20480
param: baud_rate = 115200
param: crc = 0k
param: wdg_tmo = 10000
param: parity = NO_PARITY
param: init_file =
param: soft_wdg = 0
```

mcu.sgetparams()

```
Description
    Print system parameters.
Syntax
    mcu.sgetparams()
Parameters
    nil
Returns
    nil, prints parameters
Examples
    > mcu.sgetparams()
        soft_wdg = 0
        wdg_tmo = 10000
```

stack_size = 20480
inbuf_size = 256
init_file = ""
baud_rate = 115200
 parity = 'n'

mcu.setparams()

Description

CRC ok.

Set one or more system parameters.

Syntax

mcu.setparams(paramtbl)

Parameters

```
paramtbl: Lua table containing one or more parameters
soft_wdg watchdog type, 0 or 1, default = 0 (hardware wdg)
wdg_tmo watchdog timeout in milisec, 2000~36000000, default = 10000
stack_size lua stack size in bytes, 5000~31000, default = 20480
lua inpu buffer size in bytes, 128~1024, default = 256
init_file lua serial terminal baud rate, default = "", no script executed baud_rate lua serial terminal baud rate, default = 115200
lua serial terminal parity, 'n' or 'e' or 'o', default = 'n'
```

Note: if watchdog type is changed, the system wil reboot after watchdog timeout expires

Returns

nil, prints status

```
> =mcu.setparams({stack_size=10240,soft_wdg=1,init_file="init.lua"})
updated: soft_wdg, RESET in 10 sec!
updated: stack_size
updated: init_file
New params saved.
```

GPIO Module

Function List

| gpio.mode() | Define the GPIP Pin mode, set the pin to input output or interrupt mode |
|---------------|---|
| gpio.read() | Read the pin value |
| gpio.write() | Set the pin value |
| gpio.toggle() | Toggle the pin's output value |

Constant

| gpio.INPUT | Input with an internal pull-up resistor |
|--------------------------------------|---|
| gpio.INPUT_PULL_UP | Input with an internal pull-up resistor |
| gpio.INPUT_PULL_DOWN | Input with an internal pull-down resistor |
| gpio.INPUT_INPUT_HIGH_IMPEDANCE_DOWN | Input high impedance down |
| gpio.OUTPUT | Output actively driven high and actively driven low |
| gpio.OUTPUT_PUSH_PULL | Output actively driven high and actively driven low |
| gpio.OUTPUT_OPEN_DRAIN_NO_PULL | Output actively driven low but is high-impedance when set high |
| gpio.OUTPUT_OPEN_DRAIN_PULL_UP | Output actively driven low and is pulled high with an internal resistor when set high |
| gpio.INT | Interrupt |
| gpio.HIGH | High voltage level |
| gpio.LOW | Low voltage level |

GPIO Pin Table

| WiFiMCU Index | Alternate function | Discription |
|---------------|-----------------------|--|
| D0 | GPIO/BOOT | WiFiMCU would enter into Bootloader Mode, if D0 goes to LOW |
| D1 | GPIO/PWM/ADC | |
| D2 | GPIO | |
| D3 | GPIO/PWM | |
| D4 | GPIO | |
| D5 | GPIO | SWD Flash Programming Pin: swclk |
| D6 | GPIO | SWD Flash Programming Pin: swdio |
| D7 | GPIO/SPI5_MISO | |
| D8 | GPIO/PWM/SPI5_MOSI | Uart1 rx pin: RX1 |
| D9 | GPIO/PWM | Uart1 tx pin: TX1 |
| D10 | GPIO/PWM | I2C interface: SCL |
| D11 | GPIO/PWM | I2C interface: SDA |
| D12 | GPIO/PWM | |
| D13 | GPIO/PWM/ADC | |
| D14 | GPIO/PWM | |
| D15 | GPIO/PWM/ADC | |
| D16 | GPIO/PWM/ADC/SPI5_CLK | |
| D17 | GPIO/ADC | BLUE LED on WiFiMCU board |

gpio.mode()

Description

Define the GPIO Pin mode, set the pin to input output or interrupt mode.

Syntax

```
gpio.mode(pin, mode)
gpio.mode(pin, gpio.INT, trigMode, func cb)
```

Parameters

```
pin: gpio ID, 0~17
mode: Should be one of the followings: gpio.INPUT
gpio.INPUT_PULL_UP gpio.INPUT_PULL_DOWN
gpio.INPUT_INPUT_HIGH_IMPEDANCE_DOWN gpio.OUTPUT
gpio.OUTPUT_PUSH_PULL gpio.OUTPUT_OPEN_DRAIN_NO_PULL
gpio.OUTPUT_OPEN_DRAIN_PULL_UP gpio.INT
trigMode: if mode is gpio.INT, trigMode should be:
'rising': Interrupt triggered at input signal's rising edge
'falling': Interrupt triggered at both rising and falling edge
```

func cb: if mode is gpio.INT, the interrupt call back function

Note: It's recommend that you DO NOT do too much time consuming operations in the func cb.

Returns nil

Examples

```
>gpio.mode(0, gpio.OUTPUT)
>gpio.write(0, gpio.HIGH)
>gpio.mode(1,gpio.INPUT)
>print(gpio.read(1))
>0
```

gpio.read()

Description

Read the pin value.

Syntax value=gpio.read(pin)

Parameters

```
pin: gpio ID, 0~17
```

Returns

```
value: 0 - low, 1 - high
```

Examples

```
> gpio.mode(0, gpio.INPUT)
> print(gpio.read(0))
> 0
```

gpio.write()

Description

Set the pin value.

Syntax

gpio.write(pin, value)

Parameters

```
pin: gpio ID, 0~17
```

value: 0 or 1 or gpio.HIGH or gpio.LOW

Returns nil

```
> gpio.mode(0, gpio.OUTPUT)
> gpio.write(0,gpio.HIGH)
> gpio.write(0,0)
```

gpio.toggle()

Description

Toggle the pin's output value **Syntax** gpio.toggle(pin)

Parameters

pin: gpio ID, 0~17

Returns nil

```
>gpio.mode(17, gpio.OUTPUT)
>gpio.toggle(17)
>gpio.toggle(17)
```

TIMER Module

Function List

| tmr.start() | Start a timer with call back function | |
|---------------|---|--|
| tmr.stop() | Stop a timer | |
| tmr.stopall() | Stop all the timers | |
| tmr.tick() | Get the current time tick of the MCU (ms) since startup | |
| tmr.delayms() | Delay for a assigned time in millisecond | |
| tmr.delayus() | Delay for a assigned time in microsecond | |
| tmr.wdclr() | Clear the Independent watchdog counter | |

Constant

nil

tmr.start()

Description

Start a timer with call back function.

Syntax

tmr.start(tmrID, interval, func_cb)

Parameters

tmrID: timer ID, $0\sim15$. 16 timers are supported at present

interval: interval time for the timer func cb: Callback function for the timer

Returns nil

```
> tmr.start(1,1000,function() print("tmr1 is called") end)
> tmr1 is called
tmr1 is called
tmr1 is called
```

tmr.stop()

```
Description
        Stop a timer
Syntax
        tmr.stop(tmrID)
Parameters
        tmrID: timer ID, 0~15
Returns
        nil
Examples
        > tmr.start(1,1000,function() print("tmr1 is called") end)
        tmr1 is called
        tmr1 is called
        tmr1 is called
        tmr1 is called
        tmr1 is called
```

tmr.stopall()

Description

Stop all the timer.

Syntax

tmr.stopall(tmrID)

Parameters

nil

Returns

nil

Examples

```
> tmr. stopall()
```

tmr.tick()

Description

Get the current time tick of the MCU (ms) since startup.

Syntax tick=tmr.tick()

Parameters nil

Returns nil

```
>print(tmr.tick())
1072237
```

tmr.delayms()

Description

Delay for a assigned time in millisecond.

Syntax

tmr.delayms(ms)

Parameters

ms: The delay time in millisecond

Returns

nil

Examples

> tmr.delayms(1000)

tmr.delayus()

Description

Delay for a assigned time in microsecond.

Syntax

tmr.delayus(us)

Parameters

us: The delay time in microsecond

Returns

nil

Examples

> tmr.delayus(1000)

tmr.wdclr()

Description

Clear the independent watchdog counter.

The default independent watchdog time is 10 senconds.

Note: This function should be called if some operations takes more than 10 seconds to complete

Syntax

tmr. wdclr ()

Parameters nil

Returns nil

Examples

> tmr.wdclr()

WiFi Module

Function list

| wifi.startap() | Setup wifi in soft Access Point (AP) Mode, enable DHCP function |
|---------------------|---|
| wifi.startsta() | Setup wifi in Station Mode (STA), begin to connect a AP |
| wifi.scan() | Scan APs |
| wifi.stop() | Close all the Wi-Fi connections, Both in station mode and soft ap mode |
| wifi.powersave() | Enable IEEE power save mode |
| wifi.ap.getip() | Get ip address in soft AP mode |
| wifi.ap.getipadv() | Get advanced net information in soft AP mode: DHCP mode, ip address, gateway, netmask, dns, MAC, broad cast address |
| wifi.ap.stop() | Close all the Wi-Fi connections in soft ap mode |
| wifi.sta.getip() | Get ip address in STA mode |
| wifi.sta.getipadv() | Get advanced net information in STA mode: DHCP mode, ip address, gateway, netmask, dns, MAC, broad cast address |
| wifi.sta.getlink() | Get the connected AP information in STA mode: Connect status, WiFi signal strength, ssid, bssid. |
| wifi.sta.stop() | Close all the Wi-Fi connections in STA mode |
| wifi.sta.ntptime() | Set RTC datetime from ntp server |

Constant

nil

wifi.startap()

Description

Setup wifi in soft Access Point (AP) Mode, enable DHCP function.

Syntax wifi.startap(cfg)

wifi.startap(cfg,func_cb)

Parameters

cfg: lua table, contains the configurations for soft AP mode.

cfg.ssid: soft AP's ssid

cfg.pwd: soft AP's password. It will be an open WiFi if cfg.pwd is empty

```
cfg.ip: optional. The local ip address of the module, Default: "11.11.11.1"
```

cfg.netmask: optional. Default: "255.255.255.0" optional. Dafault: "11.11.11.1"

cfg.dnsSrv: optional. DNS server address. Default: "11.11.11.1" cfg.retry_interval: optional. retry interval in micro seconds. Default: 1 sec

func_cb: The callback function when the soft AP is setup successfully or the soft

AP is shut down.

Returns nil

Examples

```
>cfg={}
>cfg.ssid="WiFiMCU_Wireless"; cfg.pwd=""
>wifi.startap(cfg)
```

wifi.startsta()

Description

Setup wifi in Station Mode (STA), begin to connect a AP.

Syntax

```
wifi.startsta(cfg)
wifi.startsta(cfg, func cb)
```

Parameters

cfg: lua table, contains the configurations for soft AP mode.

cfg.ssid: AP's ssid

cfg.pwd: AP's password

cfg.dhcp: optional. Set dhcp function: 'enable' is to enable the dhcp function.

WiFiMCU will get ip automatically. 'disable' is to disable the dhcp

function. It's 'enable' in default.

cfg.ip: optional. The local ip address of the module. If cfg.dhcp is 'disable' this

parameter must be assigned.

cfg.netmask: optional. Netmask. If cfg.dhcp is 'disable' this parameter must be assigned. cfg.gateway: optional. Gateway. If cfg.dhcp is 'disable' this parameter must be assigned. cfg.dnsSrv: optional. DNS server address. If cfg.dhcp is 'disable' this parameter must be assigned.

cfg.retry_interval: optional. retry interval in micro seconds. If cfg.dhcp is 'disable' this parameter must be assigned.

func_cb: The callback function when WiFiMCU had connected to the AP successfully, or WiFiMCU is disconnected to from the AP.

Returns nil

```
>cfg={}
>cfg.ssid="Doit"; cfg.pwd="123456789"
>wifi.startsta(cfg)
```

wifi.scan()

Description

Scan AP list and return a Lua table containing the results.

Syntax wifi.scan(fun cb(t))

Parameters

func_cb(t): The callback function when scan is finished. 't' is a Lua table in which the keys are the APs' ssid and values are strings in format (" mac, signal strength, channel, authmode")

Returns nil

Examples

wifi.stop()

Description

Close all the Wi-Fi connections, Both in station mode and soft ap mode.

Syntax wifi.stop()

Parameters nil

Returns nil

See also wifi.ap.stop() wifi.sta.stop()

Examples

```
> wifi.stop()
```

wifi.powersave()

Description

Enable IEEE power save mode.

Syntax

wifi. powersave ()

Parameters

nil

Returns

nil

```
> wifi. powersave ()
```

wifi.ap.getip()

Description

Get ip address in AP mode

Syntax

ip=wifi. ap.getip()

Parameters

nil

Returns

ip: The module ip in soft AP mode.

Examples

```
> ip=wifi.ap.getip ()
> print(ip)
11.11.11.1
```

wifi.ap.getipadv()

Description

Get advanced net information in soft AP mode: DHCP mode, ip address, gate way, net mast, dns, MAC, broadcast address.

Syntax

dhcp,ip,gw,nm,dns,mac,bip =wifi. ap.getipadv()

Parameters nil

Returns

dhcp: DHCP mode. in soft AP mode, it will be always "DHCP Server"

ip: ip address.

gw: gateway address. nm: netmask.dns: dns address. mac: MAC address.

bip: broadcast ip address.

```
> dhcp,ip,gw,nm,dns,mac,bip =wifi.ap.getipadv()
> print(dhcp,ip,gw,nm,dns,mac,bip)

DHCP_Server 11.11.11.1 11.11.1 255.255.255.0 208.67.222.222 c89346501a62
255.255.255.255
```

wifi.ap.stop()

Description

Close all the Wi-Fi connections in soft ap mode.

Syntax wifi.ap.stop()

Parameters nil

Returns nil

See also wifi.stop() wifi.sta.stop()

Examples

```
> wifi.ap.stop()
```

wifi.sta.getip()

Description

Get ip address in STA mode.

Syntax

```
ip=wifi. sta.getip()
```

Parameters

nil

Returns

ip: The module ip in STA mode.

Examples

```
> ip = wifi.sta.getip ()
> print(ip)
192.168.1.108
```

wifi.sta.getipadv()

Description

Get advanced net information in STA mode: DHCP mode, ip address, gateway, netmask, dns, MAC, broad cast address.

Syntax

```
dhcp,ip,gw,nm,dns,mac,bip =wifi. sta.getipadv()
```

Parameters nil

Returns

dhcp: DHCP mode. in STA mode, "DHCP Server" or "DHCP Client" or

DHCP Disable ip: ip address.

gw: gateway address.

nm: netmask.

dns: dns address. mac: MAC address.

bip: broadcast ip address.

Examples

```
> dhcp,ip,gw,nm,dns,mac,bip = wifi.sta.getipadv()
```

> print(dhcp,ip,gw,nm,dns,mac,bip)

DHCP_Client 192.168.1.108 192.168.1.1 255.255.255.0 192.168.1.1 c89346501a62 255.255.255

wifi.sta.getlink()

Description

Get the connected AP information in STA mode:Connect status, WiFi signal strength, ssid, bssid.

Syntax status, strength, ssid, bssid=wifi.sta.getlink()

Parameters nil

Returns

status: The connecting status. if connected it's "connected" else it's "disconnected".

It will be nil for strength/ssid/bssid if it's "disconnected".

strength: The signal strength. ssid: The connected AP's ssid. bssid: The connected AP's bssid.

Examples

```
> status,strength,ssid,bssid=wifi.sta.getlink()
> print(status,strength,ssid,bssid)
```

connected 62 Doit BC:D1:77:32:E7:2E

wifi.sta.stop()

Description

Close all the Wi-Fi connections in STA mode.

Syntax wifi.sta.stop()

Parameters nil

Returns nil

See also wifi.stop() wifi.ap.stop()

Examples

> wifi.sta.stop()

wifi.sta.ntptime()

Description

Set RTC datetime from ntp server.

Syntax

wifi.sta.ntptime()
wifi.sta.ntptime(timezone)
wifi.sta.ntptime(timezone,ntpserver)

Parameters

timezone: optional, use specified time zone offset from UTC (-12 - +14), default=0 optional, specify ntp server to use, default="time1.google.com"

Returns

status: disconnected if no wifi connection detected

Examples

> wifi.sta.ntptime(1)

Net Module

Function list

| net.new() | Create a new socket, set the socket and transmission protocol |
|-------------|---|
| net.start() | Start the socket, set remote port, remote ip address, or local port according to the socket and transmission protocol |
| net.on() | Register the callback functions for socket events |
| net.send() | Send data |
| net.close() | Close socket |
| net.getip() | Get the ip address and port of the client socket. |

Constant

| net.TCP | TCP protocol |
|-------------|--------------|
| net.UDP | UDP protocol |
| net. SERVER | Server type |
| net.CLIENT | Client type |

net.new()

Description

Create a new socket, set the socket and protocol type.

Max 4 server and max 4 client can be setup in WiFiMCU.

If the socket type is Server, max number of 5 clients are allowed to connect.

Syntax skt=net.new(protocol,type)

Parameters

protocol: The transmission protocol, must be one of the two: net.TCP,

type: socket type, must be one of the two: net.SERVER, net.CLIENT

Returns

skt: the handle for this socket

Examples

>skt = net.new(net.TCP,net.SERVER)

```
>skt2 = net.new(net.UDP,net.CLIENT)
```

net.start()

Description

Start the socket, set remote port, remote ip address, or local port according to the socket and transmission protocol.

Syntax

```
net.start(socket, localport)
net.start(socket, remoteport, "domain", [local port])
```

Parameters

socket: The socket handle returned from net.new()

localport: If the socket type is net.SERVER, It's the local binded port for this socket. remoteport: If the socket type is net.CLIENT, It's the remote server port.

"domain": If the socket type is net.CLIENT, it's the domain name string for remote server. The remote server's ip address can be used too.

local port: Optinal, if the socket type is net.CLIENT, [local port] set the local binded port for the socket. If ignored, a random port would be assigned.

Returns nil

Examples

```
> skt = net.new(net.TCP,net.SERVER)
> skt2 = net.new(net.UDP,net.CLIENT)
> net.start(skt, 80)
> net.start(skt2,9000,'11.11.11.2', 8000)
```

net.on()

Description

Register the callback functions for socket events.

Syntax net.on(socket,event,func cb)

Parameters

socket: The socket handle returned from net.new()

event: If the socket type is net.SERVER, event should be one of the following:

"accept" (TCP server socket only), "receive", "sent", "disconnect".

If the socket type is net.CLIENT, event should be one of the following:

"connect(TCP client socket only)", "receive", "sent", "disconnect", "dnsfound".

func cb: Callback function for different events. The function parameters diff from events.

"accept": TCP server socket only. If the tcp server accept a tcp client connection request, the function will be called. Function prototype is: func cb(clt, ip, port). "clt"

is the tcp client socket handle, "ip" is the client ip address, "port" is the client's port.

- "receive": If data arrived on the assigned socket, the function will be called. Function prototype is: func cb(clt, data). "clt" is the socket handle, "data" is the received data.
- "sent": When data had sent succeffuly on the assigned socket, the function will be called. Function prototype is: func cb(clt). "clt" is the socket handle.
- "disconnect": If the client socket is disconnected from server or some errors happened, the function will be called. Function prototype is: func_cb(clt). "clt" is the socket handle.
- "connect": TCP Client socket only. When the client socket connects to the remote server successfully, the function will be called. Function prototype is: func_cb(clt). "clt" is the socket handle.
- "dnsfound": TCP or UDP Client socket only. When the DNS operations has finished, the function will be called. Function prototype is: func_cb(clt, ip). "clt" is the socket handle, "ip" is the ip address for the domain.

Returns nil

Examples

```
> clt = net.new(net.TCP,net.CLIENT)
> net.on(clt,"dnsfound",function(clt,ip) print("dnsfound clt:"..clt.." ip:"..ip)
end)
> net.on(clt,"connect",function(clt) print("connect:clt:"..clt) end)
> net.on(clt,"disconnect",function(clt) print("disconnect:clt:"..clt) end)
> net.on(clt,"receive",function(clt,d) print("receive:clt:"..clt.."data:"..d)
end)
> net.start(clt,9003,"11.11.11.2")
```

net.send()

Description

Send data.

Syntax

net.send(socket, data, [func_cb])

Parameters

```
socket: The socket handle returned from net.new() data: Data to be sent.
```

func_cb: Optinal, "sent" eventcall back function. When data had sent succeffuly on the assigned socket, the function will be called. Function prototype is: func_cb(clt). "clt" is the socket handle.

Returns nil

```
>net.send(clt,"hello")
```

net.close()

Description

Close socket, release the resource of the socket.

Syntax

net.close(socket)

Parameters

socket: The socket handle returned from net.new()

Returns

nil

Examples

```
>skt = net.new(net.TCP,net.SERVER) >net.close(skt)
```

net.getip()

Description

Get the ip address and port of the client socket.

Syntax

```
ip, port = net.getip(socket)
```

Parameters

socket: The socket handle returned from net.new(). The socket handle should be a client socket.

Returns

ip: the ip address for the socket. port: the port for the socket.

```
>ip, port = net.getip(clt)
```

File Module

The file system is based on spi flash embeded in WiFiMCU. The total storage capacity is ${\sim}1550 K$

Function list

| - | |
|------------------|---|
| file.format() | Format file system, all stored data will be lost after format |
| file.open() | Open or create a file |
| file.close() | Close an opened file |
| file.write() | Write data to an opened file |
| file.writeline() | Write data to an opened file, with a '\n' added at the tailed of data |
| file.read() | Read data from an opened file |
| file.readline() | Read a line data from an opened file |
| file.list() | Get the file name and size list in file system |
| file.slist() | Print the file name and size list on terminal |
| file.remove() | Remove file |
| file.seek() | Set the position of file pointer |
| file.flush() | Clear file buffer |
| file.rename() | Rename the file |
| file.info() | Get the file system storage status |
| file.state() | Get the opened file's name and size |
| file.compile() | Compile a Lua scripts file to lc file. |
| file.recv() | Receive the file using Ymodem protocol |
| file.send() | Send the file using Ymodem protocol |
| dofile() | Run a file |

Constant

nil

file.format()

Description

Format file system, all stored data will be lost after format. It's recommended not to do anythings while formatting.

Syntax

file.format()

Parameters nil

Returns nil

If formatting is done successfully, "format done" will be printed, else "format error" will be printed.

Examples

```
>file.format()
format done
```

file.open()

Description

Open or create a file.

Syntax

```
ret = file.open(filename,mode)
```

Parameters

filename: filename string to be created or opened. Directories are not supported yet. mode: open type:

```
"r": read mode (the default parameter)
```

"r+": update mode, all previous data is preserved

"w": write mode

"w+": update mode, all previous data is erased

"a": append mode

"a+": append update mode, previous data is preserved, writing is only

allowed at the end of file

Returns

ret: true if succeed, else nil.

```
>file.open("test.lua","w+")
>file.write("This is a test") >file.close()
```

file.close()

Description

Close an opened file.

Syntax

file.close()

Parameters

nil

Returns

nil

Examples

```
>file.open("test.lua","w+")
>file.write("This is a test")
>file.close()
```

file.write()

Description

Write data to an opened file.

Syntax ret=file.write(data)

Parameters

data: The data to be wrote.

Returns

ret: true if succeed, else nil.

Examples

```
>file.open("test.lua","w+")
>file.write("This is a test")
>file.close()
```

file.writeline()

Description

Write data to an opened file, with a '\n' added at the tailed of data.

Syntax ret=file.writeline(data)

Parameters

data: The data to be wrote. A char '\n' will be added at the end of data.

Returns

ret: true if succeed, else nil.

```
>file.open("test.lua","w+")
```

```
>file.writeline("This is a test")
>file.close()
```

file.read()

Description

Read data from an opened file.

Syntax

```
ret=file.read()
ret=file.read(num)
ret=file.read(endchar)
```

Parameters

if the parameter is nil, read all byte in file.

num: if a number is assigned, read the num bytes from file, or all rest data in case of end of file.

endchar: read until endchar or EOF is reached.

Returns

ret: the file data if succeed, else nil.

Examples

```
>file.open("test.lua","r")
>data=file.read()
>file.close()
>print(data)
This is a test
>file.open("test.lua","r")
>data=file.read(10)
>file.close()
>print(data)
This is a
>file.open("test.lua","r")
>data=file.read('e')
>file.close()
>print(data)
This is a
```

file.readline()

Description

Read a line data from an opened file.

Syntax ret=file.readline ()

Parameters nil

Returns

ret: the file data if succeed, else nil.

Examples

```
>file.open ("test.lua","w+")
>file.writeline("this is a test")
>file.close()
>file.open("test.lua","r")
>data=file.readline()
>print(data)
This is a test
>file.close()
```

file.list()

Description

Get the file name and size list in file system.

Syntax ft=file.list()

Parameters nil

Returns

ft: a Lua table, in which the filename is the key, file size is the value.

Examples

```
>for k,v in pairs(file.list()) do print("name:"..k.." size(bytes):"..v) end
name:test.lua size(bytes):15
```

file.slist()

Description

Print the file name and size list on terminal.

Syntax file.slist()

Parameters nil

Returns nil

Examples

```
>file.slist()
test.lua size:15
```

file.remove()

Description

Remove file.

Syntax

file.remove(filename)

```
Parameters
```

filename: filename string to be removed.

Returns

nil

Examples

```
>file.remove("test.lua")
```

file.seek()

Description

Set the position of file pointer.

Syntax

fi = file.seek(whence, offset)

Parameters

whence: should be one of the following:

```
"set": base is position 0 (beginning of the file);
"cur": base is current position;(default value)
"end": base is end of file;
```

offset: default 0.

Returns

fi: the file pointer final position if succeed, else nil.

Examples

```
>file.open ("test.lua","r")
>file.seek("set",10)
>data=file.read()
>file.close()
>print(data)
test
```

file.flush()

Description

Clear file buffer.

Syntax

ret = file.flush()

Parameters nil

Returns

ret: true if succeed, else nil.

```
>file.open ("test.lua","r")
>file.flush ()
```

```
>file.close()
```

file.rename()

Description

Rename the file.

Syntax

ret=file.rename(oldname,newname)

Parameters

oldname: File name to be changed.

newname: New file name.

Returns

ret: true if succeed, else nil.

Examples

```
> file.slist()
test.lua size:14
>file.rename('test.lua',' testNew.lua')
>file.slist()
testNew.lua size:14
```

file.info()

Description

Get the file system storage status.

Syntax

last,used,total = file.info()

Parameters nil

Returns

last: free storage left in bytes. used: used storage in bytes.

total: all allocated storage for file system in bytes.

Examples

```
> last,used,total = file.info()
> print(last,used,total)
1140500 2750 1143250
```

file.state()

Description

Get the opened file's name and size

Syntax

```
fn,sz = file.state()
```

Parameters nil

Returns

```
fn: filename.sz: file size in bytes.
```

Examples

```
>file.open("testNew.lua","r")
>fn,sz = file.state()
>file.close()
>print(fn,sz)
testNew.lua 14
```

file.compile()

Description

Compile a Lua scripts file to lc file. The lc file will be named as the same name as the Lua file.

Syntax file.compile('filename.lua')

Parameters

filename.lua: file name of the Lua scripts.

Returns nil.

Examples

```
>file.open("test.lua","w+")
>file.write("print('Hello world!')")
>file.close()
>file.compile("test.lua")
>file.slist()
test.lua size:21 test.lc size:100
```

file.recv()

Description

Receive the file over serial line using ymodem protocol.

```
Syntax file.recv(["filename"])
```

Parameters

filename: optional; if specified, the file is saved with that name, otherwise, file name from the sender is used

Returns nil. After receive, the directory content is printed

Examples

> file.recv()

Start Ymodem file transfer...

CCCCCCCCCCCCC

Starting ymodem transfer. Press Ctrl+C to cancel.

Transferring test.lua...

100% 12 KB 12 KB/sec 00:00:01 0 Errors

Received successfully, 12389

oledtest.lua size: 1178 init.lua size: 1337 test.lua size: 12389

> file.recv("new_test.lua")

Start Ymodem file transfer...

Starting ymodem transfer. Press Ctrl+C to cancel.

Transferring test.lua...

100% 12 KB 12 KB/sec 00:00:01 0 Errors

Received successfully, 12389

oledtest.lua size: 1178
init.lua size: 1337
test.lua size: 12389
new_test.lua size: 12389

file.send()

Description

Send the file over serial line using ymodem protocol.

Syntax file.recv("filename",["newfilename"])

Parameters

Filename: name of the file to send

newfilename: optional; if specified, the file is sent with that name, othewise, the

original file name is used

Returns nil. After receive, the directory content is printed

```
Examples
```

```
> file.send("test.lua")
Start Ymodem file transfer...
CCCCCCC
Starting ymodem transfer. Press Ctrl+C to cancel.
Transferring test.lua...
 100%
          12 KB
                    12 KB/sec
                                 00:00:01
                                               0 Errors
File sent successfuly.
> file.send("test.lua","old-test.lua")
sending "test.lua" as "old-test.lua"
Start Ymodem file transfer...
CCCCCC
Starting ymodem transfer. Press Ctrl+C to cancel.
Transferring old-test.lua...
 100%
          12 KB
                    12 KB/sec
                                 00:00:01
                                               0 Errors
File sent successfuly.
```

dofile()

Description

Run a file. The file can be either a Lua scripts or a lc format file.

Syntax

dofile('filename.lua')
dofile('filename.lc')

Parameters

filename.lua: Lua scripts file. filename.lc: a lc file

Returns nil.

Examples

>dofile("test.lua")
Hello world!
>dofile("test.lc")
Hello world!

PWM Module

Function list

| pwm.start() | Start pwm function at assigned gpio pin |
|-------------|---|
| pwm.stop() | Stop pwm |

Constant

nil

Pin Table

Plaese refer: "GPIO Table" for detail.

pwm.start()

Description

Start pwm function at assigned gpio pin.

Syntax

pwm.start(pin, freq, duty)

Parameters

```
pin: gpio pin ID. There are 11 PWM ports supported in WiFiMCU: D1, D3, D4, D9, D10, D11, D12, D13, D14, D15, D16. freq: PWM output frequency in Hz, 0<freq<10KHz duty: Duty of PWM output, must be 0<=duty <=100
```

Returns nil.

```
>i=1;pin=1;
>tmr.start(1,1000,function() i=i+10;if i>=100 then i=1 end
pwm.start(pin,10000,i)
end)
>
```

pwm.stop()

Description

Stop pwm.

Syntax pwm.stop(pin)

Parameters

pin: gpio pin ID. There are 11 PWM ports supported in WiFiMCU: D1, D3, D4, D9, D10, D11, D12, D13, D14, D15, D16.

Returns nil.

Examples

>pwm.stop(1)

ADC Module

Function list

| adc.read() | Read the ADC result at assigned pin |
|--------------|---|
| adc.readmv() | Read the ADC result in mV at assigned pin |

Constant

nil

Pin Table

Plaese refer: "GPIO Table" for detail.

adc.read()

Description

Read the ADC result at assigned pin.

Syntax

data= adc.read(pin)

Parameters

pin: gpio pin ID.

There are 5 ADC ports supported in WiFiMCU: D1, D13, D15, D16, D17.

Returns

data: if succeed, data between 0~4095 is returned, else nil.

Note that: 0 presents 0V, 4095 presents 3.3V.

```
>=adc.read(1)
0
>=adc.read(1)
4095
```

adc.readmv()

Description

Read the ADC result in mV (mili volts) at assigned pin.

Syntax

```
data= adc.readmv(pin)
```

Parameters

```
pin: gpio pin ID.

There are 5 ADC ports supported in WiFiMCU: D1, D13, D15, D16, D17.
```

Returns

data: if succeed, data between 0~3300 is returned, else nil.

```
>=adc.readmv(1)
1
>=adc.readmv(1)
3300
```

UART Module

Only one uart is supported in WiFiMCU so far. The GPIO pin is D8(RX1), D9(TX1).

Function list

| uart.setup() | Setup uart parameters: buadrate, databits, parity, stopbits. |
|--------------|--|
| uart.on() | Register the callback functions for uart events |
| uart.send() | Send data via uart |

Constant

null

Warning: UART shares Rx pin with hardware SPI5. You can't use both at the same time.

uart.setup()

Description

Setup uart parameters: buadrate, databits, parity, stopbits.

Syntax

uart.setup(id, baud, parity, databits, stopbits)

Parameters

```
id: uart ID, always 1 at present. baud: baudrate, such as: 4800, 9600, 115200. parity: 'n': no parity, 'o': odd parity, 'e': even parity. databits: data bits, '5', '6', '7', '8', '9'. stopbits: stop bits, '1', '2'
```

Returns nil

```
>uart.setup(1,9600,'n','8','1')
```

uart.on()

Description

Register the callback functions for uart events.

Syntax

```
uart.on(id, event ,func cb)
```

Parameters

id: uart ID, always 1 at present.

event: always "data".

func_cb: Callback function for the event. When data arrived, the function will

be called. Function prototype is: func cb(data). "data" is the data

received.

Returns nil

Examples

```
>uart.on(1, 'data',function(t) len=string.len(t) print(len.." "..t)
uart.send(1,t) end)
```

uart.send()

Description

Send data via uart.

Syntax

```
uart.send(1, string1,[number],...[stringn])
```

Parameters

```
id: uart ID, always 1 at present.
```

string1: string ready to send.

[number]: Optional, number ready to send.

[stringn]: Optional, The nth string ready to be send.

Returns nil

```
>uart.send(1,'hello wifimcu')
>uart.send(1,'hello wifimcu','hi',string.char(0x32,0x35))
>uart.send(1,string.char(0x01,0x02,0x03))
```

Bit Module

Function List

| bit.bnot | Bitwise negation |
|-------------|---|
| bit.band | Bitwise AND |
| bit.bor | Bitwise OR |
| bit.bxor | Bitwise XOR |
| bit.lshift | Logical left shift a number |
| bit.rshift | Logical right shift a number |
| bit.arshift | Arithmetic right shift a number |
| bit.bit | Generate a number with a 1 bit (used for mask generation) |
| bit.set | Set bits in a number |
| bit.clear | Clear bits in a number |
| bit.isset | Test if a given bit is set |
| bit.isclear | Test if a given bit is cleared |

Constant

nil

bit.bnot()

Description

Bitwise negation.

Syntax num=bit.bnot(val)

Parameters

val: the number to negation, value is 32 bit width.

Returns

num: the bitwise negated value of the number.

```
>print("result: "..bit.bnot(0x00000000))
result: -1
```

bit.band()

Description

Bitwise AND.

Syntax

num= bit.band(val1, val2, ... valn)

Parameters

val1: the first number to AND val1: the second number to AND

valn: the nth number to AND

Returns

num: the bitwise AND of all the arguments.

Examples

```
> print("result: "..bit.band(0xffffffff, 0x000000ff, 0x000000f))
result: 15
```

bit.bor()

Description

Bitwise OR.

Syntax

num= bit.bor(val1, val2, ... valn)

Parameters

val1: the first number to OR val1: the second number to OR

valn: the nth number to OR

Returns

num: the bitwise OR of all the arguments.

Examples

```
> print("result: "..bit.bor(0x00000000, 0x0000000ff, 0x0000000f)) result: 255
```

bit.bxor()

Description

Bitwise XOR.

Syntax

num= bit.bxor(val1, val2, ... valn)

Parameters

val1: the first number to XOR val1: the second number to XOR

valn: the nth number to XOR

Returns

num: the bitwise XOR of all the arguments.

Examples

```
> print("result: "..bit.bxor(0x00000000, 0x0000000ff, 0x0000000f))
result: 240
```

bit.lshift()

Description

Logical left shift a number.

Syntax

```
num= bit.lshift(val, shift)
```

Parameters

val: the value to shift shift: positions to shift

Returns

num: the number shifted left.

Examples

```
> print("result: "..bit.lshift(0x00000001,8))
result: 256
```

bit.rshift()

Description

Logical right shift a number.

Syntax

```
num= bit.rshift(val, shift)
```

Parameters

val: the value to shift shift: positions to shift

Returns

num: the number shifted right.

Examples

```
> print("result: "..bit.rshift(0x00000080,1))
result: 64
```

bit.arshift()

Description

Arithmetic right shift a number.

Syntax

```
num= bit.arshift(val, shift)
```

Parameters

val: the value to shift shift: positions to shift

Returns

num: the number arithmetically shifted right.

Examples

```
> print("result: "..bit.arshift(0x00000080,1))
result: 64
```

bit.bit()

Description

Generate a number with a 1 bit (used for mask generation).

Syntax

```
num = bit.bit(pos)
```

Parameters

pos: position of the bit that will be set to 1.

Returns

num: the number that only one bit is set to 1 and 0 for the rests.

Examples

```
> print("result: "..bit.bit(8))
result: 256
```

bit.set()

Description

Set bits in a number.

Syntax

```
num= bit.set(val, pos1,pos2,...,posn)
```

Parameters

val: the base number.

pos1: first position to be set. pos2: second position to be set. posn: nth position to be set.

Returns

num: the number with the bit(s) set in the given position(s)...

```
> print("result: "..bit.set(0x00000000, 0, 1, 2, 3))
result: 15
```

bit.clear()

Description

Clear bits in a number.

Syntax

```
num= bit.clear (val, pos1,pos2,...,posn)
```

Parameters

val: the base number.

pos1: first position to be cleared. pos2: second position to be cleared. posn: nth position to be cleared.

Returns

num: the number with the bit(s) cleared in the given position(s).

Examples

```
> print("result: "..bit.clear(0x0000000f, 0, 1, 2, 3))
result: 0
```

bit.isset()

Description

Test if a given bit is set.

Syntax

```
res= bit.iset (val, pos)
```

Parameters

val: the value number to be test pos: bit position.

Returns

res: true if the bit at the given position is 1, false otherwise.

Examples

```
>=bit.isset(0x0000000f, 1) true >=bit.isset(0x0000000f, 5) false
```

bit.isclear()

Description

Test if a given bit is cleared.

Syntax

```
res= bit.isclear (val, pos)
```

Parameters

val: the value number to be test

```
pos: bit position.
```

Returns

res: true if the bit at the given position is 0, false otherwise.

```
>=bit.isclear(0x0000000f, 1)
false
>=bit. isclear (0x0000000f, 5)
true
```

Sensor Module

Function List

| sensor.dht11.init | Init DHT11/22, Assign the GPIO Pin for DHT11/22. |
|------------------------|---|
| sensor.dht11.get | Get the DHT11/22 temperature and humility values |
| sensor.ds18b20.init | Init DS18B20, Assign the GPIO Pin for 1-wire. |
| sensor.ds18b20.gettemp | Start temperature measurement and get the temperature |
| sensor.ds18b20.search | Search for DS18B20 1-wire devices |
| sensor.ds18b20.setres | Set DS18B20 resolution (9,10,11,12 bit) |
| sensor.ds18b20.getres | Get current DS18B20 resolution (9,10,11,12 bit) |
| sensor.ds18b20.getrom | Get DS18B20 ROM values (returns 8 element table) |
| sensor.ow.init | Init 1-wire device, Assign the GPIO Pin for 1-wire. |
| sensor.ow.search | Search for 1-wire devices |

Constant

```
\begin{array}{lll} sensor.ds18b20.DS18B20\_RES9 & DS18B20\ 9\ bit\ resolution\\ sensor.ds18b20.DS18B20\_RES10 & DS18B20\ 9\ bit\ resolution\\ sensor.ds18b20.DS18B20\_RES11 & DS18B20\ 9\ bit\ resolution\\ sensor.ds18b20.DS18B20\ RES12 & DS18B20\ 9\ bit\ resolution\\ \end{array}
```

sensor.dht11.init()

Description

Init DHT11 sensor. Assign the GPIO Pin for dht11.

Syntax

res = sensor.dht11.init(pin,type)

Parameters

pin: gpio ID, $0\sim17$.

type: optional, DHT type: 0=DHT11; 1=DHT22 (default: DHT11)

Returns

res: true if dht11/22 initialization successful, nil otherwise.

```
>=sensor.dht11.init(7)
true
```

sensor.dht11.get()

Description

Get the DHT11/DHT22 temperature and humility value.

Syntax

temp, hum, stat = sensor.dht11.get()

Parameters nil

Returns

temp: temperature measured by DHT (deg for DHT11; 1/10 deg for DHT22).

hum: humidity measured by DHT (% for DHT11; 1/10 % for DHT22).

stat: conversion status (0=OK; 1=read err; 2=csum err; 3=check err; 4=not init)

Examples

```
> =sensor.dht11.get()
26 65 0
```

sensor.ds18b20.init()

Description

Init ds18b20 sensor. Assign the GPIO Pin for 1-wire.

Syntax

res = sensor.ds18b20.init(pin)

Parameters

pin: gpio ID, $0\sim17$.

Returns

res: true if ds18b20 initialization successfully, false otherwise.

Examples

```
>=sensor.ds18b20.init(7)
true
```

sensor.ds18b20.search()

Description

Search for DS18B20 1-wire devices.

Syntax

res = sensor.ds18b20.search()

Parameters

nil

Returns

res: Number of found DS18B20 devises.

Examples

```
>=sensor.ds18b20.search()
1
```

sensor.ds18b20.gettemp()

Description

Start temperature measurement and get the temperature.

Syntax

tmp, n = sensor.ds18b20.gettemp(dev)

Parameters

dev: ds18b20 device number, 1~num of detected devices with sensor.ds18b20.search()

Returns

tmp: temperature

n: duration of the measurement in msec (depends on current ds18b20 resolution)

Examples

```
> = sensor.ds18b20.gettemp(1)
22.1875 591
```

sensor.ds18b20.setres()

Description

Set DS18B20 resolution (9,10,11,12 bit).

Syntax

sensor.ds18b20.setres(dev, res)

Parameters

dev: ds18b20 device number, 1~num of detected devices with sensor.ds18b20.search() res: resolution (9,10,11,12 bit)

Returns

nil

Examples

```
> = sensor.ds18b20.setres(1,10)
```

sensor.ds18b20.getres()

Description

Get DS18B20 current resolution.

Syntax

Res = sensor.ds18b20.getres(dev)

Parameters

dev: ds18b20 device number, 1~num of detected devices with sensor.ds18b20.search()

Returns

res: resolution (9,10,11,12 bit)

Examples

```
> = sensor.ds18b20.getres(1)
10
```

sensor.ds18b20.getrom()

Description

Get DS18B20 ROM values (returns 8 element table).

Syntax

rom = sensor.ds18b20.getrom(dev)

Parameters

dev: ds18b20 device number, 1~num of detected devices with sensor.ds18b20.search()

Returns

rom: Table with 8 ROM values

Examples

```
> rom=sensor.ds18b20.getrom(1); for i=1,9,1 do print(dsrom[i]) end
40
142
106
200
0
0
110
```

sensor.ow.init()

Description

Init 1-wire device. Assign the GPIO Pin for 1-wire.

Syntax

res = sensor.ow.init(pin)

Parameters

pin: gpio ID, $0\sim17$.

Returns

res: true if 1-wire initialization successfully, false otherwise.

```
>=sensor.ow.init(7)
true
```

sensor.ow.search()

Description

Search for any 1-wire devices.

Syntax

```
res = sensor.ow.search()
```

Parameters

nil

Returns

res: Number of found 1-wire devises.

```
>=sensor.ds18b20.search()
1
```

SPI Module

Function List

| spi.setup | Init spi, assign GPIO pins | |
|------------|--|--|
| spi.write | Write data via spi interface, data can be multi numbers, string or lua table | |
| spi.read | Read data from spi interface | |
| spi.deinit | Deinitializes the SPI, free gpio pins | |

Constant

| spi.BITS_8 | 8 Bits data length |
|-------------|---------------------|
| spi.BITS_16 | 16 Bits data length |

Warning: UART shares Rx pin with hardware SPI5. You can't use both at the same time.

spi.setup()

Description

Initialize SPI. SPI module works in MASTER mode.

Syntax

spi.setup(id, config)

Parameters

id: 0 for software SPI; 2 for hardware SPI5 config: Lua table with spi configuration parameters:

mode=spi mode 0,1,2,3

speed=spi_speed spi clock frequency in kHz; 100~5000 for software spi,

400~50000 for hardware spi

cs=pin gpio ID, 0~17

rw=flag optional; 1 reads from MOSI while writing; 1 no read while write

The following parameters are only for software SPI: sck=pin gpio ID, 0~17 used for SCK mosi=pin gpio ID, 0~17 used for MOSI

miso=pin optional; gpio ID, 0~17 used for MISO

Returns

0 is succes; error code if not

Examples

```
-- hardware SPI5
>res = spi.setup(2,{mode=3, cs=12, speed=15000})
-- software SPI
>res = spi.setup(0,{mode=3, cs=12, speed=1000,sck=2, mosi=4})
```

spi.write()

Description

Write data via spi interface. Data can be multi numbers, string or lua table

Syntax

```
ret = spi.write(id, databits, data1, [data2],...,[datan])
```

Parameters

```
    id: 0 for software SPI; 2 for hardware SPI5
    databits: write databits. spi. BITS_8 or spi. BITS_16.
    data1: should be 0<data1< 255 in spi. BITS_8 mode or 0<data2<65535 in spi. BITS_16 mode.</li>
    data2: optional.
    datan: optional.
```

Returns

ret: The number of data written.

Examples

```
>res = spi.setup(0,{mode=3, cs=12, speed=1000,sck=2, mosi=4})
>ret = spi.write(0, 0xAA)
```

spi.read()

Description

Read data via spi interface.

Syntax

```
ret = spi.read(id, databits, num)
```

Parameters

```
id: 0 for software SPI; 2 for hardware SPI5 databits: write databits. spi. BITS_8 or spi. BITS_16. num: the number of data to read.
```

Returns

ret: the Lua table of read data.

```
> ret = spi.read(0, 2)
> print(ret[1]); print(ret[2])
```

spi.deinit()

Description

Deinitializes the SPI, free gpio pins.

Syntax

ret = spi.deinit(id)

Parameters

id:

0 for software SPI; 2 for hardware SPI5

Returns

ret: 0 on success; err code if error

Examples

> ret = spi.deinit(2)

I2C Module

Function List

| i2c.setup | Init i2c, assign GPIO pin |
|-------------|--|
| i2c.start | Send start condition |
| i2c.stop | Send stop condition |
| i2c.address | Send i2c device address and set transmission direction |
| i2c.write | Write data via i2c interface, data can be multi numbers, string or lua table |
| i2c.read | Read data from i2c interface |

Constant

nil

i2c.setup()

Description

Init i2c, assign GPIO pin.

Syntax

i2c.setup(id, pinSDA, pinSCL)

Parameters

id: i2c id, should be 0. pinSDA: GPIO Pin 0~17 pinSCL: GPIO Pin 0~17

Returns nil

Examples

>i2c.setup(0, 1, 2)

i2c.start()

Description

Send start condition

Syntax

i2c.start(id)

Parameters

nil

Returns

nil

Examples

>i2c.start(0)

i2c.stop()

Description

Send stop condition

Syntax

i2c.stop(id)

Parameters

id: i2c id, should be 0.

Returns

nil

Examples

>i2c.stop(0)

i2c.address()

Description

Send i2c device address and set transmission direction.

Syntax

ack = i2c.address(id, dev_id, mode)

Parameters

id: i2c id, should be 0. dev_id: device id address.mode: transmission direction. Should ether 'r' or 'w'.

Returns

ack: if slave device acknowledge success, return true, else return nil.

Examples

> i2c.address(0, 0x3C)

i2c.write()

Description

Write data via i2c interface, data can be multi numbers, string or lua table

Syntax

```
ret = i2c.write(id, data1, [data2],...,[datan] )
```

Parameters

id: should be 0.

data1: should be 0<data1 < 255.

data2: optional. datan: optional.

Returns

ret: The number of data wrote.

Examples

```
> ret = i2c.write(0, 0x00)
```

i2c.read()

Description

Read data from i2c interface

Syntax

```
ret = i2c.read(id, num)
```

Parameters

id: should be 0.

num: the number of data ready to read.

Returns

ret: the string of read data.

```
> ret = i2c.read(0, 1)
> print(ret)
```

RTC Module

Function List

| rtc.getasc | Get text representation of current date&time from RTC |
|------------------|--|
| rtc.get | Get Lua Table with second, minute, hour, weekday, date, month, year from RTC |
| rtc.getstrf | Get formated string representing the current datetime |
| rtc.set | Set RTC second, minute, hour, weekday, date, month, year |
| rtc.standby | Put CPU to standby or stop mode for specified number of seconds |
| rtc.standbyUntil | Put CPU to stabdby or stop mode until specified time |

rtc.getasc()

Description

Get text representation of current date&time from RTC

Syntax

strtime = rtc.getasc()

Parameters

nil

Returns

string: Current date & time

Examples

```
> =rtc.getasc()
Wed Nov 4 15:56:06 2015
```

rtc.getstrf()

Description

Get formated string representing the current datetime from RTC

Syntax

strtime = rtc.getstrf(format)

Parameters

| Forma | t: format string, default: "%Y-%m-%d %H:%M:%S" | |
|-------|---|-----------------------------|
| fmt | Replaced by | Example |
| %a | Abbreviated weekday name * | Thu |
| %A | Full weekday name * | Thursday |
| %b | Abbreviated month name * | Aug |
| %B | Full month name * | August |
| %c | Date and time representation * | Thu Aug 23 14:55:02 2001 |
| %C | Year divided by 100 and truncated to integer (00-99) | 20 |
| %d | Day of the month, zero-padded (01-31) | 23 |
| %D | Short MM/DD/YY date, equivalent to %m/%d/%y | 08/23/01 |
| %e | Day of the month, space-padded (1-31) | 23 |
| %F | Short YYYY-MM-DD date, equivalent to %Y-%m-%d | 2001-08-23 |
| %g | Week-based year, last two digits (00-99) | 01 |
| %G | Week-based year | 2001 |
| %h | Abbreviated month name * (same as %b) | Aug |
| %Н | Hour in 24h format (00-23) | 14 |
| %I | Hour in 12h format (01-12) | 02 |
| %j | Day of the year (001-366) | 235 |
| %m | Month as a decimal number (01-12) | 08 |
| %M | Minute (00-59) | 55 |
| %n | New-line character ('\n') | |
| %p | AM or PM designation | PM |
| %r | 12-hour clock time * | 02:55:02 pm |
| %R | 24-hour HH:MM time, equivalent to %H:%M | 14:55 |
| %S | Second (00-61) | 02 |
| %t | Horizontal-tab character ('\t') | |
| %T | ISO 8601 time format (HH:MM:SS), equivalent to %H:%M:%S | 14:55:02 |
| %u | ISO 8601 weekday as number with Monday as 1 (1-7) | 4 |

| %x | Date representation * | 08/23/01 |
|----|-------------------------------|----------|
| %X | Time representation * | 14:55:02 |
| %y | Year, last two digits (00-99) | 01 |
| %Y | Year | 2001 |
| %% | A % sign | % |

Returns

string: Formated current date & time

Examples

```
> =rtc.getstrf("%c")
Sun Nov 22 18:12:02 2015
> =rtc.getstrf("%H:%M:%S Date: %m/%d")
18:14:25 Date: 11/22
```

rtc.get()

Description

Get second, minute, hour, weekday, date, month, year from RTC

Syntax

curtime = rtc.get()

Parameters

nil

Returns

Curtime: Lua table with current second, minute, hour, weekday, date, month, year

Examples

```
> ct=rtc.get()
> for i=1,7,1 do print(ct[i]); end
11
59
17
0
22
11
2015
```

rtc.set()

Description

Set RTC second, minute, hour, weekday, date, month, year

Syntax

```
res=rtc.set(timetbl)
Parameters
     timetbl: Lua table with second, minute, hour, weekday, date, month, year
Returns
     res: 1 if date&time are set or 0 if error
```

Examples

```
> =rtc.set(53,57,15,3,4,11,15)
0K
```

rtc.standby()

Description

Put CPU to power save mode for specified number of seconds Note: in STANDBY mode, CPU is RESET on wakeup.

Syntax

rtc.standby(mode, numsec)

Parameters

```
power save mode (0 for standby; 1 for stop)
numsec: number of seconds to staj in standby
```

Returns

nil, after wake up CPU resets

```
> rtc.standby(0,5)
Going to STANDBY MODE...
Wake up in 5 second(s)
(RESET)
WiFiMCU Lua starting...(Free memory 65544 bytes)
Current Time: Wed Nov 4 16:11:47 2015
[ Ver. 0.9.6_lobo_0.1 WiFiMCU Team, modified by LoBo @2015 ]
Executing init.lua...
> rtc.standby(1,5)
Going to STOP MODE...
Wake up in 5 second(s)
Back from power save mode.
```

rtc.standbyUntil()

Description

```
Put CPU to powersave mode until specified time
Note: in STANDBY mode, CPU is RESET on wakeup.
```

Syntax

```
rtc.standbyUntil(mode, time)
```

Parameters

```
mode: power save mode (0 for standby; 1 for stop) time: Lua table with hour, minute, second to wake up at
```

Returns

nil, after wake up CPU resets

Back from power save mode.

```
> rtc.standbyUntil(0, {16,16,5})
Going to STANDBY MODE...
Wake up at 16:16:05

(RESET)
WiFiMCU Lua starting...(Free memory 65544 bytes)
Current Time: Wed Nov 4 16:16:05 2015

[ Ver. 0.9.6_lobo_0.1 WiFiMCU Team, modified by LoBo @2015 ]

Executing init.lua...
> rtc.standbyUntil(1, {16,16,5})
Going to STOP MODE...
Wake up at 16:16:05
```

OLED Module

Function List

| oled.init | Initialize the oled display, |
|-----------------|--|
| oled.clear | Clear the screen |
| oled.write | Write strings and or numbers to display |
| oled.writechar | Write one character to display |
| oled.fontsize | Select the font size |
| oled.charspace | Define the space between characters |
| oled.inverse | Select normal or inverted write |
| oled.fixedwidth | Set fixed width or proportional character printing |

The module supports operations with small $(0.96" \sim 1.3")$ oled displays based on SSD1306 controller, using the 4-wire SPI interface.

oled.init()

Description

Initialize the oled display and clear the screen. You must initialize the SPI interface first.

Syntax

res = oled.init(spi id, DCpin)

Parameters

spi_id: id of the SPI interface to be used for oled DCpin: gpio ID, 0~17 used for DC control

Returns

res: 0 on success, error code on error

```
-- hardware spi

>spi.setup(2,{mode=3, cs=12, speed=15000})

>res = oled.init(2,14)

-- software spi

>spi.setup(0,{mode=3, cs=12, mosi=9, sck=16, speed=500})

>oled.init(0,14)
```

oled.clear()

```
Description
```

Clear screen.

Syntax

oled.clear()

Parameters

nil

Returns

nil

Examples

> oled.clear()

oled.write()

Description

Write strings and or numbers to display.

Syntax

oled.write(x, y, ndec, data1, [data2], ... [datan])

Parameters

```
x: x position (column; 0~127)
```

y: y = y = 0 positoin (row; 0~7)

ndec: number of decimal places if number data is float; 0 to print integer)

data1: number or string to write to the display

data2: optional datan: optional

Returns

nil

Examples

```
>oled.write(0,0,0,"WiFiMCU")
>t=2.3456
>oled.write(8,2,1,"Temp=", t)
```

oled.writechar()

Description

Write single character to display.

Syntax

oled.write(x, y, char)

Parameters

x: x position (column; 0~127) y: y position (row; 0~7)

char: character code

Returns

nil

Examples

>oled.writechar(16,5,0x42)

oled.fontsize()

Description

Set the font size (height). At the moment can be only 8 or 16

Syntax

oled.fontsize(size)

Parameters

size: new font size (8 or 16)

Returns

nil

Examples

>oled.fontsize(16)

oled.charspace()

Description

Set additional space between characters in pixels.

Syntax

oled.crarspace(chr_spc)

Parameters

chr spc: new intercharacter space (0~8)

Returns

nil

Examples

>oled.charspace(1)

oled.inverse()

```
Description
```

Set normal (light on dark) or inverse (dark on light) display.

Syntax

oled.inverse(flag)

Parameters

flag: o for normal, 1 for inverse

Returns

nil

Examples

>oled.inverse(1)

oled.fixedwidth()

Description

Set fixed width or proportional character printing.

Syntax

oled.fixedwidth(flag)

Parameters

flag: 0 to print proportional character, 1 for fixed width

Returns

nil

ММММ

```
>oled.fixedwidth(1)
>oled.write(0,0,0,"IIII\r\nMMMM")
IIII
MMMM
>oled.fixedwidth(0)
>oled.write(0,0,0,"IIII\r\nMMMM")
IIII
```

LCD Module

Function List

| 1-1:-: | Trainialing also dispulses | |
|-----------------|--|--|
| lcd.init | Initialize the display | |
| lcd.clear | Clear the screen | |
| lcd.write | Write strings and or numbers to display | |
| lcd.on | Turn display on | |
| lcd.off | Turn display off | |
| lcd.setfont | Set the font used for write function | |
| lcd.getfontsize | Get current font size in pixels | |
| lcd.fixedwidth | Set fixed width or proportional character printing | |
| lcd.setrot | Set text rotation (angle) | |
| lcd.setorient | Set display orientation, default PORTRAIT | |
| lcd.setcolor | Set foreground and background colors | |
| lcd.settransp | Set transparency for character printing | |
| lcd.invert | Set inverted/normal colors | |
| lcd.putpixel | Puts pixel on screen | |
| lcd.line | Draw line | |
| lcd.rect | Draw rectangle | |
| lcd.triangle | Draw triangle | |
| lcd.circle | Draw circle | |
| lcd.image | Show image from file | |

Constant

| lcd.PORTRAIT | Default orientation |
|--------------------|--|
| lcd.PORTRAIT_FLIP | Orientation flipped portrait |
| lcd.LANDSCAPE | Orientation landscape |
| lcd.LANDSCAPE_FLIP | Orientation flipped landscape |
| lcd.CENTER | Center text (write function) |
| lcd.RIGHT | Right allign text (write function) |
| lcd.FONT_SMALL | small font (8x12) |
| lcd.FONT_BIG | Big font (16x16) |
| lcd.FONT_7SEG | 7 segment vector font (digits,'-','.',':','deg' only |
| lcd.FONT_8X8 | Default font (8x8) |
| lcd.BLACK | Colors |
| lcd.NAVY | |
| lcd.DARKGREEN | |

| lcd.DARKCYAN | |
|-----------------|--|
| lcd.MAROON | |
| lcd.PURPLE | |
| lcd.OLIVE | |
| lcd.LIGHTGREY | |
| lcd.DARKGREY | |
| lcd.BLUE | |
| lcd.GREEN | |
| lcd.CYNAN | |
| lcd.RED | |
| lcd.MAGENTA | |
| lcd.YELLOW | |
| lcd.WHITE | |
| lcd.ORANGE | |
| lcd.GREENYELLOW | |
| lcd.PINK | |

The module supports operations with TFT SPI displays. At the moment, only displays based on ST7735 controller, using the 4-wire SPI interface are supported.

Using hardware SPI is recommended, the speed much higher.

lcd.init()

Description

Initialize the oled display and clear the screen. You must initialize the SPI interface first.

Syntax

res = lcd.init(spi id, DCpin, type [,orient])

Parameters

spi id: id of the SPI interface to be used for oled

DCpin: gpio ID, 0~17 used for DC (data/command) control type: display type, 0,1,2 (probably 1 will work best)
Orient: optional, display orientation (default: PORTRAIT)

Returns

res: 0 on success, error code on error

```
-- hardware spi with 50 MHz clock
>spi.setup(2,{mode=3, cs=12, speed=50000})
>res = lcd.init(2,14,1,lcd.LANDSCAPE)
```

```
-- software spi with ~5 Mhz clock
>spi.setup(0,{mode=3, cs=12, mosi=9, sck=16, speed=5000})
> res = lcd.init(0,14,1,PORTRAIT_FLIP)
```

lcd.clear()

Description

Clear screen to default or specified color.

Syntax

lcd.clear([color])

Parameters

color optional; fill the screen with color (default: BLACK)

Returns

nil

Examples

- > lcd.clear(lcd.BLUE)
- > lcd.clear()

lcd.off()

Description

Turns the display of, preserve power. Back light has to be turned off separately.

Syntax

lcd.off()

Parameters

nil

Returns

nil

Examples

> lcd.off()

lcd.on()

Description

Turns the display on.

Syntax

lcd.on()

```
Parameters
```

nil

Returns

nil

Examples

> lcd.on()

lcd.invert()

Description

Set inverted/normal colors.

Syntax

lcd.invert(inv)

Parameters

```
inv 0: inverted colors off; 1: inverted colors on
```

Returns

nil

Examples

> lcd.invert(0)

lcd.setorient()

Description

Set display orientation.

Syntax

lcd.setorient(orient)

Parameters

orient one of display orientation constants PORTRAIT, PORTRAIT_FLIP, LANSCAPE, LANDSCAPE FLIP

Returns

nil

Examples

- > lcd.orient(lcd.LANDCSAPE)
- > lcd.orient(PORTRAIT_FLIP)

lcd.setrot()

Description

Set text rotation (angle) for lcd.write() function.

Syntax

lcd.setrot(rot)

Parameters

rot rotation angle (0~360)

Returns

nil

Examples

```
> lcd.rot(90)
```

> lcd.write("Ratated text")

lcd.settransp()

Description

Set transparency when writing the text. If transparency is on, only text foreground color is shown.

Syntax

lcd.settransp(transp)

Parameters

transp 0: transparency off; 1: transparency on

Returns

nil

Examples

> lcd.transp(1)

lcd.setcolor()

Description

Set the color used when writing characters or drawing on display.

Syntax

lcd.setcolor(color[,bgcolor])

Parameters

color foreground color for text and drawing bgcolor optional; background color for writing text

Returns

nil

Examples

> lcd.setcolor(lcd.YELLOW)
> lcd.setcolor(lcd.ORANGE, lcd.DARKGREEN)

lcd.setfont()

Description

Set the font used when writing the text to display. Four fonts are available: FONT_8x8 (default 8x8), FONT_SMALL (8x12), FONT_BIG (16x16) and FONT 7SEG.



7-segment font is the vector font for which any size can be set (distance between bars and the bar width). Only characters **0**,**1**,**2**,**3**,**4**,**5**,**6**,**7**,**8**,.,-,:,/ are available. Character '/' draws the degree sign.

Syntax

lcd.setfont(font [,size, width])

Parameters

```
font one of the available fonts size optional; only for FONT_7SEG, distance between bars (default: 12; min=6; max=40) width optional; only for FONT_7SEG, bar width (default: 2; min=1; max=12 or size/2)
```

Returns

nil

Examples

```
> lcd.setfont(lcd.FONT_BIG)
> lcd.setfont(lcd.FONT_7SEG, 20, 4)
```

lcd.getfontsize()

Description

Get current font size in pixels. Useful if $FONT_7SEG$ is used to get actual character width and height.

Syntax

lcd.getfontsize()

Parameters

nil

Returns

```
xsize width of the font character in pixels ysize height of the font character in pixels
```

Examples

```
> lcd.getfontsize()
    8   12
```

Icd.putpixel()

Description

Draws pixel on display at coordinates (x,y) using foreground or given color

Syntax

lcd.putpixel(x, y [, color])

Parameters

x, y coordinates of pixel

color optional: pixel color (default: current foreground color)

Returns

nil

Examples

```
> lcd.putpixel(10,10)
```

> lcd.putpixel(20,40,lcd.GREEN)

lcd.line()

Description

Draws line from (x1,y1) to (x2,y2) using foreground or given color

Syntax

lcd.line(x1, y1, x2, y2 [,color])

Parameters

x1,y1 coordinates of line start point x1,y1 coordinates of line end point

color optional: line color (default: current foreground color)

Returns

nil

Examples

```
> lcd.line(0,0,127,159)
```

> lcd.line(20,40,80,10,lcd.ORANGE)

Icd.rect()

Description

Draws rectangle at (x,y) w pixels wide, h pixels high, with given color. If the fill color is given, fills the rectangle.

Syntax

```
lcd.rect(x, y, w, h, color [,fillcolor])
```

Parameters

x, y coordinates of the upper left corner of the rectangle width of the rectangle

h height of the rectangle
color rectangle outline line color
fillcolor optional: rectangle fill color

Returns

nil

Examples

```
> lcd.rect(10,10,100,110,lcd.RED)
```

> lcd.rect(0,0,128,160,lcd.ORANGE,lcd.YELLOW)

lcd.circle()

Description

Draws circle with center at (x,y) and radius r, with given color. If the fill color is given, fills the circle.

Syntax

```
lcd.circle(x, y, r, color [,fillcolor])
```

Parameters

x, y coordinates circle center r radius of the circle color circle outline line color fillcolor optional: circle fill color

Returns

nil

Examples

```
> lcd.circle(64,80,20,lcd.RED)
```

> lcd.circle(50,60,30,lcd.ORANGE,lcd.YELLOW)

lcd.triangle()

Description

Draws triangle between three given points, with given color. If the fill color is given, fills the triangle.

Syntax

```
lcd.triangle(x1, y1, x2, y2, x3, y3, color [,fillcolor])
```

Parameters

```
x1, y1, x2, y2, x3, y3 coordinates of the 3 triangle points triangle outline line color optional: triangle fill color
```

Returns

nil

Examples

```
> lcd.triangle(50,20,80,100,20,100,lcd.RED)
> lcd.triangle(50,20,80,100,20,100,lcd.RED, lcd.WHITE)
```

lcd.write()

Description

Write strings and or numbers to display. Rotation of the displayed text can be set with lcd.setrot() function

Syntax

```
lcd.write(x, y, data1, [data2, ... datan])
```

Parameters

```
x: x position (column; 0~127)
y: y positoin (row; 0~7)
data1: number or string to write to the display

If simple number is given, integer is printed. The number can be given as a table containing number (float) and number of decimal places.
data2: optional
datan: optional
```

Returns

nil

```
>lcd.setcolor(lcd.YELLOW)
>lcd.write(0,0,"WiFiMCU")
>t=2.3456
>lcd.write(8,16,"Temp=", {t,2})
```

Icd.image()

Description

Shows the image from file. The image file must be in raw 16bit format. Any image can be converted with *ImageConverter565.exe* which can be found in *binary* directory on GitHub.

Be careful to give the right image width and height.

Syntax

lcd.image(x, y, xsize, ysize, filename)

Parameters

x: x position of the image upper left cornery: y position of the image upper left corner

xsize: image xsize (width)
ysize; image ysize (height)

filename: name of the row image file

Returns

nil

```
>lcd.rot(lcd.PORTRAIT)
>lcd.clear()
>lcd.image(0,0,128,96,"wifimcu_128x96.img")
>lcd.rot(lcd.LANDSCAPE)
>lcd.image(0,0,160,128,"wifimcu_160x128.raw")
```