Kernel Driver Building – CA378-AOIS v1.1.5 for Jetpack3.3 (L4T28.2.1)

Hardware: Jetson TX2

OS: Ubuntu 16.04 LTS - JetPack 3.3 (L4T 28.2.1)

CSI Hardware: CenturyArks CA378-AOIS (Sony IMX378)

Notes

This instruction is for building kernel directly on a running Jetson board.

\$DEVDIR is the path where you download the kernel

\$... is the user command prompt

... is the super user command prompt (sudo)

References

- http://www.jetsonhacks.com/2017/03/25/build-kernel-and-modules-nvidia-jetson-tx2/
- https://elinux.org/Jetson/TX2_DTB

Prepare kernel source

Download the attached file to home directory on JetsonTX2 and run the following command.

\$ tar zxvf CA378 2L v1.1.5 L4T28.2.1 src build.tar.gz

\$ cd CA378 2L v1.1.5 L4T28.2.1 src build

\$./PrepareKernelSources.sh

Install new Linux kernel

Install kernel modules

\$./BuildKernelSources.sh

Please enter the number of connected cameras.

What is the number of camera connections?: 6

Please enter the number of framerate.

What is the number of framerate for 4056x3040? (30/24/20/15/12/10/6/5): 30

What is the number of framerate for 3840x2160 ? (30/24/20/15/12/10): 30

What is the number of framerate for 1920x1080 ? (120/96/80/60/48/40/30): 60

What is the number of framerate for 640x480 ? (512/500/480/400/350/300/240/200/150/120/60) : 200

Flash new Device Tree Binary (DTB)

Copy compiled dtb file to the host computer

\$ cd ~/JetPack/3.3/64_TX2/Linux_for_Tegra/

\$ sudo sshpass -p 'nvidia' scp -o StrictHostKeyChecking=no nvidia@192.168.xxx.xxx:/boot/*.dtb ./kernel/dtb/# nvidia@192.168.xxx.xxx is IP address on JetsonTX2.

\$ cp ./kernel/dtb/tegra186-quill-p3310-1000-c03-00-imx378.dtb ./kernel/dtb/tegra186-quill-p3310-1000-c03-00-base.dtb

Put the board into force USB Recovery Mode:

- 1. Power down the device. If connected, remove the AC adapter from the device. The device must be powered OFF, and not in a suspend or sleep state.
- 2. Connect the Micro-B plug on the USB cable to the Recovery (USB Micro-B) Port on the device and the other end to an available USB port on the host PC.
- 3. Connect the power adapter to the device.
- 4. Press POWER button
- 5. Press and hold the RECOVERY FORCE (REC) button.
- 6. While pressing the RECOVERY FORCE button, press and release the RESET button.
- 7. Wait 2 seconds and release the RECOVERY FORCE button

Flash dtb partition

Replace this original DTB with your own build DTB

JetPack/3.3/64_TX2/Linux_for_Tegra/kernel/dtb/tegra186-quill-p3 310-1000-c03-00-base.dtb

Flash

\$ sudo ./flash.sh -r -k kernel-dtb jetson-tx2 mmcblk0p1

Multi-came movie recording

Multi-camera capture (yuv)

\$ tar zxvf demo_v1.1.5_tx2.tar.gz

\$ cd ~/demo/script/

\$./multi_yuv_capture.sh

* Depending on the frame rate capture may fail.

In that case please execute the following command and restart the camera.

\$./camera restart.sh

Multi-camera viewer (yuv)

\$ sudo apt-get install libgstreamer1.0-0 gstreamer1.0-plugins-base gstreamer1.0-plugins-good gstreamer1.0-plugins-bad gstreamer1.0-libav gstreamer1.0-doc gstreamer1.0-tools

\$ cd ~/demo/script/

\$./multi_yuv_viewer.sh

Multi-camera RAW capture

\$ sudo apt-get install v4I-utils

\$ cd ~/demo/script/

\$./multi_raw_capture.sh

Install OpenCV 3.4.1

Build and Install OpenCV

\$ cd ~/CA378 2L v1.1.5 L4T28.2.1 src build

\$./InstallOpenCV.sh