The Damped Bundle Adjustment Toolbox v0.1 for Matlab

Niclas Börlin Department of Computing Science Umeå University niclas.borlin@cs.umu.se

November 13, 2013

Contents

1	Inti	roduction
	1.1	Purpose
	1.2	Limitations
	1.3	Legal
	1.4	Scientific publications
2	Inst	tallation
3	Usa	nge
	3.1	Demos
		3.1.1 loadplotdemo
		3.1.2 romabundledemo
		3.1.3 camcalibdemo
	3.2	
		3.2.1 Enabling text export from Photomodeler
		3.2.2 Export from Photomodeler
		3.2.3 Loading into Matlab
\mathbf{A}	Car	nera model

1 Introduction

1.1 Purpose

Matlab toolbox with freely available code for bundle adjustment. Intention to be state-of-the-art.

1.2 Limitations

What it can do.
What it cannot do.

1.3 Legal

Licensing.

1.4 Scientific publications

Refer to any of the papers...

2 Installation

- 1. Download the package file dbat_0.1.zip.
- 2. Unpack the package into a directory dbat.
- 3. Inside Matlab, do the following initialization: cd dbat % the directory where you installed the files. dbatSetup % set paths, etc.
- 4. Test the installation by executing loadplotdemo.
- 5. If loadplotdemo runs without errors and generates a figure with a camera network, the installation is ok.

3 Usage

- 3.1 Demos
- 3.1.1 loadplotdemo
- 3.1.2 romabundledemo
- 3.1.3 camcalibdemo
- 3.2 Using your own data
- 3.2.1 Enabling text export from Photomodeler

Some versions of Photomodeler do not have the text file export option enabled by default. In that case, follow the following steps to enable it:

- 1. Right-click on the main window toolbar, select Customize toolbar....
- 2. In the Commands tab, select the File category.

2

- 3. Drag the Export Text File... command to a toolbar of your choice.
- 4. Now you should be able to export your project as a text file by clicking on the *Export Text File* button.

3.2.2 Export from Photomodeler

To import a Photomodeler project into the toolbox, the following steps are valid in Photomodeler Scanner 2012:

- 1. Export the project using *Export Text File*. If the *Export Text File* command is not available, follow the instructions in Section 3.2.1.
- 2. After export, open the *Project/Cameras...* dialog and select the camera that was used in your project.
- 3. Open the generated text file in a text editor.
 - (a) On the 2nd line (usually reading 0.00005 20), append the width and height in pixels of your images, e.g. to 0.000500 20 5616 3744.
 - (b) Inspect the 4th line. For instance, the original data in roma.txt was (some trailing zeros removed): 24.3581 18.1143 12.0 35.96404 24.0 0.00022 -0.0 0.0 0.0 0.0
 - The values correspond to the following camera parameters: focal pp_x pp_y format_w format_h K1 K2 K3 P1 P2.

 Notice that most of the significant digits of K1-K3 were lost in the
 - (c) Update the parameter values on the 4th line with values from the camera dialog for each parameter with a larger number of significant digits in the dialog. This usually means all parameters except format_w. In the roma.txt test case, the 4th line was modified to: 24.3581 18.1143 12 35.96404 24 2.174e-4 -1.518e-7 0 0 0.

3.2.3 Loading into Matlab

text export.

- 1. In matlab, run step 3 from Section 2 if not already done.
- 2. Set the variable fName to the text export file name
 fName='c:/path/to/exported/file.txt';, or select it using
 [f,p]=uigetfile('*.txt'); fName=[f,p];
- 3. Run the loadplotdemo script. A figure with your camera network, aligned with the first camera and rotated to have +Z 'up', should now have been generated.

A Camera model