UUT Report

Station ID: IT-W-7303101

Serial Number: NONE

Date: giovedì 26 ottobre 2023

Time: 10:43:08
Operator: administrator

Execution Time: 557.5834646 seconds

Number of Results: 140

UUT Result: Terminated
Product: ARI LV
Product type: ARI HV

Comm type: COMM1_RS485

Product FW Version: 56010805 Comm FW Version: 56010000

Begin Sequence: MainSequence

(C:\Users\ITLUBAR5\ABB\LABRND VITTUONE - LabRnD_Shared\TestStand\Sequences\MOD\General_test.seq)

Simultaneous trip_open	
Status:	Skipped
General and Architecture and LED	
Status:	Terminated
Module Time:	537.9631386

Begin Sequence: General and Architecture and LED (C:\Users\ITLUBAR5\ABB\LABRND VITTUONE - LabRnD_Shared\TestStand\Sequences\MOD\General_test.seq)

Additional I	Results
Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power off and the LED is OFF.
Status:	Passed
Additional I	Results
Status:	Done
	Check that manual opening and closing of the device shall be possible when the device is power ON and in NOT- Active state.
Status:	Passed
Additional I	Results
Status:	Done
PopupString:	Check that the LED is "Blinking Green" in both active and close configurations.
Status:	Passed
Additional I	Results
Status:	Done
PopupString:	Check that the LED is "Blinking Green".
Status:	Passed
Additional I	Results
Status:	Done
	Check that manual opening and closing of the device shall be possible when the device is power ON and in NOT- Active state.
Status:	Passed
Additional I	Results

Status:	Done
PopupString:	Check that the LED is "Blinking Green"in both active and close configurations.
Status:	Passed
Additional I	Results
Status:	Done
PopupString:	Check that the LED is "Blinking Green".
Status:	Passed
Additional I	Results
Status:	Done
PopupString:	Check that the LED is "Blinking Green"in both active and close configurations.
Status:	Passed
Additional I	Results
Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power ON and in Active state.
Status:	Passed

Additional Results		
Status:	Done	
PopupString	: Check that the LED is "Fix Green"in close active configuration and "Blinking green" in open active configuration.	
Status:	Passed	
Additional	Additional Results	
Status:	Done	
PopupString	: Check that the LED is "Blinking Green".	
	Passed	

Additional Results	
Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power ON and in Active state.
Status:	Passed

Additional	Results
Status:	Done
PopupString:	Check that the LED is "Fix Green"in close active configuration and "Blinking green" in open active configuration.
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that the LED is "Fix Green".
Status:	Passed
Additional Results	
Additional	Results
	Results Done
Status:	

Status:	Done
PopupString:	Check that the LED is "Fix Green"in close active configuration and "Blinking green" in open active configuration.
Status:	Passed
Additional	Results
Additional Status:	Results Done
Status:	

Additional	Results
Status:	Done
PopupString:	Check that the LED is "Fix Green" after autoreclose.
Status:	Passed
Check LED	Status
Status:	Failed
Additional	Results
Status:	Done
PopupString:	Check that the LED was "Blinking Red" during the stand-by state and now is "Fix Red" in Lock State.
Status:	Failed
Additional	Results
Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power ON and in Locked state.
Status:	Passed
Additional	Results
Status:	Done
PopupString:	Check that the LED is "Fix Green"in close active configuration and "Blinking green" in open active configuration.
Status:	Passed

End Sequence: General and Architecture and LED

End Sequence: MainSequence

End UUT Report