UUT Report

Station ID:	IT-W-7303101
Serial Number:	NONE
Date:	**venerdì 27 ottobre 2023**
Time:	**10:55:43**
Operator:	administrator
Execution Time:	179.7630773 seconds
Number of Results:	126
UUT Result:	**Failed**
Product:	**MOD LV**
Product type:	**MOD HV**
Comm type:	**COMM1_RS485**
Product FW Version:	**56010805**
Comm FW Version:	**56010000**
Failure Chain:	

Step	Sequence	Sequence File
Check Manual Open/Close	General and Architecture and LED	General_test.seq
General and Architecture and LED	MainSequence	General_test.seq

---

Begin Sequence: MainSequence
(C:\Users\ITLUBAR5\ABB\LABRND VITTUONE - LabRnD_Shared\TestStand\Sequences\MOD\General_test.seq)

Simultaneous trip_open	
Status:	Skipped

General and Architecture and LED	
Status:	Failed
Module Time:	163.9646844

Begin Sequence: General and Architecture and LED
(C:\Users\ITLUBAR5\ABB\LABRND VITTUONE - LabRnD_Shared\TestStand\Sequences\MOD\General_test.seq)

Additional Results	
Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power off and the LED is OFF.
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power ON and in NOT-Active state.
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that the LED is "Blinking Green" in both active and close configurations.
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that the LED is "Blinking Green".
Status:	Passed

Additional Results	

Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power ON and in NOT-Active state.
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that the LED is "Blinking Green"in both active and close configurations.
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that the LED is "Blinking Green".
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that the LED is "Blinking Green"in both active and close configurations.
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power ON and in Active state.
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that the LED is "Fix Green"in both active and close configurations.
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that the LED is "Fix Green".
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power ON and in Active state.
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that the LED is "Fix Green"in both active and close configurations.
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that the LED is "Fix Green".
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power ON and in Active state.
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that the LED is "Fix Green"in both active and close configurations.
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that the LED is "Fix Red".
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power ON and in Locked state.
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that the LED is "Fix Green".
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that the LED is "Fix Red".
Status:	Passed

Check Manual Open/Close	
Status:	Failed

Additional Results	
Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power ON and in Locked state.
Status:	Failed

End Sequence: General and Architecture and LED

Input-Output	
Status:	Skipped

Power Outage	
Status:	Skipped

Motor Driver	
Status:	Skipped

Modbus Register check	
Status:	Skipped

Modbus settings check	
Status:	Skipped

COMM LED & Button	
Status:	Skipped

Firmware Upgrade	
Status:	Skipped

End Sequence: MainSequence

End UUT Report