https://content.xsens.com/download-mt-software-suite?submissionGuid=3389d0c2-f247-448a-9cb2-8f8a81c41cd7

https://www.xsens.com/hubfs/Downloads/Software/MTSS/Releases/2020.3.0-beta/MT_Software_Suite_linux-x64_2020.3.tar.gz?hsCtaTracking=71c605d6-e52c-41ae-994d-caf701dd10a5|c589e17e-6073-4af9-b53e-a3609ac13e41

http://wiki.ros.org/xsens_mti_driver

https://base.xsens.com/hc/en-us/articles/360014235960-Interfacing-MTi-devices-with-the-NVIDIA-Jetson

• 安装ros驱动

sudo apt-get install ros-melodic-xsens-driver

下载软件包

链接: https://pan.baidu.com/s/1NtMoWnVu2NhpfZzoKpHYIA

提取码: bhjx

• 安装sdk (文件在软件包中)

sudo ./mtsdk_linux-x64_2020.3.sh

- 在windows上安装MT manager (文件在软件包中)
- 下载并编译demo (从github)

xsens ros mti driver

pushd src/xsens_ros_mti_driver/lib/xspublic && make && popd
catkin_make -j8

• 运行demo

```
sudo chmod 777 /dev/ttyUSB*
roslaunch xsens_mti_driver display.launch
```