

# **Chapter 2: Understanding RTOS**

After completing this chapter, you will understand what an RTOS is and how to use one.

2.1	INTRODUCTION TO RTOS	2
2.1.1	POTENTIAL PITFALLS	2
2.1.2	TASKS/THREADS	3
2.1.3	QUEUE	3
2.1.4	TIMERS	3
2.1.5	Interrupts	3
2.1.6	Semaphore	3
2.1.7	Mutex	3
2.1.8	Events	3
2.1.9	Notifications	
2.2	CYPRESS ABSTRACTION LAYER	4
2.3	MBED OS	
2.3.1	GENERAL	4
2.3.2	Thread & ThisThread	4
2.3.3		
2.3.4	SEMAPHORE	4
2.3.5	Mutex	
2.3.6	EVENT & EVENTFLAGS & USER ALLOCATED EVENT & CONDITION VARIABLE	
2.3.7	MemoryPool	∠
2.4	FREERTOS	4
2.4.1	GENERAL	4
2.4.2	Thread & ThisThread	4
2.4.3	QUEUE & EVENT QUEUE	5
2.4.4	SEMAPHORE	5
2.4.5	Mutex	5
2.4.6	EVENT & EVENTFLAGS & USER ALLOCATED EVENT & CONDITION VARIABLE	5
2.4.7	MemoryPool	5
2.5	WICED BLUETOOTH	5
2.5.1		
2.5.2	Queue	8
2.5.3	SEMAPHORE	10
2.5.4	Mutex	11
2.5.5		



## 2.1 Introduction to RTOS

The <u>purpose of an RTOS</u> is to reduce the complexity of writing embedded firmware that has multiple asynchronous, response-time-critical tasks that have overlapping resource requirements. For example, you might have a device that is reading and writing data to a connected network, reading and writing data to an external filesystem, and reading and writing data from peripherals. Making sure that you deal with the timing requirement of responding to network requests while continuing to support the peripherals can be complex and therefore error prone. By using an RTOS you can separate the system functions into separate tasks (called **threads or tasks**) and develop them in a somewhat independent fashion.

The RTOS maintains a list of threads that are idle, halted or running and which task needs to run next (based on priority) and at what time. This function in the RTOS is called the scheduler. There are two major schemes for managing which threads/tasks/processes are active in operating systems: preemptive and co-operative.

In preemptive multitasking the CPU completely controls which task is running and can stop and start them as required. In this scheme the scheduler uses CPU protected modes to wrest control from active tasks, halt them, and move onto the next task. Higher priority tasks will be prioritized to run before lower priority tasks. That is, if a task is running and a higher priority task requests a turn, the RTOS will suspend the lower priority task and switch to the higher priority task. Preemptive multitasking is the scheme that is used in Windows, Linux etc.

In co-operative multitasking each process must be a good citizen and yield control back to the RTOS. There are a number of mechanisms for yielding control such as rtos\_delay\_milliseconds, semaphores, mutexes, and queues (which we will discuss later in this document).

Most of the RTOSs we will use are configured in a hybrid mode. It is preemptive for higher priority tasks and "round robin" for tasks of equal priority. Therefore, higher priority tasks will always run at the expense of lower priority tasks, so it is important to yield control to give lower priority tasks a turn. If not, tasks that don't yield control will prevent lower or equal priority tasks from running at all. It is good practice to have some form of yield control mechanism in every thread to prevent such situations.

#### 2.1.1 Potential Pitfalls

All of this sounds great, but there are three serious bugs which can easily be created in these types of systems and these bugs can be very hard to find. These bugs are all caused by side effects of interactions between the threads. The big three are:

- Cyclic dependencies which can cause deadlocks
- Resource conflicts when sharing memory and sharing peripherals which can cause erratic nondeterministic behavior
- Difficulties in executing inter-process communication.

But all hope is not lost. Every RTOS gives you mechanisms to deal with these problems, specifically semaphores, mutexes, and queues which we will discuss in a minute.



# 2.1.2 Tasks/Threads

#### **2.1.3** Queue

A queue is a thread-safe mechanism to send data to another thread. The queue is a FIFO - you read from the front and you write to the back. If you try to read a queue that is empty your thread will suspend until something is written into it. The payload in a queue (size of each entry) and the size of the queue (number of entries) is user configurable at queue creation time.

#### **2.1.4** Timers

An RTOS timer allows you to schedule a function to run at a specified interval - e.g. send your data to the cloud every 10 seconds. When you setup a timer you specify the function you want run and how often you want it run.

Note that there is a single execution of the function every time the timer expires rather than a continually executing thread so the function should NOT have a while(1) loop – it should just run and exit each time the timer calls it.

## 2.1.5 Interrupts

## 2.1.6 Semaphore

A <u>semaphore</u> is a signaling mechanism between threads. The name semaphore (originally sailing ship signal flags) was applied to computers by Dijkstra in a paper about synchronizing sequential processes. Semaphores can either be binary or counting. In the case of a counting semaphore, they are usually implemented as a simple unsigned integer. When you "set" a counting semaphore it increments the value of the semaphore. When you "get" a semaphore it decrements the value, but if the value is 0 the thread will SUSPEND itself until the semaphore is set. So, you can use a semaphore to signal between threads that something is ready. For instance, you could have a "sendData" thread and a "collectDataThread". The sendData thread will "get" the semaphore which will suspend the thread UNTIL the collectDataThread "sets" the semaphore when it has new data available that needs to be sent.

#### **2.1.7** Mutex

Mutex is an abbreviation for "Mutual Exclusion". A mutex is a lock on a specific resource - if you request a mutex on a resource that is already locked by another thread, then your thread will go to sleep until the lock is released. Without a mutex, you may see strange behavior if two threads try to access the same shared resource at the same time or when one thread starts to use a shared resource but is then preempted by another thread that uses the same resource before the first thread is done.

#### **2.1.8** Events



# 2.1.9 Notifications

2.2	Cypress Abstraction Layer	
2.3	Mbed OS	
2.3.1	General	
Kernel Interface Functions		
2.3.2	Thread & ThisThread	
2.3.3	Queue & Event Queue	
2.3.4	semaphore	
2.3.5	Mutex	

- 2.3.6 Event & EventFlags & User allocated Event & ConditionVariable
- 2.3.7 MemoryPool
- 2.4 FreeRTOS
- 2.4.1 General

**Kernel Interface Functions** 

2.4.2 Thread & ThisThread



## 2.4.3 Queue & Event Queue

## 2.4.4 semaphore

#### 2.4.5 Mutex


# 2.4.6 Event & EventFlags & User allocated Event & ConditionVariable

# 2.4.7 MemoryPool

## 2.5 WICED Bluetooth

WICED devices support multiple RTOSs, but <u>ThreadX</u> by <u>Express Logic</u> is built into the device ROM and the license is included for anyone using WICED chips so that is by far the best choice.

In order to simplify using multiple RTOSs, the WICED SDK has a built-in abstraction layer that provides a unified interface to the fundamental RTOS functions. You can find the documentation for the WICED RTOS APIs under the API Guide > Components > RTOS.





All the RTOS abstraction layer functions generally all work the same way. The basic process is:

- 1. Include the wiced\_rtos.h header file so that you have access to the RTOS functions.
- 2. Declare a pointer of the right type (e.g. wiced\_mutex\_t\*)
- 3. Call the appropriate create function to allocate memory and return the pointer.
- 4. Call the appropriate RTOS initialize function (e.g. wiced\_rtos\_init\_mutex()). Provide it with the pointer that was created in step 2.
- Access the pointer using one of the access functions (e.g. wiced\_rtos\_lock\_mutex()).
- If you don't need it anymore, free up the pointer with the appropriate de-init function (e.g. wiced\_rtos\_deinit\_mutex()).

All these functions need to have access to the pointer, so I generally declare these "shared" resources as static global variables within the file that they are used.

#### **2.5.1** Thread

As we discussed earlier, threads are at the heart of an RTOS. It is easy to create a new thread by calling the function <code>wiced\_rtos\_create\_thread()</code> and then <code>wiced\_rtos\_init\_thread()</code> with the following arguments:

- wiced\_thread\_t\* thread A pointer to a thread handle data structure returned by the wiced\_rtos\_create\_thread() function. This handle is used to identify the thread for other thread functions.
- *uint8 t priority* This is the priority of the thread.
  - Priorities can be from 0 to 7 where 0 is the highest priority. User applications should typically use middle priorities of ~4.
  - o If the scheduler knows that two threads are eligible to run, it will run the thread with the higher priority.
- char \*name A name for the thread. This name is only used by the debugger. You can give it any name or just use NULL if you don't want a specific name.
- wiced thread function t\*thread A function pointer to the function that is the thread.
- uint32\_t stack size How many bytes should be in the thread's stack.
  - You should be careful here as running out of stack can cause erratic, difficult to debug behavior. Using 1024 is overkill but will work for any of the exercises we do in this class. If you want to see how much a given thread uses, we'll show you how you can do that below.
- void \*arg A generic argument which will be passed to the thread.
  - o If you don't need to pass an argument to the thread, just use NULL.



As an example, if you want to create a thread that runs the function "mySpecialThread", the initialization might look something like this:

```
#define THREAD_PRIORITY (4)
#define THREAD_STACK_SIZE (1024)
.
.
wiced_thread_t* mySpecialThreadHandle; /* Typically defined as a global */
.
.
/* Typically inside the BTM_ENABLED_EVT */
mySpecialThreadHandle = wiced_rtos_create_thread();
wiced_rtos_init_thread(mySpecialThreadHandle, THREAD_PRIORITY,
"mySpecialThreadName", mySpecialThread, THREAD_STACK_SIZE, NULL);
```

The thread function must match type *wiced\_thread\_function\_t*. It must take a single argument of type *uint32\_t* and must have a *void* return.

The body of a thread looks just like the "main" function of a typical C application. Often a thread will run forever so it will have an initialization section and a while(1) loop that repeats forever. For example:


```
void mySpecialThread(uint32_t arg)
{
    /* Do any required one-time initialization here */
    #define MY_THREAD_DELAY (100)

    while(1)
    {
        processData();
        wiced_rtos_delay_milliseconds(MY_THREAD_DELAY,
ALLOW_THREAD_TO_SLEEP);
    }
}
```

**Note**: You should usually put a *wiced\_rtos\_delay\_milliseconds()* of some amount in every thread with the delay type of *ALLOW\_THREAD\_TO\_SLEEP* so that other threads get a chance to run. The exception is if you have some other thread control function such as a semaphore or queue that is guaranteed to cause the thread to periodically pause.



The functions available to manipulate a thread are in the "Component > RTOS > Threads" section of the WICED API reference.



#### **2.5.2** Queue

There are two primary queue functions (besides the standard create and init) in the WICED RTOS abstraction API: wiced\_rtos\_push\_to\_queue and wiced\_rtos\_pop\_from\_queue.

The wiced\_rtos\_push\_to\_queue function requires a timeout parameter. This comes into play if the queue is full when you try to push into it. The timeout allows the thread to continue after a specified amount of time even if the queue stays full. This can be useful in some cases to prevent a thread from stalling permanently if the queue stays full due to an error condition. The timeout is specified in milliseconds. If you want the thread to wait indefinitely for room in the queue rather than timing out after a specific delay, use WICED\_WAIT\_FOREVER for the timeout. If you want the thread to continue immediately if there isn't room in the queue, then use WICED\_NO\_WAIT. Note that if the function times out, then the value is not added to the queue.


Likewise, the wiced\_rtos\_pop\_from\_queue function requires a timeout parameter to specify how long the thread should wait if the queue is empty. If you want the thread to wait indefinitely for a value in



the queue rather than continuing execution after a specific delay, then use WICED\_WAIT\_FOREVER. If you want the application to continue immediately if there isn't anything in the queue, then use WICED\_NO\_WAIT.

There are also functions to check to see if the queue is full or empty and to determine the number of entries in the queue.

The queue functions are available in the documentation under Components > RTOS > Queues.



You should always create and initialize a queue <u>before</u> starting any threads that use it. Otherwise, you may see unpredictable behavior. For example:

```
wiced_queue_t* myQueue; /* Typically defined as a global */
.
.
myQueue = wiced_rtos_create_queue(); /* Typically inside the
BTM_ENABLED_EVT */
wiced_rtos_init_queue( myQueue, "myQueue", sizeof(uint32_t), 5 );
```




## 2.5.3 Semaphore

Semaphores in the WICED RTOS abstraction have a set function called *wiced\_rtos\_set\_semaphore* and a get function called *wiced\_rtos\_get\_semaphore*.

The get function requires a timeout parameter. This allows the thread to continue after a specified amount of time even if the semaphore doesn't get set. This can be useful in some cases to prevent a thread from stalling permanently if the semaphore is never set due to an error condition. The timeout is specified in milliseconds. If you want the thread to wait indefinitely for the semaphore to be set rather than timing out after a specific delay, use WICED\_WAIT\_FOREVER for the timeout.

The semaphore functions are available in the documentation under Components  $\rightarrow$  RTOS  $\rightarrow$  Semaphores.



You should always create and initialize a semaphore <u>before</u> starting any threads that use it. Otherwise, you may see unpredictable behavior. For example:


```
wiced_semaphore_t* mySemaphore; /* Typically defined as a global */
.
.
mySemaphore = wiced_rtos_create_semaphore(); /* Typically inside the
BTM_ENABLED_EVT */
wiced_rtos_init_semaphore( mySemaphore );
```

It is generally not a good idea to use a semaphore <u>get</u> inside an interrupt callback or a timer callback with a non-zero timeout since it may lock up your program waiting for a set that never occurs.



#### 2.5.4 Mutex

The mutex functions are available in the documentation under Components > RTOS > Mutex.



You should always create and initialize a mutex <u>before</u> starting any threads that use it. Otherwise, you may see unpredictable behavior. For example:

```
wiced_mutex_t* myMutex; /* Typically defined as a global */
.
.
myMutex = wiced_rtos_create_mutex(); /* Typically inside the
BTM_ENABLED_EVT */
wiced rtos init mutex( myMutex );
```

Note that a mutex can only be unlocked by the same thread that locked it.



## 2.5.5 Stack Usage

If you want to see how much stack a thread is using, you need to use the underlying functions for the RTOS you are using. For example, if you are using ThreadX (the default RTOS in WICED) you first need to include the header to get access to the native ThreadX functions:

```
#include "tx api.h"
```

Next, you could add this function to find the max stack size used by a given thread since it was started:

```
/* This will return the max amount of stack a thread has used */
/* This is ThreadX specific code so it will only work for ThreadX */
uint32_t maxStackUsage(TX_THREAD *thread)
{
    uint8_t *end = thread->tx_thread_stack_end;
    uint8_t *start = thread->tx_thread_stack_start;
    while(start < end)
    {
        if(*start != 0xEF)
        {
            return end-start;
        }
        start++;
    }
    return 0;
}</pre>
```

Finally, you can call the function occasionally in your application (e.g. in a timer or whenever a button is pressed) and then print the value. For example:

```
uint32_t size;
size = maxStackUsage((TX_THREAD*) mySpecialThreadHandle);
WICED BT TRACE("Max Stack Size: %d\n\r", size);
```