

### C Language Primer



### What is C?



```
* Copyright 2014, YFS Corporation. All rights reserved.
#include <project.h>
#define MYCHANNEL (0)
* Function Name: main
* Reads the ADC and displays the voltage on the LCD.
int main()
 int16 output;
 /* Start the components */
 LCD Start();
 ADC Start();
 ADC StartConvert(); // Start the ADC conversions
 /* Display the value of ADC output on LCD */
 LCD Position(0,0);
 LCD PrintString( "ADC Output" );
 while(1)
    /* If ADC has data - read, convert to mV and print */
   if ( ADC IsEndConversion ( ADC RETURN STATUS ) )
      output = ADC GetResult16( MYCHANNEL );
      output = ADC CountsTo mVolts( MYCHANNEL, output );
      LCD Position(1,0);
      LCD PrintInt16( output );
```

# Language for controlling the ARM processor

Lets you run sequences of instructions from Flash Manipulate data variables in SRAM

C code is written in text files (extension ".c")

### Comments



```
* Copyright 2014, YFS Corporation. All rights reserved.
#include <project.h>
#define MYCHANNEL (0)
* Function Name: main
* Reads the ADC and displays the voltage on the LCD.
int main()
 int16 output;
 /* Start the components */
 LCD Start();
 ADC Start();
 ADC StartConvert(); // Start the ADC conversions
 /* Display the value of ADC output on LCD */
 LCD Position(0,0);
 LCD PrintString( "ADC Output" );
 while(1)
    /* If ADC has data - read, convert to mV and print */
   if ( ADC IsEndConversion ( ADC RETURN STATUS ) )
      output = ADC GetResult16( MYCHANNEL );
      output = ADC CountsTo mVolts( MYCHANNEL, output );
     LCD Position(1,0);
      LCD PrintInt16( output );
```

### Tell the reader what the code does

Compiler ignores comments

Often have a companystandard copyright notice

/\* block comment \*/
// end of line comment

### Variables



```
* Copyright 2014, YFS Corporation. All rights reserved.
#include <project.h>
#define MYCHANNEL (0)
* Function Name: main
* Reads the ADC and displays the voltage on the LCD.
int main()
 int16 output;
 /* Start the components */
 LCD Start();
 ADC Start();
 ADC StartConvert(); // Start the ADC conversions
 /* Display the value of ADC output on LCD */
 LCD Position(0,0);
 LCD PrintString( "ADC Output" );
 while(1)
    /* If ADC has data - read, convert to mV and print */
   if ( ADC IsEndConversion ( ADC RETURN STATUS ) )
      output = ADC GetResult16( MYCHANNEL );
      output = ADC CountsTo mVolts( MYCHANNEL, output );
      LCD Position(1,0);
      LCD PrintInt16( output );
```

# SRAM-based data int8 / int16 / int32

Simple numbers

int8: -128..127

int16: -32768..32767

#### uint8 / uint16 / uint32

Unsigned numbers

uint8: 0..255

uint16: 0..65535

#### Use memorable names

int8 ADCvalue; // good name

int8 myvar; // bad name

### **Operators**



### **Assignment**

$$x=2$$

$$x=2$$
 Set x to 2

#### **Arithmetic**



x+2 Add up x and 2

### **Compound (shortcuts)**

$$x*=2$$

$$x^*=2$$
  $x = x * 2$ 

#### Increment and Decrement

$$X++$$

$$x^{++}$$
  $x = x + 1$ 

### Comparison

$$\leq =$$

$$x = = 2$$

== != < <= >= x==2 Compare x with 2

### **Functions**



```
* Copyright 2014, YFS Corporation. All rights reserved.
***********************************
#include <project.h>
#define MYCHANNEL (0)
* Function Name: main
* Reads the ADC and displays the voltage on the LCD.
*/
int main()
 int16 output;
 /* Start the components */
 LCD Start();
 ADC Start();
 ADC StartConvert(); // Start the ADC conversions
 /* Display the value of ADC output on LCD */
 LCD Position(0,0);
 LCD PrintString( "ADC Output" );
 while(1)
   /* If ADC has data - read, convert to mV and print */
   if( ADC IsEndConversion( ADC RETURN STATUS ) )
     output = ADC GetResult16( MYCHANNEL );
     output = ADC CountsTo mVolts( MYCHANNEL, output );
     LCD Position(1,0);
     LCD PrintInt16( output );
```

#### **Bundles of instructions**

Better than copy-paste of similar code

# Run functions by typing the name and parentheses

```
function1();
```

# Pass values inside the parentheses

```
function2(5);
```

### Get data back in the "return value"

```
pos = getPos();
```

### Logical Arithmetic – AND and OR



#### Compare true with false

Zero means false

Non-zero means true, operators yield 1

### Logical AND ( && ) is true if BOTH are true

```
0 && 1 yields 0
1 && 2 yields 1
```

### Logical OR (||) is true if EITHER are true

```
0 || 1 yields 1
1 || 2 yields 1
0 || 0 yields 0
```

### Often use multiple comparisons

```
((x > 7) & (y < 10))
```

### Conditionals – "if"



```
* Copyright 2014, YFS Corporation. All rights reserved.
#include <project.h>
#define MYCHANNEL (0)
* Function Name: main
* Reads the ADC and displays the voltage on the LCD.
int main()
 int16 output;
 /* Start the components */
 LCD Start();
 ADC Start();
 ADC StartConvert(); // Start the ADC conversions
 /* Display the value of ADC output on LCD */
 LCD Position(0,0);
 LCD PrintString( "ADC Output" );
 while(1)
    /* If ADC has data - read, convert to mV and print */
   if( ADC IsEndConversion( ADC RETURN STATUS ) )
      output = ADC GetResult16( MYCHANNEL );
      output = ADC CountsTo mVolts( MYCHANNEL, output );
      LCD Position(1,0);
      LCD PrintInt16( output );
```

# **Execute instructions if a condition is true**

#### **Format:**

```
if( condition )
{
   /* Execute block */
}
```

# If the condition is not true, skip the block

Always use a block { ... }

### Conditionals - "if" and "else"



```
* Copyright 2014, YFS Corporation. All rights reserved.
#include <project.h>
#define MYCHANNEL (0)
* Function Name: main
* Reads the ADC and displays the voltage on the LCD.
int main()
 int16 output;
 /* Start the components */
 LCD Start();
 ADC Start();
 ADC StartConvert(); // Start the ADC conversions
 /* Display the value of ADC output on LCD */
 LCD Position(0,0);
 LCD PrintString( "ADC Output" );
 while(1)
    /* If ADC has data - read, convert to mV and print */
   if ( ADC IsEndConversion ( ADC RETURN STATUS ) )
      output = ADC GetResult16( MYCHANNEL );
      output = ADC CountsTo mVolts( MYCHANNEL, output );
     LCD Position(1,0);
      LCD PrintInt16( output );
```

# Alternative action If the condition is not true, do something else

```
if( condition )
{
    /* Execute if true */
}
else
{
    /* Execute if false */
}
```

Note: Indenting (tabbing) the code is good style

### Loops - "while"



```
* Copyright 2014, YFS Corporation. All rights reserved.
#include <project.h>
#define MYCHANNEL (0)
* Function Name: main
* Reads the ADC and displays the voltage on the LCD.
int main()
 int16 output;
 /* Start the components */
 LCD Start();
 ADC Start();
 ADC StartConvert(); // Start the ADC conversions
 /* Display the value of ADC output on LCD */
 LCD Position(0,0);
 LCD PrintString( "ADC Output" );
 while(1)
    /* If ADC has data - read, convert to mV and print */
   if( ADC IsEndConversion( ADC RETURN STATUS ) )
      output = ADC GetResult16( MYCHANNEL );
      output = ADC CountsTo mVolts( MYCHANNEL, output );
      LCD Position(1,0);
      LCD PrintInt16( output );
```

# Repeat instructions until the condition is not true

#### **Format:**

```
while( condition )
{
}
```

# Condition typically the changes in the loop

```
while(x!=0)
{
  x = ADC_GetResult16();
  /* more code */
}
```

### Loops – "for"



```
* Copyright 2014, YFS Corporation. All rights reserved.
#include <project.h>
#define MYCHANNEL (0)
* Function Name: main
* Reads the ADC and displays the voltage on the LCD.
int main()
 int16 output;
 /* Start the components */
 LCD Start();
 ADC Start();
 ADC StartConvert(); // Start the ADC conversions
 /* Display the value of ADC output on LCD */
 LCD Position(0,0);
 LCD PrintString( "ADC Output" );
 while(1)
    /* If ADC has data - read, convert to mV and print */
   if ( ADC IsEndConversion ( ADC RETURN STATUS ) )
      output = ADC GetResult16( MYCHANNEL );
      output = ADC CountsTo mVolts( MYCHANNEL, output );
     LCD Position(1,0);
      LCD PrintInt16( output );
```

### Three expressions

#### **Format:**

```
for( init; cond; incr )
{
}
```

### Bundle loop controls into one statement

```
int i;
for( i=0; i<100; i++ )
{
   /* Loop 100 times */
}</pre>
```

### Infinite Loops



```
* Copyright 2014, YFS Corporation. All rights reserved.
#include <project.h>
#define MYCHANNEL (0)
* Function Name: main
* Reads the ADC and displays the voltage on the LCD.
int main()
 int16 output;
 /* Start the components */
 LCD Start();
 ADC Start();
 ADC StartConvert(); // Start the ADC conversions
 /* Display the value of ADC output on LCD */
 LCD Position(0,0);
 LCD PrintString( "ADC Output" );
 while(1)
    /* If ADC has data - read, convert to mV and print */
   if ( ADC IsEndConversion ( ADC RETURN STATUS ) )
      output = ADC GetResult16( MYCHANNEL );
      output = ADC CountsTo mVolts( MYCHANNEL, output );
     LCD Position(1,0);
      LCD PrintInt16( output );
```

# **Embedded systems never stop**

Power on and run forever

#### Use never-false condition

```
while( 1 )
{
}
```

# Can also omit for-loop conditions

```
for( ; ; )
{
}
```

### Understanding Numbers – uint8



Bit #	7	6	5	4	3	2	1	0		
	0	0	0	0	0	0	0	0	== 0	(0x00)
	0	0	0	0	0	0	0	1	== 1	(0x01)
	0	0	0	0	0	0	1	0	== 2	(0x02)
	0	0	0	0	0	1	0	0	== 4	(0x04)
	0	0	0	0	1	0	0	0	== 8	(80x0)
	0	0	0	1	0	0	0	0	== 16	(0x10)
	0	0	1	0	0	0	0	0	== 32	(0x20)
	0	1	0	0	0	0	0	0	== 64	(0x40)
	1	0	0	0	0	0	0	0	== 128	(0x80)

### Understanding Numbers – uint8



Bit #	7	6	5	4	3	2	1	0		
	0	0	0	0	0	0	0	0	== 0	(0x00)
	0	0	0	0	0	0	0	1	== 1	(0x01)
	0	0	0	0	0	0	1	0	== 2	(0x02)
	0	0	0	0	0	1	0	0	== 4	(0x04)
	0	0	0	0	1	0	0	0	== 8	(80x0)
	0	0	0	1	0	0	0	0	== 16	(0x10)
	0	0	1	0	0	0	0	0	== 32	(0x20)
	0	1	0	0	0	0	0	0	== 64	(0x40)
	1	0	0	0	0	0	0	0	== 128	(08x0)
	0	0	0	0	0	0	1	1	== 3	(0x03)
	0	0	0	0	1	1	1	1	== 15	(0x0F)

### Understanding Numbers – uint8



Bit #	7	6	5	4	3	2	1	0		
	0	0	0	0	0	0	0	0	== 0	(0x00)
	0	0	0	0	0	0	0	1	== 1	(0x01)
	0	0	0	0	0	0	1	0	== 2	(0x02)
	0	0	0	0	0	1	0	0	== 4	(0x04)
	0	0	0	0	1	0	0	0	== 8	(80x0)
	0	0	0	1	0	0	0	0	== 16	(0x10)
	0	0	1	0	0	0	0	0	== 32	(0x20)
	0	1	0	0	0	0	0	0	== 64	(0x40)
	1	0	0	0	0	0	0	0	== 128	(0x80)
	0	Λ	Λ	0	Λ	0	1	1	2	(0,,02)
	0	0	0	0	0	0	1	1	== 3	(0x03)
	0	0	0	0	1	1	1	1	== 15	(0x0F)
	1	1	1	1	0	0	0	0	== 240	(0xF0)
		I	l	1	U	U	U	U	240	
	0	0	1	1	0	0	1	1	== 51	(0x33)

### Bitwise Arithmetic – AND and OR




# Compare the bit patterns Bitwise AND ( & ) sets the bit if BOTH are 1

== 0x02

### Bitwise Arithmetic



# Compare the bit patterns Bitwise AND (&) sets the bit if BOTH are 1




== 0x02

== 0x00

### Bitwise Arithmetic



# Compare the bit patterns Bitwise AND (&) sets the bit if BOTH are 1



== 0x02

0x03 & 0x08 0 0 0 0 0 0 0

& 0 0 0 0 1 0 0

== 0x00

### Bitwise OR (|) sets the bit if EITHER are 1

0x03 | 0x02

0 0 0 0 0 0 1 1


0 0 0 0 0 0 1 0

== 0x03

### Bitwise Arithmetic



# Compare the bit patterns Bitwise AND (&) sets the bit if BOTH are 1



### Bitwise OR (|) sets the bit if EITHER are 1

 $0x03 \mid 0x02 \quad \boxed{0} \quad \boxed{0} \quad \boxed{0} \quad \boxed{0} \quad \boxed{0} \quad \boxed{0} \quad \boxed{1} \quad \boxed{1} \quad \boxed{0} \quad \boxed{0} \quad \boxed{0} \quad \boxed{0} \quad \boxed{0} \quad \boxed{1} \quad \boxed{0} \quad \boxed{0} = 0x03$ 

 $0x03 \mid 0x08 \quad \boxed{0 \mid 0 \mid 0 \mid 0 \mid 0 \mid 1 \mid 1} \mid \boxed{0 \mid 0 \mid 0 \mid 0 \mid 1 \mid 0 \mid 0} \quad == 0x0B (11)$ 

### Bit Shift




- << move all the bits left (up)
- >> move all the bits right (down)

### Bit Shift



- << move all the bits left (up)
- >> move all the bits right (down)



### Bit Shift



### << move all the bits left (up)

### >> move all the bits right (down)

### Arrays and Strings



#### Consecutive group of variables

e.g. lookup tables

#### Use square brackets to create and use arrays

```
/* Array of four 8-bit signed integers */
int8 buffer[4];
/* set the specific element to 99 */
buffer[2] = 99;
```

### Arrays always start at zero

buffer[0] is the first element in the array

buffer[3] is the last element in the array

### Strings are arrays of chars

Use double quotes "Print me"

### Array Example



### Initialize arrays with { comma-separated list }

int8 buffer[] = { 10, 20, 30, 40 };

0x20000007:

0x20000006:

0x20000005:

0x20000004:

0x20000003:

0x20000002:

0x20000001:

0x20000000:

← buffer[3]

← buffer[2]

← buffer[1]

← buffer[0]

40

30

20

10

### Array Example



```
int8 buffer[] = { 10, 20, 30, 40 };
buffer[2] = 99;
```

0x20000007:

0x20000006:

0x20000005:

0x20000004:

0x20000003:

0x20000002:

0x20000001:

0x20000000:

← buffer[3]

← buffer[2]

← buffer[1]

← buffer[0]

40

99

20

10

### Macros - #define



```
* Copyright 2014, YFS Corporation. All rights reserved.
#include <project.h>
#define MYCHANNEL (0)
* Function Name: main
* Reads the ADC and displays the voltage on the LCD.
int main()
 int16 output;
 /* Start the components */
 LCD Start();
 ADC Start();
 ADC StartConvert(); // Start the ADC conversions
 /* Display the value of ADC output on LCD */
 LCD Position(0,0);
 LCD PrintString( "ADC Output" );
 while (1)
    /* If ADC has data - read, convert to mV and print */
   if ( ADC IsEndConversion ( ADC RETURN STATUS ) )
      output = ADC GetResult16( MYCHANNEL );
      output = ADC CountsTo mVolts( MYCHANNEL, output );
      LCD Position(1,0);
      LCD PrintInt16( output );
```

#### Simple text substitution

```
#define MYCHANNEL 0
#define MSG "Hello!"
```

#### Improve readability

Magic numbers


### Improve quality

Need to change the ADC channel?

Just one edit and rebuild

Cannot forget to change every use





■ Detector - PSoC Creator 2.0 [C:\Creator\Detector\Detector\Coetcor\cup\General Detector\Coetcor\Coet