ModusToolbox[™] Software Training Level 3 – Wi-Fi



Answer Key

Table of contents

1.1	Chapter 2		
1.1.1	Exercise 2		
1.2		r 4b	
1.2.1	Exercise 4		
1.2.2	Exercise 5		
1.2.3	Exercise 6	2	
1.3	Chapter 4c		
	Exercise 5		

Document conventions

Convention	Usage	Example
Courier New	Displays code and text commands	<pre>CY_ISR_PROTO(MyISR); make build</pre>
Italics	Displays file names and paths	sourcefile.hex
[bracketed, bold]	Displays keyboard commands in procedures	[Enter] or [Ctrl] [C]
Menu > Selection	Represents menu paths	File > New Project > Clone
Bold	Displays GUI commands, menu paths and selections, and icon names in procedures	Click the Debugger icon, and then click Next .



1.1 Chapter 2

1.1.1 Exercise 2

- 1) There are two changes required in the wifi_config.h file:
 - a. WIFI_SSID changes to "WW1010PEN"
 - b. WIFI_SECURITY changes to CY_WCM_SECURITY_OPEN

Note:

You can find all of the security types available by right clicking on CY_WCM_SECURITY_OPEN (or any other security name) and selecting **Open Declaration**.

1.2 Chapter 4b

1.2.1 Exercise 4

- 1) Which server port is used for HTTP (non-secure)?
- 2) What header(s) is/are sent with each request?

In this case, three headers are sent:

Host: httpbin.org

User-Agent: anycloud-http-client

X-Amzn-Trace-Id: Root=...

- 3) What is the variable "connected" used for? Why is it needed?
 - The variable "connected" is used to determine if the connection to the server is still active. It is needed because the server can disconnect at any time. Therefore, before sending another request, we need to see if the connection is still there. If not, we need to restart everything.
- 4) Uncomment the section of code to wait for the server to disconnect between requests. How long does the server wait before closing the connection?

The server disconnects after about 60 seconds of inactivity.

1.2.2 Exercise 5

- 1) Which server port is used for HTTPS (secure)?
 - Port 443.
- 2) What function call and parameter specifies that the connection should use TLS?

The 1st parameter to cy_http_client_connect is of type cy_awsport_ssl_credentials_t and has all of the TLS information

1.2.3 Exercise 6

1) What headers sent with the POST request?

There are 5 headers:

Host: httpbin.org

Content-Type: application/json

Content-Length: 18

User-Agent: anycloud-http-client

X-Amzn-Trace-Id: Root=...



(back-slashes don't count in the content length)

2) What is the JSON content that is posted? The JSON is a key-value pair of {"any cloud":"yes"}

1.3 Chapter 4c

1.3.1 Exercise 5

- 1) How do the MQTT library functions (e.g. IotMqtt_PublishSync()) get into your project? The #include for "iot_mqtt.h" in the C file cause the AWS library functions to be included in the project.
- 2) What function is called when the button is pressed? isr button press()
- 3) How does the button callback unlock the publisher task?
 It notifies the publisher task by calling:
 xTaskNotifyFromISR(publisher_task_handle, new_device_state,
 SetValueWithoutOverwrite, &xHigherPriorityTaskWoken);
- 4) Are all messages sent to the AWS IOT MQTT Message Broker required to be in JSON format? No, but messages that affect the shadow have to be JSON.
- 5) What steps are required to get an AWS connection established? Connect to the network Initialize the Cypress Secure Sockets and MQTT libraries Set up network info and connection info Open the connection using IotMqtt_Connect()
- 6) What function is called to send data to the server? IotMqtt PublishSync()

Trademarks

All referenced product or service names and trademarks are the property of their respective owners.

Published by Infineon Technologies AG 81726 Munich, Germany

© 2021 Infineon Technologies AG. All Rights Reserved.

IMPORTANT NOTICE

The information given in this document shall in no event be regarded as a guarantee of conditions or characteristics ("Beschaffenheitsgarantie").

With respect to any examples, hints or any typical values stated herein and/or any information regarding the application of the product, Infineon Technologies hereby disclaims any and all warranties and liabilities of any kind, including without limitation warranties of non-infringement of intellectual property rights of any third party.

In addition, any information given in this document is subject to customer's compliance with its obligations stated in this document and any applicable legal requirements, norms and standards concerning customer's products and any use of the product of Infineon Technologies in customer's applications.

The data contained in this document is exclusively intended for technically trained staff. It is the responsibility of customer's technical departments to evaluate the suitability of the product for the intended application and the completeness of the product information given in this document with respect to such application.

For further information on the product, technology, delivery terms and conditions and prices please contact your nearest Infineon Technologies office (www.infineon.com).

WARNINGS

Due to technical requirements products may contain dangerous substances. For information on the types in question please contact your nearest Infineon Technologies office.

Except as otherwise explicitly approved by Infineon Technologies in a written document signed by authorized representatives of Infineon Technologies, Infineon Technologies' products may not be used in any applications where a failure of the product or any consequences of the use thereof can reasonably be expected to result in personal injury.