Smart Irrigation and Plant Health Detection using Raspberry PICO

How to Use Oled Display, Capacitive Moisture Sensor, DHT11 Temperature, Humidity Sensor and Relays with WIZnet Pico

In this project, we'll create a smart irrigation system that can detect the moisture level in the water and irrigate the plant accordingly. The system also contains a failsafe mechanism that allows the moisture sensor to recalibrate so that the plant is not overwatered. It also shows the current humidity level and temperature in degrees, as well as the plant's health condition, which is presented on the OLED screen. This project employs YOLOV5, a powerful object detection model capable of monitoring plant health in real time and transmitting the information to a MQTT server. The MQTT server sends messages to the Raspberry PICO, which it displays on the OLED panel.

Things used in this project

1 Hardware

- Wiznet Pico board
- Jumper wires
- OLED Display 0.96inch
- Capacitive Moisture Sensor
- DHT11 Temperature & Humidity Sensor
- 5v Pump
- 5v single channel relay
- Light Pipe
- Bread Board
- DC Power Jack
- 5V Power Supply
- Web Cam

2 Software

- Arduino IDE
- YOLOV5 Object Detection

Story

India is one of the largest freshwater users in the world, and our country uses a larger amount of fresh water than other countries. There is a large amount of water used in agriculture rather than in the domestic and industrial sector. 65% of total water is contributed as groundwater. Today water has become one of the most important sources on the earth and most of it is used in the agriculture field. As the a capacitive soil-moisture sensor and temperature/humidity sensor are placed in the root zone of the plants, the system can distribute this information to the microcontroller. The raspberry pico is the heart of the system. The system can use the sensors such as soil moisture sensor and atmosphere humidity and temperature. The raspberry pi model is programmed such that if either soil moisture dips below a predefined threshold level, the irrigation system is activated, i.e. the relay connected to the raspberry pico will turn ON or OFF the motor. In order to prevent over irrigation a timeout is added. For small use cases such as a houseplant, the motor will turn on only for 5 seconds waits for recalibration of the moisture sensor if water is adequate and is above threshold it will stop irrigating else it will pump again for 5 seconds. Moreover the onboard OLED display and Serial Monitor will display the current temperature, moisture, humidity level and healthiness of the plant. Healthiness of the plant is determined by using a webcam connected to a laptop and by making use of YOLOV5 which will send the plants current status to an MQTT server. This project presents an efficient, fairly cheap and easy automated irrigation system. This system once installed has less maintenance cost and is easy to use.


Component Used	Image	Description
Wiznet PICO ethernet hat	Water and the second se	Controls and coordinates the pump system, collects data from the sensors, receives messages from the MQTT Server and displays it on the OLED Display.
Capacitive Moisture Sensor	O'A ASSAULT O'A AS	Reads Moisture value from the soil.
DHT11		Reads Temperature and Humidity from the root of soil.

5V Single Channel Relay	STORING STORIN	Activates pump based on the humidity reading
0.96 inch OLED Display		Reads and displays data from the sensors. Also displays the plant health information from the MQTT Server
Breadboard and Jumper wire		Helps with interconnecting circuit elements with the Raspberry PICO


USB Webcam	ADD NAZOS	Captures plant images to the YOLOV5 Object detection model for analysis
Light pipe		To collect water from reservoir to the soil
5V Pump		Supplies water from reservoir to soil

DC 5v Jack	Helps providing power supply to the 5V pump
5V DC Adapter	Converts AC Current to DC current at 5V 1 amps to power the pump

Circuit Diagram



AI Integration



Explanation

VCC , GND are connected to a common point in the bread board so that other sensors can share this point. The DHT sensor is connected to GPIO PIN 9 of the pico board which will provide temperature and humidity readings. The capacitive moisture sensor is connected to Analogue PIN A0 which will provide current soil moisture readings. The SDA and SCL pins of the OLED display are connected to the GPIO 5 and 4. Readings from DHT11 and moisture sensor are displayed on the OLED display. A relay is connected to the GPIO PIN 14 for turning on and off the pump. The +ve of the pump is connected to the relay and -ve is directly connected to the pump from the DC jack. +ve of the DC jack is connected to the common point of the relay. The system uses a 5v motor powered by a 5v DC adapter. If the moisture percent drops below 30% the relay will activate the pump mechanism for 5 seconds. It turns off the pump for 10 sec inorder for the moisture sensor to recalibrate. The microcontroller will check for the moisture level and activate the pump if the moisture level is still below 30. The relay will stop activating if the water level is above 30 inorder to prevent over watering. The OLED display will also display the health status of the plant.

How to integrate AI?

In this project we have used the YOLOV5 object detection model on a custom trained dataset which could detect accurately when a plant is dry or not. Training is done by collecting dry pictures and healthy pictures of the same plant type. We then annotate these pictures differentiating between dry and healthy. Then feed it to the training algorithm. Ensure that the present working directory is the YOLOV5 directory and all dependencies are installed. The coco128.yaml file has to be updated with the dataset directory and also the classes used [Healthy,dry]. Train using the command:

!python train.py --img 416 --batch 16 --epochs 100 --data coco128.yaml --weights yolov5s.pt --cache

A pertained weight has been assigned to the training [yolov5s.pt] and is running at 100 epochs. Once the training is done check in the "runs" folder to check the accuracy of predictions in the .jpg files. The real time detection can be used with the command:

python detect.py --weights runs\plant\best.pt --img 416 --conf 0.25 --source 1

While running this command the present working directory should be the root of the yolov5 folder. The weight file ending in ".pt" file has to be given in the --weight argument. The source can be set to 1 or 0 depending on the webcam used internal or external. On running this command a frame opens up with bounding box detection. In the detect.py we have made some edits so that the frames will only only be sent at a slower rate so that it matches with the speed of mqtt receiver in the microcontroller. The status of the plant will be displayed in the console. In this project we are sending this plant status to the mqtt server. These status messages include "plant is healthy", "plant is dried", in case no plants are detected "no plant detected". On receiving the status from the mqtt server in raspberry pico, we check for keywords such as "healthy", "dried" and "no". A global variable is assigned for each status and this status will be displayed in the OLED display as well as the Serial Monitor.

```
0001 // Author Sain Saji
2 // Reference for OLED
3 //
https://github.com/sainsaji/SSD1306-Base-Code-for-Raspberry-Pico-Ardunio-L
ibrary/edit/main/README.md
6 //Libraries Included
7 #include <SPI.h>
8 #include <Wire.h>
9 #include <Ethernet.h>
10 #include <PubSubClient.h>
11 #include <Adafruit GFX.h> //External Libraries for driving the OLED
display
12 #include <Adafruit SSD1306.h> //External Libraries for driving the OLED
display
13 #include <DHT.h>
14
15 //MQTT Global Variables
16 byte mac[] = { 0xDE, 0xED, 0xBA, 0xFE, 0xFE, 0xED };
17 IPAddress ip(172, 16, 0, 100);
18 IPAddress myDns(192, 168, 0, 1);
19 char server [] ="broker.emqx.io";
20 EthernetClient ethClient;
21 PubSubClient client(ethClient);
22
23 //Definitions
24 #define SCREEN WIDTH 128 // OLED display width, in pixels
25 #define SCREEN HEIGHT 64
                                // OLED display height, in pixels
26 #define OLED RESET
                                // Make sure this is set to -1 for Pico
                        -1
27 #define SCREEN ADDRESS 0x3C
                                // Use 3C with Pico for 128x64 OLED
28 #define DHTPIN 9
                                 // Digital pin connected to the DHT
sensor
29 #define DHTTYPE DHT11
                                // Defining DHT Version ,use DHT22 for
newer models
30
31 //Initialization
```

```
32 Adafruit SSD1306 display(SCREEN WIDTH, SCREEN HEIGHT, &Wire,
OLED RESET);
33 DHT dht(DHTPIN, DHTTYPE);
34
35 //Global Variables
36 int current status=3;
                          //Initial plant status [0:Healthy,1:
Unhealthy, 3: No plant detected]
37 int rightX=26;
                              //Display right X value
38 int leftY=5;
                              //Display left Y value
39 int soilMoistureValue = 0; //Initial moisture value
40 int soilmoisturepercent=0; //Moisture value in percentage
41
42 //Global Constants
43 const int AirValue = 620; // Airvalue after calibrating
44 const int WaterValue = 310; // Water Value after calibrating
45
46 //Display Frame bitmap
47 const unsigned char baseframe [] PROGMEM = {
    0x00, 0x1e, 0x00, 0x00, 0x00, 0x00, 0x00, 0x01, 0x00, 0x00, 0x00,
0x00, 0x00, 0x00, 0x00, 0x00,
    0x00, 0x3f, 0x00, 0x00, 0x00, 0x00, 0x01, 0x00, 0x00, 0x00,
0x00, 0x00, 0x00, 0x00, 0x00,
    0x00, 0x73, 0x80, 0x00, 0x00, 0x00, 0x01, 0x00, 0x00, 0x00,
0x00, 0x00, 0x00, 0x00, 0x00,
    0x00, 0xe1, 0xc0, 0x00, 0x00, 0x00, 0x01, 0x00, 0x00, 0x00,
0x00, 0x00, 0x00, 0x00, 0x00,
   0x00, 0xe1, 0xc0, 0x00, 0x00, 0x00, 0x00, 0x01, 0x00, 0x00, 0x00,
0x00, 0x00, 0x00, 0x00, 0x00,
53
   0x00, 0xe1, 0xc0, 0x00, 0x00, 0x00, 0x00, 0x01, 0x00, 0x00, 0x00,
0x00, 0x00, 0x00, 0x00, 0x00,
    0x00, 0xe1, 0xc0, 0x00, 0x00, 0x00, 0x01, 0x00, 0x00, 0x00,
0x00, 0x00, 0x00, 0x00, 0x00,
    0x00, 0xe1, 0xc0, 0x00, 0x00, 0x00, 0x01, 0x00, 0x00, 0x00,
0x00, 0x00, 0x00, 0x00, 0x00,
    0x00, 0xe1, 0xc0, 0x00, 0x00, 0x00, 0x00, 0x01, 0x00, 0x00, 0x00,
0x00, 0x00, 0x00, 0x00, 0x00,
57
    0x00, 0xed, 0xc0, 0x00, 0x00, 0x00, 0x01, 0x00, 0x00, 0x00,
0x00, 0x00, 0x00, 0x00, 0x00,
    0x00, 0xed, 0xc0, 0x00, 0x00, 0x00, 0x00, 0x01, 0x00, 0x00, 0x00,
0x00, 0x00, 0x00, 0x00, 0x00,
```

```
0x00, 0xed, 0xc0, 0x00, 0x00, 0x00, 0x00, 0x01, 0x00, 0x00, 0x00,
0x00, 0x00, 0x00, 0x00, 0x00,
     0x00, 0xed, 0xc0, 0x00, 0x00, 0x00, 0x00, 0x01, 0x00, 0x00, 0x00,
0x00, 0x00, 0x00, 0x00, 0x00,
     0x00, 0xed, 0xc0, 0x00, 0x00, 0x00, 0x01, 0x00, 0x00, 0x00,
0 \times 00, 0 \times 00, 0 \times 00, 0 \times 00, 0 \times 00,
     0x00, 0xed, 0xc0, 0x00, 0x00, 0x00, 0x00, 0x01, 0x00, 0x00, 0x00,
0x00, 0x00, 0x00, 0x00, 0x00,
    0x00, 0xed, 0xc0, 0x00, 0x00, 0x00, 0x01, 0x00, 0x00, 0x00,
0x00, 0x00, 0x00, 0x00, 0x00,
    0x00, 0xed, 0xc0, 0x00, 0x00, 0x00, 0x01, 0x00, 0x00, 0x00,
64
0x00, 0x00, 0x00, 0x00, 0x00,
    0x01, 0xcc, 0xe0, 0x00, 0x00, 0x00, 0x00, 0x01, 0x00, 0x00, 0x00,
0x00, 0x00, 0x00, 0x00, 0x00,
    0x03, 0x9e, 0x70, 0x00, 0x00, 0x00, 0x00, 0x01, 0x00, 0x00, 0x00,
0 \times 00, 0 \times 00, 0 \times 00, 0 \times 00, 0 \times 00,
    0x03, 0xbf, 0x70, 0x00, 0x00, 0x00, 0x01, 0x00, 0x00, 0x00,
0x00, 0x00, 0x00, 0x00, 0x00,
    0x03, 0x3f, 0x30, 0x00, 0x00, 0x00, 0x01, 0x00, 0x00, 0x00,
0x00, 0x00, 0x00, 0x00, 0x00,
    0x03, 0x3f, 0x30, 0x00, 0x00, 0x00, 0x01, 0x00, 0x00, 0x00,
0x00, 0x00, 0x00, 0x00, 0x00,
    0x03, 0xbf, 0x70, 0x00, 0x00, 0x00, 0x01, 0x00, 0x00, 0x00,
0x00, 0x00, 0x00, 0x00, 0x00,
    0x03, 0x9e, 0x70, 0x00, 0x00, 0x00, 0x01, 0x00, 0x00, 0x00,
0x00, 0x00, 0x00, 0x00, 0x00,
    0x01, 0xc0, 0xe0, 0x00, 0x00, 0x00, 0x01, 0x00, 0x00, 0x00,
0x00, 0x00, 0x00, 0x00, 0x00,
    0x00, 0xf3, 0xc0, 0x00, 0x00, 0x00, 0x00, 0x01, 0x00, 0x00, 0x00,
0 \times 00, 0 \times 00, 0 \times 00, 0 \times 00, 0 \times 00,
    0x00, 0x7f, 0x80, 0x00, 0x00, 0x00, 0x01, 0x00, 0x00, 0x00,
0x00, 0x00, 0x00, 0x00, 0x00,
    0x00, 0x3f, 0x00, 0x00, 0x00, 0x00, 0x01, 0x00, 0x00, 0x00,
0x00, 0x00, 0x00, 0x00, 0x00,
    0x00, 0x00, 0x00, 0x00, 0x00, 0x00, 0x01, 0x00, 0x00, 0x00,
0x00, 0x00, 0x00, 0x00, 0x00,
    0xff, 0xff,
0xff, 0xff, 0xff, 0xff, 0xff,
    0x00, 0x00, 0x00, 0x00, 0x00, 0x00, 0x00, 0x01, 0x00, 0x00, 0x00,
0x00, 0x00, 0x00, 0x00, 0x00,
```

```
0x00, 0x00, 0x00, 0x00, 0x00, 0x00, 0x00, 0x01, 0x00, 0x0c, 0x00,
0x00, 0x00, 0x00, 0x00, 0x00,
    0x00, 0x08, 0x00, 0x00, 0x00, 0x00, 0x00, 0x01, 0x00, 0x1e, 0x00,
0x00, 0x00, 0x00, 0x00, 0x00,
    0x00, 0x1c, 0x00, 0x00, 0x00, 0x00, 0x00, 0x01, 0x00, 0x3e, 0x00,
0 \times 00, 0 \times 00, 0 \times 00, 0 \times 00, 0 \times 00,
    0x00, 0x1e, 0x00, 0x00, 0x00, 0x00, 0x01, 0x00, 0x7f, 0x00,
0x00, 0x00, 0x00, 0x00, 0x00,
    0x00, 0x3f, 0x00, 0x00, 0x00, 0x00, 0x01, 0x00, 0xff, 0x80,
0x00, 0x00, 0x00, 0x00, 0x00,
84
    0x00, 0x7f, 0x00, 0x00, 0x00, 0x00, 0x01, 0x00, 0xff, 0xc0,
0x00, 0x00, 0x00, 0x00, 0x00,
    0x00, 0xff, 0x80, 0x00, 0x00, 0x00, 0x00, 0x01, 0x01, 0xff, 0xc0,
0x00, 0x00, 0x00, 0x00, 0x00,
    0x00, 0xff, 0xc0, 0x00, 0x00, 0x00, 0x00, 0x01, 0x03, 0xff, 0xe0,
0x00, 0x00, 0x00, 0x00, 0x00,
    0x01, 0xff, 0xc0, 0x00, 0x00, 0x00, 0x00, 0x01, 0x03, 0xdf, 0xf0,
0x00, 0x00, 0x00, 0x00, 0x00,
    0x03, 0xff, 0xe0, 0x00, 0x00, 0x00, 0x01, 0x07, 0x0e, 0x70,
0x00, 0x00, 0x00, 0x00, 0x00,
    0x03, 0xff, 0xf0, 0x00, 0x00, 0x00, 0x01, 0x07, 0x24, 0x78,
0x00, 0x00, 0x00, 0x00, 0x00,
    0x07, 0xff, 0xf0, 0x00, 0x00, 0x00, 0x01, 0x0f, 0x0c, 0xf8,
0x00, 0x00, 0x00, 0x00, 0x00,
    0x07, 0xff, 0xf8, 0x00, 0x00, 0x00, 0x01, 0x0f, 0x99, 0xfc,
0x00, 0x00, 0x00, 0x00, 0x00,
92
    0x0f, 0xff, 0xf8, 0x00, 0x00, 0x00, 0x00, 0x01, 0x1f, 0xf2, 0x7c,
0x00, 0x00, 0x00, 0x00, 0x00,
93
    0x1f, 0xff, 0xfc, 0x00, 0x00, 0x00, 0x01, 0x1f, 0xe4, 0x3e,
0 \times 00, 0 \times 00, 0 \times 00, 0 \times 00, 0 \times 00,
    0x1f, 0xff, 0xfc, 0x00, 0x00, 0x00, 0x00, 0x01, 0x3f, 0xc9, 0x3e,
0x00, 0x00, 0x00, 0x00, 0x00,
    0x1f, 0xff, 0xfe, 0x00, 0x00, 0x00, 0x01, 0x3f, 0x9c, 0x7e,
0x00, 0x00, 0x00, 0x00, 0x00,
96
    0x3f, 0xff, 0xfe, 0x00, 0x00, 0x00, 0x01, 0x3f, 0xff, 0xff,
0x00, 0x00, 0x00, 0x00, 0x00,
    0x3f, 0xff, 0xfe, 0x00, 0x00, 0x00, 0x01, 0x3f, 0xff, 0xff,
0x00, 0x00, 0x00, 0x00, 0x00,
    0x3f, 0xff, 0xfe, 0x00, 0x00, 0x00, 0x01, 0x38, 0x61, 0x87,
0x00, 0x00, 0x00, 0x00, 0x00,
```

```
0x3f, 0xff, 0xfe, 0x00, 0x00, 0x00, 0x01, 0x38, 0x00, 0x07,
0x00, 0x00, 0x00, 0x00, 0x00,
      0x3f, 0xff, 0xfe, 0x00, 0x00, 0x00, 0x01, 0x38, 0x00, 0x07,
0x00, 0x00, 0x00, 0x00, 0x00,
      0x3f, 0xff, 0xfe, 0x00, 0x00, 0x00, 0x01, 0x38, 0x00, 0x0e,
0x00, 0x00, 0x00, 0x00, 0x00,
      0x1f, 0xff, 0xfc, 0x00, 0x00, 0x00, 0x00, 0x01, 0x3c, 0x00, 0x0e,
102
0x00, 0x00, 0x00, 0x00, 0x00,
103
      0x1f, 0xff, 0xfc, 0x00, 0x00, 0x00, 0x01, 0x1c, 0x00, 0x1e,
0x00, 0x00, 0x00, 0x00, 0x00,
      0x0f, 0xff, 0xf8, 0x00, 0x00, 0x00, 0x01, 0x1e, 0x00, 0x3c,
104
0x00, 0x00, 0x00, 0x00, 0x00,
105
      0x07, 0xff, 0xf8, 0x00, 0x00, 0x00, 0x00, 0x01, 0x0f, 0x00, 0x78,
0x00, 0x00, 0x00, 0x00, 0x00,
      0x03, 0xff, 0xf0, 0x00, 0x00, 0x00, 0x00, 0x01, 0x07, 0xe1, 0xf8,
0x00, 0x00, 0x00, 0x00, 0x00,
     0x01, 0xff, 0xc0, 0x00, 0x00, 0x00, 0x01, 0x03, 0xff, 0xe0,
0x00, 0x00, 0x00, 0x00, 0x00,
108
     0x00, 0x7f, 0x00, 0x00, 0x00, 0x00, 0x01, 0x00, 0xff, 0xc0,
0x00, 0x00, 0x00, 0x00, 0x00,
      0x00, 0x00, 0x00, 0x00, 0x00, 0x00, 0x00, 0x01, 0x00, 0x3e, 0x00,
109
0x00, 0x00, 0x00, 0x00, 0x00,
      0 \times 00, 0 \times 01, 0 \times 00, 0 \times 00, 0 \times 00,
110
0x00, 0x00, 0x00, 0x00, 0x00,
      0x00, 0x00, 0x00, 0x00, 0x00, 0x00, 0x00, 0x01, 0x00, 0x00, 0x00,
111
0x00, 0x00, 0x00, 0x00, 0x00
112 };
113
114 //MQTT callback funtion
115 void callback(char* topic, byte* payload, unsigned int length) {
116
      Serial.print("Message arrived [");
117
     Serial.print(topic);
118
     Serial.print("] ");
119
     char messageBuffer[30];
120
     memcpy(messageBuffer, payload, length);
121
     messageBuffer[length] = '\0';
122
     Serial.println(messageBuffer);
123
      for (int i=0;i<length;i++) {</pre>
124
        Serial.print((char)payload[i]);
125
```

```
126
      //For convering payload to string
127
      char message[30];
128
      for(int i=0;i<length;i++){</pre>
129
        message[i]=payload[i];
130
131
      String msg = String(message);
132
133
      //Checking if index contain healthy
134
      int he = msg.indexOf("healthy");
     //Checking if index contain "no" as in "no plants detected"
135
136
      int no = msq.indexOf("no");
137
138
     //if index contain "healthy" set current status as 0 else 1
139
     if(he>0)
140
     current status=0;
141
     else
142
     current status=1;
143
     //if index contain "no" set current status as 3
144
     if(no>=0)
145
     current status=3;
146
     Serial.println();
147 }
148
149 //MQTT Reconnect callback
150 void reconnect() {
151
      // Loop until we're reconnected
152
      while (!client.connected()) {
153
        Serial.print("Attempting MQTT connection...");
154
        // Attempt to connect
155
        if (client.connect("arduinoClient")) {
156
          Serial.println("connected");
157
          client.subscribe("home/planthealth/2147230");
158
        } else {
159
          Serial.print("failed, rc=");
160
          Serial.print(client.state());
161
          Serial.println(" try again in 5 seconds");
162
          // Wait 5 seconds before retrying
163
          delay(5000);
164
165
```

```
166 }
167
168 //MQTT Ethernet initialization
169 void ethstart()
170 {
171
     //ethernet codes
172
     Ethernet.init(17); // WIZnet W5100S-EVB-Pico
173
    Serial.begin(115200);
174
    while (!Serial) {
175
        ; // wait for the serial port to connect. Needed for native USB
port only
176
177
        Serial.println("Initialize Ethernet with DHCP:");
178
179
      if (Ethernet.begin(mac) == 0) {
180
        Serial.println("Failed to configure Ethernet using DHCP");
181
        // Check for Ethernet hardware present
182
        if (Ethernet.hardwareStatus() == EthernetNoHardware) {
183
          Serial.println("Ethernet shield was not found. Sorry, can't run
without hardware. :(");
184
          while (true) {
185
            delay(1); // do nothing, no point running without Ethernet
hardware
186
          }
187
188
        if (Ethernet.linkStatus() == LinkOFF) {
189
          Serial.println("Ethernet cable is not connected.");
190
191
        // try to congifure using IP address instead of DHCP:
192
       Ethernet.begin(mac, ip, myDns);
193
      } else {
194
        Serial.print(" DHCP assigned IP ");
195
        Serial.println(Ethernet.localIP());
196
197
      // give the Ethernet shield a second to initialize:
198
     delay(1000);
199
     Serial.print("connecting to ");
200
     Serial.print(server);
201
     Serial.println("...");
202
      client.setClient(ethClient);
```

```
203
      client.setServer(server, 1883);
204
     client.setCallback(callback);
205
      // Allow the hardware to sort itself out
206
      delay(1500);
207
208 }
209
210 //To print temperature to OLED
211 void printTemp(int temp)
212 {
213
      display.setCursor(rightX,leftY);
214
     display.setTextSize(2);
215
     display.setTextColor(WHITE);
216
     display.println(temp);
217
     display.setCursor(rightX+24,leftY);
     display.println("C");
218
219 }
220
221 //To print Humidity to OLED
222 void printHumidity(int humid)
223 {
224
      display.setCursor(rightX,leftY+33);
225
     display.setTextSize(2);
226
     display.setTextColor(WHITE);
     display.println(humid);
227
228
     display.setCursor(rightX+24,leftY+33);
229
      display.println("%");
230 }
231
232 //To print moisture to OLED
233 void printMoist(int moist)
234 {
235
      display.setCursor(rightX+65,leftY+33);
236
     display.setTextSize(2);
237
     display.setTextColor(WHITE);
238
     display.println(moist);
239
     display.setCursor(rightX+24+65,leftY+33);
240
     display.println("%");
241 }
242
```

```
243 ///To print plant status to OLED
244 void printStatus(String status)
245 {
246
     display.setCursor(rightX+40,leftY);
247
    display.setTextSize(1.5);
248
     display.setTextColor(WHITE);
249
     display.println(status);
250 }
251
252
253 //setup
254 void setup()
255 {
256
     Serial.begin(115200);
257 dht.begin();
258
    pinMode(14,OUTPUT);
259
     pinMode(LED BUILTIN, INPUT);
260
     display.begin(SSD1306 SWITCHCAPVCC,0x3C);
261
     display.fillScreen(0); //0 for filling with black dots. 1 for white
262
     printStatus("Recalibrating");
263
    display.display();
264
     ethstart();
     pinMode(LED BUILTIN, OUTPUT);
265
266 }
267
268
269 void loop()
270
271
      //Reconnect to MQTT server if disconnected
272
       if (!client.connected()) {
273
       reconnect();
274
275
       //Subscribe to topic
276
      client.subscribe("home/planthealth/2147230");
277
278
     //Read temperature and humidity
279
     int temp=dht.readTemperature();
280
     int humidity = dht.readHumidity();
281
282
      //Read mositure Value
```

```
283
      soilMoistureValue = analogRead(A0); //put Sensor insert into soil
284
      soilmoisturepercent = map(soilMoistureValue, AirValue, WaterValue,
0, 100);
285
286
       // Check if any reads failed and exit early (to try again).
287
      if (isnan(humidity) || isnan(temp)) {
288
        Serial.println(F("Failed to read from DHT sensor!"));
289
        return;
290
291
      display.clearDisplay();
292
      printTemp(temp);
293
      Serial.println("Temperature");
294
      Serial.println(temp);
295
      printHumidity(humidity);
296
      Serial.println("Humidity");
297
      Serial.println(humidity);
298
      printMoist(soilmoisturepercent);
299
300
      //Startup pump if moisture percentage drops below 30%
301
      if(soilmoisturepercent<=30)</pre>
302
303
        digitalWrite(14,HIGH);
304
        Serial.println("Pump Status: ");
305
        Serial.print("ON");
306
        delay(2000);
307
        digitalWrite(14,LOW);
308
        Serial.println("Pump Status: ");
309
        Serial.println("OFF");
310
        Serial.println("Recalibrating Moisture.....");
311
        delay(10000);
312
313
      else
314
315
        digitalWrite(14,LOW);
316
317
      Serial.println("Moisture");
318
      Serial.println(soilmoisturepercent);
319
320
      //Draw base frame on OLED
      display.drawBitmap(0, 0, baseframe, 128, 64, WHITE);
321
```

```
322
    //Display plant status based on current_status variable
323
     if(current_status==0)
324
325
326
       printStatus("HEALTHY");
327
328
      else if(current_status==1)
329
      {
330
       printStatus("DRIED");
331
332
     else
333
     printStatus("NO PLANT");
334
     display.display();
335
     delay(100);
336
337
    //To recieve MQTT messages
338
    client.loop();
339 }
340
```

Code Explanation

The code starts with including all the libraries required for the components and the mqtt server (line no 7-13). All global variables and definitions for the MQTT server are initialized (Line no 16-21). Width and Height information for the OLED display and the DHT11 pin number is initialized (Line no 24-29). The baseframe for the OLED display bitmap is initialized (Line no 47-112). On powering the system, the microcontroller initializes all the global variables and readings from the sensors (line no 36-40). The system has to be connected to ethernet so that it will be able to receive messages from the MQTT server. Global constants for the moisture sensor is provided (Line no 43,44). The void loop function initializes pins and the OLED display and attempt to connect to the MQTT server, when this script is run a recalibration message is displayed on the OLED screen (Line no 255-256). The ethernet initialization is done by the function ethstart(); (Line no 264) and is defined in Line 169-206. It attempts to connect to the ethernet and displays a warning message to the serial port in case of any issues.


Once connected to the ethernet it also provides a delay for the system to sort itself out (Line no 206). Once the void setup function is executed looping begins in the void loop() function (Line no 269-339). If the microcontroller is disconnected from the ethernet it attempts to reconnect (Line no 272-274). Subscription to the topic is defined in line 276. The temperature, humidity and moisture data is read (Line no 279-284). If the reading fails it displays a warning message to the serial monitor (Line no 287-289). The temperature, humidity and moisture data is displayed to the OLED display using function printTemp, printHumidity and printMoist. These functions are defined in Line no 211,222,233 which sets upto the cursor in the specific row and column and prints the data to the display. Based on the moisture level the pump will be activated ,if the moisture drops below 30% the pump activates for 5 seconds by turning on the relay and stops this allowing the moisture sensor to calibrate. If the moisture percentage is above 30 percent the relay stays off(Line no 324-335).

The global variable current_status is set by the callback function to MQTT server (Line no 115). The message from the MQTT server is in the form of a character array. We use the indexOf function to check whether a string exists in the array(Line no 134,136). If found "healthy" the current variable is set to 0, else 1. If "no" is found then it is set to 3. This information is displayed to OLED using the printStatus() function (Line no 244).

Images




































Video Link

References

- Pawar, S. B., Rajput, P., & Shaikh, A. (2018). Smart irrigation system using IOT and raspberry pi. *International Research Journal of Engineering and Technology*, 5(8), 1163-1166.
- https://how2electronics.com/interface-capacitive-soil-moisture-sensor-arduino/
- https://create.arduino.cc/projecthub/pibots555/how-to-connect-dht11-sensor-with-arduino-uno-f4d239
- https://lastminuteengineers.com/oled-display-arduino-tutorial/