

# REST API for Intwine Connect CTA-2045 Universal Communication Modules

### 1 Overview

This document describes the RESTful API to the Intwine Connect CTA-2045 Universal Communication Module (UCM). This API is used for both AC and DC form-factor UCM, however all messages may not be supported based on the specific Smart Grid Device (SGD) connected.

To use these API it is necessary to first configure the UCM to connect to a Wi-Fi access point and then get the IP address of the UCM. For testing purposes, Postman<sup>1</sup> or similar API testing tools can be used.

Finally, it is the responsibility of the user (or head-node) to issue a "good" Outside Comm State message at a regular interval (no more than 15 minutes). If this is not done, the SGD may stop any curtailment events in progress.

### 2 Contents

1	Overview 1				
2	Contents				
		API			
	3.1	Outside Comm State			
	3.2	End Shed / Run Normal			
	3.3	Shed Load	3		
	3.4	Critical Peak Event	2		
	3.5	Grid Emergency	Ę		
	3.6	Load Up	6		
	3.7	Request Change in Power Level	6		
	3.8	Present Relative Price	7		
	3.9	Next Period Relative Price	8		

October 24, 2017

1



<sup>&</sup>lt;sup>1</sup> https://www.getpostman.com/postman



3.10	Time Remaining in Price Period	8
3.11	Get Current State	9
3.12	Request Information	11
3.13	Update Local Time	12
3.14	Get Setpoint	13
3.15	Set Setpoint	14
	Get Present Temperature	
	Start Autonomous Cycling	
3.18	Terminate Autonomous Cycling	17
3.19	Get Commodity Read	17

#### 3 API

#### 3.1 Outside Comm State

URL	/comm.cgi
METHOD	POST
URL PARAMS	N/A
DATA PARAMS	{"commstate": "xxxx" } possible values are "good" or "lost"
SUCCESS	HTTP 200 OK
RESPONSE	
<b>ERROR RESPONSE</b>	HTTP 400 - BAD REQUEST: BAD PAYLOAD BYTE #2
	HTTP 401 - UNAUTHORIZED: BUSY
	HTTP 403 – FORBIDDEN: OTHER ERROR
	HTTP 414- URL TOO LONG : LENGTH ERROR
	HTTP 500- INTERNAL SERVER ERROR
	HTTP 501- NOT IMPLEMENTED: UNSUPPORTED COMMAND
SAMPLE CALL	
NOTES	Sent by the UCM to the SGD to indicate the availability of external
	communications to the UCM.
	Opcode1 = 0x0E
	Opcode2 = 0x01 or 0x00 for "good" or "lost", respectively



### 3.2 End Shed / Run Normal

URL	/load.cgi
METHOD	POST
URL PARAMS	N/A
DATA PARAMS	{ "event_name": "normal" }
SUCCESS RESPONSE	HTTP 200 OK
ERROR RESPONSE	HTTP 400 – BAD REQUEST: BAD PAYLOAD BYTE #2 HTTP 401 - UNAUTHORIZED: BUSY HTTP 403 – FORBIDDEN: OTHER ERROR HTTP 414- URL TOO LONG: LENGTH ERROR HTTP 500- INTERNAL SERVER ERROR HTTP 501- NOT IMPLEMENTED: UNSUPPORTED COMMAND
SAMPLE CALL	
NOTES	This command must be sent once from the UCM to the SGD when a load shed or other curtailment event ends, regardless of whether the Event Duration is provided for informational purposes.  Curtailment event commands that are terminated by this End Shed include: Shed 0x01, Request for Power Level 0x06, Critical Peak Event 0x0A, Grid Emergency 0x0B, and Load Up 0x17.  Opcode1 = 0x02 Opcode2 = 0x00

## 3.3 Shed Load

URL	/load.cgi
METHOD	POST
URL PARAMS	N/A
DATA PARAMS	{ "event_name": "shed", "event_duration": "xxxxxxxx"} integer number of seconds [see Note]
SUCCESS RESPONSE	HTTP 200 OK
ERROR RESPONSE	HTTP 400 – BAD REQUEST: BAD PAYLOAD BYTE #2 HTTP 401 - UNAUTHORIZED: BUSY HTTP 403 – FORBIDDEN: OTHER ERROR HTTP 414- URL TOO LONG: LENGTH ERROR HTTP 500- INTERNAL SERVER ERROR HTTP 501- NOT IMPLEMENTED: UNSUPPORTED COMMAND



SAMPLE CALL	
NOTES	Event Duration is encoded internally to the UCM as: Time in Seconds = 2 * (Byte Value)^2
	Possible values range from [2, 43200] seconds. The Byte Value will always be rounded up (actual event may be longer than desired, but will never be shorter).
	Sent from the UCM to the SGD when a load shed event begins.
	If other load management commands are attempted but not accepted by the SGD, then the UCM must fall back to this Opcode.
	Event Duration: See Section 8.1.2 for description and usage.
	Note: Event Durations of 10 minutes or less relate to "spinning reserve" uses. Event Durations greater than 10 minutes relate to "shift" uses.
	Opcode1 = 0x01 Opcode2 = Event Duration
	Max Event duration = 12 hours

#### Critical Peak Event 3.4

URL	/load.cgi
METHOD	POST
URL PARAMS	N/A
DATA PARAMS	{ "event_name": "critical_peak", "event_duration": "xxxxxxx"} integer number of seconds [see Note]
SUCCESS RESPONSE	HTTP 200 OK
ERROR RESPONSE	HTTP 400 – BAD REQUEST: BAD PAYLOAD BYTE #2 HTTP 401 - UNAUTHORIZED: BUSY HTTP 403 – FORBIDDEN: OTHER ERROR HTTP 414- URL TOO LONG: LENGTH ERROR HTTP 500- INTERNAL SERVER ERROR HTTP 501- NOT IMPLEMENTED: UNSUPPORTED COMMAND
SAMPLE CALL	



**NOTES** Event Duration is encoded internally to the UCM as:

Time in Seconds = 2 \* (Byte Value)^2

Possible values range from [2, 43200] seconds. The Byte Value will always be rounded up (actual event may be longer than desired, but

will never be shorter).

Opcode1 = 0x0A

Opcode2 = Event Duration

Max Event duration = 12 hours

#### Grid Emergency 3.5

URL	/load.cgi
METHOD	POST
URL PARAMS	N/A
DATA PARAMS	<b>\{</b>
	"event_name": "grid_emergency",
	"event_duration": "xxxxxxxx"} integer number of seconds [see Note]
SUCCESS	HTTP 200 OK
RESPONSE	
ERROR RESPONSE	HTTP 400 - BAD REQUEST: BAD PAYLOAD BYTE #2
	HTTP 401 - UNAUTHORIZED: BUSY
	HTTP 403 – FORBIDDEN: OTHER ERROR
	HTTP 414- URL TOO LONG : LENGTH ERROR
	HTTP 500- INTERNAL SERVER ERROR
	HTTP 501- NOT IMPLEMENTED: UNSUPPORTED COMMAND
SAMPLE CALL	
NOTES	Event Duration is encoded internally to the UCM as:
	Time in Seconds = 2 * (Byte Value)^2
	Possible values range from [2, 43200] seconds. The Byte Value will
	always be rounded up (actual event may be longer than desired, but
	will never be shorter).
	Opcode1 = 0x0B
	Opcode2 = Event Duration
	Max Event duration = 12 hours



## 3.6 Load Up

URL	/load.cgi
METHOD	POST
URL PARAMS	N/A
DATA PARAMS	{"event_name": "load_up",
	"event_duration" : "xxxxxxx" }
SUCCESS	HTTP 200 OK
RESPONSE	
ERROR RESPONSE	HTTP 400 – BAD REQUEST: BAD PAYLOAD BYTE #2
	HTTP 401 - UNAUTHORIZED: BUSY
	HTTP 403 – FORBIDDEN: OTHER ERROR
	HTTP 414- URL TOO LONG : LENGTH ERROR
	HTTP 500- INTERNAL SERVER ERROR
	HTTP 501- NOT IMPLEMENTED: UNSUPPORTED COMMAND
SAMPLE CALL	
NOTES	This command is the opposite (complement) of the "Shed" command. It requests that the end device run now, and continue as possible. The assumption of this command is that energy is not wasted, but rather that things like thermal devices will cycle on and operate until the maximum stored energy state is reached.
	Sent from the UCM to SGD at the beginning of the event.
	The End Shed/Run Normal message will end this event.
	Event Duration
	See section 8.1.2 for description and usage
	Opcode1 = 0x17
	Opcode2 = duration

## 3.7 Request Change in Power Level

URL	/load.cgi
METHOD	POST
URL PARAMS	N/A
DATA PARAMS	{ "event_name": "change_level",
	"load_percent": "xxxxxxxx"} integer between [-100, 100] inclusive.
	Negative implies load reduction, positive implies load increase



SUCCESS RESPONSE	HTTP 200 – OK
ERROR RESPONSE	HTTP 400 – BAD REQUEST: BAD PAYLOAD BYTE #2 HTTP 401 - UNAUTHORIZED: BUSY HTTP 403 – FORBIDDEN: OTHER ERROR HTTP 414- URL TOO LONG: LENGTH ERROR HTTP 500- INTERNAL SERVER ERROR HTTP 501- NOT IMPLEMENTED: UNSUPPORTED COMMAND
SAMPLE CALL	
NOTES	Sent from the UCM to the SGD to request that its average Power Level (relative to the full rating of the device) be reduced to a level between 0 and 100% of full value on a 7 bit precision scale.  Percent Setting:  MSbit = 0, Least significant 7 bits:  0x00 to 0x7F = 0 to 100% power absorbed MSbit = 1, Least significant 7 bits:  0x00 to 0x7F = 0 to 100% power produced  Details regarding the use of this command are provided in Section 8.2.1 .  Opcode1 = 0x06 Opcode2 = Percent Setting

## 3.8 Present Relative Price

URL	/price.cgi
METHOD	POST
URL PARAMS	N/A
DATA PARAMS	{ "cur_price": "xxxxxx"}
SUCCESS	HTTP 200 OK
RESPONSE	
<b>ERROR RESPONSE</b>	HTTP 400 - BAD REQUEST: BAD PAYLOAD BYTE #2
	HTTP 401 - UNAUTHORIZED: BUSY
	HTTP 403 – FORBIDDEN: OTHER ERROR
	HTTP 414- URL TOO LONG : LENGTH ERROR
	HTTP 500- INTERNAL SERVER ERROR: ANY OTHER ERROR
	HTTP 501- NOT IMPLEMENTED: UNSUPPORTED COMMAND
SAMPLE CALL	



**NOTES** Sent from the UCM to the SGD when a change in relative price occurs

to inform of the new relative price.

**Relative Price Indicator:** 

See Section 8.2.2 for description and usage.

Opcode1 = 0x07

Opcode2 = Relative price Indicator

#### 3.9 Next Period Relative Price

URL	/price.cgi
METHOD	POST
URL PARAMS	N/A
DATA PARAMS	{ "next_price": "xxxxxxx"}
SUCCESS	HTTP 200 OK
RESPONSE	
<b>ERROR RESPONSE</b>	HTTP 400 - BAD REQUEST: BAD PAYLOAD BYTE #2
	HTTP 401 - UNAUTHORIZED: BUSY
	HTTP 403 – FORBIDDEN: OTHER ERROR
	HTTP 414- URL TOO LONG : LENGTH ERROR
	HTTP 500- INTERNAL SERVER ERROR: ANY OTHER ERROR
	HTTP 501- NOT IMPLEMENTED: UNSUPPORTED COMMAND
SAMPLE CALL	
NOTES	Sent from the UCM to the SGD when a change in relative price occurs
	to inform of the relative price in the next future period.
	Relative Price Indicator:
	See Section 8.2.2 for description and usage.
	Opcode1 = 0x08 – all are used one after the other
	Opcode2 = Relative price Indicator
	· ·

### 3.10 Time Remaining in Price Period

URL	/price.cgi
METHOD	POST
URL PARAMS	N/A



DATA PARAMS	{ "time_remaining": "xxxxxxx" }
SUCCESS	HTTP 200 OK
RESPONSE	
<b>ERROR RESPONSE</b>	HTTP 400 - BAD REQUEST: BAD PAYLOAD BYTE #2
	HTTP 401 - UNAUTHORIZED: BUSY
	HTTP 403 – FORBIDDEN: OTHER ERROR
	HTTP 414- URL TOO LONG : LENGTH ERROR
	HTTP 500- INTERNAL SERVER ERROR: ANY OTHER ERROR
	HTTP 501- NOT IMPLEMENTED: UNSUPPORTED COMMAND
SAMPLE CALL	
NOTES	Sent from the UCM to the SGD when a change in price occurs to
	inform of the duration of the present price period.
	Event Duration:
	See Section 8.1.2 for description and usage.
	Opcode1 = 0x09
	Opcode2 = Event Duration
	HTTP 401 - UNAUTHORIZED: BUSY HTTP 403 - FORBIDDEN: OTHER ERROR HTTP 414- URL TOO LONG: LENGTH ERROR HTTP 500- INTERNAL SERVER ERROR: ANY OTHER ERROR HTTP 501- NOT IMPLEMENTED: UNSUPPORTED COMMAND  Sent from the UCM to the SGD when a change in price occurs to inform of the duration of the present price period.  Event Duration: See Section 8.1.2 for description and usage.  Opcode1 = 0x09

### 3.11 Get Current State

URL	/state_sgd.cgi?
METHOD	GET
URL PARAMS	N/A
DATA PARAMS	N/A
SUCCESS	HTTP 200 OK
RESPONSE	{ "code": "xx",
	"meaning": "xxxxxxxx"}
<b>ERROR RESPONSE</b>	HTTP 400 - BAD REQUEST: BAD PAYLOAD BYTE #2
	HTTP 401 - UNAUTHORIZED: BUSY
	HTTP 403 – FORBIDDEN: OTHER ERROR
	HTTP 414- URL TOO LONG : LENGTH ERROR
	HTTP 500- INTERNAL SERVER ERROR
	HTTP 501- NOT IMPLEMENTED: UNSUPPORTED COMMAND
SAMPLE CALL	
NOTES	Code 0 "Idle Normal" Indicates that no demand response event is in effect and the SGD has no/insignificant energy consumption.
	Code 1 "Running Normal" Indicates that no demand response event is in effect and the SGD has significant energy consumption.

October 24, 2017

9



Code 2 "Running Curtailed" Indicates that a curtailment type demand response event is in effect and the SGD has significant energy consumption.

Code 3 "Running Heightened" Indicates that a heightened-operation type of demand response event is in effect and the SGD has significant energy consumption.

Code 4 "Idle Curtailed" Indicates that a curtailment type demand response event is in effect and the SGD has no/insignificant energy consumption.

Code 5 "SGD Error Condition" Indicates that the SGD is not operating because it needs maintenance support or is in some way disabled (i.e. no response to the grid)

Code 6 "Idle Heightened" Indicates that a heightened-operation type of demand response event is in effect and the SGD has no/insignificant energy consumption.

Code 7 "Cycling On" Indicates that a cycling type of demand response event is in effect and the SGD has significant energy consumption (i.e. cycled on)

Code 8 "Cycling Off" Indicates that a cycling type of demand response event is in effect and the SGD has no/insignificant energy consumption (i.e. cycled off)

Code 9 "Variable Following" Indicates that a variable-setting type of demand response event is in effect and the SGD is presently following the specified setting.

Code 10 "Variable Not Following" Indicates that a variablesetting type demand response event is in effect and the SGD is presently not following the specified setting (e.g. the has no/insignificant energy consumption.

Code 11 "Idle, Opted Out" Indicates that the SGD is presently opted out of any demand response events and the SGD has no/insignificant energy consumption.

Code 12 "Running, Opted Out" Indicates that the SGD is presently opted out of any demand response events and the SGD has significant energy consumption.

\_\_\_\_\_

Opcode1 = 0x12

Response:

Sent from the SGD to the UCM in response to an Opcode 0x12 query



**Operating State Codes:** 

See Section 8.2.4 for description and usage.

Opcode1=0x13

Opcode2 = Operating state code

## 3.12 Request Information

URL	/info_sgd.cgi
METHOD	GET
URL PARAMS	N/A
DATA PARAMS	N/A
SUCCESS RESPONSE	HTTP 200 OK  {"CTA-2045 ver": xx,  "Vendor ID": xx,  "Device Type": xx,  "Capability Bitmap": xx,  "Model Number": "XXXXXXXXXXXXXXXX,  "Serial Number": "XXXXXXXXXXXXXXXX,  "Firmware Year": 20XX,  "Firmware Month": XX,  "Firmware Major": X,  "Firmware Major": X,
ERROR RESPONSE	HTTP 400 – BAD REQUEST: BAD PAYLOAD BYTE #2 HTTP 401 - UNAUTHORIZED: BUSY HTTP 403 – FORBIDDEN: OTHER ERROR HTTP 414- URL TOO LONG: LENGTH ERROR HTTP 500- INTERNAL SERVER ERROR HTTP 501- NOT IMPLEMENTED: UNSUPPORTED COMMAND
SAMPLE CALL	
NOTES	Vendor ID Vendors who support this command must request a unique vendor ID provided by the standard development organization or users alliance.  Device Type Used by both SGDs and UCMs, this is a 16 bit value identifying the class to



which a device belongs. For more information see section 9.1.1.1.

#### Capability Bitmap

Bit (2 <sup>n</sup> )	Description
0	Cycling supported
1	Tier mode supported
2	Price mode supported
3	Temperature Offset supported
4-15	Reserved

#### **Model Number**

Device model number, all zeros = not supported

#### **Serial Number**

Device serial number, all zeros = not supported

#### Firmware Year

Year - 2000 (e.g., Firmware Year = 11 (0x0B) for 2011)

#### Firmware Month

0 (0x00) = January, 11 (0x0B) = December

#### Firmware Day

1 - 31

### 3.13 Update Local Time

URL	/time.cgi	
METHOD	POST	
URL PARAMS	N/A	
DATA PARAMS	{"day": "x", "hour": "xx"}	Day of week: 0=Sunday, 6=Saturday Local hour of day [0, 23]
SUCCESS	HTTP 200 OK	
RESPONSE		
<b>ERROR RESPONSE</b>	HTTP 400 – BAD F	REQUEST: BAD PAYLOAD BYTE #2
	HTTP 401 - UNAU	THORIZED: BUSY
	HTTP 403 - FORB	IDDEN: OTHER ERROR
	HTTP 414- URL TO	O LONG : LENGTH ERROR
	HTTP 500- INTERN	IAL SERVER ERROR



	HTTP 501- NOT IMPLEMENTED: UNSUPPORTED COMMAND
SAMPLE CALL	
NOTES	When supported, this command is sent from the UCM to the SGD on the hour.
	Time Value:
	Bits 75 = Weekday (0 = Sunday, 6 = Saturday)
	Bits 40 = Hour* of Day (0 to 23)
	*This is the local hour, including DST where applicable, for display on the SGD clock as-is.
	Opcode1 = 0x16
	Opcode2 = Time Value

## 3.14 Get Setpoint

URL	/setpoint.cgi
METHOD	GET
URL PARAMS	N/A
DATA PARAMS	
SUCCESS RESPONSE	HTTP 200 OK
	{"setpoint1": xx,
	"setpoint2": xxx,
	"units": "X"
	}
ERROR RESPONSE	HTTP 400 – BAD REQUEST: BAD PAYLOAD BYTE #2 HTTP 401 - UNAUTHORIZED: BUSY HTTP 403 – FORBIDDEN: OTHER ERROR HTTP 414- URL TOO LONG: LENGTH ERROR HTTP 500- INTERNAL SERVER ERROR HTTP 501- NOT IMPLEMENTED: UNSUPPORTED COMMAND
SAMPLE CALL	
NOTES	See section 9.1.6
	Setpoint1 is mandatory, setpoint2 is optional.
	Set Point 1 Signed 16 bit value. First temperature value, 0x8000 (-32768) = don't



change (set)/not supported (get). For Water Heaters, Top Element set point. For Thermostats, Heat set point. For Refrigerator/Freezer, Refrigerator set point.

#### Set Point 2

Signed 16 bit value. Second temperature value, 0x8000 = don't change (set)/not supported (get). For Water Heaters, Bottom Element set point. For Thermostats, Cool set point. For Refrigerator/Freezer, Freezer set point.

### 3.15 Set Setpoint

URL	/setpoint.cgi
METHOD	POST
URL PARAMS	N/A
DATA PARAMS	{"deviceType": xxx, "units": xxx, "setpoint1": xxx, "setpoint2": xxxx }
SUCCESS	HTTP 200 OK
RESPONSE	
ERROR RESPONSE	HTTP 400 – BAD REQUEST: BAD PAYLOAD BYTE #2 HTTP 401 - UNAUTHORIZED: BUSY HTTP 403 – FORBIDDEN: OTHER ERROR HTTP 414- URL TOO LONG: LENGTH ERROR HTTP 500- INTERNAL SERVER ERROR HTTP 501- NOT IMPLEMENTED: UNSUPPORTED COMMAND
SAMPLE CALL	
NOTES	See section 9.1.6  Device type MUST match that of the receiving SGD!
	Both setpoint fields are optional (will be sent as "do not change").
	Set Point 1 Signed 16 bit value. First temperature value, 0x8000 (-32768) = don't change (set)/not supported (get). For Water Heaters, Top Element set point. For Thermostats, Heat set point. For Refrigerator/Freezer,



Refrigerator set point.

Set Point 2

Signed 16 bit value. Second temperature value, 0x8000 = don't change (set)/not supported (get). For Water Heaters, Bottom Element set point. For Thermostats, Cool set point. For Refrigerator/Freezer, Freezer set point.

### 3.16 Get Present Temperature

URL	<del>/temperature.cgi</del>
METHOD	GET
URL PARAMS	N/A
DATA PARAMS	
SUCCESS	HTTP 200 OK
RESPONSE	
	<del>{"setpoint": xx,</del>
	"setpointOffset": xxx,
	"actual": xxxx
	}
ERROR RESPONSE	HTTP 400 - BAD REQUEST: BAD PAYLOAD BYTE #2
	HTTP 401 - UNAUTHORIZED: BUSY
	HTTP 403 - FORBIDDEN: OTHER ERROR
	HTTP 414- URL TOO LONG : LENGTH ERROR
	HTTP 500- INTERNAL SERVER ERROR
	HTTP 501- NOT IMPLEMENTED: UNSUPPORTED COMMAND
SAMPLE CALL	
NOTES	See section 9.1.7
	Reply:
	<del>Opcode1 = 0x06</del>
	Opcode2 = 0x80
	Opcode3 = Response Code
	Opcode4 = Commodity Code
	Opcode5-10 = Instantaneous Rate (48bit unsigned)
	Opcode11-16 = Cumulative Amount (48bit unsigned, only use the
	delta, not the absolute value!!)
	Commodity Code: see table in 9.3.1



### 3.17 Start Autonomous Cycling

URL	<del>/load.cgi</del>	
METHOD	POST	
URL PARAMS	N/A	
DATA PARAMS	{"event_name ": "start_cycling",     "eventID": "xxxx",     "start_time": "xxxx",	
	"event_duration": "xx".	
	"duty_cycle": "x",	
	"start_rand": "x",	
	"end_rand":"x"}	
SUCCESS	HTTP 200 OK	
RESPONSE		
ERROR RESPONSE	HTTP 400 - BAD REQUEST: BAD PAYLOAD BYTE #2	
	HTTP 401 - UNAUTHORIZED: BUSY	
	HTTP 403 – FORBIDDEN: OTHER ERROR	
	HTTP 414- URL TOO LONG : LENGTH ERROR	
	HTTP 500- INTERNAL SERVER ERROR	
	HTTP 501- NOT IMPLEMENTED: UNSUPPORTED COMMAND	
SAMPLE CALL		
NOTES	Event ID Unsigned 32 bit value control event identifier	
	Start Time Unsigned 32 bit value of seconds since 1/1/2000 00:00:00 UTC, 0 =	
	<u>NowDuration</u>	
	Duration of the control event in minutes	
	Duty Cycle	
	% reduction of the load (e.g., 75 means that the device will be off 34 of	
	the time)	
	Start Randomization	
	The start of the control will be delayed by this randomized value in	
	minutes. The start randomization does not change the duration of the	
	event.	
	End Randomization	



The event duration will be lengthened by this random value given in minutes.

### 3.18 Terminate Autonomous Cycling

URL	<del>/load.cgi</del>		
METHOD	POST		
URL PARAMS	N/A		
DATA PARAMS	{"event_name ": "stop_cycling",		
	"eventID": "xxxxx",		
	<del>"end_rand":"x"}</del>		
SUCCESS	HTTP 200 OK		
RESPONSE			
<b>ERROR RESPONSE</b>	HTTP 400 - BAD REQUEST: BAD PAYLOAD BYTE #2		
	HTTP 401 - UNAUTHORIZED: BUSY		
	HTTP 403 - FORBIDDEN: OTHER ERROR		
	HTTP 414- URL TOO LONG : LENGTH ERROR		
	HTTP 500- INTERNAL SERVER ERROR		
	HTTP 501- NOT IMPLEMENTED: UNSUPPORTED COMMAND		
SAMPLE CALL			
NOTES	Event ID		
	Unsigned 32 bit value control event identifier		
	End Randomization		
	Continue the control for random value time to prevent large groups		
	from turning on at the same time (given in minutes).		
	,		

## 3.19 Get Commodity Read

URL	/commodity.cgi
METHOD	GET
URL PARAMS	N/A
<b>DATA PARAMS</b>	
SUCCESS	HTTP 200 OK
RESPONSE	
	{"commodity":["code": xx,
	"iRate": xxx,



	"cAmount": xxxx]} }	
ERROR RESPONSE	HTTP 400 – BAD REQUEST: BAD PAYLOAD BYTE #2 HTTP 401 - UNAUTHORIZED: BUSY HTTP 403 – FORBIDDEN: OTHER ERROR HTTP 414- URL TOO LONG: LENGTH ERROR HTTP 500- INTERNAL SERVER ERROR HTTP 501- NOT IMPLEMENTED: UNSUPPORTED COMMAND	
SAMPLE CALL		
NOTES	Note that the largest possible return value of iRate or cAmount is 2 <sup>30</sup> = 2,147,483,647	
	Reply: code = Commodity Code iRate = Instantaneous Rate (48bit unsigned) cAmount = Cumulative Amount (48bit unsigned, only use the delta, not the absolute value!!)	

Commodity Code: see table in 9.3.1 (reproduced below)

*Lower	Description	Units
7-bits		
0	Electricity Consumed	W & W-hr
1	Electricity Produced	W & W-hr
2	Natural gas	cu-ft/hr & cu-ft
3	Water	Gal/hr & Gallons
4	Natural gas	cubic meters/hour (m³) &
		cubic meters (m³)
5	Water	liters/hr & liters
6	Total Energy	W-hr
	Storage/Take	Note: Instantaneous field
	Capacity	in CommodityRead is not
	(see Figure 1)	used.
7	Present Energy	W-hr
	Storage/TakeCapacity	Note: Instantaneous field
	(see Figure 1)	in CommodityRead is not
		used.





